

TABLE OF CONTENTS



Chapter 1: Introduction

Purpose of this Manual	1-2
Other Reference Materials	1-2
Who Should Read this Manual	1-2
Technical Support	1-2
Conventions Used	1-3
Key Topics for Each Chapter	1-3
Ethernet Remote Master (ERM)	1-4
Ethernet Remote Slaves	1-4
Configuring the Ethernet Remote I/O Network	1-5
Running the Ethernet Remote I/O Network	1-5
ERM / ECOM Systems	1-6
How the PLC CPU Updates Remote I/O Points	1-7
Frequently Asked Questions	1-8

Chapter 2: ERM / Slave Network Addressing Modes

ERM / Remote Slave Network Identifiers	2-2
ERM / Slave Configuration Tools	2-2
ERM / Slave Module ID	2-3
IP Address	2-4
Ethernet Address	2-4
Using Multiple Network Identifiers	2-4

Chapter 3: Installation and Network Layouts

Inserting the ERM Module in the I/O Base	3-2
DL205/Do-more Slot Choices	3-2
H2-ERM (100, -F) Module Installation	3-2

Table of Contents

DL405 Slot Choices	3-3
H4-ERM (100, -F) Module Installation	3-4
Which Modules are Supported in the Ethernet Slaves	3-4
ERM Network Layouts	3-5
Configuring the Ethernet Remote I/O Network	3-5
Running the Ethernet Remote I/O Network	3-5
ERM / ECOM Systems	3-6
Network Cabling	3-7
ERM Supports Three Standards	3-7
10/100BaseT Networks	3-7
10/100BaseT	3-8
UTP Cable	3-8
10BaseFL	3-8
Fiber Optic Cable	3-8
Fiber Optic Module ST Connector	3-8
Maximum Cable Length	3-9

Chapter 4: Configuring the ERM and Slave Modules with ERM Workbench

ERM Workbench Software	4-3
Launching ERM Workbench	4-3
Adding IPX Network Protocol Support (Windows XP/32 bit or earlier)	4-4
Running ERM Workbench PLC Wizard	4-5
Step 1: Choosing the ERM Network Configuration	4-5
Step 2: Connecting the ERM Workbench PC to the ERM Network	4-5
Establishing Communication with the ERM	4-6
Step 3: Select and Configure the Slaves	4-6
Step 4: Map I/O to PLC Memory	4-7
Step 5: Download Configuration to ERM	4-7
ERM Workbench Main Configuration Window	4-8
Running ERM Workbench	4-9
Connecting the ERM Workbench PC to the Network Modules	4-9
Configure the ERM	4-10
Configuring the ERM	4-10

Selecting PLC as Interface	4-10
PLC Map	4-11
Advanced ERM Configuration	4-11
Select the Slaves	4-12
Selecting the Slaves	4-12
Configure the Slaves	4-13
Setting the Slave's Parameters	4-13
Write Configuration to ERM	4-15
Analog I/O Data Registers	4-16
Analog I/O Data Registers	4-16
Reserved PLC Memory for ERM	4-17
ERM Status Word / Reset Slave Code	4-17
Saving ERM Configuration to Disk	4-18
Clear ERM Configuration	4-18
Printing/Exporting the ERM Configuration	4-18
Chapter 5: Using NetEdit	
Using NetEdit	5-2
The NetEdit Window	5-2
Ethernet Communication Protocol	5-2
Adding IPX Network Protocol Support (Windows XP/32 bit or earlier)	5-3
Ethernet Address	5-3
Module ID / IP Address / Name / Description	5-4
Module Information	5-4
Using NetEdit to Configure the EBC Base	5-5
EBC Settings Tab	5-5
General Settings	5-6
Serial Port	5-6
I/O Base	5-6
Show Base Contents	5-7
Update Firmware	5-8
Update Booter	5-8
Restore Factory Defaults	5-8

Chapter 6: Maintenance and Troubleshooting

Isolating a Communication Problem6-2
Diagnostic Tools and Techniques6-2
Troubleshooting Chart6-2
ERM Module Diagnostic LEDs6-4
ERM LEDs6-4
Link Good Indicator6-4
ACT Indicator6-4
Error Indicator6-4
Slave Module Diagnostic LEDs6-4
EBC LEDs6-4
Error Indicator6-4
Using ERM Workbench for Troubleshooting6-5
Read from ERM6-5
Reserved PLC Memory for ERM6-6
Detailed ERM Statistics6-6
Select Slaves Window6-7
Using NetEdit for Troubleshooting6-8
Select a Module6-8
Module Information6-8
Change Protocol6-9
Replacing the ERM / Slave Module6-9
Diagnosing Network Cable Problems6-10

Appendix A: General Specifications

General SpecificationsA-2
SpecificationsA-2
Ethernet StandardsA-4

Appendix B: ERM / Slave Diagnostics and Error Codes

ERM DiagnosticsB-2
ERM Status Word / Resetting the SlaveB-2

DirectLOGIC Example	B-3
Do-more Example	B-3
ERM Status Word Error Codes	B-4
Reading ERM Statistics	B-5
Reading ERM Statistics using Ladder Logic with DirectLOGiC	B-5
Reading ERM Statistics using Ladder Logic with Do-more	B-6
Reading Error Codes from Slaves	B-7
Reading Error Codes from Slaves with DirectLOGIC	B-7
Reading Error Codes from Slaves with Do-more	B-9
Slave Diagnostic Word Memory	B-10
Current / Last State Slave Error Codes	B-12
Extended Slave Error Codes	B-13
 Appendix C: ERM and ERM Workbench Default Settings	
ERM and ERM Workbench Factory Default Settings	C-2
 Appendix D: Mapping ERM Slave I/O in a Think & Do WinPLC System	
Mapping ERM Slave I/O Points	D-2
Launching Connectivity Center Tool	D-2
Connecting to the WinPLC Base I/O	D-2
Connecting to the ERM Slave I/O	D-3
Mapping I/O Points to Data Items	D-3
 Appendix E: Configuring Terminator I/O Analog Output Modules	
Analog Output Module Control Byte	E-2
 Appendix F: H2-EBC(100) Analog Module Addressing	
H2-EBC(100) Analog Module Addressing (H2/4-ERM(100))	F-2

Table of Contents

Notes:

