


HITACHI

L100/SJ100 Ethernet Interface User Manual



WARNING

Thank you for purchasing automation equipment from Automationdirect.com™. We want your new automation equipment to operate safely. Anyone who installs or uses this equipment should read this publication (and any other relevant publications) before installing or operating the equipment.

To minimize the risk of potential safety problems, you should follow all applicable local and national codes that regulate the installation and operation of your equipment. These codes vary from area to area and usually change with time. It is your responsibility to determine which codes should be followed, and to verify that the equipment, installation, and operation is in compliance with the latest revision of these codes.

At a minimum, you should follow all applicable sections of the National Fire Code, National Electrical Code, and the codes of the National Electrical Manufacturer's Association (NEMA). There may be local regulatory or government offices that can also help determine which codes and standards are necessary for safe installation and operation.

Equipment damage or serious injury to personnel can result from the failure to follow all applicable codes and standards. We do not guarantee the products described in this publication are suitable for your particular application, nor do we assume any responsibility for your product design, installation, or operation.

Our products are not fault-tolerant and are not designed, manufactured or intended for use or resale as on-line control equipment in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines, or weapons systems, in which the failure of the product could lead directly to death, personal injury, or severe physical or environmental damage ("High Risk Activities"). Automationdirect.com™ specifically disclaims any expressed or implied warranty of fitness for High Risk Activities.

For additional warranty and safety information, see the Terms and Conditions section of our catalog. If you have any questions concerning the installation or operation of this equipment, or if you need additional information, please call us at 770-844-4200.

This publication is based on information that was available at the time it was printed. At Automationdirect.com™ we constantly strive to improve our products and services, so we reserve the right to make changes to the products and/or publications at any time without notice and without any obligation. This publication may also discuss features that may not be available in certain revisions of the product.

Trademarks

This publication may contain references to products produced and/or offered by other companies. The product and company names may be trademarked and are the sole property of their respective owners. Automationdirect.com™ disclaims any proprietary interest in the marks and names of others.

**Copyright 2002, Automationdirect.com™ Incorporated
All Rights Reserved**

No part of this manual shall be copied, reproduced, or transmitted in any way without the prior, written consent of Automationdirect.com™ Incorporated. Automationdirect.com™ retains the exclusive rights to all information included in this document.

AVERTISSEMENT

Nous vous remercions d'avoir acheté l'équipement d'automatisation de Automationdirect.comMC. Nous tenons à ce que votre nouvel équipement d'automatisation fonctionne en toute sécurité. Toute personne qui installe ou utilise cet équipement doit lire la présente publication (et toutes les autres publications pertinentes) avant de l'installer ou de l'utiliser.

Afin de réduire au minimum le risque d'éventuels problèmes de sécurité, vous devez respecter tous les codes locaux et nationaux applicables régissant l'installation et le fonctionnement de votre équipement. Ces codes diffèrent d'une région à l'autre et, habituellement, évoluent au fil du temps. Il vous incombe de déterminer les codes à respecter et de vous assurer que l'équipement, l'installation et le fonctionnement sont conformes aux exigences de la version la plus récente de ces codes.

Vous devez, à tout le moins, respecter toutes les sections applicables du Code national de prévention des incendies, du Code national de l'électricité et des codes de la National Electrical Manufacturer's Association (NEMA). Des organismes de réglementation ou des services gouvernementaux locaux peuvent également vous aider à déterminer les codes ainsi que les normes à respecter pour assurer une installation et un fonctionnement sûrs.

L'omission de respecter la totalité des codes et des normes applicables peut entraîner des dommages à l'équipement ou causer de graves blessures au personnel. Nous ne garantissons pas que les produits décrits dans cette publication conviennent à votre application particulière et nous n'assumons aucune responsabilité à l'égard de la conception, de l'installation ou du fonctionnement de votre produit.

Nos produits ne sont pas insensibles aux défaillances et ne sont ni conçus ni fabriqués pour l'utilisation ou la revente en tant qu'équipement de commande en ligne dans des environnements dangereux nécessitant une sécurité absolue, par exemple, l'exploitation d'installations nucléaires, les systèmes de navigation aérienne ou de communication, le contrôle de la circulation aérienne, les équipements de survie ou les systèmes d'armes, pour lesquels la défaillance du produit peut provoquer la mort, des blessures corporelles ou de graves dommages matériels ou environnementaux («activités à risque élevé»). La société Automationdirect.comMC nie toute garantie expresse ou implicite d'aptitude à l'emploi en ce qui a trait aux activités à risque élevé.

Pour des renseignements additionnels touchant la garantie et la sécurité, veuillez consulter la section Modalités et conditions de notre documentation. Si vous avez des questions au sujet de l'installation ou du fonctionnement de cet équipement, ou encore si vous avez besoin de renseignements supplémentaires, n'hésitez pas à nous téléphoner au 770-844-4200.

Cette publication s'appuie sur l'information qui était disponible au moment de l'impression. À la société Automationdirect.com, nous nous efforçons constamment d'améliorer nos produits et services. C'est pourquoi nous nous réservons le droit d'apporter des modifications aux produits ou aux publications en tout temps, sans préavis ni quelque obligation que ce soit. La présente publication peut aussi porter sur des caractéristiques susceptibles de ne pas être offertes dans certaines versions révisées du produit.

Marques de commerce

La présente publication peut contenir des références à des produits fabriqués ou offerts par d'autres entreprises. Les désignations des produits et des entreprises peuvent être des marques de commerce et appartiennent exclusivement à leurs propriétaires respectifs. Automationdirect.comMC nie tout intérêt dans les autres marques et désignations.

**Copyright 2002, Automationdirect.com™ Incorporated
Tous droits réservés**

Nulle partie de ce manuel ne doit être copiée, reproduite ou transmise de quelque façon que ce soit sans le consentement préalable écrit de la société Automationdirect.com™ Incorporated.

Automationdirect.com™ conserve les droits exclusifs à l'égard de tous les renseignements contenus dans le présent document.



HITACHI SJ100

ETHERNET INTERFACE

USER MANUAL

Please include the Manual Number and the Manual Issue, both shown below, when communicating with Technical Support regarding this publication.

Manual Number: HA-EDRV-M

Issue: First Edition

Issue Date: 02/05/03

Publication History		
Issue	Date	Description of Changes
First Edition	02/05/03	Original



TABLE OF CONTENTS

In This Manual...

Manual Overview	2
HA-EDRV2 Overview	3
HA-EDRV2 Board Layout	4
Setting the HA-EDRV2 Address	6
Network Connections	7
HA-EDRV to Hitachi L100/SJ100 Connection	8
Setting the Hitachi L100/SJ100 Parameters	8
Connecting the HA-EDRV to an ERM Module	9
Troubleshooting	10

Manual Overview

Overview of this Publication

The HA-EDRV2 User Manual describes the installation, configuration, and operation of the HA-EDRV2 Ethernet Interface card.

Who Should Read This Manual

This manual contains important information for those who will install, maintain, and/or operate any HA-EDRV2 card.

Supplemental Publications

The **Ethernet Remote Master Module Manual** (H24-ERM-M) is available from **AutomationDirect** and may be useful for your application.

Technical Support

By Telephone: 770-844-4200

(Mon.-Fri., 9:00 a.m.-6:00 p.m. E.T.)

On the Web: www.automationdirect.com

Our technical support group is glad to work with you in answering your questions. If you cannot find the solution to your particular application, or, if for any reason you need additional technical assistance, please call technical support at **770-844-4200**. We are available weekdays from 9:00 a.m. to 6:00 p.m. Eastern Time.

We also encourage you to visit our Web site where you can find technical and non-technical information about our products and our company. Visit us at www.automationdirect.com.

Special Symbols



When you see the “notepad” icon in the left-hand margin, the paragraph to its immediate right will be a special note.



When you see the “exclamation mark” icon in the left-hand margin, the paragraph to its immediate right will be a WARNING. This information could prevent injury, loss of property, or even death (in extreme cases).

HA-EDRV2 Overview

The Ethernet Interface for the Hitachi L100/SJ100 (HA-EDRV2) provides a low-cost, high-performance 10BaseT Ethernet link between a PLC-based Control system and a Hitachi L100/SJ100 AC Drive. The HA-EDRV2 mounts on DIN rail and communicates through cable connections to the AC drive and Ethernet hub/switch or H2(4)-ERM module.

The function of the interface is to:

- process input signals from the AC drive
- format signals to conform to the Ethernet standard
- transmit signals to the PLC controller
- receive and translate output signals from the PLC/PC-based Control software
- send the output signals to the AC drive

The control function is not performed by the interface. The control function is performed by PLC-based control system. The I/O mapping function is performed by an H2(4)-ERM module (purchased separately) and the ERM Workbench Utility which is part of the **DirectSOFT32** PLC programming software.


Package Contents

After receiving the HA-EDRV2, please check for the following:

- Make sure that the part number indicated on the package corresponds with the part number of your order.
- Make sure that the package includes a HA-EDRV2 card, one piece of **SNAPTRACK™**, two DIN mounting clips, and one serial connection cable.
- Inspect the contents to insure they were not damaged during shipment.



HA-EDRV2 Board Layout



Relay Terminals

- NO: Normally Open Terminal
- - NC: Normally Closed Terminal
- - COM: Common Terminal

Relay Specifications

Form C Relay

Resistive Load

2A (NO)/2A (NC) @ 277VAC
5A (NO)/3A (NC) @ 125VAC
5A (NO)/3A (NC) @ 30VDC

Inductive Load

0.5A@ 250VAC, cosf>=0.4
1A@ 250VAC, cosf>=0.8
0.8A@ 250VAC, cosf>=0.9

Power Terminals

Chassis or system Ground (GNDC) connection

Negative connection (-) or 0VDC

Positive connection (+) or +24VDC

Power Terminals

Power for the HA-EDRV2 is connected directly to the card using a nominal 24VDC supply (+24VDC, -0VDC). The GNDC terminal is for a chassis or system Ground.

Input Voltage

18-33 VDC with a 24VDC nominal supply

Input Current

90-135 mA

Communication Ports

Two comm ports are provided to make a connection from an Hitachi L100/SJ100 (Serial port) to an Ethernet device or network (Ethernet port).

DIP Switches

The DIP Switches are used to set the Module ID for the HA-EDRV2 card.

LED Indicators

POWER Indicator

The green POWER LED is steady on when the HA-EDRV2 is correctly powered by a 24VDC supply.

ERROR Indicator

If the HA-EDRV's red Error (ERROR) indicator is flashing or steady on, a fatal error has occurred. The error may be in the card itself, or a network problem may be causing this symptom. The ERROR indication can be caused by a faulty ground, an electrical spike or other types of electrical disturbances. Cycle power to the system to attempt clearing the error.

LINK GOOD Indicator

The green LINK GOOD LED is steady on when the HA-EDRV2 is correctly connected to an active device on the network. The LINK LED verifies that the proper cables are connected, and the card is functioning correctly. If a mismatch with the 10BaseT connections occurs this LED will not be illuminated.

LINK ACTIVE Indicator

The red LINK ACTIVE LED flashes to indicate that the card sees data travelling on the network. If any network device is sending or receiving data, the ACTIVE LED will be illuminated. In idle mode (no network traffic) this LED is OFF. During heavy communication loads this LED will be steady on.

TXD

The green TXD LED flashes to indicate that the card sees data travelling to the AC drive. During heavy communication loads, this LED will be steady on.

RXD

The green RXD LED flashes to indicate that the card sees data traveling from the AC drive. During heavy communication loads this LED will be steady on.

Setting the HA-EDRV2 Address

Each HA-EDRV2 must have an identification (ID) or address in order to be recognized on the network, and each ID must be unique. Duplicate IDs on the same network will cause unpredictable results and must be avoided.



WARNING: Duplicate IDs on the same network will cause unpredictable results and must be avoided.

Setting Module ID with DIP Switches

You can use the DIP switch to set the ID to a number from one to sixty-three. Do not use ID "0" for communications.

If the DIP switch is set to a number greater than 0, the software tools are disabled from setting the ID. Again, the software tools will only allow changes to the ID if the DIP switch setting is 0 (zero, all switches OFF).





Note: The DIP switch settings are read only at power-up. You must cycle power if you change the DIP switches.

The HA-EDRV2 DIP switch contains eight individual switches, but only six of these are active. You will find that the printed circuit board is labeled 0 (zero) through 7. The numbers on the printed circuit board indicate the power of 2 represented by each individual switch. For example, switch 0 represents 2^0 (or 1), switch 1 is 2^1 (or 2), switch 2 is 2^2 (or 4), and so on.


The ID equals the sum of the binary values of the slide switches set in the ON

DIP Switches



position. For example, if you set slide switches 1, 2, and 3 to the ON position, the ID will be 14. This is found by adding $8+4+2=14$. The maximum value you can set on the DIP switch is $32+16+8+4+2+1=63$. This is achieved by setting switches 0 through 5 to the ON position.

Network Connections



10BaseT Connections

The HA-EDRV2 has an eight-pin modular jack that accepts RJ45 connector plugs. UTP (Unshielded Twisted-Pair) cable is rated according to its data-carrying ability (bandwidth) and is given a "category" number. We strongly recommend using a category 5 cable for all Ethernet 10BaseT connections. For convenient and reliable networking, we recommend that you purchase commercially manufactured cables (cables with connectors already attached).

To connect an HA-EDRV2 to a hub, switch, or repeater, use a patch cable (sometimes called a straight-through cable). The cable used to connect an H2(4)-ERM directly to an HA-EDRV2 or to connect two hubs is referred to as a crossover cable.

Patch (Straight-through) Cable			Crossover Cable		
EDRV	OR/WHT	OR/WHT	EDRV	OR/WHT	GRN/WHT
TD+ 1	OR	OR	TD+ 1	OR	GRN
TD- 2	GRN/WHT	GRN/WHT	TD- 2	GRN/WHT	OR/WHT
RD+ 3	BLU	BLU	RD+ 3	BLU	BLU
4	BLU/WHT	BLU/WHT	4	BLU/WHT	BLU/WHT
5	GRN	GRN	5	GRN	OR
RD- 6	BRN/WHT	BRN/WHT	6 TD-	BRN/WHT	BRN/WHT
7	BRN	BRN	7	BRN	BRN
8			8		
RJ45			RJ45		

This diagram illustrates the standard wire positions in the RJ45 connector. We recommend all Ethernet 10BaseT cables to be Category 5, UTP cable.

HA-EDRV to Hitachi L100/SJ100 Connection

A serial connection cable (2 ft. in length) is provided with the HA-EDRV2 to make a RS-422 connection with a Hitachi L100/SJ100 AC drive.

Setting the Hitachi L100/SJ100 Parameters

The following parameters need to be set in the Hitachi SJ100 in order to operate properly with the HA-EDRV interface card.

A01: 02 – Frequency source setting determined by Function F01 setting.

A02: 02 – Run command source is set by run key on keypad or remote operator.

Note: The previous list of parameter settings are the minimum required to communicate with a Hitachi L100/SJ100 through a HA-EDRV interface card. There may be other parameters that need to be set to meet the needs of your application.




Connecting the HA-EDRV to an ERM Module

The HA-EDRV interface card can be added to any H2(4)-ERM module using the ERM Workbench Utility. For more details on selecting and configuring slaves for the ERM module, see CHAPTER 4 of the H24-ERM-M.

Reserved PLC Memory for the HA-EDRV

Once the HA-EDRV is added the ERM module, 8 DWORD inputs and 2 DWORD outputs are mapped back to the PLC. The assigned PLC addresses are shown in the ERM Workbench Utility.



Input/Output Word Map

The Input and Output DWORDS for the HA-EDRV are mapped to specific parameters and functions in the Hitachi L100/SJ100 AC drives. The following tables show the Input and Output DWORDS and their functions.

Input Word Map		
Input Word	Parameter Reference	Function
1	D1	Output Frequency Monitor
2	D2	Output Current Monitor
3	D3	Rotation Direction Monitor
4	D4	Process Variable (PV), PID Feedback Monitor
5	D5	Intelligent Input Terminal Status
6	D6	Intelligent Output Terminal Status
7	D7	Scaled Output Frequency Monitor
8	O21	Trip Indicator (if bit 0 is set)

Output Word Map		
Output Word	Parameter Reference	Function
1	O1	Run Mode [0=Stop, 1=Forward, 2=Reverse]
2	F1	Output Frequency Setting

When a drive trip occurs, Input DWORD 8 (O21) will go to 1. To reset the trip, write Output DWORD 1 (O1) to a zero to stop/reset the drive.

Troubleshooting

Troubleshooting help for the ERM module and its slaves is available in CHAPTER 6 of the Ethernet Remote Master User Manual (H24-ERM-M).



HA-EDRV2-M