

APPLICATION EXAMPLES



In this Appendix...

Example 1: Using Modbus Poll to MB-GATEWAY with DL06 Slave	A-2
Items needed for this example:	A-2
Step 1: Connect the MB-GATEWAY serial port to the DL06 secondary communications port.	A-2
Step 2: Configure the DL06 PLC serial port and MB-GATEWAY serial port.	A-3
Step 3: Connect to the MB-GATEWAY using the Modbus Poll simulator software.	A-7
Example 2: Using Modbus Poll to MB-GATEWAY with CLICK Slave	A-11
Items needed for this example:	A-11
Step 1: Connect the MB-GATEWAY serial port to Port 3 of the CLICK PLC.....	A-11
Step 2: Configure the CLICK serial port and MB-GATEWAY serial port.	A-12
Step 3: Connect to the MB-GATEWAY using the Modbus Poll simulator software.	A-18
Example 3: Using P3000 as Master (Client) to MB-GATEWAY with CLICK Slave. ...	A-24
Step 1: Connect CLICK to the MB-GATEWAY as shown in example 2.	A-24
Step 2: Connect P3000 CPU (P3-550) to MB-GATEWAY via Ethernet Switch and Two Ethernet Cables.	A-24
Step 3: Configure the MRX instruction to read data from the MB-GATEWAY.	A-28
Example 4: DirectLogic 06 (H0-ECOM100) as Master (Client) to MB-GATEWAY with Multiple GS Drives as Slaves.	A-29
Step 1: Set up Peer to Peer Configuration	A-30
Step 2: Set the Serial Port Configuration	A-31
Step 3: Set the Communication Parameters	A-31
Step 4: Using Automatic Reads.....	A-32
Step 5: Access the Automatic Read Data	A-33
Step 6: Read and Write from the DL06	A-36

Example 1: Using Modbus Poll to MB-GATEWAY with DL06 Slave


This example will illustrate how to use Modbus Poll, which is a PC based Modbus Master simulator tool, to connect through the MB-GATEWAY to a DL06 PLC via 2 wire RS-485.

Items needed for this example:

- MB-GATEWAY
- DirectLogic 06 PLC (any model)
- PC with Modbus Poll installed (free demo is available at www.modbustools.com)
- Small length of Belden 9842 or equivalent cable
- ZL-CMA15 ZipLink communication port adapter, 15-pin high density female to terminal block
- Ethernet switch and cables to connect from the PC to MB-GATEWAY


Step 1: Connect the MB-GATEWAY serial port to the DL06 secondary communications port.

Using the short length of Belden 9842, connect the MB-GATEWAY to the DL06 Port 2 as shown:




Step 2: Configure the DL06 PLC serial port and MB-GATEWAY serial port.

Connect to the DL06 PLC with DirectSoft. Go to the PLC pulldown and select Setup > Setup Secondary Comm. Port as shown:



Setup the port as shown for Modbus protocol, 38400 baud rate, Odd parity, 1 Stop bit and Station Number 1. Match everything else as shown. Note the Station Number configured in the PLC. Once this has been done, click on the icon on the upper right hand side with the arrow pointing to the PLC to save the settings in the PLC.



In order to match the serial port settings of the DL06 to the MB-GATEWAY open up a web browser, such as Internet Explorer, and enter in the IP address of the MB-GATEWAY to access the main screen as shown:

A




Gateway Modbus ID:	255 (0xFF)
Module Name:	Modbus Gateway 1
Module Description:	Modbus Gateway.
Ethernet Address:	00 E0 62 40 47 07
IP Setup:	Address: 192.168.15.47 Subnet: 255.255.0.0 Gateway: 192.168.1.10
Booter Version:	5.0.53
OS Version:	1.0.597
Serial Port Configuration:	0-7-NONE-1-RTU
Slave Timeout/Retrys:	Timeout=1000 Retrys=2
Automatic Reads:	Reading from: none
Show Status:	Monitor Status Information
Firmware Updates:	Hosteng.com



For instructions on connecting with a web browser see NetEdit Configuration section in Chapter 3.

Click on the link to the right of “Serial Port Configuration” and set up the window to match the DL06 PLC port and then click on the Send button to save the settings:


A




Step 3: Connect to the MB-GATEWAY using the Modbus Poll simulator software.

Once the software has been obtained from www.modbustools.com and installed according to the directions provided from their website, open up the Modbus Poll software.

Click on the Setup pulldown menu and select Read/Write Definition as shown:



Configure the Read/Write definition for a simple read of the register 400001, which equates to V0 in the DirectLogic PLCs.
 (see http://support.automationdirect.com/docs/Modbus_xref.pdf for more information on Modbus addressing to DirectLogic PLC addressing equivalents).




Enter in 1 for the Slave ID. This matches the Unit ID in the protocol that will determine which Modbus Serial Slave will be targeted on the serial side of the MB-GATEWAY. Entering 1 here will match up to the Station Number configured above in DirectSoft for the DL06 PLC.




Choosing Function 3 sets up the read for 4xxxx registers. Checking the "PLC Addresses (Base 1)" in the lower right corner matches the addressing to the cross reference chart mentioned above. Once this windows has been configured as shown above, click on OK.

Now click on the Connection pulldown menu and select Connect:




In the Connection Setup window, choose the Modbus TCP/IP connection type. Enter the IP address of your MB-GATEWAY module in the lower left hand corner. Match everything else as shown:




Click on OK to connect to the MB-GATEWAY.

If everything has been configured correctly, the counter next to “TX =” will increment rapidly and the counter next to “Err =” will not increment. If the Error counter is incrementing, go back and verify that all the steps prior to this one have been followed. If you get an error that says, “Modbus TCP connection failed”, verify that the IP address of the PC and the IP address of the GATEWAY are in compatible subnets and can communicate.



Once Modbus Poll is communicating to the PLC, go into DirectSoft, open up a Data View window and enter in V0 and change the display type to “Decimal” to match the Modbus Poll software:



Change the value in data view for V0 to various values and watch the value change in Modbus Poll to match.

Example 2: Using Modbus Poll to MB-GATEWAY with CLICK Slave


This example will illustrate how to use Modbus Poll, which is a PC based Modbus Master simulator tool, to connect through the MB-GATEWAY to a CLICK PLC via 2 wire RS-485.

Items needed for this example:

- MB-GATEWAY
- CLICK PLC (any C0-01xx-x or C0-02xx-x PLC with 3 pin terminal RS-485 port)
- PC with Modbus Poll installed (free demo is available at www.modbustools.com)
- Small length of Belden 9842 or equivalent cable
- Ethernet switch and cables to connect from the PC to MB-GATEWAY


Step 1: Connect the MB-GATEWAY serial port to Port 3 of the CLICK PLC.

Using the short length of Belden 9842, connect the MB-GATEWAY to CLICK's Port 3 as shown:




Step 2: Configure the CLICK serial port and MB-GATEWAY serial port.


Connect to the CLICK PLC with CLICK programming software. Go to the Setup pulldown and select Com Port Setup... as shown:




Click the Port 3: Setup... button to configure Port 3 of the PLC.



Configure the port for 38400 baud rate, Odd parity, 1 Stop Bit and Node Address 1. Leave the other settings as shown below. Note the Node Address number configured here. Once the settings are configured, Click on the Ok button.




Next, transfer the project to the PLC for the Port 3 settings to take effect. Select the PLC pull-down menu and choose Write Project into PLC...



A


Choose Ok and follow the steps when prompted to transfer the project to the PLC.



Now go into the MB-GATEWAY configuration and match the serial port settings to the PLC Port 3 settings.


Open up a web browser, such as Internet Explorer, and enter in the IP address of the MB-GATEWAY to access the main screen as shown.

A



Click on the link to the right of “Serial Port Configuration” and set up the window to match the CLICK PLC port and then click on the Send button to save the settings:


A




Step 3: Connect to the MB-GATEWAY using the Modbus Poll simulator software.

Once the software has been obtained from www.modbustools.com and installed according to the directions provided from their website, open up the Modbus Poll software.

Click on the Setup pulldown menu and select Read/Write Definition as shown:



Configure the Read/Write definition for a simple read of the register 400001, which equates to DS1 in the CLICK PLC as shown.



Address Picker : Edit Mode

Fill Down (Nickname) Find: Exact Match

All	Address	Data Type	MODBUS Address (Function code)	Nickname	Used	Initial Value	Retentive	Address Comment
	DS1	RW INT	400001 (03,06,16)		No	Disable	Yes	
X	DS2	RW INT	400002 (03,06,16)		No	Disable	Yes	
Y	DS3	RW INT	400003 (03,06,16)		No	Disable	Yes	
C	DS4	RW INT	400004 (03,06,16)		No	Disable	Yes	
T	DS5	RW INT	400005 (03,06,16)		No	Disable	Yes	
CT	DS6	RW INT	400006 (03,06,16)		No	Disable	Yes	
SC	DS7	RW INT	400007 (03,06,16)		No	Disable	Yes	
	DS8	RW INT	400008 (03,06,16)		No	Disable	Yes	
	DS9	RW INT	400009 (03,06,16)		No	Disable	Yes	
DS	DS10	RW INT	400010 (03,06,16)		No	Disable	Yes	
DD	DS11	RW INT	400011 (03,06,16)		No	Disable	Yes	
DH	DS12	RW INT	400012 (03,06,16)		No	Disable	Yes	
DF	DS13	RW INT	400013 (03,06,16)		No	Disable	Yes	
	DS14	RW INT	400014 (03,06,16)		No	Disable	Yes	
XD	DS15	RW INT	400015 (03,06,16)		No	Disable	Yes	
YD	DS16	RW INT	400016 (03,06,16)		No	Disable	Yes	
TD	DS17	RW INT	400017 (03,06,16)		No	Disable	Yes	
CTD	DS18	RW INT	400018 (03,06,16)		No	Disable	Yes	
SD	DS19	RW INT	400019 (03,06,16)		No	Disable	Yes	
	DS20	RW INT	400020 (03,06,16)		No	Disable	Yes	
TXT	DS21	RW INT	400021 (03,06,16)		No	Disable	Yes	

Data Type Filter

Display All Data Types

Integer Integer (2Words)

HEX Floating Point

Bit Text

Used/Unused Address

Display both used and unused

Display only used

Display only unused


Display MODBUS Address

MODBUS 984 Addressing

MODBUS HEX Addressing



Enter in 1 for the Slave ID. This matches the Unit ID in the protocol that will determine which Modbus Serial Slave will be targeted on the serial side of the MB-GATEWAY. Entering 1 here will match up to the Node Address configured above in the CLICK programming software for Port 3.




Enter in 1 for the Slave ID. This matches the Unit ID in the protocol that will determine which Modbus Serial Slave will be targeted on the serial side of the MB-GATEWAY. Entering 1 here will match up to the Station Number configured above in the CLICK software.




Choosing Function 3 sets up the read for 4xxxx registers. Checking the "PLC Addresses (Base 1)" in the lower right corner matches the addressing to the cross reference chart mentioned above. Once this window has been configured as shown above, click on OK.

Now click on the Connection pulldown menu and select Connect:




In the Connection Setup window, choose the Modbus TCP/IP connection type. Enter the IP address of your MB-GATEWAY module in the lower left hand corner. Match everything else as shown:




Click on OK to connect to the MB-GATEWAY.

If everything has been configured correctly, the counter next to “TX =” will increment rapidly and the counter next to “Err =” will not increment. If the Error counter is incrementing, go back and verify that all the steps prior to this one have been followed. If you get an error that says, “Modbus TCP connection failed”, verify that the IP address of the PC and the IP address of the GATEWAY are in compatible subnets and can communicate.



Once Modbus Poll is communicating to the PLC, go into the CLICK programming software, open up a Data View window and enter in DS1 as shown.



Change the value in data view for DS1 to various values and watch the value change in Modbus Poll to match.


Example 3: Using P3000 as Master (Client) to MB-GATEWAY with CLICK Slave.

Step 1: Connect CLICK to the MB-GATEWAY as shown in example 2.


Step 2: Connect P3000 CPU (P3-550) to MB-GATEWAY via Ethernet Switch and Two Ethernet Cables.

Configure the IP address of the P3 CPU and the MB-GATEWAY to be compatible subnets. Steps to configure the IP address of the P3-550 CPU areas follows:


Click on Setup on the top menu bar and choose “Hardware Configuration”.




Double click on the image of the P3-550 in the center of the hardware configuration.



Click on the “Ethernet Ports” tab and configure the IP address in the “Use the Following:” IP address field. Once the correct IP address and Subnet Mask is entered, click on the OK button and close the hardware configuration window.



Transfer the project to the PAC in order to have the new settings take effect. To do this, select File from the pulldown menu and then Transfer Project >To PAC...



Step 3: Configure the MRX instruction to read data from the MB-GATEWAY.

Double click on the instruction MRX Read to configure the MRX instruction as shown.

IP Address: address of the GATEWAY.

TCP Port Number: Leave at default 502.

Slave Node Number: This should match the Node address of Port 3 of the CLICK PLC.
Leave at 1 in this case.


Slave Modbus Starting Address: Set to 1 to read address DS1 in the CLICK PLC.

Tag Name Mapping: Create a Tag called CLICK_DS1 as an Signed Int 16 Tag to read in DS1 from the CLICK PLC.

Use the status bits and Exception Response String to verify whether communications were successful or not. If the Error bit comes on, look at the Exception Response String to see which error occurred. If the Timeout Bit comes on, check the IP address settings of the P3-550 and the GATEWAY and make sure that they are in compatible subnets.

If the Successful Status bit comes on, add the CLICK_DS1 tag to the Data View at the bottom of the Productivity Suite Programming Software and check the values. Change the values in the CLICK data view for DS1 and verify that the CLICK_DS1 tag matches.

Example 4: DirectLogic 06 (H0-ECOM100) as Master (Client) to MB-GATEWAY with Multiple GS Drives as Slaves.



Step 1: Set up Peer to Peer Configuration

In NetEdit, Scan Network to find your H0-ECOM100.

Set the Module ID, IP address and Subnet Mask as appropriate for your network. In our example, we use 7, 10.11.0.221 and 255.255.255.0 respectively.

General Settings

Module ID: 7

Name: H0-ECOM100

Description: H0-ECOM100 Ethernet Communications Module

Obtain an IP address automatically:

Use the following IP settings:

IP Address: 10 . 11 . 0 . 221

Subnet mask: 255 . 255 . 255 . 0

Gateway: 0 . 0 . 0 . 0

OK Cancel

In the ECOM Settings tab, click the Peer to Peer Config button. Add the Devices appropriate for your project.

Peer to Peer Configuration

Device	Protocol	Configuration
1	Modbus/TCP	IP = 10.11.0.233, Port = 502, Unit ID = 1
2	Modbus/TCP	IP = 10.11.0.233, Port = 502, Unit ID = 2
3	Modbus/TCP	IP = 10.11.0.233, Port = 502, Unit ID = 3

Add... Edit... Delete Delete All OK Cancel

In our example we have added three devices that are the MB-GATEWAY:

Device 1 is the Automatic Reads table that resides in the MB-GATEWAY, so it is configured with the MB-GATEWAY IP address and the MB-GAEWAY Unit ID.

Device 2 is the first drive. It is configured with the MB-GATEWAY IP address and the first drive Unit ID.

Device 3 is the second drive. It is configured with the MB-GATEWAY IP address and the second drive Unit ID.

Step 2: Set the Serial Port Configuration

In the NetEdit Module List, select your MB-GATEWAY. Set the IP address and subnet mask as appropriate for your network. In our example, we use 10.11.0.233 and 255.255.255.0.

Click Start Web Based Config... To set the Gateway Modbus ID as appropriate for your network. In our example, we use 1.

Set the Serial Port Configuration as appropriate for your network. For our example, we use:

Baud rate = 19200

Parity = Odd

Stop bit = 1

Step 3: Set the Communication Parameters

Set the communication parameters in the drives as appropriate for your network.

In our example:

Parameter Number	Parameter Description	First Drive	Second Drive
P9.00	Drive ID	02	03
P9.01	Baud Rate	02	02
P9.02	Modbus RTU, 8-Odd-1	05	05
P3.00	RS-485 interface, Keypad STOP disabled	04	04
P4.00	Frequency determined by RS-485 interface	05	05

Step 4: Using Automatic Reads

In the MB-GATEWAY browser configuration utility, click the Automatic Reads link. Slave number 2 is the first drive and Slave number 3 is the second drive in our example. Configure the lines as appropriate.

For our example, we will read the status registers for each drive:

Setup Automatic Reads - Windows Internet Explorer

http://10.11.0.233/settable.html

File Edit View Favorites Tools Help

Setup Automatic Reads

Setup Automatic Reads

Gateway Modbus Address = 1

Auto Assign Gateway Addresses


Memory To Read	Slave Number	RTU Start Address	Number of Elements	Gateway Memory Address
3-Holding Regs	2	8448	4	0
3-Holding Regs	3	8448	6	4
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0
0-Unused Entry	0	0	0	0

Back Send Reset

Done Internet 100%


Step 5: Access the Automatic Read Data

The ECRX iBox is used since the data will be read by the ECOM100, rather than a serial connection



The screenshot shows a configuration window titled "ECOM100 RX Network Read" with a green close button in the top right corner. The window contains several fields for configuration:

ECOM100 RX Network Read	
ECRX	IB-740
ECOM100 #	K7
Workspace	V503
Slave ID	K2
From Slave Element (Src)	V20400
Number Of Bytes	K6
To Master Element (Dest)	V2000
Success	C100
Error	C101



ECOM100# = defined for this DL program in the ECOM100 iBox in our Rung 1
Workspace = an internal, private register used by this iBox and **MUST BE UNIQUE** in this one instruction and **MUST NOT** be used anywhere else in your program.
Slave ID = The MB-GATEWAY Modbus Gateway ID, 1, since we are reading the Automatic Read data stored in the MB-GATEWAY
From Slave Element (Src) = the Gateway Memory Address identified on the MB-GATEWAY Setup Automatic Reads config page. Note that the address in the MB-GATEWAY, “0” should be entered here as “V0” and DirectSoft software will change the name to TA0. This is a naming convention for addresses internal to the PLC and will not

affect either the targeted address or the use of Timer 0 in the DL program.

Number of Bytes = 20. Since our addresses for both example drives are contiguous, we can read all 10 elements with one iBox. Each element is a word, 2 bytes, so we want to read 20 bytes to get all 10 elements.


To Master Element (Dest) = the location where the slave data will be placed in the master ECOM100 PLC

Success = a bit that will turn on once the request is completed successfully


Error = a bit that will turn on if the instruction is not successfully completed

Step 6: Read and Write from the DL06

To Read data from a drive instead of using of the Automatic Read feature of the MB-GATEWAY, and to Write data to the drive, the Slave ID in the ECRX and/or ECWX iBoxes will be the Drive ID. The From Slave Element and/or To Slave Element values will be the addresses in the drive



continued



ECOM100 RX Network Read	
ECRX	IB-740
ECOM100 #	K7
Workspace	V503
Slave ID	K2
From Slave Element (Src)	V20400
Number Of Bytes	K6
To Master Element (Dest)	V2000
Success	C100
Error	C101

In our example ECRX boxes:

ECOM100# = defined for this DL program in the ECOM100 iBox in our Rung 1.

Workspace = an internal, private register used by this iBox and **MUST BE UNIQUE** in this one instruction and **MUST NOT** be used anywhere else in your program.

Slave ID = The GS Drive Node ID, 2 or 3, depending on which drive we target

From Slave Element (Src) = V20400 equates to Status Monitor 1 in the GS Drive (Hex 2100 and Modbus Decimal 48449). See GS Drive manual for details.

Number of Bytes = Each Modbus register (element) that we want to read is a word, 2 bytes; in our example we will read 3 status registers.

To Master Element (Dest) = the location where the slave data will be placed in the master ECOM100 PLC

Success = a bit that will turn on once the request is completed successfully

Error = a bit that will turn on if the instruction is not successfully completed

ECOM100 VXX Network Write	
ECWX	IB-741
ECOM100 #	K7
Workspace	V504
Slave ID	K2
From Master Element (Src)	V2100
Number Of Bytes	K4
To Slave Element (Dest)	V4432
Success	C102
Error	C103

In our example ECWX boxes:

ECOM100# = Module ID, set in NetEdit and defined for the DL program in the ECOM100 iBox in our Rung 1

Workspace = an internal, private register used by this iBox and **MUST BE UNIQUE** in this one instruction and **MUST NOT** be used anywhere else in your program.

Slave ID = The GS Drive Node ID, 2 or 3, depending on which drive we target

From Master Element (Src) = the location of data in the Master PLC that will be written to the drive

Number of Bytes = 4. In our example, we will write the speed (2 bytes) to the Comm Speed Reference register and set the next register to RUN (2 bytes)

To Slave Element (Dest) = the Modbus register where the data will be written in the drive. In this case, V4432 equates to P9.26 Comm Speed Reference. See GS Drive manual for more details.

Success = a bit that will turn on once the instruction is completed successfully

Error = a bit that will turn on if the instruction is not successfully completed