

# D2–RMSM Setup Programming and Troubleshooting

---

In This Chapter. . . .


- Getting Started with the Programming
  - Writing the Remote I/O Setup
  - Example Program Using Discrete Modules
  - Example Program Using Analog Modules
  - Changing Configurations
  - Shared Memory Table for D2–RMSM
  - Troubleshooting Remote I/O
  - Special CPU Memory for Diagnostics
  - D2–RMSM Memory for Diagnostics
  - How to Access Diagnostic Information
-

## Getting Started with the Programming

You can write your program using either a handheld programmer or a PC loaded with software such as **DirectSOFT**. The examples that follow will show you how to do it using **DirectSOFT**.

To get started, enter **DirectSOFT** and carry out the normal **DirectSOFT** setup procedures for communicating with your DL205 CPU. If you do not know how to do this, refer to your **DirectSOFT** Manual. Your DL205 User's Manual has a very good coverage of the basic commands available and examples of using the commands to write general ladder logic. We will be showing you in this chapter only those commands that pertain to setting up your remote I/O initialization and its successful utilization.

First open **DirectSOFT** from Windows and establish a link with your CPU. Then enter the Edit Mode for programming. You should now be looking at a screen similar to the one shown below:



The **DirectSOFT** window shown above depicts a program that has already been written. Your window, of course, will be empty when you first enter it. The pages that follow will show you how to write each part of your initialization program.

## Writing the Remote I/O Setup


### Step 1: Decide How You Are Going to Call Your Program

Is your setup logic going to be in the main program body or is it going to be in a subroutine?

A subroutine for your remote I/O setup has an advantage over writing the code into the program's main body. Some remote I/O setup logic becomes quite lengthy. By putting the setup in a subroutine, you don't have to scroll through extra logic during routine troubleshooting procedures. We advise you to use a subroutine for your remote I/O initialization. Here's how:

### Using the GTS Command for the Setup Logic

Note: SP0 is a special relay contact which energizes only on the first scan of the program




## Step 2: Write the Setup Logic for Each Channel

Whether you choose to write the remote I/O setup program as a subroutine or as a part of the main program, the procedure is still the same. You have several things you must do for each channel of remote I/O:


- Tell the remote master to initiate setup, and define the auto return to network option.
- Tell the remote master the starting V-memory address for inputs and outputs, and the total number of each for the channel. You do this with address *pointers* and constant data.
- Tell the remote master how many input and output points are located in each base.
- Tell the remote master to save the parameters in EEPROM (setup is complete).

To write the setup logic, we use the CPU instructions described below. If you are not familiar with these instructions, you may want to refer to the DL205 User Manual for more details and examples.


The Load instruction is a 16-bit instruction that loads the value (Aaaa), which is either a V-memory location or a 4-digit constant, into the lower 16 bits of the accumulator. The upper 16 bits of the accumulator are set to 0.




The Load Address instruction is a 16 bit instruction. It converts any octal value or address to the HEX equivalent value and loads the HEX value into the accumulator.



The OUT instruction is a 16 bit instruction that copies the values in the lower 16 bits of the accumulator to a specified V-memory location (Aaaa).



The WT instruction writes a block of data (1–128 bytes max.) to an intelligent I/O module from a block of V-memory in the CPU. The function parameters (module base/slot address, number of bytes, and the intelligent I/O module memory address) are loaded into the first and second level of the accumulator stack, and the accumulator by three additional instructions. In the WT instruction, Aaaa specifies the starting V-memory address where the data will be written from in the CPU.



You use these instructions to set up the configuration data in a block of V-memory which serves as a buffer. Use WT instructions to store the data to various shared memory locations in the Remote Master module. Use your worksheets to assist you in creating the setup logic.


# Example Program Using Discrete I/O Modules

## Example 1: Addressing using X and Y Memory

To illustrate the setup program for a system using X's as remote inputs and Y's as remote outputs, we will use the example system from Chapter 2, shown here with a completed Channel Configuration Worksheet.

The first block of logic tells the remote master to initiate the setup, and to enable the Auto Return to Network option. To find the D2-RMSM shared memory addresses used in the setup program, refer to the Shared Memory Table at the end of this chapter.

### Write Configuration Byte




Channel Configuration Sheet					
D2-RMSM Remote Master Module					
Master Slot Address <u>4</u> (1-7)					
Protocol Selected <u>RM-NET</u> (RM-NET or SM-NET)					
Circle one selection for each parameter (selections for each protocol are shown)					
Configuration Parameter	RM-NET		SM-NET		
Baud Rate (in Kbaud), determined by required distance to last slave	19.2	<u>38.4</u>	19.2	38.4	153.6
Operator Interface	<u>N/A</u>		YES	NO	
Auto Return to Network (either protocol)	<u>YES</u>		NO		

Starting Input V Memory Address: V 40402 Starting Output V Memory Address: V 40502

Total No. Inputs 96 Total No. Outputs 112

Slave Station			Slave Station		
	No. Inputs	No. Outputs		No. Inputs	No. Outputs
0	N/A	N/A	16		
1	<b>32</b>	<b>48</b>	17		
2	<b>16</b>	<b>32</b>	18		
3	<b>48</b>	<b>32</b>	19		
4			20		
5			21		
6			22		
7			23		
8			24		
9			25		
10			26		
11			27		
12			28		
13			29		
14			30		
15			31		



This block of logic tells the remote master the starting V-memory addresses for the inputs and outputs, and the total number of each for the channel. Use the LD, LDA, and OUT commands to load the starting addresses and point totals into temporary memory, then write the values to the master's shared memory. The Quick Reference Table shows the correct shared memory addresses in octal.

**Write Input and Output Pointers, and Input and Output Ranges for Channel**

The LDA instruction uses octal numbers, designated by the capital O in front of the number.

**Channel Configuration Worksheet**  
**D2-RMSM Remote Master Module**  
 Master Slot Address 4 (1-7)  
 Protocol Selected RM-NET (RM-NET or SM-NET)


Circle one selection for each parameter (selections for each protocol are shown)

Configuration Parameter	RM-NET		SM-NET	
	19.2	38.4	19.2	38.4 153.6
Baud Rate (in KBaud), determined by required distance to last slave			307.2	614.4
Operator Interface	N/A		YES	NO
Auto Return to Network (either protocol)	YES	NO	YES	NO

Starting Input V Memory Address: V 40402 Starting Output V Memory Address: V 40502

Total Inputs 96 Total Outputs 112

Slave Station	No. of Inputs	No. of Outputs	Slave Station	No. of Inputs	No. of Outputs
0	N/A	N/A	16		
1	32	48	17		
2	16	32	18		
3	48	32	19		
4			20		
5			21		
6			22		
7			23		
8			24		
9			25		
10			26		
11			27		
12			28		
13			29		
14			30		
15			31		




**Quick Reference Table of Shared Memory Addresses**

D2-RMSM				
Setup Initiation Byte				176
Setup Complete Byte				177
Slave	Input Address	Output Address	Number of Input Pts	Number of Output Pts
ALL	000	002	124	126
1	N/A	N/A	004	006
2	N/A	N/A	010	012
3	N/A	N/A	014	016
4	N/A	N/A	020	022
5	N/A	N/A	024	026
6	N/A	N/A	030	032
7	N/A	N/A	034	036

This block of logic tells the remote master how many input and output points are located in each base. Each group of four instructions loads the I/O ranges for a slave into temporary memory, the values for which are retrieved from the Remote Slave Worksheets. The WT instruction stores the entire buffer area to the master's shared memory. The Quick Reference Table shows the correct shared memory addresses in octal.

**Write Input and Output Ranges for each Slave**



The last four instructions write the slaves' range data to the Master's shared memory. Address 004 is the *start* of the slave data; the byte length of 12 writes 6 consecutive words of data.

**Channel Configuration Worksheet**  
**D2-RMSM Remote Master Module**  
**Master Slot Address** 4 (1-7)  
**Protocol Selected** RM-NET (RM-NET or SM-NET)

Circle one selection for each parameter (selections for each protocol are shown)


Configuration Parameter	RM-NET		SM-NET	
	19.2	38.4	19.2	38.4
Baud Rate (in KBAud), determined by required distance to last slave		<input checked="" type="radio"/>	307.2	614.4
Operator Interface	<input checked="" type="radio"/> N/A		YES	NO
Auto Return to Network (either protocol)	<input checked="" type="radio"/> YES	NO	YES	NO

Starting Input V Memory Address: v 40402 Starting Output V Memory Address: v 40502  
 Total Inputs 96 Total Outputs 112

Slave Station	No. of Inputs	No. of Outputs	Slave Station	No. of Inputs	No. of Outputs
0	N/A	N/A	16		
1	<u>32</u>	<u>48</u>	17		
2	<u>16</u>	<u>32</u>	18		
3	<u>48</u>	<u>32</u>	19		
4			20		
5			21		
6			22		
7			23		
8			24		
9			25		
10			26		
11			27		
12			28		
13			29		
14			30		
15			31		

**Quick Reference Table of Shared Memory Addresses**


D2-RMSM				
Configuration Byte				176
Setup Complete Byte				177
Slave	Input Address	Output Address	Number of Input Pts	Number of Output Pts
ALL	000	002	124	126
1	N/A	N/A	<u>004</u>	006
2	N/A	N/A	010	012
3	N/A	N/A	014	016
4	N/A	N/A	020	022
5	N/A	N/A	024	026
6	N/A	N/A	030	032
7	N/A	N/A	034	036

**Write Setup Complete (store channel parameters to EEPROM)**

We can now complete the setup program. This last block of logic tells the remote master to save the parameters in EEPROM (setup is complete). The setup complete logic structure is the same for any channel using a D2-RMSM as a master.

The completed setup program for this example is shown on the next page.

## Completed Setup Program for X and Y Addressing



### Example Program Using Analog I/O Modules


#### Example 2: Addressing using V-Memory

The following example uses Terminator I/O discrete and analog I/O modules. **It is recommended to use V memory addressing when using analog modules since each analog I/O channel uses a double (two) word each.** Thus, an 8 channel analog I/O module uses 256 discrete points and a 16 channel analog I/O module uses 512 discrete points. **Analog output modules are configured using the Module Control Byte** located in the most significant byte of the most significant word of channel 1 of the module. **V memory addressing requires the use of "Bit-of-Word" (DL250 only) instructions to address the I/O points.**

The first block of logic tells the remote master to initiate the setup, and to enable the Auto Return to Network option. To find the D2-RMSM shared memory addresses used in the setup program, refer to the Shared Memory Table at the end of this chapter.


#### Write Configuration Byte

##### Main Base with Master



X0-X17 X20-X37 Y0-Y17 Y20-Y37  
V40400 V40401 V40500 V40501

##### 1st Remote



T1F-08AD-2

T1F-16DA-2

Use Bit-of-Word instructions to address the I/O points when mapping the remote I/O to V memory.

#### Channel Configuration Sheet

##### D2-RMSM Remote Master Module

Master Slot Address 4 (1-7)

Protocol Selected RM-NET (RM-NET or SM-NET)

Circle one selection for each parameter (selections for each protocol are shown)


Configuration Parameter	RM-NET	SM-NET
Baud Rate (in Kbaud), determined by required distance to last slave	19.2 <u>38.4</u>	19.2 38.4 153.6 307.2 614.4
Operator Interface	<u>N/A</u>	YES NO
Auto Return to Network (either protocol)	<u>YES</u>	NO

Starting Input V Memory Address: V 3000 Starting Output V Memory Address: V V3100

Total No. Inputs 272

Total No. Outputs 528

Slave Station	Slave Station		Slave Station	Slave Station	
	No. Inputs	No. Outputs		No. Inputs	No. Outputs
0	N/A	N/A	16		
1	<b>272</b>	<b>528</b>	17		
2			18		
3			19		
4			20		
5			21		
6			22		
7			23		
8			24		
9			25		
10			26		
11			27		
12			28		
13			29		
14			30		
15			31		



This block of logic tells the remote master the starting V-memory addresses for the inputs and outputs, and the total number of each for the channel. Use the LD, LDA, and OUT commands to load the starting addresses and point totals into temporary memory, then write the values to the master's shared memory. The Quick Reference Table shows the correct shared memory addresses in octal.

**Write Input and Output Pointers, and Input and Output Ranges for Channel**

The LDA instruction uses octal numbers, designated by the capital O in front of the number.


**Channel Configuration Worksheet**  
**D2-RMSM Remote Master Module**  
 Master Slot Address 4 (1-7)  
 Protocol Selected RM-NET (RM-NET or SM-NET)

Circle one selection for each parameter (selections for each protocol are shown)

Configuration Parameter	RM-NET		SM-NET	
	19.2	38.4	19.2	38.4 153.6
Baud Rate (in KBaud), determined by required distance to last slave			307.2	614.4
Operator Interface	N/A		YES	NO
Auto Return to Network (either protocol)	YES	NO	YES	NO

Starting Input V Memory Address: V 3000 Starting Output V Memory Address: V 3100  
 Total Inputs 272 Total Outputs 528

Slave Station	No. of Inputs	No. of Outputs	Slave Station	No. of Inputs	No. of Outputs
0	N/A	N/A	16		
1	272	528	17		
2			18		
3			19		
4			20		
5			21		
6			22		
7			23		
8			24		
9			25		
10			26		
11			27		
12			28		
13			29		
14			30		
15			31		




**Quick Reference Table of Shared Memory Addresses**

D2-RMSM				
Setup Initiation Byte				176
Setup Complete Byte				177
Slave	Input Address	Output Address	Number of Input Pts	Number of Output Pts
ALL	000	002	124	126
1	N/A	N/A	004	006
2	N/A	N/A	010	012
3	N/A	N/A	014	016
4	N/A	N/A	020	022
5	N/A	N/A	024	026
6	N/A	N/A	030	032
7	N/A	N/A	034	036

This block of logic tells the remote master how many input and output points are located in each base. Each group of four instructions loads the I/O ranges for a slave into temporary memory, the values for which are retrieved from the Remote Slave Worksheets. The WT instruction stores the entire buffer area to the master's shared memory. The Quick Reference Table shows the correct shared memory addresses in octal.

### Write Input and Output Ranges for each Slave



The last four instructions write the slaves' range data to the Master's shared memory. Address 004 is the *start* of the slave data; the byte length of 4 writes 2 consecutive words of data.

### Channel Configuration Worksheet

D2-RMSM Remote Master Module  
 Master Slot Address 4 (1-7)  
 Protocol Selected RM-NET (RM-NET or SM-NET)

Circle one selection for each parameter (selections for each protocol are shown)

Configuration Parameter	RM-NET	SM-NET
Baud Rate (in KBaud), determined by required distance to last slave	19.2 <u>38.4</u>	19.2 38.4 153.6 307.2 614.4
Operator Interface	<u>N/A</u>	YES NO
Auto Return to Network (either protocol)	<u>YES</u> NO	YES NO


Starting Input V Memory Address: V 3000 Starting Output V Memory Address: V 3100  
 Total Inputs 272 Total Outputs 528

Slave Station	No. of Inputs	No. of Outputs	Slave Station	No. of Inputs	No. of Outputs
0	N/A	N/A	16		
1	<u>272</u>	<u>528</u>	17		
2			18		
3			19		
4			20		
5			21		
6			22		
7			23		
8			24		
9			25		
10			26		
11			27		
12			28		
13			29		
14			30		
15			31		

### Quick Reference Table of Shared Memory Addresses

D2-RMSM				
Configuration Byte				176
Setup Complete Byte				177
Slave	Input Address	Output Address	Number of Input Pts	Number of Output Pts
ALL	000	002	124	126
1	N/A	N/A	<u>004</u>	006
2	N/A	N/A	010	012
3	N/A	N/A	014	016
4	N/A	N/A	020	022
5	N/A	N/A	024	026
6	N/A	N/A	030	032
7	N/A	N/A	034	036


### Write Setup Complete (store channel parameters to EEPROM)



We can now complete the setup program. This last block of logic tells the remote master to save the parameters in EEPROM (setup is complete). The setup complete logic structure is the same for any channel using a D2-RMSM as a master.

The completed setup program for this example is shown on the next page.

### Completed Setup Program for V-Memory Addressing



Analog Programming example continued on next page

Quick Reference Table of Shared Memory Addresses

D2-RMSM				
Setup Initiation Byte				176
Setup Complete Byte				177
Slave	Input Address	Output Address	Number of Input Pts	Number of Output Pts
ALL	000	002	124	126
1	N/A	N/A	004	006
2	N/A	N/A	010	012
3	N/A	N/A	014	016
4	N/A	N/A	020	022
5	N/A	N/A	024	026
6	N/A	N/A	030	032
7	N/A	N/A	034	036







## Completed Setup Program for V-Memory Addressing (con't)

### Main Program Body

#### Configure T1F-16DA-2 Analog Output Module:

- Bipolar
- 0-5VDC

Use X, C, etc. permissive contact if needed



The Control Bits of an Analog Output module are located in the most significant byte of the most significant word of the first output channel (channel 1).

Channel 1 Memory Map of 8&16-Channel Analog Output Module (T1F-08DA, T1F-016DA)									
Decimal Bit	07	06	05	04	03	02	01	00	Size
Octal Bit	07	06	05	04	03	02	01	00	
	Analog Value Channel 1								Write Byte 1
	Analog Value Channel 1								Write Byte 2
	not used								Write Byte 3
	<b>Module Control Byte</b>								Write Byte 4

Module Control Byte of 8&16-Channel Analog Output Module (T1F-08DA, T1F-16DA)									
Decimal Bit	31	30	29	28	27	26	25	24	Read/Write
Octal Bit	37	36	35	34	33	32	31	30	
Bit 24	<b>Outputs Enable</b> 0 = All outputs OFF 1 = All outputs Enabled								Write
Bit 25	<b>Unipolar / Bipolar</b> 0 = Unipolar selected 1 = Bipolar selected								Write
Bit 26	<b>5V / 10V Range</b> 0 = 5V range 1 = 10V range								Write
Bit 27	<b>0 – 20mA / 4–20mA Range</b> 0 = 0 – 20mA range 1 = 4 – 20mA range								Write
Bit 28 – 31	Reserved for system use								–

## Changing Configurations

If you have stored a configuration to the D2-RMSM via the setup program and need to change it, follow these guidelines to ensure the module accepts the new configuration:

1. Change the constants in the setup program that are affected by the new system configuration. For example, if you add an I/O module to a remote slave unit, you must change the input or output range for that slave, as well as the range total for the channel. If the new range totals do not match the sum of the individual slave ranges, the D2-RMSM *will not* accept the new configuration. It will retain the old configuration, and give you an I/O error.
2. If you are removing a slave from the channel, you must change the logic of the setup program to clear that slave's range data in the D2-RMSM shared memory. Otherwise it will still see the old data from the previous configuration. For example, if you remove the third slave from our example system, you would load a constant of zero into the slave's input and output range data, located at buffer memory addresses V2007 and V2010. If removing I/O, remember to reduce the total I/O range values also.
3. After you have modified the setup program, cycle CPU power, or transition from the STOP to RUN mode to execute the new setup logic. This is necessary if the setup logic executes on the first CPU scan.
4. **If you get an error after making the appropriate set up program changes, it may be necessary to clear the shared memory in the remote master module.** To clear the shared memory in the master module, you will need to:
  - 1) Remove CPU base power and remove the remote master module from the base.
  - 2) Turn on Dip switch 8 on the master module and return it to the base.
  - 3) Apply power to the CPU base noting that the master module LEDs cycle through and then all come ON.
  - 4) Remove CPU base power and remove the remote master module from the base.
  - 5) Turn off Dip switch 8 on the master module and return it to the base.
  - 6) Apply power to the CPU base and check for proper remote I/O operation.

## Shared Memory Table for D2-RMSM Remote Master

OCTAL ADDRESS	FUNCTION (Slaves 1–15)	FUNCTION (Slaves 16–31)	# Bytes
For memory addresses 000 to 077, the user's setup program must store the correct values into these locations.			
000	Starting V-memory address for inputs on the channel (in octal)	Number of input points for Slave 16	2
002	Starting V-memory address for outputs on the channel (in octal)	Number of output points for Slave 16	2
004	Number of input points for Slave 1	Number of input points for Slave 17	2
006	Number of output points for Slave 1	Number of output points for Slave 17	2
010	Number of input points for Slave 2	Number of input points for Slave 18	2
012	Number of output points for Slave 2	Number of output points for Slave 18	2
014	Number of input points for Slave 3	Number of input points for Slave 19	2
016	Number of output points for Slave 3	Number of output points for Slave 19	2
020	Number of input points for Slave 4	Number of input points for Slave 20	2
022	Number of output points for Slave 4	Number of output points for Slave 20	2
024	Number of input points for Slave 5	Number of input points for Slave 21	2
026	Number of output points for Slave 5	Number of output points for Slave 21	2
030	Number of input points for Slave 6	Number of input points for Slave 22	2
032	Number of output points for Slave 6	Number of output points for Slave 22	2
034	Number of input points for Slave 7	Number of input points for Slave 23	2
036	Number of output points for Slave 7	Number of output points for Slave 23	2
040	Number of input points for Slave 8	Number of input points for Slave 24	2
042	Number of output points for Slave 8	Number of output points for Slave 24	2
044	Number of input points for Slave 9	Number of input points for Slave 25	2
046	Number of output points for Slave 9	Number of output points for Slave 25	2
050	Number of input points for Slave 10	Number of input points for Slave 26	2
052	Number of output points for Slave 10	Number of output points for Slave 26	2
054	Number of input points for Slave 11	Number of input points for Slave 27	2
056	Number of output points for Slave 11	Number of output points for Slave 27	2
060	Number of input points for Slave 12	Number of input points for Slave 28	2
062	Number of output points for Slave 12	Number of output points for Slave 28	2
064	Number of input points for Slave 13	Number of input points for Slave 29	2
066	Number of output points for Slave 13	Number of output points for Slave 29	2
070	Number of input points for Slave 14	Number of input points for Slave 30	2
072	Number of output points for Slave 14	Number of output points for Slave 30	2
074	Number of input points for Slave 15	Number of input points for Slave 31	2
076	Number of output points for Slave 15	Number of output points for Slave 31	2

OCTAL ADDRESS	FUNCTION	DETAIL	# Bytes
100 – 121	Reserved		18
122	Status of Rotary Switches on module – <b>Read Only</b>	Data is 00 to 1F hex, representing the address of the module set by the rotary switches.	1
123	Status of DIP Switches on module – <b>Read Only</b>	Bit status represents the setting of each switch on the module's DIP Switch , which sets configuration parameters. 0=OFF, 1=ON.  Bit 0 SW1 status Bit 1 SW2 status Bit 2 SW3 status Bit 3 SW4 status Bit 4 SW5 status Bit 5 SW6 status Bit 6 SW7 status Bit 7 SW8 status	1
124	Number of input points committed to the entire channel	User's setup program stores the correct BCD value to this memory location.	2
126	Number of output points committed to the entire channel	User's setup program stores the correct BCD value to this memory location.	2

OCTAL ADDRESS	FUNCTION	DETAIL	# Bytes
130 – 131	Communication stop mode selection (communication stops when any specified slave fails)	<p>In communication stop mode, the master stops updating the entire channel when a communication error occurs with any specified slave station. To select this mode for each slave, turn ON the corresponding bit of the shared memory shown below.</p> <p style="text-align: center;"><u>Address 130</u>    <u>Address 131</u></p> <p>Bit 0    Entire channel stops when any slave fails    Slave 16</p> <p>Bit 1    Slave 1    Slave 17</p> <p>Bit 2    Slave 2    Slave 18</p> <p>Bit 3    Slave 3    Slave 19</p> <p>Bit 4    Slave 4    Slave 20</p> <p>Bit 5    Slave 5    Slave 21</p> <p>Bit 6    Slave 6    Slave 22</p> <p>Bit 7    Slave 7    Slave 23</p> <p>Bit 8    Slave 8    Slave 24</p> <p>Bit 9    Slave 9    Slave 25</p> <p>Bit 10    Slave 10    Slave 26</p> <p>Bit 11    Slave 11    Slave 27</p> <p>Bit 12    Slave 12    Slave 28</p> <p>Bit 13    Slave 13    Slave 29</p> <p>Bit 14    Slave 14    Slave 30</p> <p>Bit 15    Slave 15    Slave 31</p>	2

OCTAL ADDRESS	FUNCTION	DETAIL	# Bytes																																																			
132 – 133	Slave removal mode selection (communication stops to only the slave(s) with a communication error)	<p>In slave removal mode, the master stops updating only the slave(s) with a communication error. It continues updating the I/O for the other slaves on the channel. To select this mode for each slave, turn ON the corresponding bit of the shared memory shown below.</p> <table border="1"> <thead> <tr> <th></th> <th>Address 132</th> <th>Address 133</th> </tr> </thead> <tbody> <tr><td>Bit 0</td><td>Not used</td><td>Slave 16</td></tr> <tr><td>Bit 1</td><td>Slave 1</td><td>Slave 17</td></tr> <tr><td>Bit 2</td><td>Slave 2</td><td>Slave 18</td></tr> <tr><td>Bit 3</td><td>Slave 3</td><td>Slave 19</td></tr> <tr><td>Bit 4</td><td>Slave 4</td><td>Slave 20</td></tr> <tr><td>Bit 5</td><td>Slave 5</td><td>Slave 21</td></tr> <tr><td>Bit 6</td><td>Slave 6</td><td>Slave 22</td></tr> <tr><td>Bit 7</td><td>Slave 7</td><td>Slave 23</td></tr> <tr><td>Bit 8</td><td>Slave 8</td><td>Slave 24</td></tr> <tr><td>Bit 9</td><td>Slave 9</td><td>Slave 25</td></tr> <tr><td>Bit 10</td><td>Slave 10</td><td>Slave 26</td></tr> <tr><td>Bit 11</td><td>Slave 11</td><td>Slave 27</td></tr> <tr><td>Bit 12</td><td>Slave 12</td><td>Slave 28</td></tr> <tr><td>Bit 13</td><td>Slave 13</td><td>Slave 29</td></tr> <tr><td>Bit 14</td><td>Slave 14</td><td>Slave 30</td></tr> <tr><td>Bit 15</td><td>Slave 15</td><td>Slave 31</td></tr> </tbody> </table>		Address 132	Address 133	Bit 0	Not used	Slave 16	Bit 1	Slave 1	Slave 17	Bit 2	Slave 2	Slave 18	Bit 3	Slave 3	Slave 19	Bit 4	Slave 4	Slave 20	Bit 5	Slave 5	Slave 21	Bit 6	Slave 6	Slave 22	Bit 7	Slave 7	Slave 23	Bit 8	Slave 8	Slave 24	Bit 9	Slave 9	Slave 25	Bit 10	Slave 10	Slave 26	Bit 11	Slave 11	Slave 27	Bit 12	Slave 12	Slave 28	Bit 13	Slave 13	Slave 29	Bit 14	Slave 14	Slave 30	Bit 15	Slave 15	Slave 31	2
	Address 132	Address 133																																																				
Bit 0	Not used	Slave 16																																																				
Bit 1	Slave 1	Slave 17																																																				
Bit 2	Slave 2	Slave 18																																																				
Bit 3	Slave 3	Slave 19																																																				
Bit 4	Slave 4	Slave 20																																																				
Bit 5	Slave 5	Slave 21																																																				
Bit 6	Slave 6	Slave 22																																																				
Bit 7	Slave 7	Slave 23																																																				
Bit 8	Slave 8	Slave 24																																																				
Bit 9	Slave 9	Slave 25																																																				
Bit 10	Slave 10	Slave 26																																																				
Bit 11	Slave 11	Slave 27																																																				
Bit 12	Slave 12	Slave 28																																																				
Bit 13	Slave 13	Slave 29																																																				
Bit 14	Slave 14	Slave 30																																																				
Bit 15	Slave 15	Slave 31																																																				
134	Communication hold or resume mode	The program can cause the communications on a channel to stop by setting the first bit in this byte ON. After communication stops, only a mode transition of the CPU (from STOP to RUN) will restart the communications. The bit is not cleared automatically, so if using this mode, the user program should clear this byte on the first scan.	1																																																			
135 – 137	Reserved		3																																																			
140	Network Error Flags – <b>Read Only</b>	<p>Bit status represents network errors detected by the D2-RMSM. 0=OK, 1=ERROR</p> <p>Bit 0 Configuration Error (see Address 142 for details)</p> <p>Bit 1 Communication Error (see Address 144 for details)</p> <p>Bit 2 Diagnostics Error (see Address 150 for details)</p>	2																																																			

OCTAL ADDRESS	FUNCTION	DETAIL	# Bytes
142	Configuration Error Code – <b>Read Only</b>	Error code in BCD 20 Total inputs exceeds 512 21 Total outputs exceeds 512 24 I/O address out of I/O range 25 I/O address allocated to bad range 29 A slave has more than 512 points 70 Discrepancy between current configuration and old one 71 A module is in the wrong slot 72 Slave configuration is different from old one 73 Different slave is there	1
143	Station Number of Configuration Error – <b>Read Only</b>	Station number in BCD	1
144	Communication Error Code – <b>Read Only</b>	Error code in BCD 01 slave does not respond 02 wrong I/O information 03 I/O update error : CRC check error	1
145	Station Number of Communication Error Code – <b>Read Only</b>	Station number in BCD	1
146	Communication Error Counter – <b>Read Only</b>	Number of communication errors detected since CPU went into RUN mode, in BCD	2
150	Diagnostics Error Code	Error code in BCD 0201 Terminal block removed 0202 module not present 0203 Blown fuse 0206 Low battery voltage 0226 Power capacity exceeded	2
152	Reserved		1
153	Station number of Diagnostics error – <b>Read Only</b>	Station number in BCD	1

OCTAL ADDRESS	FUNCTION	DETAIL	# Bytes
154 – 157	Reserved		4
160	Current bus scan time – <b>Read Only</b>	BCD value of current bus scan, in msec	2
162	Bus scan time upper limit	User can store BCD value of bus scan upper limit, in msec. Default is 100 msec.	2
164	Shortest bus scan time – <b>Read Only</b>	BCD value of shortest bus scan detected since CPU went into RUN mode, in msec	2
166	Longest bus scan time – <b>Read Only</b>	BCD value of longest bus scan detected since CPU went into RUN mode, in msec	2
170	Bus scan counter – <b>Read Only</b>	BCD value of number of bus scans detected since CPU went into RUN mode	2
172	Overlimit Bus scan counter – <b>Read Only</b>	BCD value of number of bus scans which have exceeded the scan time upper limit	2
174 – 175	Reserved		2
176	Setup Initiation Byte (includes Auto Return to Network)	User's setup program stores the correct bit pattern to this memory location to configure the following modes:  Bits 0,1, and 2 must be ON to initiate setup of remote slave addressing  Bit 7 ON=Specifies that offline slaves can return to the network without cycling CPU	1
177	Copy Configuration to EEPROM ( Setup Complete)	User's setup program stores a BCD value to this location to log the parameters stored by the setup program to the Master's EEPROM.  C1 – Signifies that setup is complete.  Hint: This should be the last function of your setup program.	1
200 – 374	Reserved		125

OCTAL ADDRESS	FUNCTION	DETAIL	# Bytes
375	Slave Page Selection	User's setup program stores a BCD value to this location to select the page of slave parameters for setup programming: 81 Slaves 1-15 82 Slaves 16-31	1
376 - 377	Reserved		2

## Quick Reference Table of Shared Memory Addresses

D2-RMSM				
<b>Setup Initiation Byte</b>				176
<b>Setup Complete Byte</b>				177
Slave	Input Address	Output Address	Number of Input Points	Number of Output Points
ALL	000	002	124	126
1	N/A	N/A	004	006
2	N/A	N/A	010	012
3	N/A	N/A	014	016
4	N/A	N/A	020	022
5	N/A	N/A	024	026
6	N/A	N/A	030	032
7	N/A	N/A	034	036
8	N/A	N/A	040	042
9	N/A	N/A	044	046
10	N/A	N/A	050	052
11	N/A	N/A	054	056
12	N/A	N/A	060	062
13	N/A	N/A	064	066
14	N/A	N/A	070	072
15	N/A	N/A	074	076
<b>2nd page of slave range data</b>				
16	N/A	N/A	000	002
17	N/A	N/A	004	006
18	N/A	N/A	010	012
19	N/A	N/A	014	016
20	N/A	N/A	020	022
21	N/A	N/A	024	026
22	N/A	N/A	030	032
23	N/A	N/A	034	036
24	N/A	N/A	040	042
25	N/A	N/A	044	046
26	N/A	N/A	050	052
27	N/A	N/A	054	056
28	N/A	N/A	060	062
29	N/A	N/A	064	066
30	N/A	N/A	070	072
31	N/A	N/A	074	076

## Troubleshooting Remote I/O

### Troubleshooting Quick Steps

If the remote I/O channel does not seem to be working correctly, check the following items. These items represent the problems found most often.

1. Cable and connections. Incorrectly wired cables and loose terminations cause the majority of problems. Verify you've selected the proper cable configuration and check the cable, making sure it is wired correctly. Also check the cable routing to ensure that the installation guidelines in Chapter 2 were followed.
2. Incorrect Baud Rate. Make sure you've set all T1K-RSSS units to match the communication parameters set on the master station.
3. Incorrect protocol. Make sure you've set all T1K-RSSS units to match the protocol setting on the master station.
4. Setup program. Check the setup program for errors such as incorrect pointers or constants, or writing to the wrong module address. Be sure that the total inputs and outputs values match the sum of the individual slave input and output ranges; otherwise, the D2-RMSM *will not* accept the setup data. If program errors were corrected and the remote I/O channel still does not seem to be working correctly, it may be necessary to clear the shared memory in the remote master module. Refer to step 4 in the Changing Configurations section earlier in this chapter.



---

**NOTE:** If you need more in-depth troubleshooting, see the chart on the next page. It provides several different indicator patterns that may help identify your exact problem.

---



The following chart identifies the indicator status, possible cause, and corrective action for a variety of commonly found problems.

Master Station Indicators	Slave Station Indicators	Possible Cause	Corrective Action
RUN  DIAG  I/O  LINK 	RUN is off. RUN  DIAG  I/O  LINK 	1. Master PLC power is disconnected. 2. Remote Master is defective.	1. Check the PLC power source. 2. Replace the Remote Master.
RUN  DIAG  I/O  LINK 	RUN is on. RUN  DIAG  I/O  LINK 	1. Switch setting on master or slave station is incorrect. 2. Communications wiring is incorrect.	1. Check the DIP switches on Remote Master and slaves to ensure their baud rate and protocol settings match. 2. Check the communications wiring and termination resistors.
RUN  DIAG  I/O  LINK 	RUN is flashing, I/O is on. RUN  DIAG  I/O  LINK 	1. Setup program is not correct. 2. I/O totals do not match values in D2-RMSM shared memory 124 and 126.	1. Check the setup program to ensure pointer values and configuration constants are correct. 2. Check the I/O totals against the sum of the individual slave ranges in the setup program.
RUN  DIAG  I/O  LINK 	LINK is on. RUN  DIAG  I/O  LINK 	1. I/O module failure at slave. 2. Slave module is missing 24VDC power. 3. Slave base pwer budget overloaded.	1. Check the I/O modules in the slave unit for failures.
RUN  DIAG  I/O  LINK 	Lights blink in sequence, then all lights turn on. RUN  DIAG  I/O  LINK 	1. Module's Diagnostic DIP switch is ON.	1. Check the Diagnostic DIP switch on Master or slave to ensure that it is off.
RUN  DIAG  I/O  LINK 	RUN is on. RUN  DIAG  I/O  LINK 	1. Rotary switches' setting for slave ID exceeds valid address for chosen protocol.	1. Check rotary switches on slave for valid unit number: must be 31 or less for SM-NET, must be 7 or less for RM-NET

## Special CPU Memory for Diagnostics

### Communication Status Flags in V-memory

This table provides a listing of the individual flags in V-memory for communication status. The corresponding bit of V-memory turns ON when the slave is communicating. Station 0 represents the master; its bit turns on when communication begins with its slaves. You may use **DirectSOFT** or the application program to monitor these flags. If there is a communications error, this memory may not show the correct data.

Station	Master in Slot No.:							
	0	1	2	3	4	5	6	7
	N/A	V7661	V7662	V7663	V7664	V7665	V7666	V7667
0	Bit 0							
1	Bit 1							
2	Bit 2							
3	Bit 3							
4	Bit 4							
5	Bit 5							
6	Bit 6							
7	Bit 7							
8	Bit 8							
9	Bit 9							
10	Bit 10							
11	Bit 11							
12	Bit 12							
13	Bit 13							
14	Bit 14							
15	Bit 15							

**Error Flags in V-memory**

This table provides a listing of the individual flags in V-memory for slave errors. The corresponding bit of V-memory turns ON when the slave has an error. Station 0 represents the master; its bit turns on when an error occurs with any slave. You may use **DirectSOFT** or the application program to monitor these flags. If there is a communications error, this memory may not show the correct data.

Station	Master in Slot No.:							
	0	1	2	3	4	5	6	7
	N/A	V7671	V7672	V7673	V7674	V7675	V7676	V7677
0	Bit 0							
1	Bit 1							
2	Bit 2							
3	Bit 3							
4	Bit 4							
5	Bit 5							
6	Bit 6							
7	Bit 7							
8	Bit 8							
9	Bit 9							
10	Bit 10							
11	Bit 11							
12	Bit 12							
13	Bit 13							
14	Bit 14							
15	Bit 15							

## D2-RMSM Memory for Diagnostics

Status and error information about the D2-RMSM Remote Master module and its attached remote I/O network are available in the Remote Master shared memory described earlier in this chapter.

**Hardware Status** Octal address status bytes 122 – 123 available in the D2-RMSM shared memory report the hardware settings. You can implement logic to read these bytes to check your configuration without having to remove the module.

**Bus Scan Status** Octal address status bytes 160–172 available in the D2-RMSM shared memory provide information on bus performance. You can implement logic to read these bytes to check your configuration without having to remove the module.



**Network Errors** Octal address status bytes 140 – 146 available in the D2-RMSM shared memory provide information on network errors and their location. You can implement logic to read these bytes to check your configuration without having to remove the module.

The next section provides specific examples on how to read status data from the Master module.



## How to Access Diagnostics Information

To access diagnostics information, we exchange data with the D2-RMSM module. The remote master unit is an intelligent module, which means it operates asynchronously from the CPU, and it has its own memory. We use the CPU instructions described below to communicate with an intelligent module.

The WT instruction writes a block of data (1–128 bytes max.) to an intelligent I/O module from a block of V-memory in the CPU. The function parameters (module base/slot address, number of bytes, and the intelligent I/O module memory address) are loaded into the first and second level of the accumulator stack, and the accumulator by three additional instructions. In the WT instruction, Aaaa specifies the starting V-memory address where the data will be written from in the CPU. Listed below are the steps to program the WT instruction:




The RD instruction reads a block of data (1–128 bytes max.) from an intelligent I/O module into the CPU's V-memory. The function parameters (module base/slot address, number of bytes, and the intelligent I/O module memory address) are loaded into the first and second level of the accumulator stack, and the accumulator by three additional instructions. In the RD instruction, Aaaa specifies the starting V-memory address where the intelligent module stores the data in the CPU. Listed below are the steps to program the RD instruction:



### Example 1: Reading Diagnostic Errors

The diagnostic error information can assist you in locating errors on a remote I/O network, either during installation or for a previously operating system. During installation, we might expect configuration errors caused by incorrect switch settings or an invalid setup program. For a previously operating system, the diagnostics can help locate such faults as a slave not responding, an I/O module not present, or a loose terminal block.

In this example, we read the network error flags each scan, and if there is a configuration error present, we read the error details.



You can then use the retrieved data in logic or display it in a Dataview in **DirectSOFT** to determine the nature and location of the error. The Network Error Table describes the error codes.


### Example 2: Writing Bus Scan Overlimit and Reading Bus Scan Status

In certain applications, the scan time of the remote I/O bus can be an important factor in the response time of the system. Factors which affect the scan time include number of slaves on the bus and the baud rate. Required bus performance may dictate your system layout. For example, you may want to increase the number of remote channels in the system to decrease the number of slaves on each channel. Or you may need to choose SM-NET as the protocol to operate at a higher baud rate.


Bus scan performance data includes current bus scan time, the longest and shortest scans detected, a scan counter, and a scan overlimit counter. The overlimit counter records the number of times the scan has exceeded the overlimit value. The overlimit value, in msec, can be set by the user's logic; the default is 100 msec.

In this example, we demonstrate how to set the bus scan overlimit parameter, and then read the bus scan data to check performance.


On the first scan, load the desired bus scan overlimit parameter value into V memory



Store the overlimit value to the D2-RMSM shared memory



On every scan, read all bus scan diagnostic information from the master into V-memory



You can then use the retrieved data in logic or display it in a Dataview in **DirectSOFT** (shown on the next page) to monitor bus performance. The Bus Scan Status Table describes the definitions of the status values.

