

ACNACDRIVEUSERMANUALTABLEOFCONTENTS



ACN USER MANUAL TOC

WARNINGS AND TRADEMARKS	W-1
~ WARNING ~	W-1
Trademarks.	W-1
~ AVERTISSEMENT ~	W-2
Marques de commerce	W-2
Warnings	W-3
ACN SERIES DRIVES MANUAL REVISION HISTORY	H-1
ACN AC DRIVE USER MANUAL TABLE OF CONTENTS	TOC-1
CHAPTER 1: GETTING STARTED	1-1
User Manual Overview	1-2
Overview of this Publication	1-2
Who Should Read This Manual.	1-2
Supplemental Publications	1-2
Technical Support	1-2
Special Symbols	1-2
Purpose of AC Drives	1-3
Selecting the Proper Drive Rating	1-3
Determine Motor Full-Load Amperage (FLA)	1-3
Determine Motor Overload Requirements	1-3
Determine Application Type; Constant Torque or Variable Torque	1-3
Parts Locator	1-4
Continuous Rated Current Derating	1-5
Heat Emission	1-7
Watt Loss and Efficiency	1-7
IRONHORSE ACN Series AC Drive Environmental Information.	1-7
Storage and Transportation.	1-7
Environmental Conditions	1-8
IRONHORSE ACN SERIES AC Drive Specifications.	1-9
230V Class – (Model Specifications)	1-9
230V Class – (Model Specifications)	1-10
460V Class – (Model Specifications)	1-11
460V Class – (Model Specifications)	1-12
Specifications Applicable to All ACN Series Models	1-13
Receiving and Inspection	1-15
Drive Package Contents.	1-15
Model Number Explanation	1-16
Nameplate Information.	1-16
CHAPTER 2: INSTALLATION AND WIRING.	2-1
Drive Models by Frame Size	2-3

Installation	2-3
Basic Configuration Diagram	2-3
Installation Considerations	2-4
Minimum Clearances and Air Flow	2-4
Dimensions	2-5
Mounting the Drive	2-6
Removing Front Cover	2-8
Cable Wiring	2-9
Floating Ground System	2-10
Cable Selection	2-11
Ground Cable and Power Cable Specifications	2-11
Control (signal) Cable Specifications	2-12
Ground Connection	2-12
Power Terminal Wiring	2-13
0.5 – 1 HP (3-phase)	2-13
2.0 – 3.0 HP (3-phase)	2-13
5 HP (3-phase)	2-14
7.5 – 30 HP (3-phase)	2-14
Main Circuit Wiring Diagram (all frames)	2-15
Power Terminal Labels and Descriptions	2-15
Terminals for Connecting DC Reactor, External Brake Resistor, and DC Circuit	2-15
Wiring Guidelines	2-16
Motor Operation Precautions	2-16
Single Phase Input Utility Wiring and Operation	2-17
Power (HP), Input Current and Output Current	2-18
Input Frequency and Voltage Tolerance	2-18
Protection	2-18
Control Terminal Wiring	2-19
Control Board Switches	2-19
Connector	2-19
Input Terminal Labels and Descriptions	2-21
Output/Communication Terminal Labels and Descriptions	2-22
Pre-insulated Crimp Terminal Connectors (Bootlace Ferrule)	2-23
PNP/NPN Mode Wiring and Selection	2-24
PNP Mode (Source)	2-24
NPN Mode (Sink)	2-25
Run Command Wiring	2-25
Digital Output Wiring	2-26
Analog Wiring	2-26
AO Wiring	2-28
System Wiring Diagram	2-28
Re-assembling the Cover	2-28
Post-Installation Checklist	2-29
Test Run	2-30
Verifying the Motor Rotation	2-31
CHAPTER 3: KEYPAD OPERATION AND QUICK START	3-1
Learning to Perform Basic Operations	3-2
About the Keypad	3-2
Learning to Use the Keypad	3-5
Actual Application Examples	3-10

Monitoring the Operation	3-17
CHAPTER 4: AC DRIVE PARAMETERS.	4-1
AC Drive Parameters	4-3
Bit Selection	4-3
Parameter Table Format Explanation.	4-3
Operation Parameter Group	4-5
DRIVE Parameter Group (dr, DRV)	4-7
BASIC Parameter group (bA, BAS)	4-12
ADVANCED Parameter group (Ad, ADV).	4-17
CONTROL Parameter Group (Cn, CON)	4-21
INPUT Parameter Group (In, IN)	4-27
OUTPUT Parameter Group (OU, OUT)	4-32
COMMUNICATION Parameter Group (Cm, COM)	4-35
APPLICATION Parameter Group (AP , APP)	4-41
Extension IO Parameter Group (AO , APO)	4-44
PROTECTION Parameter Group (Pr, PRT).	4-47
2nd MOTOR Parameter Group (m2, M2).	4-51
USER SEQUENCE Parameter Group (US, USS).	4-53
USER SEQUENCE FUNCTION Parameter Group (UF , USF)	4-56
Trip Mode (TRP Last-x)	4-61
Config Mode (CNF)	4-62
IronHorse® ACN Drive Operation and Parameter Details	4-65
Chart Key	4-65
Learning Basic Features	4-66
Setting Frequency Reference	4-68
Frequency Hold by Analog Input.	4-76
Changing the Displayed Units (Hz↔Rpm)	4-77
Setting Multi-step Frequency.	4-77
Command Source Configuration.	4-79
Local/Remote Mode Switching.	4-82
Forward or Reverse Run Prevention	4-84
Power-on Run	4-85
Reset and Restart	4-86
Setting Acceleration and Deceleration Times	4-87
Acc/Dec Pattern Configuration	4-91
Stopping the Acc/Dec Operation.	4-92
V/F (Voltage/Frequency) Control.	4-93
Torque Boost	4-96
Output Voltage Setting	4-97
Start Mode Setting	4-97
Stop Mode Setting.	4-98
Frequency Limit	4-101
2nd Operation Mode Setting.	4-103
Multi-function Input Terminal Control.	4-104
P2P Setting.	4-105
Multi-keypad Setting	4-106
User Sequence Setting	4-107
Fire Mode Operation	4-122
Improvement of output voltage drop	4-123
Learning Advanced Features	4-124
Operating with Auxiliary References	4-125

Jog operation	4-128
Up-down Operation.	4-131
3-Wire Operation	4-133
Safe Operation Mode	4-134
Dwell Operation	4-135
Slip Compensation Operation	4-137
PID Control.	4-138
Auto Tuning	4-145
Sensorless Vector Control for Induction Motors	4-147
Sensorless Vector Control for PM (Permanent-Magnet) Synchronous Motors.	4-153
Kinetic Energy Buffering Operation	4-160
Torque Control.	4-162
Energy Saving Operation	4-166
Speed Search Operation	4-167
Auto Restart Settings	4-170
Operational Noise Settings (carrier frequency settings)	4-171
2nd Motor Operation	4-172
Supply Power Transition.	4-173
Cooling Fan Control	4-174
Input Power Frequency and Voltage Settings	4-175
Read, Write, and Save Parameters	4-175
Parameter Initialization (Reset to Defaults)	4-175
Parameter View Lock	4-176
Parameter Lock	4-177
Changed Parameter Display	4-178
User Group.	4-178
Easy Start On.	4-179
Config(CNF) Mode.	4-180
Multi-function IO Timer Settings.	4-181
Brake Control.	4-182
Multi-Function Output On/Off Control	4-183
Press Regeneration Prevention.	4-183
Analog Output.	4-184
Digital Output	4-188
Keypad Language Settings	4-192
Operation State Monitor	4-193
Operation Time Monitor	4-195
Learning Protection Features.	4-196
Motor Protection	4-196
Drive and Sequence Protection.	4-202
Dynamic Braking.	4-205
Under load Fault Trip and Warning.	4-207
Fault/Warning List	4-211
CHAPTER 5: SERIAL COMMUNICATIONS	5-1
Serial RS-485 Communication Features	5-2
Communication Standards	5-2
Common Third-Party Modbus RTU Masters.	5-2
AutomationDirect PLCs as Modbus Master	5-3
RS-232C to RS-485 Conversion.	5-4
Communication Protocol	5-12
Drive Expansion Common Area Parameter	5-16

Drive Parameter Modbus Communication Addresses 5-25

CHAPTER 6: MAINTENANCE AND TROUBLESHOOTING 6-1

Operations Lockout 6-2

Maintenance and Inspections 6-3

 Monthly Inspection 6-3

 Annual Inspection 6-3

 Recharge Capacitors (for drives not in service) 6-3

 Recommended Inspection Schedules 6-4

 Storage and Disposal 6-7

Troubleshooting 6-8

 Trips and Warnings 6-8

 Fault Trips. 6-8

APPENDIX A: ACCESSORIES A-1

Fuses/Circuit Breakers. A-2

High Performance EMI Input Filters A-3

 EMI Filter Installation A-3

 Recommended Motor Cable Length. A-5

Line Reactors / Voltage Time Filters A-6

 Line Reactor A-6

 Load Reactor/Voltage Time Filter. A-6

 DC Reactor A-7

 Line/Load Reactors and Output Filters Selection Charts A-8

 Line Reactor Applications and Wiring Connections. A-8

 Recommended Cable Length. A-11

Dynamic Braking A-12

 Braking Units. A-12

 Choosing and Installing a Braking Resistor A-13

[ACN-232C IronHorse ACN 232 USB to RJ45 Port Cable](#) A-14

[ACN-LCD Remote LCD Keypad](#). A-15

 About the Keypad A-15

 Menu Items A-18

 Navigating Modes. A-19

 Navigating Modes and Parameters A-22

 Navigating through Codes (Function Items) A-25

 Setting Parameters A-28

 Monitoring Operating Status A-30

 Monitoring Faults A-33

 Initializing Parameters. A-36

 Parameter Lock (LCD) A-37

[ACN-3MRC LCD Keypad Mount Kit and Cable](#) A-38

[ACN-LCDKM Remote LCD Keypad NEMA4X Mounting Kit and Cable](#) A-39

 Installation Procedure A-39

Replacement Cooling Fans A-43

VFD Suite. A-44

 Connecting to VFD Suite A-45

 VFD Suite Serial Connection Setup. A-46

 VFD Suite Ethernet Connection Setup A-48

APPENDIX B: OPTIONAL I/O CARD B-1

 Basic Information B-2

 Characteristics B-2

Components	B-2
Specifications	B-3
Input and Output Specification.	B-3
Installation	B-4
Installation of ACN I/O Card	B-4
Control Terminal Wiring.	B-6
Signal (Control) Cable Specifications.	B-8
Parameter Configuration	B-10
Basic Features	B-10
Basic Function	B-10
Setting Frequency Reference	B-10
Analog Output.	B-17
Digital Output	B-19
Setting Multi-step Frequency.	B-23
Multi-step Acc/Dec Time Configuration.	B-25
Stopping the Acc/Dec Operation.	B-26
Multi-function Input Terminal Control.	B-27
APPENDIX C: ETHERNET MODULE ACN-ETH	C-1
Ethernet/Modbus Card Quick Start	C-3
Hardware	C-3
Parameters	C-4
Introduction	C-5
ACN-ETH Module	C-5
Components	C-5
Ethernet Communication Module Features.	C-6
Common Features.	C-6
Layout of Ethernet Communication Module	C-6
Installation	C-7
Terminal Block of Ethernet communication Specifications.	C-9
Network Cable Specification	C-10
Protocol Selection	C-10
LED information	C-11
LED display feature	C-11
Ethernet Line LED (EtherNet/IP and Modbus TCP are same).	C-11
Modbus TCP LED & Troubleshooting	C-11
EtherNet/IP LED & Troubleshooting	C-12
Keypad Parameter of Ethernet Communication	C-13
FBus S/W Ver (CM.06)	C-13
FBus Led (CM.09)	C-13
IP Address, Subnet Mask, Gateway (CM.10~21) Setting	C-14
Ethernet Speed (CM.22).	C-14
CIP Input Instance (CM.29)	C-15
CIP Output Instance(CM.49)	C-16
Number of Output Parameters (CM.30)	C-16
Parameter Status (CM.31~CM.38)	C-17
Number of Input Parameters (CM.50)	C-17
Parameter Control (CM.51~CM.58)	C-17
Comm Update (CM.94)	C-17
Modbus TCP	C-18
Modbus TCP Frame Structure.	C-18

Function Code Description C-18

Read Holding Register. C-18

Read Input Register C-18

Write Single Register C-19

Write Multiple Register C-19

Except Frame. C-20

Exception Frame Structure C-20

Exception Code Type C-20

EtherNet/IP. C-21

 Basic Protocol Configuration C-21

 Implicit Message. C-22

 Explicit Message C-27

 Supported Object C-28

Lost Command C-33

 Drive Keypad Parameter. C-33

APPENDIX D: SAFE TORQUE OFF D-1

 Introduction D-2

 Introduction D-2

 Terminal Configuration D-2

 Safe Torque Off Terminal Function Description D-2

 Operation Conditions Description D-2

 Wiring Diagrams. D-3

 Internal Sto Circuit. D-3

 STO Circuit when using external 24VDC power D-3

 Operating Sequence Description D-4

 Normal Operation Status D-4

 Safe Function Failure Rate D-5

 Safety Requirements Specification. D-5

 Installation Considerations D-5

 Safe Function Performance D-5

