

# DRIVE QUICK START GUIDE



# IRONHORSE®

## ACM AC DRIVE

This quick start reference is included in the VFD packaging and is meant to be a supplement to the User Manual, which is available for free download at [Automationdirect.com](http://Automationdirect.com). This reference informs the installer of the proper steps for mounting, wiring, and basic programming/operation of the ACM VFD up to 2.2kW/3.0HP.



**WARNING: IMPROPER WIRING AND OPERATION MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH**

Follow the recommended wiring practices suggested in this document as well as in the User Manual. The minimum size of the protective earth (ground) conductor must comply with local safety regulations and applicable codes.

Please review all ACM related documents included with the product before proceeding with any installation and wiring.

### STEP 1 – ACM MODEL NUMBER AND MOUNTING

#### MODEL NUMBER


Verify that you have the appropriate VFD by checking the nameplate information. Use the example name plate shown to assist you with this. The model number and specifications will depend on the drive.

**NOTE:** Verify that the input voltage rating matches the voltage source applied to the VFD.

**NOTE:** Confirm that the output power of the VFD is equal to or greater than the rating of the motor which will be connected. Ratings for single-phase input power can be found in the manual.

<b>MODEL : ACM-10P2</b>			IE2 (1.4%)
INPUT	100-120V 1 Phase	50/60Hz	UL US LISTED IND.CONT.EQ 8724
	HD: 1.8A		
OUTPUT	0-Input V 3 Phase	0.01-400Hz	EAC CE
	HD: 1.4A 1.9kVA (D) IP 20		
QR Code	Ser. No 550E1042ABC Inspected by S.G. SHIN 60400001AD		MADE IN KOREA
IRONHORSE Automationdirect.com			

#### DIMENSIONS



**NOTE:** Drive diagram (Frame A) is a reference for dimensions chart below. See manual for specific Drive Frame diagrams as they differ slightly


		Dimensions									
Frame	Part no	W1	W2	H1	H2	H3	H4	D1	A	B	Ø
A	ACM-20P1	85	75	135	135.5	145	5	100	5	4.5	4.5
	ACM-20P2	[3.35]	[2.95]	[5.31]	[5.33]	[5.71]	[0.20]	[3.94]	[0.20]	[0.18]	[0.18]
B	ACM-10P2	85	75	153	153.5	163	5	123	5	4.5	4.5
	ACM-10P5										
	ACM-20P5										
	ACM-21P0										
C	ACM-11P0	100	90	180	180.5	190	5	140	5	4.5	4.5
	ACM-22P0										
	ACM-23P0										

Units: mm [in]

#### MOUNTING


When selecting an installation location consider the following points:

- The drive must be installed on a wall or panel that can support the drive's weight.
- The location must be free from vibration. Vibration can adversely affect the operation of the drive.
- The drive can become very hot during operation. Install the drive on a surface that is fire-resistant or flame-retardant and with sufficient clearance around the drive to allow air to circulate. The illustrations below detail the required minimum installation clearances.



#### COVER REMOVAL

After mounting, slide the front cover downward while pressing and holding the upper-center part of the cover. Remove the cover by lifting it upward from the bottom and moving it away from the drive.



## STEP 2 – CONNECT LINE AND MOTOR POWER


Use the wiring diagrams below to properly wire the main power connections to the VFD. This step should be done with power OFF! Refer to the User Manual for additional wiring recommendations. Be sure to follow good wiring and grounding practices. Follow applicable local codes if needed.



**DANGER: LETHAL VOLTAGES ARE PRESENT. BE SURE THAT ALL POWER IS TURNED OFF WHILE PERFORMING THE RECOMMENDED POWER WIRING. REINSTALL ALL PROTECTIVE COVERS ON THE ACM BEFORE REAPPLYING POWER**

Proper wiring for 1-Phase applications is shown below. The physical terminal layout varies according to frame size. Terminal names (e.g. R, T, etc) will remain consistent.

### SINGLE PHASE INPUT



**NOTE: B1 and B2 terminals (Frame C only) should not be connected to power or ground.**

Part Number	Power Terminal Screw Size	Screw Torque (Nm)	Recommended Wire size AWG [mm <sup>2</sup> ]	
			Power R,S,T	Ground
ACM-10P2	M3	0.5	14 [2.5]	12 [4]
ACM-10P5	M3	0.5	14 [2.5]	12 [4]
ACM-11P0	M4	0.8	12 [4]	12 [4]
ACM-20P1	M3	0.5	14 [2.5]	12 [4]
ACM-20P2	M3	0.5	14 [2.5]	12 [4]
ACM-20P5	M3	0.5	14 [2.5]	12 [4]
ACM-21P0	M3	0.5	14 [2.5]	12 [4]
ACM-22P0	M4	0.8	12 [4]	12 [4]
ACM-23P0	M4	0.8	12 [4]	12 [4]

Use copper wires with 600 V, 75°C [167°F] for power terminal wiring.

## STEP 3 – KEYPAD NAVIGATION AND PARAMETER CHANGES

### OPERATION GROUP

From the main screen (0.00), the UP and DOWN arrows will navigate through the Operation group. The Operation group contains many basic start up parameters for control and monitoring. See the list of Operation group parameters below.


Display	Operation Group	Display	Operation Group
0.00	Command Frequency	IOv	Output voltage setting
ACC	Acceleration time	Ftb	Forward boost
dEC	Deceleration time	rtb	Reverse boost
drv	Command source	CUr	Output current
Frq	Frequency source reference	rPM	Motor RPM
MkW	Motor selection	dCL	Drive DC voltage
MrC	Rated motor current	uOL	User select signal
MbF	Base frequency	nOn	Current fault
FrM	Maximum frequency	OGr	Open hidden groups

### PARAMETER GROUPS

Pressing the MODE/SHIFT button will move through the different parameter groups, while the UP and DOWN arrows will navigate through the different parameter code numbers in the selected group. To display and access all groups, set OGr in Operation group to "1".


Display	Parameter Group
dr	Drive
bA	Basic
Ad	Expanded
Cn	Control
In	Input Terminal Block
OU	Output Terminal Block
CM	Communication
AP	Application
Pr	Protection
M2	2nd Motor (In.65-69-> any one of these parameters is set to 26)
CF	Configuration

Move up and down through the codes using the UP and DOWN arrow keys.




Any of the above parameter and monitor settings can be accessed by pressing the ENT key. Press the MODE key to move to the group you want. Press the ENT key again to save the entered value.

Press MODE with either arrow key to escape and make no change.



"rd" indicates reserved and cannot be selected.



### CHANGING ACCELERATION TIME EXAMPLE

- 1) Press UP arrow from the main display (0.00) until ACC is displayed.
- 2) Press ENT key one time to display the present value.
- 3) Use the UP and DOWN arrows to increase and decrease the value.
- 4) Use the MODE/SHIFT key to move the cursor over to select different digits.
- 5) Press the ENT key TWO TIMES once the desired value is set. This saves the change.
- 6) ACC will be displayed again indicating the parameter change has taken effect.



**NOTE: Press the ENT key TWO times to save parameter changes! Press UP and DOWN arrows at the same time to escape parameter setting and make no changes.**



**NOTE: "rd" and "OL" can not be selected. "rd" indicates reserved, "OL" indicates set value repetition.**


**STEP 4 – CONNECT CONTROL WIRING**

**CONTROL WIRE SIZE**

Terminal	Terminal Screw Size	Screw Torque (Nm)	Wire Size AWG [mm <sup>2</sup> ] Bare Wire	Wire Size AWG [mm <sup>2</sup> ] with Bootlace Ferrule
24, P1-P5, CM, VR, V1, I2, A0, Q1, EG	M2.6	4.0	18 [0.75]	20 [0.5]
A1/B1/C1/A2/C2	M2.6	4.0	17 [1.0]	15 [1.5]

\*See User Manual for crimp terminal cable size and detail

**3-Wire Control**




3-Wire control consists of momentary push buttons to run and stop the VFD. The Forward and Reverse buttons are Normally Open while the Stop button is Normally Closed.

drv=1 (FX/RX-1)  
 P1(In.65)=0 (FWD Run, Fx)  
 P2(In.66)=1 (REV Run, Rx)  
 P5(In.69)=17 (3-Wire Stop)  
 CM=Common

**FREQUENCY REFERENCE WIRING**


**Speed Pot Wiring (0-10 VDC)**



Controlling the VFD with an external speed potentiometer can be accomplished by setting Operation Menu parameter frq=3 and wiring according to the example below. For 0-10VDC signals from a PLC or controller, simply wire to V1 and CM.

VR = 10 VDC  
 V1 = Wiper  
 CM = Common

**PLC or Controller Wiring (4-20 mA)**




For speed control with a 4-20 mA signal, set Operation Menu parameter frq=4.

I2 = + Signal  
 CM = - Common

**RUN COMMAND WIRING**

**2-Wire Control**




2-wire control consists of maintained run signals. This can be accomplished via toggle switches, relays, jumpers, etc. Default parameters support this operation.

**Forward-Run/Reverse-Run**  
 drv=2 (FX/RX-2)  
 P1(In.65)=0 Fx (1=Run, 0=Stop)  
 P2 (In.66)=1 Rx (1=Reverse, 0=Forward)  
 CM=Common

**Run/Direction**  
 drv=2 (FX/RX-2)  
 P1(In.65)=0 Fx (1=Run,0=Stop)  
 P2(In.66)=1 Rx (1=Reverse, 0=Forward)

**I/O WIRING**



**Digital Input Description**

Terminal Labels	Description
P1-P5	Multi-Function Inputs with Default value and NPN sink mode wiring. Parameters In.65-In.69.
CM	Common terminal

**Analog Input Description**

Terminal Labels	Description
VR	Power Terminal for Setting Frequency 12V/100mA
V1	Frequency Setting (Voltage): 0-10 V Parameters In.7-11
I2	Frequency Setting (Current): 4-20 mA Voltage: 0-10 V (12 V max) Parameters In.52-In.56

**Output Description**

Terminal Labels	Description
AO	Analog Output: 0-10 V Use CM for Common. Parameter OU.1 Default: 0 (Frequency)
P24	External 24 V Power
A1/C1/B1	Relay 1: Multi-Function Output Parameter OU.31 Default: 17 (Fault output setting)
A2/C2	Relay 2: Multi-Function Output Parameter OU.32 Default: 12 (RUN)

**STEP 5 – BASIC SETUP PARAMETERS**

**REQUIRED MOTOR PARAMETERS**

Set these motor parameters based on the nameplate.

Group	No	Description	Default	Set Options
OPG	MkW	Motor capacity	Model dependent	Model dependent
bA	11	Poles	4	2-12
OPG	MrC	Motor rated current	Model dependent	Model dependent
OPG	IOv	Motor voltage	Model dependent	Model dependent

**dr.14: HP to kW Conversion Chart (Parameter in kW)**

HP	kW
1/4	0.2
1/2	0.4
1	0.75
1.5	1.1
2	1.5
3	2.2
5	3.7
7	5.5
10	7.5
15	11
20	15
25	18.5
30	22
40	30

**Motor RPM to Poles Chart**

RPM	3600	1800	1200
Poles	2	4	6

EXAMPLE: If actual motor RPM is 3450, set Motor Poles = 2. This is due to motor slip. In this example, the motor has 150 RPM of slip. (Slip=Synchronous speed - Rated Speed)

**OPTIONAL PARAMETERS**

- To automatically start after a power loss, set Ad.10=1. To enable power-on run, set the Operation Group drv parameter to Fx/Rx-1 or Fx/Rx-2. Run signal must stay present on power up.
- Enable phase loss protection by setting Pr.5=1.
- Enable auto restart after a fault trip by setting the following...
  - » Pr.8 = 1
  - » Pr.9 = # of retry attempts

**STEP 5 – BASIC SETUP PARAMETERS (CONT'D)**

**FAULT CODES**

Keypad Display	Fault Name	Description
<b>olt</b>	Overload	Motor overload trip. Operates when Pr.20 > 0
<b>oct</b>	Over Current	Drive output current exceeds 200% of rated current
<b>ovt</b>	Over Voltage	Internal DC voltage exceeds the specified value
<b>lvt</b>	Low Voltage	Internal DC circuit voltage less than the limit
<b>gft</b>	Ground Trip	Ground Fault trip occurs on drive output side and causes the current to exceed limit
<b>eth</b>	E-Thermal	Thermal load calculation determines motor overheating. Operates when Pr.40 >0
<b>opo</b>	Out Phase Open	Drive output phase(s) in open circuit condition. Operates when Pr.05 Bit 1=1
<b>iol</b>	Drive OLT	Overload and resultant overheating based on thermal limits
<b>rot</b>	rOt*	Displayed when input power is unstable or an initial charging circuit trip occurs while supplying power to the drive.
<b>oht</b>	Over Heat	Drive heat sink temperature exceeds limit
<b>ntc</b>	NTC Open	Insulated Gate Bipolar Transistor (IGBT) Temperature sensor error
<b>fan</b>	Fan Trip	Cooling Fan malfunction.
<b>eta, etb</b>	External Trip A,B	External fault input signal is ON. Operates when In.65-69=4
<b>com</b>	Communication Trip	Displayed when communication between drive and IO CPU is disconnected for more than 500 ms.
<b>nbr</b>	nbr	Drive's output current is below value in Ad.41 during the external brake signal operation when OU.31 or OU.32 = 19.
<b>hold, errc</b>	IO Board Trip	Hold: Displayed when power is supplied to the drive and communication is disconnected. ErrC: Displayed when communication is disconnected for more than 2 seconds.

\*ACM drives rated for 2.2 kW or less are the only models that support "rOt" fault. There is a possibility of a "rOt" fault when power is turned on within 1 second of an lvt fault due to power off.

See User Manual for other fault codes.

**COMMONLY SET PARAMETERS**

Pr.Code	Parameter Name	Setting Range	Units	Initial Value
<b>Op Menu: 0.00</b>	Command Frequency	Start Freq(dr.19) - Max Freq(dr.20)	Hz	0
<b>Op Menu: ACC</b>	Acceleration Time	0.0 - 6000.0	sec	5.0
<b>Op Menu: dEC</b>	Deceleration Time	0.0 - 6000.0	sec	10.0
<b>Op Menu: drV</b>	Command Source	0: Keypad 1: Fx/Rx -1 (Fwd/Rev Run) 2: Fx/Rx -2 (Run/Dir) 3: RS-485	-	1
<b>Op Menu: Frq</b>	Frequency Source Reference	0: Keypad-1 1: Keypad-2 2: V0: Built-in potentiometer 3: V1 (0-10 V) 4: I2 (0-20 mA) 5: I2 (0-10 V) 6: V0+I2 (0-20 mA) 7: V0+I2 (0-10 V) 8: V0+V1 9: RS-485 10: Up-Down 11: V1+I2 (0-10 V)	-	0
<b>dr.9</b>	Control Mode	0: V/F 1: Slip Compensation 2: IM Sensorless	-	1
<b>dr.11</b>	JOG Frequency	0.00, Start frequency-Maximum frequency	Hz	10.00
<b>dr.19</b>	Start Frequency	0.01 - 10.00	Hz	0.50
<b>dr.20</b>	Rotation direction	F: Forward run R: Reverse run	-	F
<b>Op Menu: MbF</b>	Base frequency	30.00-400.00 Hz	Hz	60.0
<b>Op Menu: FrM</b>	Maximum frequency	40.00-400.00 Hz	Hz	60.0
<b>cf.93</b>	Parameter Initialize (Reset to Defaults)	0: No 1: All groups 2: Operation group 3: dR group 4: bA group 5: Ad group 6: Cn group 7: In group 8: OU group 9: CM group 10: AP group 11: Pr group 12: M2 group 13: Run group	-	0
<b>ba.19</b>	AC Input Volt	170 - 480	V	220
<b>Ad.9</b>	Rotation direction prevention	0: None 1: Forward Prevent 2: Reverse Prevent	-	0
<b>Ad.10</b>	Power-on Run	0: No 1: Yes	-	0
<b>In.65</b>	P1 Define	See Multifunction Discrete Input Selection Chart	-	0: Fx
<b>In.66</b>	P2 Define		-	1: Rx
<b>In.67</b>	P3 Define		-	2: Bx
<b>In.68</b>	P4 Define		-	3: Rst
<b>In.69</b>	P5 Define		-	4: JOG
<b>OU.1</b>	Analog output setting	See Analog Output (AO) Selection Chart	-	0: Freq
<b>OU.31</b>	Relay 1 (A1/B1/C1)	See Multifunction Relay Output Selection Chart	-	17: Trip
<b>OU.32</b>	Relay 2 (A2/C2)		-	12: Run

**MULTIFUNCTION INPUT/OUTPUT SELECTION CHARTS**

Multi-Function P1-P5 Discrete Input Selections	Multi-Function R1/R2 Relay Output Selections	Multi-Function AO Selections
0: Fx	0: FDT-1	0: Frequency
1: Rx	1: FDT-2	1: Output Current
2: Emergency Stop Trip	2: FDT-3	2: Output Voltage
3: Reset (RST)	3: FDT-4	3: DCLink Voltage
4: JOG	4: FDT-5	
5: Spd-L	5: Over Load	
6: Spd-M	6: IOL	
7: Spd-H	7: Motor Stall	
8: Xcel-L	8: Over voltage (Ovt)	
9: Xcel-M	9: Low voltage (Lvt)	
10: Xcel-L	10: Over Heat (OHT)	
11: DC Braking	11: Lost Command	
12: 2nd Motor	12: Run	
13: Reserved	13: Stop	
14: Reserved	14: Steady	
15: Up-down Freq Up	15: Speed Search	
16: Up-down Freq Dwn	16: Ready	
17: 3-wire	17: Fault Output	
18: EtA	18: Fan Alarm	
19: EtB	19: Brake Signal Setting	
20: Reserved		
21: PID to general op		
22: 2nd Source		
23: Fix Analog Command Frequency		
24: ACC/DEC Stop		
25: Init Up-down Freq		
26: FWD JOG		
27: REV JOG		