

ACNACDRIVEUSERMANUALTABLEOFCONTENTS



ACN USER MANUAL TOC

| | |
|--------------------------------------------------------------------------|-------|
| WARNINGS AND TRADEMARKS | W-1 |
| ~ WARNING ~ | W-1 |
| Trademarks. | W-1 |
| ~ AVERTISSEMENT ~ | W-2 |
| Marques de commerce | W-2 |
| Warnings. | W-3 |
| ACN SERIES DRIVES MANUAL REVISION HISTORY | H-1 |
| ACN AC DRIVE USER MANUAL TABLE OF CONTENTS | TOC-1 |
| CHAPTER 1: GETTING STARTED | 1-1 |
| User Manual Overview | 1-2 |
| Overview of this Publication | 1-2 |
| Who Should Read This Manual. | 1-2 |
| Supplemental Publications | 1-2 |
| Technical Support | 1-2 |
| Special Symbols | 1-2 |
| Purpose of AC Drives | 1-3 |
| Selecting the Proper Drive Rating | 1-3 |
| Determine Motor Full-Load Amperage (FLA) | 1-3 |
| Determine Motor Overload Requirements | 1-3 |
| Determine Application Type; Constant Torque or Variable Torque | 1-3 |
| Parts Locator. | 1-4 |
| Continuous Rated Current Derating | 1-5 |
| Heat Emission | 1-7 |
| Watt Loss and Efficiency | 1-7 |
| IRONHORSE ACN Series AC Drive Environmental Information. | 1-7 |
| Storage and Transportation. | 1-7 |
| Environmental Conditions | 1-8 |
| IRONHORSE ACN SERIES AC Drive Specifications. | 1-9 |
| 230V Class – (Model Specifications) | 1-9 |
| 230V Class – (Model Specifications) | 1-10 |
| 460V Class – (Model Specifications) | 1-11 |
| 460V Class – (Model Specifications) | 1-12 |
| Specifications Applicable to All ACN Series Models | 1-13 |
| Receiving and Inspection | 1-15 |
| Drive Package Contents. | 1-15 |
| Model Number Explanation | 1-16 |
| Nameplate Information. | 1-16 |
| CHAPTER 2: INSTALLATION AND WIRING. | 2-1 |
| Drive Models by Frame Size | 2-3 |

| | |
|----------------------------------------------------------------------------------------|------|
| Installation | 2-3 |
| Basic Configuration Diagram | 2-3 |
| Installation Considerations | 2-4 |
| Minimum Clearances and Air Flow | 2-4 |
| Dimensions | 2-5 |
| Mounting the Drive | 2-6 |
| Removing Front Cover | 2-8 |
| Cable Wiring | 2-9 |
| Floating Ground System | 2-10 |
| Cable Selection | 2-11 |
| Ground Cable and Power Cable Specifications | 2-11 |
| Control (signal) Cable Specifications | 2-12 |
| Ground Connection | 2-12 |
| Power Terminal Wiring | 2-13 |
| 0.5 – 1 HP (3-phase) | 2-13 |
| 2.0 – 3.0 HP (3-phase) | 2-13 |
| 5 HP (3-phase) | 2-14 |
| 7.5 – 30 HP (3-phase) | 2-14 |
| Main Circuit Wiring Diagram (all frames) | 2-15 |
| Power Terminal Labels and Descriptions | 2-15 |
| Terminals for Connecting DC Reactor, External Brake Resistor, and DC Circuit | 2-15 |
| Wiring Guidelines | 2-16 |
| Motor Operation Precautions | 2-16 |
| Single Phase Input Utility Wiring and Operation | 2-17 |
| Power (HP), Input Current and Output Current | 2-18 |
| Input Frequency and Voltage Tolerance | 2-18 |
| Protection | 2-18 |
| Control Terminal Wiring | 2-19 |
| Control Board Switches | 2-19 |
| Connector | 2-19 |
| Input Terminal Labels and Descriptions | 2-21 |
| Output/Communication Terminal Labels and Descriptions | 2-22 |
| Pre-insulated Crimp Terminal Connectors (Bootlace Ferrule) | 2-23 |
| PNP/NPN Mode Wiring and Selection | 2-24 |
| PNP Mode (Source) | 2-24 |
| NPN Mode (Sink) | 2-25 |
| Run Command Wiring | 2-25 |
| Digital Output Wiring | 2-26 |
| Analog Wiring | 2-26 |
| AO Wiring | 2-28 |
| System Wiring Diagram | 2-28 |
| Re-assembling the Cover | 2-28 |
| Post-Installation Checklist | 2-29 |
| Test Run | 2-30 |
| Verifying the Motor Rotation | 2-31 |
| CHAPTER 3: KEYPAD OPERATION AND QUICK START | 3-1 |
| Learning to Perform Basic Operations | 3-2 |
| About the Keypad | 3-2 |
| Learning to Use the Keypad | 3-5 |
| Actual Application Examples | 3-10 |

| | |
|----------------------------------------------------------------|-------|
| Monitoring the Operation | 3-17 |
| CHAPTER 4: AC DRIVE PARAMETERS. | 4-1 |
| AC Drive Parameters | 4-3 |
| Bit Selection | 4-3 |
| Parameter Table Format Explanation. | 4-3 |
| Operation Parameter Group | 4-5 |
| DRIVE Parameter Group (dr, DRV) | 4-7 |
| BASIC Parameter group (bA, BAS) | 4-12 |
| ADVANCED Parameter group (Ad, ADV). | 4-17 |
| CONTROL Parameter Group (Cn, CON) | 4-21 |
| INPUT Parameter Group (In, IN) | 4-27 |
| OUTPUT Parameter Group (OU, OUT) | 4-32 |
| COMMUNICATION Parameter Group (Cm, COM) | 4-35 |
| APPLICATION Parameter Group (AP , APP) | 4-41 |
| Extension IO Parameter Group (AO , APO) | 4-44 |
| PROTECTION Parameter Group (Pr, PRT). | 4-47 |
| 2nd MOTOR Parameter Group (m2, M2). | 4-51 |
| USER SEQUENCE Parameter Group (US, USS). | 4-53 |
| USER SEQUENCE FUNCTION Parameter Group (UF , USF) | 4-56 |
| Trip Mode (TRP Last-x) | 4-61 |
| Config Mode (CNF) | 4-62 |
| IronHorse® ACN Drive Operation and Parameter Details | 4-65 |
| Chart Key. | 4-65 |
| Learning Basic Features. | 4-66 |
| Setting Frequency Reference | 4-68 |
| Frequency Hold by Analog Input. | 4-76 |
| Changing the Displayed Units (Hz↔Rpm). | 4-77 |
| Setting Multi-step Frequency. | 4-77 |
| Command Source Configuration. | 4-79 |
| Local/Remote Mode Switching. | 4-82 |
| Forward or Reverse Run Prevention | 4-84 |
| Power-on Run | 4-85 |
| Reset and Restart | 4-86 |
| Setting Acceleration and Deceleration Times | 4-87 |
| Acc/Dec Pattern Configuration | 4-91 |
| Stopping the Acc/Dec Operation. | 4-92 |
| V/F (Voltage/Frequency) Control. | 4-93 |
| Torque Boost | 4-96 |
| Output Voltage Setting | 4-97 |
| Start Mode Setting | 4-97 |
| Stop Mode Setting. | 4-98 |
| Frequency Limit | 4-101 |
| 2nd Operation Mode Setting. | 4-103 |
| Multi-function Input Terminal Control. | 4-104 |
| P2P Setting. | 4-105 |
| Multi-keypad Setting | 4-106 |
| User Sequence Setting | 4-107 |
| Fire Mode Operation | 4-122 |
| Improvement of output voltage drop | 4-123 |
| Learning Advanced Features | 4-124 |
| Operating with Auxiliary References | 4-125 |

| | |
|---------------------------------------------------------------------------------|------------|
| Jog operation | 4-128 |
| Up-down Operation. | 4-131 |
| 3-Wire Operation | 4-133 |
| Safe Operation Mode | 4-134 |
| Dwell Operation | 4-135 |
| Slip Compensation Operation | 4-137 |
| PID Control. | 4-138 |
| Auto Tuning | 4-145 |
| Sensorless Vector Control for Induction Motors | 4-147 |
| Sensorless Vector Control for PM (Permanent-Magnet) Synchronous Motors. | 4-153 |
| Kinetic Energy Buffering Operation | 4-160 |
| Torque Control. | 4-162 |
| Energy Saving Operation | 4-166 |
| Speed Search Operation | 4-167 |
| Auto Restart Settings | 4-170 |
| Operational Noise Settings (carrier frequency settings) | 4-171 |
| 2nd Motor Operation | 4-172 |
| Supply Power Transition. | 4-173 |
| Cooling Fan Control. | 4-174 |
| Input Power Frequency and Voltage Settings | 4-175 |
| Read, Write, and Save Parameters | 4-175 |
| Parameter Initialization (Reset to Defaults) | 4-175 |
| Parameter View Lock | 4-176 |
| Parameter Lock | 4-177 |
| Changed Parameter Display | 4-178 |
| User Group. | 4-178 |
| Easy Start On. | 4-179 |
| Config(CNF) Mode. | 4-180 |
| Multi-function IO Timer Settings. | 4-181 |
| Brake Control. | 4-182 |
| Multi-Function Output On/Off Control | 4-183 |
| Press Regeneration Prevention. | 4-183 |
| Analog Output. | 4-184 |
| Digital Output | 4-188 |
| Keypad Language Settings | 4-192 |
| Operation State Monitor | 4-193 |
| Operation Time Monitor | 4-195 |
| Learning Protection Features. | 4-196 |
| Motor Protection | 4-196 |
| Drive and Sequence Protection. | 4-202 |
| Dynamic Braking. | 4-205 |
| Under load Fault Trip and Warning. | 4-207 |
| Fault/Warning List | 4-211 |
| CHAPTER 5: SERIAL COMMUNICATIONS | 5-1 |
| Serial RS-485 Communication Features | 5-2 |
| Communication Standards | 5-2 |
| Common Third-Party Modbus RTU Masters. | 5-2 |
| AutomationDirect PLCs as Modbus Master | 5-3 |
| RS-232C to RS-485 Conversion. | 5-4 |
| Communication Protocol | 5-12 |
| Drive Expansion Common Area Parameter | 5-16 |
| IHACN Series AC Drive User Manual – 2nd Ed., Rev A – 10/21/2024 | Page TOC-4 |

| | |
|----------------------------------------------------------------------------|------------|
| Drive Parameter Modbus Communication Addresses | 5-25 |
| CHAPTER 6: MAINTENANCE AND TROUBLESHOOTING | 6-1 |
| Operations Lockout | 6-2 |
| Maintenance and Inspections | 6-3 |
| Monthly Inspection | 6-3 |
| Annual Inspection | 6-3 |
| Recharge Capacitors (for drives not in service) | 6-3 |
| Recommended Inspection Schedules | 6-4 |
| Storage and Disposal | 6-7 |
| Troubleshooting | 6-8 |
| Trips and Warnings | 6-8 |
| Fault Trips. | 6-8 |
| APPENDIX A: ACCESSORIES | A-1 |
| Fuses/Circuit Breakers. | A-2 |
| High Performance EMI Input Filters | A-3 |
| EMI Filter Installation | A-3 |
| Recommended Motor Cable Length. | A-5 |
| Line Reactors / Voltage Time Filters | A-6 |
| Line Reactor | A-6 |
| Load Reactor/Voltage Time Filter. | A-6 |
| DC Reactor | A-7 |
| Line/Load Reactors and Output Filters Selection Charts | A-8 |
| Line Reactor Applications and Wiring Connections. | A-8 |
| Recommended Cable Length. | A-11 |
| Dynamic Braking | A-12 |
| Braking Units. | A-12 |
| Choosing and Installing a Braking Resistor | A-13 |
| <u>ACN-232C IronHorse ACN 232 USB to RJ45 Port Cable</u> | A-14 |
| <u>ACN-LCD Remote LCD Keypad</u> | A-15 |
| About the Keypad | A-15 |
| Menu Items | A-18 |
| Navigating Modes. | A-19 |
| Navigating Modes and Parameters | A-22 |
| Navigating through Codes (Function Items) | A-25 |
| Setting Parameters | A-28 |
| Monitoring Operating Status. | A-30 |
| Monitoring Faults | A-33 |
| Initializing Parameters. | A-36 |
| Parameter Lock (LCD) | A-37 |
| <u>ACN-3MRC LCD Keypad Mount Kit and Cable</u> | A-38 |
| <u>ACN-LCDKM Remote LCD Keypad NEMA4X Mounting Kit and Cable</u> | A-39 |
| Installation Procedure | A-39 |
| Replacement Cooling Fans | A-43 |
| VFD Suite. | A-44 |
| Connecting to VFD Suite | A-45 |
| VFD Suite Serial Connection Setup. | A-46 |
| VFD Suite Ethernet Connection Setup | A-48 |
| APPENDIX B: OPTIONAL I/O CARD | B-1 |
| Basic Information | B-2 |
| Characteristics | B-2 |

| | |
|------------------------------------------------------------------|------------|
| Components | B-2 |
| Specifications | B-3 |
| Input and Output Specification. | B-3 |
| Installation | B-4 |
| Installation of ACN I/O Card | B-4 |
| Control Terminal Wiring. | B-6 |
| Signal (Control) Cable Specifications. | B-8 |
| Parameter Configuration | B-10 |
| Basic Features | B-10 |
| Basic Function | B-10 |
| Setting Frequency Reference | B-10 |
| Analog Output. | B-17 |
| Digital Output | B-19 |
| Setting Multi-step Frequency. | B-23 |
| Multi-step Acc/Dec Time Configuration. | B-25 |
| Stopping the Acc/Dec Operation. | B-26 |
| Multi-function Input Terminal Control. | B-27 |
| APPENDIX C: ETHERNET MODULE ACN-ETH | C-1 |
| Ethernet/Modbus Card Quick Start | C-3 |
| Hardware | C-3 |
| Parameters | C-4 |
| Introduction | C-5 |
| ACN-ETH Module | C-5 |
| Components | C-5 |
| Ethernet Communication Module Features. | C-6 |
| Common Features. | C-6 |
| Layout of Ethernet Communication Module | C-6 |
| Installation | C-7 |
| Terminal Block of Ethernet communication Specifications. | C-9 |
| Network Cable Specification | C-10 |
| Protocol Selection | C-10 |
| LED information | C-11 |
| LED display feature | C-11 |
| Ethernet Line LED (EtherNet/IP and Modbus TCP are same). | C-11 |
| Modbus TCP LED & Troubleshooting | C-11 |
| EtherNet/IP LED & Troubleshooting | C-12 |
| Keypad Parameter of Ethernet Communication | C-13 |
| FBus S/W Ver (CM.06) | C-13 |
| FBus Led (CM.09) | C-13 |
| IP Address, Subnet Mask, Gateway (CM.10~21) Setting | C-14 |
| Ethernet Speed (CM.22). | C-14 |
| CIP Input Instance (CM.29) | C-15 |
| CIP Output Instance(CM.49) | C-16 |
| Number of Output Parameters (CM.30) | C-16 |
| Parameter Status (CM.31~CM.38) | C-17 |
| Number of Input Parameters (CM.50) | C-17 |
| Parameter Control (CM.51~CM.58) | C-17 |
| Comm Update (CM.94) | C-17 |
| Modbus TCP | C-18 |
| Modbus TCP Frame Structure. | C-18 |

| | |
|---------------------------------------------------------|------------|
| Function Code Description | C-18 |
| Read Holding Register. | C-18 |
| Read Input Register | C-18 |
| Write Single Register | C-19 |
| Write Multiple Register | C-19 |
| Except Frame. | C-20 |
| Exception Frame Structure | C-20 |
| Exception Code Type | C-20 |
| EtherNet/IP. | C-21 |
| Basic Protocol Configuration | C-21 |
| Implicit Message. | C-22 |
| Explicit Message | C-27 |
| Supported Object | C-28 |
| Lost Command | C-33 |
| Drive Keypad Parameter. | C-33 |
| APPENDIX D: SAFE TORQUE OFF | D-1 |
| Introduction | D-2 |
| Introduction | D-2 |
| Terminal Configuration | D-2 |
| Safe Torque Off Terminal Function Description | D-2 |
| Operation Conditions Description | D-2 |
| Wiring Diagrams. | D-3 |
| Internal Sto Circuit. | D-3 |
| STO Circuit when using external 24VDC power | D-3 |
| Operating Sequence Description | D-4 |
| Normal Operation Status | D-4 |
| Safe Function Failure Rate | D-5 |
| Safety Requirements Specification. | D-5 |
| Installation Considerations | D-5 |
| Safe Function Performance | D-5 |

