



USER MANUAL TABLE OF CONTENTS

Chapter 1: Getting Started	1-1
Introduction.....	1-2
Supplemental Manuals.....	1-2
Technical Support	1-2
Conventions Used	1-3
Product Overview	1-4
Quick Start Steps	1-5
C-more LED Status Indicators.....	1-11
Chapter 2: Specifications	2-1
Specifications	2-2
Communication Ports and Memory Expansion	2-5
Communication Ports	2-6
User Defined LED.....	2-8
Compatible Touch Screen Monitors.....	2-9
Handling External Memory Devices	2-11
Writing to External Memory devices	2-11
Minimizing Data Errors	2-12
Monitoring Available Memory.....	2-13
Power Loss Retention.....	2-13
Watchdog Timeout.....	2-14
Chapter 3: Accessories	3-1
Accessories Overview	3-2
D-SUB 15-pin to Terminal Block Adapter	3-3
SD Card	3-4
USB FLASH Drive	3-4
Chapter 4: Installation and Wiring	4-1
Safety Guidelines	4-2
Introduction.....	4-3
Mounting	4-4
Wiring Guidelines	4-6
Agency Approvals.....	4-6
Providing Power to the HMI	4-7
C-more LED Status Indicators.....	4-8

Chapter 5: System Setup Screens5-1

- Introduction.....5-4**
 - Information5-4
 - Settings.....5-4
 - Test Menu5-4
 - Memory.....5-4
- Accessing the System Setup Screens (no project loaded).....5-5**
- Accessing the System Setup Screens (with project loaded).....5-6**
 - Using RHMI USB Remote5-7
 - System Setup Screens5-9
 - Password Protecting System Screen Access.....5-9
- System Setup Screens – Enable Password in Software5-10**
- System Setup Screens Flowchart5-16**
- Main Menu5-17**
- Information Screen5-18**
 - Information – Ethernet Tab5-20
- Settings Screen5-23**
 - Settings – Options5-30
- Test Menu5-31**
 - Test Menu – Test Touch Panel.....5-32
 - Test Menu – Test Beep/Audio5-33
 - Test Menu – Test Serial Port5-34
 - Test Menu – PLC Serial Comm Port - Loop back test.....5-35
- Memory Screen5-42**
 - Memory – Backup5-44
 - Memory – Restore.....5-49
 - Memory – Clear Memory5-53
 - Memory – Reset to Factory Default5-57

Chapter 6: PLC Communications6-1

- Introduction.....6-2**
- DirectLOGIC PLCs Password Protection6-2**
- PLC Protocols.....6-3**
- PLC Communication Cables & Wiring Diagrams6-5**
 - AutomationDirect PLCs RS-232C Serial Cables Wiring Diagrams6-7
 - AutomationDirect PLCs PLCs RS-422A/RS-485A Cables Wiring Diagrams.....6-9
 - Allen-Bradley PLCs RS-232C/RS-485A Serial Cables Wiring Diagrams6-19
 - GE PLCs RS-422/RS-232C Serial Cables Wiring Diagrams.....6-22
 - Mitsubishi PLCs RS-422/RS-232C Serial Cables Wiring Diagrams6-23
 - Omron PLCs RS-232C Serial Cables Wiring Diagrams.....6-25
 - Modicon PLCs RS-232C Serial Cables Wiring Diagrams.....6-26
 - Siemens PLCs RS-485A Serial Cables Wiring Diagrams6-27

Chapter 7: Maintenance	7-1
Maintenance	7-2
Project Backup.....	7-2
Check Operating Environment.....	7-2
Check Operating Voltage.....	7-2
Check Status Indicators.....	7-2
Check Physical Conditions.....	7-2
Run Tests under System Setup Screens.....	7-3
Check Memory Usage	7-4
Check Error Log.....	7-4
Check Project Functionality.....	7-5
Checks from <i>C-more</i> Programming Software	7-5
Chapter 8: Troubleshooting	8-1
Common Problems	8-2
Troubleshooting Flow Chart	8-3
HMI Does Not Power Up	8-4
<i>C-more</i> LED Status Indicators	8-5
General Errors and Warnings	8-6
No User Program	8-8
Select Touch Panel Driver	8-11
Safe Mode Recovery	8-15
No Communications Between Panel and PC (Personal Computer) via Ethernet	8-18
No Communications between Panel and PC (Personal Computer)	8-20
Safe Mode (ERR-202-5).....	8-23
No Communications Between Panel and PC (Personal Computer) via USB	8-24
USB Driver Troubleshooting	8-25
No Communications between Panel and PLC	8-28
IP Address in System Setup Screens Displays 0.0.0.0.....	8-32
Difficulty Connecting to the Panel over the Internet (Webserver (Secure HTTPs)and Remote Access Features)	8-33
PLC Protocol Error Codes	8-34
HMI Runtime Errors	8-34
Data Not Logging Problems	8-35
Electrical Noise Problems	8-36
Touch Screen Not Working	8-36
Chapter 9: Replacement Parts	9-1
Replacement Parts Overview	9-2
3-wire Communications Terminal Block – EA9-3TB	9-3
DC Power Connector Replacement – C0-4TB	9-3

Appendix A: Panel and PLC Error Code tables	A-1
Introduction.....	A-2
<i>C-more</i> Touch Panel Error Code Table	A-3
<i>Direct</i> LOGIC – Panel Error Code PLC-499 Explanation	A-5
<i>Direct</i> LOGIC K-Sequence Protocol - PLC Error Code Table	A-5
<i>Direct</i> LOGIC DirectNET Protocol – PLC Error Codes.....	A-5
Modbus Protocols Error Code P499 Explanation	A-6
DirectLOGIC ECOM Protocol – PLC Error Codes	A-7
AutomationDirect Do-More Error Codes	A-8
Allen-Bradley – Panel Error Code PLC-499 Explanation.....	A-9
Allen-Bradley DF1 Protocol – PLC Error Code Tables.....	A-10
Allen-Bradley EtherNet/IP Protocol – Panel Error Code PLC-496, 497 and 498 Explanation	A-12
Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables ControlLogix, CompactLogix, & FlexLogix	A-13
Allen-Bradley – Micro800 Serial and EtherNet/IP Tag Based PLC Error Code Tables	A-17
Allen-Bradley – EtherNet/IP Protocol – PLC Error Code Tables.....	A-21
Generic EtherNet IP Protocol – PLC Error Codes	A-25
GE 90-30 – Panel Error Code PLC-499 Explanation	A-26
GE 90-30 SNPX Protocol – PLC Error Code Tables.....	A-27
Mitsubishi FX Protocol – PLC Error Codes	A-35
Omron – Panel Error Code PLC-499 Explanation	A-35
Omron Host Link Protocol – PLC Error Code Table.....	A-36
Omron FINS Protocol – PLC Error Code Table	A-37
Omron – Panel Error Code PLC-495 Explanation	A-39
Omron CS/CJ FINS Ethernet Protocol – PLC Error Code Table.....	A-40
Siemens – Panel Error Code P499 Explanation.....	A-41
Siemens PPI Protocol – PLC Error Code Table.....	A-42
Siemens ISO over TCP Protocol – PLC Error Code Table	A-43
 Appendix B: Touch Panel Runtime Errors.....	 B-1
Introduction.....	B-2
Runtime Errors.....	B-3
 Appendix C: System Screen Error Codek	 C-1
<i>C-more</i> Touch Panel System Screen Error Code Table.....	C-2
 Appendix D: Security Considerations for Control Systems Networks.....	 D-1
Security Considerations for Control Systems Networks.....	D-2