

INDEX



A

Accessing the System Setup Screens, 5-3

Accessories, 3-2

EA-MG-BZ1, 3-2, 3-9, 3-10

EA-MG-BZ2, 3-2, 3-12

EA-MG-COV-CL, 3-2

EA-MG-P1, 3-2

EA-MG-PGM-CBL, 3-2

EA-MG-PGMSW, 3-2

EA-MG-SP1, 3-2

Agency Approvals, 1-5

Available Models, 2-2

Available PLC Protocols, 6-2

C

Cables, 6-22

Available Purchased, 6-22

User Constructed, 6-34

Wiring Diagrams, 6-24

Chemical Compatibility, 2-8

Communications Ports, 2-7

Port 1 (built-in), 2-7

Port 2 (optional), 2-7

Conventions Used, 1-3

D

DC Power Adapter, 3-15

Dimensions, 3-15

EA-MG-P1, 3-15

Installed onto a Panel, 3-17

- Installed onto a Panel with 8-Button Keypad Bezel, 3–18
 - Panel Overall Depth with Adapter Installed, 3–15
 - Specifications, 3–16
 - Wiring Diagram, 3–15
- Dimensions, 2–6
- DirectLOGIC PLCs TERM Mode & Password Protection, 6–5

E

- Enclosure Thickness, 2–6
- Error Code P499 Explanation, A–7
- Allen-Bradley, A–8
 - DirectLOGIC, A–7
 - GE, A–13
 - Modbus Protocols, A–4
 - AutomationDirect CLICK, A–4
 - AutomationDirect DirectLOGIC - Modbus (Koyo), A–4
 - Entivity Modbus RTU, A–4
 - Modicon Modbus RTU, A–4
 - Omron, A–25
 - Siemens, A–30

F

- Function Keys Insert Label, 9–4
- Customizing, 9–4

I

- Installation and Wiring, 4–3
- Cutout Dimensions, 4–4
 - Enclosure Mounting Thickness Ranges, 4–4
 - Introduction, 4–3
 - Mounting Bracket Screw Torque, 4–4

K

- Keypad Bezel, 3–9
- 20-button, 3–12
 - Assembly, 3–14
 - Dimensions, 3–12
 - Panel Cutout, 3–12

- Panel Thickness, 3-12
- Specifications, 3-13
- 8-Button, 3-9
 - Assembly, 3-11
 - Dimensions, 3-9
 - Panel Cutout, 3-9
 - Panel Thickness, 3-9
 - Specifications, 3-10

M

Maintenance, 7-2

- Check Operating Environment, 7-2
- Check Operating Voltage, 7-2
- Check Physical Conditions, 7-3
- Check Project Functionality, 7-6
- Check Settings under the System Setup Screens, 7-5
- Check Transmit and Receive Indicators, 7-3
- Checks from the C-more Micro-Graphic Programming Software, 7-6
- Cleaning the Display Screen, 7-5
- Project Backup, 7-2
- Run Tests under the System Setup Screens, 7-4

Mounting Clip Screw Torque, 2-6

P

Panel & PLC Error Code Tables, A-2

- Allen-Bradley DF1 Protocol, A-9, A-10
- Allen-Bradley DH485 Protocol, A-11, A-12
- AutomationDirect Do-more, A-6
- AutomationDirect Productivity3000, A-5
- C-more Micro-Graphic Panel, A-3, A-4
- DirectLOGIC – K-Sequence PLC, A-7
- GE SNPX Protocol, A-14, A-15, A-16, A-17, A-18, A-19, A-20, A-21, A-22
- Introduction, A-2
- Mitsubishi FX Protocol, A-23
- Mitsubishi Q / QnA Series, A-23
- Omron FINS Protocol, A-27, A-28, A-29
- Omron Host Link Protocol, A-26
- Siemens PPI Protocol, A-31

Panel Objects, 3-5

- Adjust Display Contrast, 3-6

- Analog Meter, 3-5
- Bar Meter, 3-5
- Bitmap Button, 3-5
- Circle, 3-5
- Dynamic Bitmap, 3-6
- Dynamic Text, 3-6
- Frame, 3-5
- Function, 3-6
- Graphic Indicator Light, 3-5
- Increment/Decrement Value, 3-5
- Indicator Button, 3-5
- Indicator Light, 3-5
- Line, 3-5
- Line Graph, 3-5
- Lookup Text, 3-6
- Numeric Display, 3-5
- Numeric Entry, 3-5
- Pushbutton, 3-5
- Real Time Graph, 3-5
- Recipe, 3-6
- Rectangle, 3-5
- Screen Change Pushbutton, 3-6
- Screen Selector, 3-6
- Scroll Text, 3-6
- Static Bitmap, 3-5
- Static Text, 3-6
- Switch, 3-5
- Part Number Key, 1-5
- PC Requirements, 3-4
- PLC Communications, 6-2
 - Introduction, 6-2
- PLC Compatibility and Connection Charts, 6-5
 - Allen-Bradly PLCs, 6-18
 - CLICK, 6-8
 - DirectLOGIC DL05, DL06, D0-DCM Module & DL105 PLCs, 6-10
 - DirectLOGIC DL205 PLCs, D2-DCM Module and WINPLC, 6-12
 - DirectLOGIC DL305 PLCs and D3-DCM Module, 6-14
 - DirectLOGIC DL405 PLCs and D4-DCM Module, 6-16
 - Do-more, 6-8
 - GE, Mitsubishi, Omron, Modicon and Siemens PLCs, 6-20
 - GS Drives, 6-8

- Instructions for using, 6–7
- Productivity Series, 6–8
- SOLO Temperature Controller, 6–8
- Port 1, Built-in, 6–3
- Port 2, EA-MG-SP1 Optional, 6–4
- Product Label Examples, 1–6
- Product Overview, 1–4
- Programming Cable Assembly, 3–7
 - Converter, 3–7
 - Dimensions, 3–7
 - Status LEDs, 3–7
 - USB Connectivity, 3–7
 - USB to RS-232, 3–7
- Programming Software, 3–3

Q

- Quick Start Steps, 1–7
 - Step 1 – Unpack and Inspect, 1–7
 - Step 10 – Connect C-more Micro-Graphic Panel to PLC, 1–16
 - Step 2 – Install Optional Hardware Accessories, 1–8
 - Step 3 – Become Familiar with Available Communication Ports, 1–9
 - Step 4 – Install Micro-Graphic Panel, 1–10
 - Step 5 – Install the Programming Software and Develop a Project, 1–11
 - Step 6 – Connect C-more Micro-Graphic Panel to Computer, 1–12
 - Step 7 – Provide Power to the C-more Micro-Graphic Panel, 1–13
 - Step 8 – Accessing the C-more Micro-Graphic Panel Setup Screens, 1–14
 - Step 9 – Choose C-more Micro-Graphic Panel to PLC Protocol & Cables, 1–15

R

- Replacement Parts, 9–3
 - DC Power Connector Part No. EA-MG-DC-CON, 9–3
 - Function Keys Label Inserts Part No. EA-MG-S3ML-FKL, 9–3
 - Keypad Bezel 1 Gasket Part No. EA-MG-BZ1-GSK, 9–2
 - Keypad Bezel 1 Mounting Clips Part No. EA-MG-BZ1-BRK, 9–2
 - Keypad Bezel 2 Gasket Part No. EA-MG-BZ2-GSK, 9–3
 - Keypad Bezel 2 Mounting Clips Part No. EA-MG-BZ2-BRK, 9–3
 - Panel Gasket Part No. EA-MG-S3ML-GSK, 9–2
 - Panel Mounting Clips Part No. EA-MG-S3ML-BRK, 9–2
- Replacement Parts at a Glance, 9–2

- Replacement Parts Overview, 9–2
- RS-422A/RS-485A Multi-Drop Wiring Diagram Examples, 6–44
- Runtime Errors, B–2
 - Introduction, B–2
 - Panel Errors, B–2

S

- Safety Guidelines, 4–2
 - Plan for Safety, 4–2
- Screen Overlay, 3–22
 - Dimensions, 3–22
 - EA-MG-COV-CL, 3–22
 - Installation, 3–22
- Serial Number and Date Code formats, 1–6
- Serial Port with DC Power Adapter, 3–19
 - Available PLC Protocols, 3–21
 - Dimensions, 3–19
 - EA-MG-SP1, 3–19
 - Installed onto a Panel with 20-Button Keypad Bezel, 3–21
 - Panel Overall Depth with Adapter Installed, 3–19
 - PLC Serial Communications Port 1, 3–21
 - Specifications, 3–20
 - Wiring Diagram, 3–19
- Setting – Hourglass, 5–13
- Specifications, 2–4
- System Setup Screens, 5–2
 - Exit, 5–17
 - Information Menu, 5–6
 - Extensions, 5–6
 - Memory, 5–6
 - Protocol, 5–6
 - Versions, 5–6
- Introduction, 5–2
 - Information, 5–2
 - Setting, 5–2
 - Test Menu, 5–2
 - Setting – Backlight, 5–8, 5–9
 - Setting – Beep, 5–10
 - Setting – Calibration, 5–11

- Setting – Clear User Memory, 5–12
- Setting – LCD Contrast, 5–7
- Setting – Reset to Factory Default, 5–12
- Setting Menu, 5–7
- Setup Menu, 5–5
 - Exit, 5–5
 - Information, 5–5
 - Setting, 5–5
 - Test Menu, 5–5

System Setup Screens Flowchart, 5–4

T

Technical Support, 1–2

Test Menu, 5–14

- Buzzer Test, 5–16
- PLC Enquiry Test, 5–16
- Serial Port1 - Loop Back Test, 5–14
- Serial Port2 - Loop Back Test, 5–15
- Touch Panel Test, 5–17

Troubleshooting, 8–2

- Display is Blank, 8–2
- Display is Dim, 8–3
- Electrical Noise Problems, 8–10
- Lost Firmware – Red ‘Update Mode’ Screen Displayed, 8–4
- Micro-Graphic Panel does not Power up, 8–2
 - Powered from 12-24 VDC, 8–2
 - Powered from 5 VDC, 8–2
- No Communications between Panel and PC, 8–5
- No Communications between Panel and PLC, 8–7
- No User Program, 8–3
- Panel Runtime Errors, 8–9
- PLC Protocol Error Codes, 8–8
 - PLC Protocol Error Example, 8–8

U

User Manual Introduction, 1–2

W

Wiring Guidelines, 4–5

Panel Powered from a DC Power Adapter, 4–6

Wiring Diagrams, 4–6

Panel Powered from Direct LOGIC PLC, 4–5

Providing Power to the Micro-Graphic Panel, 4–5