

INDEX



A

Accessing the System Setup Screens, 5–3

Accessories, 3–2

EA-MG-BZ1, 3–2, 3–9, 3–10

EA-MG-BZ2, 3–2, 3–12

EA-MG-COV-CL, 3–2

EA-MG-P1, 3–2

EA-MG-PGM-CBL, 3–2

EA-MG-PGMSW, 3–2

EA-MG-SPI, 3–2

Agency Approvals, 1–5

Available Models, 2–2

Available PLC Protocols, 6–2

C

Cables, 6–22

Available Purchased, 6–22

User Constructed, 6–34

Wiring Diagrams, 6–24

Chemical Compatibility, 2–8

Communications Ports, 2–7

Port 1 (built-in), 2–7

Port 2 (optional), 2–7

Conventions Used, 1–3

D

DC Power Adapter, 3–15

Dimensions, 3–15

- EA-MG-P1, 3–15
- Installed onto a Panel, 3–17
- Installed onto a Panel with 8-Button Keypad Bezel, 3–18
- Panel Overall Depth with Adapter Installed, 3–15
- Specifications, 3–16
- Wiring Diagram, 3–15

Dimensions, 2–6

DirectLOGIC PLCs TERM Mode & Password Protection, 6–5

E

Enclosure Thickness, 2–6

Error Code P499 Explanation, A–7

- Allen-Bradley, A–8
- DirectLOGIC, A–7
- GE, A–13
- Modbus Protocols, A–4
 - AutomationDirect CLICK, A–4
 - AutomationDirect DirectLOGIC - Modbus (Koyo), A–4
 - Entivity Modbus RTU, A–4
 - Modicon Modbus RTU, A–4
- Omron, A–25
- Siemens, A–30

F

Function Keys Insert Label, 9–4

- Customizing, 9–4

I

Installation and Wiring, 4–3

- Cutout Dimensions, 4–4
- Enclosure Mounting Thickness Ranges, 4–4
- Introduction, 4–3
- Mounting Bracket Screw Torque, 4–4

K

Keypad Bezel, 3–9

- 20-button, 3–12
 - Assembly, 3–14
 - Dimensions, 3–12
 - Panel Cutout, 3–12
 - Panel Thickness, 3–12
 - Specifications, 3–13
- 8-Button, 3–9
 - Assembly, 3–11
 - Dimensions, 3–9
 - Panel Cutout, 3–9
 - Panel Thickness, 3–9
 - Specifications, 3–10

M

- Maintenance, 7–2
 - Check Operating Environment, 7–2
 - Check Operating Voltage, 7–2
 - Check Physical Conditions, 7–3
 - Check Project Functionality, 7–6
 - Check Settings under the System Setup Screens, 7–5
 - Check Transmit and Receive Indicators, 7–3
 - Checks from the C-more Micro-Graphic Programming Software, 7–6
 - Cleaning the Display Screen, 7–5
 - Project Backup, 7–2
 - Run Tests under the System Setup Screens, 7–4
- Mounting Clip Screw Torque, 2–6

P

- Panel & PLC Error Code Tables, A–2
 - Allen-Bradley DF1 Protocol, A–9, A–10
 - Allen-Bradley DH485 Protocol, A–11, A–12
 - AutomationDirect Do-more, A–6
 - AutomationDirect Productivity3000, A–5
 - C-more Micro-Graphic Panel, A–3, A–4
 - DirectLOGIC – K-Sequence PLC, A–7
 - GE SNPX Protocol, A–14, A–15, A–16, A–17, A–18, A–19, A–20, A–21, A–22
 - Introduction, A–2

- Mitsubishi FX Protocol, A-23
- Mitsubishi Q / QnA Series, A-23
- Omron FINS Protocol, A-27, A-28, A-29
- Omron Host Link Protocol, A-26
- Siemens PPI Protocol, A-31
- Panel Objects, 3-5
 - Adjust Display Contrast, 3-6
 - Analog Meter, 3-5
 - Bar Meter, 3-5
 - Bitmap Button, 3-5
 - Circle, 3-5
 - Dynamic Bitmap, 3-6
 - Dynamic Text, 3-6
 - Frame, 3-5
 - Function, 3-6
 - Graphic Indicator Light, 3-5
 - Increment/Decrement Value, 3-5
 - Indicator Button, 3-5
 - Indicator Light, 3-5
 - Line, 3-5
 - Line Graph, 3-5
 - Lookup Text, 3-6
 - Numeric Display, 3-5
 - Numeric Entry, 3-5
 - Pushbutton, 3-5
 - Real Time Graph, 3-5
 - Recipe, 3-6
 - Rectangle, 3-5
 - Screen Change Pushbutton, 3-6
 - Screen Selector, 3-6
 - Scroll Text, 3-6
 - Static Bitmap, 3-5
 - Static Text, 3-6
 - Switch, 3-5
- Part Number Key, 1-5
- PC Requirements, 3-4
- PLC Communications, 6-2

- Introduction, 6–2
- PLC Compatibility and Connection Charts, 6–5
 - Allen-Bradly PLCs, 6–18
 - CLICK, 6–8
 - DirectLOGIC DL05, DL06, D0-DCM Module & DL105 PLCs, 6–10
 - DirectLOGIC DL205 PLCs, D2-DCM Module and WINPLC, 6–12
 - DirectLOGIC DL305 PLCs and D3-DCM Module, 6–14
 - DirectLOGIC DL405 PLCs and D4-DCM Module, 6–16
 - Do-more, 6–8
 - GE, Mitsubishi, Omron, Modicon and Siemens PLCs, 6–20
 - GS Drives, 6–8
 - Instructions for using, 6–7
 - Productivity Series, 6–8
 - SOLO Temperature Controller, 6–8
- Port 1, Built-in, 6–3
- Port 2, EA-MG-SP1 Optional, 6–4
- Product Label Examples, 1–6
- Product Overview, 1–4
- Programming Cable Assembly, 3–7
 - Converter, 3–7
 - Dimensions, 3–7
 - Status LEDs, 3–7
 - USB Connectivity, 3–7
 - USB to RS-232, 3–7
- Programming Software, 3–3

Q

- Quick Start Steps, 1–7
 - Step 1 – Unpack and Inspect, 1–7
 - Step 10 – Connect C-more Micro-Graphic Panel to PLC, 1–16
 - Step 2 – Install Optional Hardware Accessories, 1–8
 - Step 3 – Become Familiar with Available Communication Ports, 1–9
 - Step 4 – Install Micro-Graphic Panel, 1–10
 - Step 5 – Install the Programming Software and Develop a Project, 1–11
 - Step 6 – Connect C-more Micro-Graphic Panel to Computer, 1–12
 - Step 7 – Provide Power to the C-more Micro-Graphic Panel, 1–13
 - Step 8 – Accessing the C-more Micro-Graphic Panel Setup Screens, 1–14

Step 9 – Choose C-more Micro-Graphic Panel to PLC Protocol & Cables, 1–15

R

Replacement Parts, 9–3

DC Power Connector Part No. EA-MG-DC-CON, 9–3

Function Keys Label Inserts Part No. EA-MG-S3ML-FKL, 9–3

Keypad Bezel 1 Gasket Part No. EA-MG-BZ1-GSK, 9–2

Keypad Bezel 1 Mounting Clips Part No. EA-MG-BZ1-BRK, 9–2

Keypad Bezel 2 Gasket Part No. EA-MG-BZ2-GSK, 9–3

Keypad Bezel 2 Mounting Clips Part No. EA-MG-BZ2-BRK, 9–3

Panel Gasket Part No. EA-MG-S3ML-GSK, 9–2

Panel Mounting Clips Part No. EA-MG-S3ML-BRK, 9–2

Replacement Parts at a Glance, 9–2

Replacement Parts Overview, 9–2

RS-422A/RS-485A Multi-Drop Wiring Diagram Examples, 6–44

Runtime Errors, B–2

Introduction, B–2

Panel Errors, B–2

S

Safety Guidelines, 4–2

Plan for Safety, 4–2

Screen Overlay, 3–22

Dimensions, 3–22

EA-MG-COV-CL, 3–22

Installation, 3–22

Serial Number and Date Code formats, 1–6

Serial Port with DC Power Adapter, 3–19

Available PLC Protocols, 3–21

Dimensions, 3–19

EA-MG-SP1, 3–19

Installed onto a Panel with 20-Button Keypad Bezel, 3–21

Panel Overall Depth with Adapter Installed, 3–19

PLC Serial Communications Port 1, 3–21

Specifications, 3–20

Wiring Diagram, 3–19

- Setting – Hourglass, 5–13
- Specifications, 2–4
- System Setup Screens, 5–2
 - Exit, 5–17
 - Information Menu, 5–6
 - Extensions, 5–6
 - Memory, 5–6
 - Protocol, 5–6
 - Versions, 5–6
 - Introduction, 5–2
 - Information, 5–2
 - Setting, 5–2
 - Test Menu, 5–2
 - Setting – Backlight, 5–8, 5–9
 - Setting – Beep, 5–10
 - Setting – Calibration, 5–11
 - Setting – Clear User Memory, 5–12
 - Setting – LCD Contrast, 5–7
 - Setting – Reset to Factory Default, 5–12
 - Setting Menu, 5–7
 - Setup Menu, 5–5
 - Exit, 5–5
 - Information, 5–5
 - Setting, 5–5
 - Test Menu, 5–5
- System Setup Screens Flowchart, 5–4

T

- Technical Support, 1–2
- Test Menu, 5–14
 - Buzzer Test, 5–16
 - PLC Enquiry Test, 5–16
 - Serial Port1 - Loop Back Test, 5–14
 - Serial Port2 - Loop Back Test, 5–15
 - Touch Panel Test, 5–17
- Troubleshooting, 8–2
 - Display is Blank, 8–2

- Display is Dim, 8–3
- Electrical Noise Problems, 8–10
- Lost Firmware – Red ‘Update Mode’ Screen Displayed, 8–4
- Micro-Graphic Panel does not Power up, 8–2
 - Powered from 12-24 VDC, 8–2
 - Powered from 5 VDC, 8–2
- No Communications between Panel and PC, 8–5
- No Communications between Panel and PLC, 8–7
- No User Program, 8–3
- Panel Runtime Errors, 8–9
- PLC Protocol Error Codes, 8–8
 - PLC Protocol Error Example, 8–8

U

- User Manual Introduction, 1–2

W

- Wiring Guidelines, 4–5
 - Panel Powered from a DC Power Adapter, 4–6
 - Wiring Diagrams, 4–6
 - Panel Powered from Direct LOGIC PLC, 4–5
 - Providing Power to the Micro-Graphic Panel, 4–5