GMCBU-AUX11/GMCBU-ALM11 INSTRUCTION MANUAL(UL489)



A Before installation, wiring, operation, maintenance and inspection of the device, be sure to read the operating instructions carefully to ensure proper operations.

Customer Center-Quick Responsive, Excellent technical support TEL,1-800-633-0405 | Home page, http://www.AutomationDirect.com

Specifications in this catalog are subject to change without notice due to continuous product development and improvement.

3. Safety Precaution

♠ DANGER -

- 1) Turn off the upstream circuit breaker before installing or service to prevent electric shocks and burns due to short circuit,
- 2) Do not touch any live naked terminals. It makes an electric shock.
- 3) Do not touch two live lines simultaneously. The circuit breaker does not operate even if an electric shock occurs.


- 1) Installation by qualified electrician only, per NEC.
- 2) Do not install the circuit breaker in place of environment with shock, high temperature, humidity, dust, corrosive gases, excessive vibration, etc. to prevent fire accidents and malfunction of the device.
- 3) Use the breaker in a range of the rated voltage and current shown on the name plate. Or it may cause malfunction.







- 4) Each terminal or conductor pole should be connected in parallel as shown below.
- 5) Be sure to ground the ground terminals of electrical devices.
- 6) When the circuit breaker trips, remove the fault and turn the handle "ON". Or else, it may lead to the fire accident.
- 7) Do not modify the device unless it is permitted.
- 8) When the device become useless, it should be dispose of them as an industrial waste.
- 9) In order to fix MCB in DIN-Rail, Install end bracket on the both MCB side, After wiring.

4. Dimension





- of attachment
- * Applicable: GMCBU



79561472008