

Installation and User manual

Summary of Content

1. INTRODUCTION	3
1.1 Obtaining the SWC5090	3
1.2 Configurable models	3
1.3 Requirements	3
2. SWC5090 MAIN WINDOW	4
2.1 Main Menu	5
2.2 Bottom Bar	8
3. APPLICATION WINDOWS	8
3.1 D5060S	8
3.1.1 Configuration	8
3.1.1 Monitor	10
3.1.1 Data Logger	11
3.2 D5072S/D6072S, D5072D/D6072D, D5273S/D6273S (up to software revision 2)	12
3.2.1 Configuration	12
3.2.2 Monitor	15
3.2.3 Data Logger	16
3.3 D5072S/D6072S, D5072D/D6072D, D5273S/D6273S (from software revision 3 up to 4)	16
3.3.1 Configuration	17
3.3.2 Monitor	20
3.3.3 Data Logger	21
3.4 D5072S/D6072S, D5072D/D6072D, D5273S/D6273S (from software revision 5)	21
3.4.1 Configuration	22
3.4.2 Monitor	25
3.4.3 Data Logger	26
3.5 D5072S-087/D6072S-087, D5072D-087/D6072D-087 (from software revision 3)	26
3.5.1 Configuration	27
3.5.2 Monitor	27
3.5.3 Data Logger	28
3.6 D5072S-096/D6072S-096, D5072D-096/D6072D-096	29
3.6.1 Configuration	29
3.6.2 Monitor	30
3.6.3 Data Logger	30
3.7 D5231E / D6231E (up to software revision 0)	31
3.7.1 Configuration	31
3.7.2 Monitor	32
3.7.3 Data Logger	32
3.8 D5231E / D6231E (from software revision 1)	33
3.8.1 Configuration	33
3.8.2 Monitor	35
3.8.3 Data Logger	36
3.9 D5240T	36
3.9.1 Configuration	37
3.9.2 Data Logger	38
3.10 D5293S, D5294S (software revision 0)	39
3.10.1 Configuration	39
3.10.2 Monitor	43
3.10.3 Examples and Applications	43
3.11 D5293S (software revisions 1 and 2)	44
3.11.1 Configuration	44
3.11.2 Monitor	46
3.11.3 Data Logger	47
3.12 D5294S, D5295S (software revisions 1 and 2)	47
3.12.1 Configuration	48
3.12.2 Monitor	51
3.12.3 Data Logger	52

3.13	D5264S	52
3.13.1	Configuration	53
3.13.2	Monitor	54
3.13.3	Data Logger	55
3.14	D5254S/D6254S	56
3.14.1	Configuration	56
3.14.2	Monitor	59
3.14.3	Data Logger	59
3.15	D5212Q/D6212Q	60
3.15.1	Configuration	60
3.15.2	Monitor	63
3.15.3	Data Logger	64
3.16	5700, 5700-110	64
3.16.1	Configuration	64
3.17	D5232Q/D6232Q and D5233Q/D6233Q	65
3.17.1	Configuration	66
3.17.2	Monitor	66
3.17.3	Data Logger	67
3.18	D5274S	67
3.18.1	Configuration	68
3.18.2	Monitor	70
3.18.3	Data Logger	71
4.	MONITOR	72
5.	DATA LOGGER	72
6.	CONFIGURATION FILE	72
7.	REPORT SHEET	72
8.	INSTALLATION AND QUICK START	73
8.1	Installing the PPC5092 USB-to-Mini USB Adapter driver	73
8.2	Installing the SWC5090 Configuration Software	73

1. Introduction

The Configuration Software SWC5090 provides a PC user interface for D5000/D6000 series modules that allows the user to:

- Read and Write configuration parameters from and to the unit (via COM port);
- Restore data to and from local hard drive for backup;
- Monitor Input values (via COM port).
- Record monitoring sessions and save data to file.

1.1 Obtaining the SWC5090

The SWC5090 is absolutely free-of-charge and is distributed in each CD included in PPC5092 adapter package. Moreover, the most updated version can always be freely downloaded from www.gmintsr.com

1.2 Configurable models

G.M. International models that can be configured via SWC5090 software are:

- Smart Solenoid Drivers: D5293S, D5294S, D5295S.
- Frequency-Pulse Converter & Repeater: D5060S.
- Temperature Converters: D5072S, D5072D, D5273S, D6072S, D6072D, D6273S.
- Resistance Repeaters: D5072S-087, D5072D-087.
- Thermocouple/mV Repeaters: D5072S-096, D5072D-096.
- Analog Input: D5212Q, D6212Q
- Digital Input: D5231E, D6231E, D5232Q, D6232Q, D5233Q, D6233Q.
- Digital Output: D5240T.
- Analog Signal Converter and Trip Amplifiers: D5254S, D6254S.
- Load Cell/Strain Gauge Converter: D5246S.
- HART® Mux Modem: 5700/5700-110.
- Temperature Converter with trimmers: D5274S

1.3 Requirements

The Configuration Software has to be installed on a machine with the following minimum requirements:

- Pentium class Processor 200MHz;
- 800x600 pixels screen resolution;
- 256 MB RAM;
- 1 USB port;
- "Microsoft Windows" operating system with latest updates installed;
- Windows 7 and 8 users should set text size at 100% (Small) in the Display settings of the Control Panel (see screenshot in Figure 1).




Figure 1: display text size settings screenshot.

Furthermore, the following items are required:

- PPC5092 (USB-to-Mini USB Adapter) with correct drivers installed (See Section 8.1);
- Mini USB cable (provided with PPC5092).



Figure 2: PPC5092 Adapter.



Figure 3: Mini-USB cable included with PPC5092.

2. SWC5090 Main Window

At start-up, the SWC5090 Configuration Software loads a Main Window, which is the same for all modules. The Main Window is basically a frame with a menu at the top and a bottom bar.

In case the module is already connected to the PC correctly, the SWC5090 detects it and asks the user if he wishes to Read parameters from module directly. COM port is automatically set in the configuration file for future sessions.

Instead, if the module is not connected at startup, the user can:

- decide to work offline by selecting the desired model from the "Module" entry in the Menu

- read offline parameters saved to file by going to “File -> Open file” entry in the Menu

If the module is connected after startup of the SWC5090, the user has to manually read parameters by pressing the dedicated button on the top right of the screen.

2.1 Main Menu




Figure 4: Menu.

The menu at the top of the Main Window (see Figure 4) is divided into the following entries:

- **“File”**
 - **Open:** load configuration data from local hard drive backup;
 - **Save:** save configuration data to the present local hard drive backup;
 - **Save as...:** save configuration data to a different local hard drive backup;
 - **Print Preview:** screen preview of the configuration report to be printed;
 - **Print:** configuration report print on paper;
 - **Exit:** exit from the configuration software.

- **“Settings”**

- **Serial**

In the COM Port Setup window (see Figure 5) the user can choose the COM Port of the PPC5092 in the drop-down menu at the top. The connection to the module can be tested by pressing the **“Test Port COM#”** button. Finally the COM Port can be updated by pressing the **“Update Com Port & Exit”** button or left unchanged by pressing the **“Exit without changes”** button.





Figure 5: COM Port Setup window.

- **Modbus**

In the Module Modbus Setup window (see Figure 6) the user can introduce the Modbus address of the module (from 1 to 247), the Modbus Baud Rate (selectable among 4800, 9600, 19200, 38400, 57600 and 115200 bps) and the Modbus Format (no parity 1 stop bit, even parity 1 stop bit, odd parity 1 stop bit).


The changes are saved by pressing the **“Ok”** button, while they are discarded by pressing **“Cancel”**. Note that the **“Store to device”** button on the menu bar must be pressed to make the Modbus settings effective. Moreover, the module must be power cycled.



The image shows a 'Module Modbus Setup' dialog box. It contains several configuration fields: 'Address' with a text input containing '1'; 'Baud Rate' with a dropdown menu showing '38400'; 'Format' with a dropdown menu showing 'no parity' and '1 stop bit'; 'Term Res' with a dropdown menu showing 'OFF'; and 'Endianness' with a dropdown menu showing 'Little Endian'. At the bottom, there are 'Ok' and 'Cancel' buttons. The 'Cancel' button is highlighted with a blue border.

Figure 6: Modbus Setup window.

- **Temperature Scale (only available with Temperature converters)**
Choose between °C and °F. The setting is stored into the configuration file for future uses.
- **“Module”**
 - **Select Model:** during off-line operations, select the module window among supported ones;
 - **Show Identification:** show the instrument and option code, and the software and hardware release. Identification is only available after that a read operation from module has been successfully completed.
 - **Load Factory Settings:** loads default parameters to configurator screen, for the selected module.
- **“?”**
 - **Show EULA:** The End User License Agreement is displayed and a copy can be saved;
 - **Help:** Opens this document in pdf format;
 - **About SWC5090:** Shows the release of the current SWC5090 Configuration Software.
 - In the Update Manager window (see Figure 7) the user can automatically check the “Running Version” against the “Last released Version” from G.M. International database. The Configuration Software can be updated by pressing the “Update” button or left unchanged by pressing the “Exit” button.
To download the latest version, you must log in to our website.



The image shows an 'Update Manager' dialog box. It has two rows: 'Running Version' with a text input containing '1.3.6' and 'Last Released Version' with a text input containing '1.3.6'. Below these is a message box that says 'The current version is the latest available Push button <Exit> to terminate'. At the bottom, there are 'Update' and 'Exit' buttons. The 'Exit' button is highlighted with a blue border.

Figure 7: Update Manager window.

– **Log in:**

User can login according to two alternative roles (see Figure 8):

- (1) **OBSERVER:** can perform only read operations. No password is required.
- (2) **ADMINISTRATOR:** can perform all the read and write operations. Password is required.

In case of password failure after three times, at the last wrong attempt a 1-minute retry timer will run, after which the user will be forced to Observer role.

Administrator password is restore to factory value after any installation process.

The factory administrator password is: **default**




Figure 8 Log in window

– **Administrator tools.**

The Password management window (see Figure 9), allow the administrator to change password and activate or deactivate it.

Password is string with up to 16 alphanumeric characters, and will be stored and compared in encrypted format. After password changed a new log in is requested.

If the software is protected (Enable password checked), after 10 minutes inactivity login window pop up again as if the software were started from scratch.

In case of loss of password a new installation process is required.




Figure 9 Password management window.

On the right of the menu, two quick buttons are available: **“Load from device”**, **“Store to device”**.

By pressing the first one, the configuration settings, the Modbus settings and the Tag currently stored in the Module are read from the module and displayed. Since this operation overwrites the settings on the screen, the user is asked for confirmation.

The **“Store to device”** button allows the storage to the Module of the configuration settings, the Modbus settings and the Tag, which are currently displayed on the Configuration window. By doing so, the previous settings saved on the Module are overwritten.

Note that all configuration functions are available only when offline (Monitor or Data Logger are inactive).

In particular, the **“Store to device”** button is activated only when configuration data was successfully read from the Module or loaded from a backup file.

2.2 Bottom Bar




Figure 10: Bottom Bar.

The Bottom Bar (see Figure 10) includes a status bar, a progress bar that indicates that the operation is in progress, and the current date & time.

3. Application Windows

The center of the SWC5090 Configuration Software window is filled with the Application Window, which is different for each module. In the Application Window the user can read the field data, configure the data ranges and so on.

3.1 D5060S

D5060S is a Frequency-Pulse Converter & Repeater that receives a frequency signal from magnetic pick-up (selectable among different families), contact, proximity, open-collector sensor or TTL/CMOS logic, located in Hazardous Area, and converts, with isolation, the signal to drive a Safe Area load, suitable for applications requiring SIL 2 level in safety related systems for high risk industries

- **Configuration**
- **Monitor**
- **Data Logger**

3.1.1 Configuration




Figure 11: D5060S Configuration screen.

INPUT

Input frequency range:

- 50Hz
- 500Hz
- 5kHz
- 50kHz

Resolution is always 1/50000 of full scale, hence respectively 1 mHz, 10 mHz, 100 mHz and 1 Hz..

Downscale: input value, expressed in division, depending on input frequency range, corresponding to the output current downscale, typically 4 mA.

Upscale: input value, expressed in division, depending on input frequency range, corresponding to the output current upscale, typically 20 mA.

Input fault enable: reference junction compensation type (thermocouple only)

- **OFF** fault condition is not triggered
- **ON** fault condition is triggered

OUTPUT

Type:

- 4-20 mA Source
- 4-20 mA Sink
- 1-5 Vdc
- 4-20 mA Custom Source (All Output parameters are fully customizable)
- 4-20 mA Custom Sink (All Output parameters are fully customizable)
- 1-5 Vdc Custom (All Output parameters are fully customizable)

Divider: Drive the output repeater with the input frequency, divided by the configured frequency divider

- 1:1
- 10:1
- 100:1
- 1000:1
- 10000:1
- 100000:1
- 1000000:1

Downscale: output current value (expressed in 100 nA, or 100 μ V) corresponding to the input downscale value.

Upscale: output current value (expressed in 100 nA, or 100 μ V) corresponding to the input upscale value.

Under range: minimum output current value (expressed in 100 nA, or 100 μ V) below the downscale.

Overrange: minimum output current value (expressed in 100 nA, or 100 μ V) below the upscale.

Fault Output Value: output current value (expressed in 100 nA, or 100 μ V) in case of fault.

Damping Factor: causes conventional single-pole low pass filtering which is similar to an R-C network.

Although high damping values will greatly suppress noise and make the output signal stable, it causes a slow response time.

TAG

Tag: 16 alphanumeric characters

ALARM

Type:

- None: alarm is disabled
- Low: alarm is triggered when source descends below “Low Set”
- High: alarm is triggered when source ascends over “High Set”
- Window: alarm is triggered below “Low Set” and above “High Set”
- Fault Repeater: alarm output reflects fault status

NO Contact position in alarm:

- Open Alarm is switched to open in case of alarm (Fail-safe state)
- Closed Alarm is switched to close in case of alarm

Alarm fault configuration:

- Ignore: alarm is not affected
- Lock: alarm remains in the same status as it was before fault condition occurred
- Alarm Active: alarm is triggered
- Alarm Inactive: alarm is deactivated

Low Set: expressed in div (1/50000) referred to the input frequency range, below which the alarm should be asserted (in Low, Low Lock, Window)

Low Hysteresis: expressed in div (1/50000) referred to the input frequency range, to be applied to the alarm low threshold before removing the alarm.

High Set: expressed in div (1/50000) referred to the input frequency range, above which the alarm should be asserted.

High Hysteresis: expressed in div (1/50000) referred to the input frequency range, to be applied to the alarm high threshold before removing the alarm.

On Delay: time for which the source variable has to be in alarm condition before the alarm output is triggered; configurable from 0 to 1000 seconds in steps of 100 ms

Off Delay: time for which the source variable has to be in normal condition before the alarm output is deactivated; configurable from 0 to 1000 seconds in steps of 100 ms

3.1.1 Monitor

The SWC5090 is able to continuously scan the module and display real-time values on screen.

Note that while the module is being monitored, configuration screens are disabled.




Figure 12: D5060S Monitor screen.

The display shows Input and Theoretical Output values, fault and alarm status and a graph of chosen variable.

3.1.1.1 Input

Input Sensor Frequency LF: expressed in div (1/50000 FS)

Input Sensor Frequency HF: expressed in div (1/50000 FS)

Input Sensor Frequency: expressed in div (1/50000 FS)

Theoretical output current value: expressed in 100nA

Theoretical output repeater frequency: expressed in div (1/50000 FS)

3.1.1.2 Alarm and fault status

Alarm and fault status are respectively represented by a LED, which is RED when activated.

The LED status reflects the status of the Alarm or fault exactly as configured.

3.1.1 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals.

By changing the parameters, the user can decide the duration of the recording period and the frequency of readings.

After pressing “Start” button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format.

Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.




Figure 13: Data Logger screen.

3.2 D5072S/D6072S, D5072D/D6072D, D5273S/D6273S (up to software revision 2)

D5072S, D5072D, D5273S, D6072S, D6072D, D6273S are Universal Converters and share the same screens, except for the number of input, output and alarm channels.

The Application Window user interface is organized into the following areas:

- **Configuration**
 - Input
 - Output
 - Alarm
- **Monitor**
- **Data Logger**

3.2.1 Configuration

3.2.1.1 Input




Figure 14: D5072D / D6072D Input configuration screen.

INPUT

Sensor Connection:

- TC
- RTD
- Potentiometer
- Voltage
- Resistance

Sensor Type: input sensor type (see list in section “Input specifications”)
possibility of configuring a completely customized input curve (TC/RTD)

Wires: 2, 3, 4 wires selection for RTD/Resistance inputs

Downscale: input value of measuring range corresponding to defined low output value

Upscale: input value of measuring range corresponding to defined high output value

Cold Junction Source: reference junction compensation type (thermocouple only)

- Automatic via internal compensator (1 for each channel)
- Fixed programmable temperature compensation at fixed temperature
- Other Input remote compensation using RTD on remaining channel

Cold Junction Reference: fixed temperature compensation value (Cold Junction type Fixed only), range from -60 to +100 °C.

Integration speed:

- Slow 250 ms (mV/TC, 2 wire RTD); 375 ms (Pot.), 500 ms (3,4 wire RTD)
- Fast 50 ms (mV/TC, 2 wire RTD); 75 ms (Pot.), 100 ms (3,4 wire RTD)

Mains Frequency:

- 50 Hz
- 60 Hz only available with fast integration speed

Offset: value to be added/subtracted to input (μV or $\text{m}\Omega$ depending on input sensor)

Multiplier: input multiplication value

Tag: 16 alphanumeric characters

Note: Downscale and Upscale settings should follow Minimum Span requirements stated in the data sheet, in order to avoid negative impacts on Output resolution.

3.2.1.2 Output




Figure 15: D5072D / D6072D Output configuration screen.

OUTPUT

Function:

- Input 1 analog output represents input of first channel
- Input 2 analog output represents input of second channel
- Input 1 + 2 analog output represents the sum of the two input channels
- Input 1 - 2 analog output represents the subtraction of the two input ch.
- Min(Input 1, Input 2) analog output represents the lower of the two input ch.
- Max(Input 1, Input 2) analog output represents the higher of the two input ch.

Type:

- 0-20 mA Sink
- 4-20 mA Sink
- Custom Sink
- 0-20 mA Source

All Output parameters are fully customizable

- 4-20 mA Source
 - Custom Source
- All Output parameters are fully customizable

Downscale: analog output downscale in normal working condition (range 0 to 24 mA)

Upscale: analog output downscale in normal working condition (range 0 to 24 mA)

Under range: analog output downscale in under range condition (range 0 to 24 mA)

Overrange: analog output downscale in overrange condition (range 0 to 24 mA)

Fault Output Value: analog output value in case of fault condition (range 0 to 24 mA)

Fault in case of: analog output is forced to "Fault Output Value" in case of:

- Burnout input sensor interruption
- Internal fault module internal fault
- Sensor out of range input sensor out of configured input range
- Output Saturation output is below Under range or above Overrange
- Module Temp. Out of range internal module temp. under or over specified module operating temp. limits

3.2.1.3 Alarm





Figure 16: D5072D/D6072D (on the left) and D5273S/D6273S (on the right) alarm configuration screen.

ALARM

Type:

- None alarm is disabled
- Low alarm is triggered when source descends below "Low Set"
- Low Lock alarm is inhibited until source ascends over "Low Set" and then, it behaves as a standard "Low" configuration
- High alarm is triggered when source ascends over "High Set"
- High Lock alarm is inhibited until source descends below "High Set" and then, it behaves as a standard "High" configuration
- Window alarm is triggered below "Low Set" and above "High Set"
- Fault Repeater alarm output reflects selected (one or more) Fault status

Source: reference value for alarm triggering

- Input 1 input of first channel
- Input 2 input of second channel
- Input 1 + 2 sum of the two input channels
- Input 1 - 2 subtraction of the two input channels
- Min(Input 1, Input 2) lower of the two input channels
- Max(Input 1, Input 2) higher of the two input channels

Condition:

- NE alarm output is normally energized when deactivated

- **ND** alarm output is normally de-energized when deactivated

Low Set: source value at which the alarm is triggered (in Low, Low Lock, Window)

Low Hysteresis: triggered Low alarm deactivates when source value reaches Low Set + Low Hysteresis (0-500 °C, 0-50 mV, 0-50 %)

High Set: source value at which the alarm is triggered (in High, High Lock, Window)

High Hysteresis: triggered High alarm deactivates when source value reaches High Set - High Hysteresis (0-500 °C, 0-50 mV, 0-50 %)

On Delay: time for which the source variable has to be in alarm condition before the alarm output is triggered; configurable from 0 to 1000 seconds in steps of 100 ms

Off Delay: time for which the source variable has to be in normal condition before the alarm output is deactivated; configurable from 0 to 1000 seconds in steps of 100 ms

In case of fault:

- **Ignore** alarm is not affected
- **Lock status** alarm remains in the same status as it was before Fault occurred
- **Go On** alarm is triggered,
- **Go Off** alarm is deactivated

Faults: if "Type" is set to "Fault repeater" select which faults will be repeated by alarm output; if "In case of fault" is different from "Ignore", select which faults should influence alarm output behavior.

3.2.2 Monitor

The SWC5090 is able to continuously scan the module and display real-time values on screen.

Note that while the module is being monitored, configuration screens are disabled.




Figure 17: D5273S/D6273S Monitor screen.

The display shows Input and Theoretical Output values, fault and alarm status and a graph of chosen variable.

3.2.2.1 Input

Input variable is shown as it is detected by the module, after having applied configured calculations (Offset, Multiplier) and conversions.

Cold Junction Temperature shows the value of the internal Cold Junction; this value will influence the Output measure when Cold Junction configuration is set to "Automatic".

3.2.2.2 Output

This value represents the theoretical output. During certain conditions, this value may differ from the measured value at output terminal blocks.

3.2.2.3 Alarm status

Alarm status is represented by a LED, which is RED when activated.
The LED status reflects the status of the Alarm exactly as configured.

3.2.2.4 Faults

Each Fault status is represented by a LED, which is RED when activated.

Note that the LED status does not take into account the current module configuration, therefore it only indicates the existence of the fault condition, independently from any configured behavior in case of fault.

3.2.2.5 Graph

The graph can show only one variable that must be chosen from the checkboxes above.

3.2.3 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals.

By changing the parameters, the user can decide the duration of the recording period and the frequency of readings.

After pressing "Start" button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format.

Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.




Figure 18: Data Logger screen.

3.3 D5072S/D6072S, D5072D/D6072D, D5273S/D6273S (from software revision 3 up to 4)

D5072S, D5072D, D5273S, D6072S, D6072D, D6273S are Universal Converters and share the same screens, except for the number of input, output and alarm channels.

The Application Window user interface is organized into the following areas:

- **Configuration**
 - Input
 - Output
 - Alarm
- **Monitor**
- **Data Logger**

3.3.1 Configuration

3.3.1.1 Input




Figure 19: D5072D / D6072D Input configuration screen.

INPUT

Sensor family:

- TC
- RTD
- Voltage
- Resistance
- Potentiometer

Sensor Type: input sensor type (see list in section “Input specifications”)
possibility of configuring a completely customized input curve (TC/RTD)

Sensor connection: 2, 3, 4 wires selection for RTD/Resistance inputs
2 wires or External compensator selection for TC
3 wires selection for potentiometer

Downscale: input value of measuring range corresponding to defined low output value

Upscale: input value of measuring range corresponding to defined high output value

Cold Junction Source: reference junction compensation type (thermocouple only)

- Internal via internal compensator (1 for each channel) for TC
- External via external compensator (1 for each channel) for TC
- Fixed programmable temperature compensation at fixed temperature
- Other remote compensation using RTD on remaining channel (only for “D” variants)

Cold Junction Reference: fixed temperature compensation value (Cold Junction type Fixed only), range from -60 to +100 °C.

Cable resistance: available only for RTD and resistance sensors. Configurable from 0 to 50 Ω

External compensator: compensation using RTD, Callendar Van Dusen or custom curve.

Integration speed:

- Slow
- Fast

Multiplier: input multiplication value

Tag: 16 alphanumeric characters

Note: Downscale and Upscale settings should follow Minimum Span requirements stated in the data sheet, in order to avoid negative impacts on Output resolution.

3.3.1.2 Output




Figure 20: D5072D / D6072D Output configuration screen.

OUTPUT

Function:

- Temp 1 analog output represents input of first channel
- Temp 2 analog output represents input of second channel
- Temp 1 - 2 analog output represents the subtraction of the two input channels
- Temp 2 - 1 analog output represents the subtraction of the two input channels
- Temp mean represents the inputs mean value.
- Minimum analog output represents the lower of the two input channels
- Maximum analog output represents the higher of the two input channels
- Redundancy When both sensors are available (no burnout condition) the input value represents the mean value of inputs. In case of one of them go on burnout condition, the input value represents the only working sensor.
- Value 1 analog output represents input of first channel (Not available only for TC\RTD sensors)
- Value 2 analog output represents input of second channel (Not available only for TC\RTD sensors)

Drive: Source, Sink mode.

Type:

- 4-20 mA Low
- 4-20 mA High
- 0-20mA High
- 4-20 mA NE43 Low, NAMUR RECOMMENDATION
- 4-20 mA NE43 High, NAMUR RECOMMENDATION
- Custom Scale: all Output parameters are fully customizable

Damping factor: causes conventional single-pole low pass filtering which is similar to an R-C network. Although high damping values will greatly suppress noise and make the output signal stable, it causes a slow response time.

Downscale: analog output downscale in normal working condition (range 0 to 24 mA)

Upscale: analog output downscale in normal working condition (range 0 to 24 mA)

Under range: analog output downscale in under range condition (range 0 to 24 mA)

Overrange: analog output downscale in overrange condition (range 0 to 24 mA)

Fault Output Value: analog output value in case of fault condition (range 0 to 24 mA)

Fault: analog output is forced to “Fault Output Value” in case of:

- Burnout input sensor interruption
- Internal fault module internal fault
- Cold junction
- Cable resistance when resistance value is higher than 50 Ω
- Sensor out of range input sensor out of configured input range
- Output Saturation output is below Under range or above Overrange

3.3.1.3 Alarm




Figure 21: D5072D/D6072D alarm configuration screen.

ALARM

Type:

- None alarm is disabled
- Low alarm is triggered when source descends below “Low Set”
- High alarm is triggered when source ascends over “High Set”
- Window alarm is triggered below “Low Set” and above “High Set”
- Fault Repeater alarm output reflects selected (one or more) Fault status

Function:

- Temp 1 analog output represents input of first channel
- Temp 2 analog output represents input of second channel
- Temp 1 - 2 analog output represents the subtraction of the two input channels
- Temp 2 - 1 analog output represents the subtraction of the two input channels
- Temp mean represents the inputs mean value.
- Minimum analog output represents the lower of the two input channels
- Maximum) analog output represents the higher of the two input channels
- Redundancy When both sensors are available (no burnout condition) the input value represents the mean value of inputs. In case of one of them go on burnout condition, the input value represents the only working sensor.
- Value 1 analog output represents input of first channel (Not available only for TC\RTD sensors)
- Value 2 analog output represents input of second channel (Not available only for TC\RTD sensors)

Alarm lock: alarm is inhibited until source ascends over “Low Set or descends below “High Set, and then it behaves as a standard “Low” or “High” configuration

NO Contact position in alarm:

- Open alarm output is normally Open in case of alarm condition
- Closed alarm output is normally Closed in case of alarm condition

Low Set: source value at which the alarm is triggered (in Low, Low Lock, Window)

Low Hysteresis: triggered Low alarm deactivates when source value reaches Low Set + Low Hysteresis

High Set: source value at which the alarm is triggered (in High, High Lock, Window)

High Hysteresis: triggered High alarm deactivates when source value reaches High Set - High Hysteresis

On Delay: time for which the source variable has to be in alarm condition before the alarm output is triggered; configurable from 0 to 1000 seconds in steps of 100 ms

Off Delay: time for which the source variable has to be in normal condition before the alarm output is deactivated; configurable from 0 to 1000 seconds in steps of 100 ms

In case of fault:

- Ignore alarm is not affected
- Lock alarm remains in the same status as it was before Fault occurred
- Alarm active alarm is triggered,
- Alarm inactive alarm is deactivated

Faults: if "Type" is set to "Fault repeater" select which faults will be repeated by alarm output; if "In case of fault" is different from "Ignore", select which faults should influence alarm output behavior.

3.3.2 Monitor

The SWC5090 is able to continuously scan the module and display real-time values on screen.

Note that while the module is being monitored, configuration screens are disabled.




Figure 22: D5072D/D6072D Monitor screen.

The display shows Input and Theoretical Output values, fault and alarm status and a graph of chosen variable.

3.3.2.1 Input

Input variable is shown as it is detected by the module, after having applied configured calculations (Multiplier) and conversions.

3.3.2.2 Output

This value represents the theoretical output. During certain conditions, this value may differ from the measured value at output terminal blocks.

3.3.2.3 Alarm status

Alarm status is represented by a LED, which is RED when activated.

The LED status reflects the status of the Alarm exactly as configured.

3.3.2.4 Faults

Each Fault status is represented by a LED, which is RED when activated.

Note that the LED status does not take into account the current module configuration, therefore it only indicates the existence of the fault condition, independently from any configured behavior in case of fault.

3.3.3 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals.

By changing the parameters, the user can decide the duration of the recording period and the frequency of readings.

After pressing “Start” button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format.

Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.




Figure 23: Data Logger screen.

3.4 D5072S/D6072S, D5072D/D6072D, D5273S/D6273S (from software revision 5)

D5072S, D5072D, D5273S, D6072S, D6072D, D6273S are Universal Converters and share the same screens, except for the number of input, output and alarm channels.

The Application Window user interface is organized into the following areas:

- **Configuration**
 - Input
 - Output
 - Alarm
- **Monitor**
- **Data Logger**

3.4.1 Configuration

3.4.1.1 Input




Figure 24: D5072D / D6072D Input configuration screen.

INPUT

Sensor family:

- TC
- RTD
- Voltage
- Resistance
- Potentiometer

Sensor Type: input sensor type (see list in section “Input specifications”)
possibility of configuring a completely customized input curve (TC/RTD)

Sensor connection: 2, 3, 4 wires selection for RTD/Resistance inputs
2 wires or External compensator selection for TC
3 wires selection for potentiometer

Downscale: input value of measuring range corresponding to defined low output value

Upscale: input value of measuring range corresponding to defined high output value

Cold Junction Source: reference junction compensation type (thermocouple only)

- Internal via internal compensator (1 for each channel) for TC
- External remote via external compensator (1 for each channel) for TC, when placed away, typically on a support terminal board connected to the module with copper wire;
- External local via external compensator (1 for each channel) for TC, when placed close to the module terminal block
- Fixed programmable temperature compensation at fixed temperature
- Other remote compensation using RTD on remaining channel (only for “D” variants)

Cold Junction Reference: fixed temperature compensation value (Cold Junction type Fixed only), range from -60 to +100 °C.

Cable resistance: available only for RTD and resistance sensors. Configurable from 0 to 50 Ω

External compensator: compensation using RTD, Callendar Van Dusen or custom curve.

Integration speed:

- Slow
- Fast

Multiplier: input multiplication value

Tag: 16 alphanumerical characters

Note: Downscale and Upscale settings should follow Minimum Span requirements stated in the data sheet, in order to avoid negative impacts on Output resolution.

3.4.1.2 Output




Figure 25: D5072D / D6072D Output configuration screen.

OUTPUT

Function:

- Temp 1 analog output represents input of first channel
- Temp 2 analog output represents input of second channel
- Temp 1 - 2 analog output represents the subtraction of the two input channels
- Temp 2 - 1 analog output represents the subtraction of the two input channels
- Temp mean represents the inputs mean value.
- Minimum analog output represents the lower of the two input channels
- Maximum analog output represents the higher of the two input channels
- Redundancy When both sensors are available (no burnout condition) the input value represents the mean value of inputs. In case of one of them go on burnout condition, the input value represents the only working sensor.
- Value 1 analog output represents input of first channel (Not available only for TC\RTD sensors)
- Value 2 analog output represents input of second channel (Not available only for TC\RTD sensors)

Drive: Source, Sink mode.

Type:

- 4-20 mA Low
- 4-20 mA High
- 0-20mA High
- 4-20 mA NE43 Low, NAMUR RECOMMENDATION
- 4-20 mA NE43 High, NAMUR RECOMMENDATION
- Custom Scale: all Output parameters are fully customizable

Damping factor: causes conventional single-pole low pass filtering which is similar to an R-C network. Although high damping values will greatly suppress noise and make the output signal stable, it causes a slow response time.

Downscale: analog output downscale in normal working condition (range 0 to 24 mA)

Upscale: analog output downscale in normal working condition (range 0 to 24 mA)

Under range: analog output downscale in under range condition (range 0 to 24 mA)

Overrange: analog output downscale in overrange condition (range 0 to 24 mA)

Fault Output Value: analog output value in case of fault condition (range 0 to 24 mA)

Fault: analog output is forced to “Fault Output Value” in case of:

- Burnout input sensor interruption
- Internal fault module internal fault
- Cold junction
- Cable resistance when resistance value is higher than 50 Ω
- Sensor out of range input sensor out of configured input range
- Output Saturation output is below Under range or above Overrange

3.4.1.3 Alarm




Figure 26: D5072D/D6072D alarm configuration screen.

ALARM

Type:

- None alarm is disabled
- Low alarm is triggered when source descends below “Low Set”
- High alarm is triggered when source ascends over “High Set”
- Window alarm is triggered below “Low Set” and above “High Set”
- Fault Repeater alarm output reflects selected (one or more) Fault status

Function:

- Temp 1 analog output represents input of first channel
- Temp 2 analog output represents input of second channel
- Temp 1 - 2 analog output represents the subtraction of the two input channels
- Temp 2 - 1 analog output represents the subtraction of the two input channels
- Temp mean represents the inputs mean value.
- Minimum analog output represents the lower of the two input channels
- Maximum analog output represents the higher of the two input channels
- Redundancy When both sensors are available (no burnout condition) the input value represents the mean value of inputs. In case of one of them go on burnout condition, the input value represents the only working sensor.
- Value 1 analog output represents input of first channel (Not available only for TC\RTD sensors)
- Value 2 analog output represents input of second channel (Not available only for TC\RTD sensors)

Alarm lock: alarm is inhibited until source ascends over “Low Set or descends below “High Set, and then it behaves as a standard “Low” or “High” configuration

NO Contact position in alarm:

- Open alarm output is normally Open in case of alarm condition

- Closed alarm output is normally Closed in case of alarm condition

Low Set: source value at which the alarm is triggered (in Low, Low Lock, Window)

Low Hysteresis: triggered Low alarm deactivates when source value reaches Low Set + Low Hysteresis

High Set: source value at which the alarm is triggered (in High, High Lock, Window)

High Hysteresis: triggered High alarm deactivates when source value reaches High Set - High Hysteresis

On Delay: time for which the source variable has to be in alarm condition before the alarm output is triggered; configurable from 0 to 1000 seconds in steps of 100 ms

Off Delay: time for which the source variable has to be in normal condition before the alarm output is deactivated; configurable from 0 to 1000 seconds in steps of 100 ms

In case of fault:

- Ignore alarm is not affected
- Lock alarm remains in the same status as it was before Fault occurred
- Alarm active alarm is triggered,
- Alarm inactive alarm is deactivated

Faults: if "Type" is set to "Fault repeater" select which faults will be repeated by alarm output; if "In case of fault" is different from "Ignore", select which faults should influence alarm output behavior.

3.4.2 Monitor

The SWC5090 is able to continuously scan the module and display real-time values on screen.

Note that while the module is being monitored, configuration screens are disabled.




Figure 27: D5072D/D6072D Monitor screen.

The display shows Input and Theoretical Output values, fault and alarm status and a graph of chosen variable.

3.4.2.1 Input

Input variable is shown as it is detected by the module, after having applied configured calculations (Multiplier) and conversions.

3.4.2.2 Output

This value represents the theoretical output. During certain conditions, this value may differ from the measured value at output terminal blocks.

3.4.2.3 Alarm status

Alarm status is represented by a LED, which is RED when activated.

The LED status reflects the status of the Alarm exactly as configured.

3.4.2.4 Faults

Each Fault status is represented by a LED, which is RED when activated.

Note that the LED status does not take into account the current module configuration, therefore it only indicates the existence of the fault condition, independently from any configured behavior in case of fault.

3.4.3 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals.

By changing the parameters, the user can decide the duration of the recording period and the frequency of readings.

After pressing “Start” button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format.

Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.




Figure 28: Data Logger screen.

3.5 D5072S-087/D6072S-087, D5072D-087/D6072D-087 (from software revision 3)

D5072S-087, D5072D-087 are Universal Repeaters and share the same screens, except for the number of input, output and alarm channels.

The Application Window user interface is organized into the following areas:

- **Configuration**
 - **Input / Output**
- **Monitor**
- **Data Logger**

3.5.1 Configuration

3.5.1.1 Input




Figure 29: D5072D-087 Input / Output configuration screen.

INPUT

Sensor connection: 2, 3, 4 wires selection

Input / Output function:

- Linear standard: output reflects the input signal (standard range)
- Linear extended: output reflects the input signal (extended range)
- Custom: possibility of configuring a completely customized input curve

Burnout:

- Active: when selected burnout fault condition is triggered
- Inactive: when selected burnout fault condition is not triggered

Multiplier: input multiplication value

Cable resistance: configurable from 0 to 50 Ω

Tag: 16 alphanumeric characters

Output Integration speed:

- Slow
- Fast

Fault condition:

- Internal fault: module internal fault
- Burnout: input sensor interruption

Input Integration speed:

- Slow
- Fast

Output duplication:

- Active/inactive: when selected, it disables Input 2 and Output 2 configuration

3.5.2 Monitor

The SWC5090 is able to continuously scan the module and display real-time values on screen.

Note that while the module is being monitored, configuration screens are disabled.




Figure 30: D5072D-087 Monitor screen.

The display shows Field values and Fault status.

3.5.2.1 Field values

Field values represent heads measured values and theoretical outputs.

3.5.2.2 Faults

Each Fault status is represented by a LED, which is RED when activated.

Note that the LED status does not take into account the current module configuration, therefore it only indicates the existence of the fault condition, independently from any configured behavior in case of fault.

3.5.3 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals.

By changing the parameters, the user can decide the duration of the recording period and the frequency of readings.

After pressing “Start” button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format.

Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.




Figure 31: Data Logger screen.

3.6 D5072S-096/D6072S-096, D5072D-096/D6072D-096

D5072S-096, D5072D-096 are Universal Repeaters and share the same screens, except for the number of input, output and alarm channels.

The Application Window user interface is organized into the following areas:

- **Configuration**
 - **Input / Output**
- **Monitor**
- **Data Logger**

3.6.1 Configuration

3.6.1.1 Input




Figure 32: D5072D-096 Input / Output configuration screen.

INPUT

Input / Output function:

- **Linear:** output reflects the input signal
- **Custom:** possibility of configuring a completely customized input curve(Thermocouple)
- **Thermocouple:** input sensor type(see list in section “Input specifications”)

Burnout

- **Active:** when selected burnout fault condition is triggered
- **Inactive:** when selected burnout fault condition is not triggered

Cold junction source:

- **Internal:** via internal compensator (1 for each channel)
- **External:** programmable temperature compensation at fixed temperature

Cold Junction Reference: fixed temperature compensation value (Cold Junction type Fixed only), range from -60 to +100 °C.

Tag: 16 alphanumerical characters

Integration speed:

- **Slow**
- **Fast**

Fault condition:

- **Internal fault:** module internal fault
- **Burnout:** input sensor interruption

3.6.2 Monitor

The SWC5090 is able to continuously scan the module and display real-time values on screen.
Note that while the module is being monitored, configuration screens are disabled.




Figure 33: D5072D-096 Monitor screen.

The display shows Field values and Fault status.

3.6.2.1 Field values

Field values represent heads measured values and theoretical outputs.

3.6.2.2 Faults

Each Fault status is represented by a LED, which is RED when activated.

Note that the LED status does not take into account the current module configuration, therefore it only indicates the existence of the fault condition, independently from any configured behavior in case of fault.

3.6.3 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals.

By changing the parameters, the user can decide the duration of the recording period and the frequency of readings.

After pressing “Start” button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format.

Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.




Figure 34: Data Logger screen.

3.7 D5231E / D6231E (up to software revision 0)

D5231E is an intrinsically safe eight channel Switch/Proximity detector repeater interface.

Modbus RTU RS-485 output is available on Bus connector.

The Application Window user interface is organized into the following areas:

- **Configuration**
- **Monitor**
- **Data Logger**

3.7.1 Configuration




Figure 35: D5231E / D6231E input (on the left) and output (on the right) configuration screen.

Configuration parameters can be read and written from the module or from saved file. It is also possible to reset the module configuration to factory default settings. A report sheet containing complete configuration can be printed.

INPUTS 1 to 8:

- **Sensor Type:**
 - Proximity
 - Dry Contact

Note: To enable line diagnostic on Voltage free contacts, follow instructions in Section “Operation” of Instruction Manual ISM0172 and configure sensor as “Proximity”.

TAGS 1 to 8:

16 alphanumerical characters

OUTPUTS 1 to 8:

- **Source:**
 - Input 1 Output represents Input 1
 - Input 2 Output represents Input 2
 - Input 3 Output represents Input 3
 - Input 4 Output represents Input 4
 - Input 5 Output represents Input 5
 - Input 6 Output represents Input 6
 - Input 7 Output represents Input 7
 - Input 8 Output represents Input 8
 - Logical function Output represents AND/OR function of selected inputs
 - Cumulative fault: Output represents OR function of selected inputs fault conditions
- **Contact: normal condition of output contact**
 - Open
 - Closed

- **In case of fault:**
 - Ignore
 - Open
 - Closed
- **Fault repeater:** Output represents Input Fault status
- **Logical Function:** visible only when selected in “Output source”
Allows the logical binding of 2 or more (up to 8) Inputs.
 - AND Output represents AND logical function of selected Inputs,
 - OR Output represents OR logical function of selected Inputs.

3.7.2 Monitor

The SWC5090 is able to continuously scan the module and display real-time values on screen.
Note that while the module is being monitored, configuration screens are disabled.




Figure 36: D5231E / D6231E Monitor screen.

INPUT STATUS:

- The status of each input is shown
 - Open circuit Open circuit fault (only for Proximity Inputs)
 - Off Off
 - On On
 - Short circuit Short circuit fault (only for Proximity Inputs)

OUTPUT STATUS:

- The status of each output contact is shown
 - Open
 - Closed

3.7.3 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals.
By changing the parameters, the user can decide the duration of the recording period and the frequency of readings.
After pressing “Start” button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format.
Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.




Figure 37: Data Logger screen.

PARAMETERS SETUP:

- **Days:** Number of days to acquire
- **Hours:** Number of hours to acquire
- **Minutes:** Number of minutes to acquire
- **Scan rate:** Frequency interval for acquisitions

3.8 D5231E / D6231E (from software revision 1)

D5231E is an intrinsically safe eight channel Switch/Proximity detector repeater interface.

Modbus RTU RS-485 output is available on Bus connector.

The Application Window user interface is organized into the following areas:

- **Configuration**
- **Monitor**
- **Data Logger**

3.8.1 Configuration





Figure 38: D5231E / D6231E input (on the left) and output (on the right) configuration screen.




Figure 39: D5231E / D6231E custom function selection.






Figure 40: D5231E / D6231E custom function configuration.



Configuration parameters can be read and written from the module or from saved file. It is also possible to reset the module configuration to factory default settings. A report sheet containing complete configuration can be printed.

INPUTS 1 to 8:

- **Sensor Type:**
 - Proximity
 - Dry Contact

Note: To enable line diagnostic on Voltage free contacts, follow instructions in Section “Operation” of Instruction Manual ISM0172 and configure sensor as “Proximity”.

TAGS 1 to 8:

16 alphanumeric characters

OUTPUTS 1 to 8:

- **Source:**
 - Input 1 Output represents Input 1
 - Input 2 Output represents Input 2
 - Input 3 Output represents Input 3
 - Input 4 Output represents Input 4
 - Input 5 Output represents Input 5
 - Input 6 Output represents Input 6
 - Input 7 Output represents Input 7

- Input 8 Output represents Input 8
- Logical function Output represents AND/OR function of selected inputs
- Cumulative fault: Output represents OR function of selected inputs fault conditions
- Custom function: Output is fully configurable by user and its behavior depends of the logical configuration of the selected inputs.
- **Contact: normal condition of output contact**
 - Open
 - Closed
- **In case of fault:**
 - Ignore
 - Open
 - Closed
- **Fault repeater:** Output represents Input Fault status
- **Logical Function:** visible only when selected in “Output source”
Allows the logical binding of 2 or more (up to 8) Inputs.
 - AND Output represents AND logical function of selected Inputs,
 - OR Output represents OR logical function of selected Inputs.
- **Custom Function (Configuration procedure):**
 - Select from Output Source “Custom Function”
 - Click the “VIEW TABLE” button to open the configuration panel
 - Click the “ADD OR REMOVE INPUTS” to modify the inputs used in custom function
 - Click the “UPDATE TABLE” to open the logical truth table, then modify the value (0 or 1) in the output column corresponding to the inputs values configuration.
 - Click the “IMPORT CHANGES” to save the truth table.

3.8.2 Monitor

The SWC5090 is able to continuously scan the module and display real-time values on screen.
Note that while the module is being monitored, configuration screens are disabled.




Figure 41: D5231E / D6231E Monitor screen.

INPUT STATUS:

- The status of each input is shown
 - Open circuit Open circuit fault (only for Proximity Inputs)

- Off Off
- On On
- Short circuit Short circuit fault (only for Proximity Inputs)

OUTPUT STATUS:

- The status of each output contact is shown
 - Open
 - Closed

3.8.3 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals. By changing the parameters, the user can decide the duration of the recording period and the frequency of readings. After pressing “Start” button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format. Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.




Figure 42: Data Logger screen.

PARAMETERS SETUP:

- **Days:** Number of days to acquire
- **Hours:** Number of hours to acquire
- **Minutes:** Number of minutes to acquire
- **Scan rate:** Frequency interval for acquisitions

3.9 D5240T

Note: Software revision of the module can be found by clicking on “Module > Show identification > Software revision”.

D5240T is a Digital Output Isolator, suitable for driving solenoid valves, visual or audible alarms or other process control devices in Hazardous Area.

The Application Window user interface is organized into the following areas:

- **Configuration**
- **Data Logger**

3.9.1 Configuration




Figure 43: D5240T configuration screen.

Configuration parameters can be read and written from the module or from saved file. It is also possible to reset the module configuration to factory default settings. A report sheet containing complete configuration can be printed.

TAG: Identification of the specific operating loop of the module.

External inputs status: Status of each Input channel is indicated in the related field.

Outputs configuration: Each Output can be configured to be driven by an independent Input, or by its opposite.

D5240T Input can be Hardware (via Terminal blocks) and/or Software (via Modbus). Both types can be used to drive the Output. For Software input see next Section.

Hardware input:

Output 1 to 3:

- Input1: Output represents Input1
- Input2 :Output represents Input2
- Input3: Output represents Input3
- Not Input1: Output represents Not Input1 *
- Not Input2 :Output represents Not Input2 *
- Not Input3: Output represents Not Input3 *

* Note: example: Input = 1; Output = 0




Figure 44: D5240T Advanced configuration options.

ADVANCED OPTIONS:

Advanced options for configuration can be found by clicking on the “Module > Advanced Options” entry of the main menu. Hardware and Software Input can be logically combined to drive the Output.

Hardware Input	Logical function	Software Input	Output
0	AND	0	0
0	AND	1	0
1	AND	0	0
1	AND	1	1
0	OR	0	0
0	OR	1	1
1	OR	0	1
1	OR	1	1

Note: Selecting “Not Input” changes Input to opposite state (1 to 0; 0 to 1).

Note: Only when the selected Modbus input is different from “None”, the hardware input can be set to “None”.

3.9.2 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals. By changing the parameters, the user can decide the duration of the recording period and the frequency of readings. After pressing “Start” button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format. Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.




Figure 45: Data Logger screen.

PARAMETERS SETUP:

Days: Number of days to acquire

Hours: Number of hours to acquire

Minutes: Number of minutes to acquire

Scan rate: Frequency interval for acquisitions

3.10 D5293S, D5294S (software revision 0)

Note: Software revision of the module can be found by clicking on “Module > Show identification > Software revision”.

The D5293S-D5294S Application Window user interface is organized into three Tabs:

- **Configuration**
 - User Manual Settings
 - Fault Conditions Monitoring
 - Tag
 - Acquire Functions
 - Continuous Scan
- **Monitor**
 - Measured Values
 - Graph
- **Data Logger**

3.10.1 Configuration

3.10.1.1 Continuous Scan




Figure 46: Continuous Scan box.

By pressing the **“Start”** button in the **Continuous Scan** box (see Figure 46), the module starts acquiring the data field (in the **Measured Values**) periodically. To interrupt data acquisition press the same button – this time the label will be **“Stop”** – shall be pressed.

3.10.1.2 Tag




Figure 47: Tag box.

The **Tag** (see Figure 47) provides a label that can be associated to the specific loop.

3.10.1.3 User Manual Settings




Figure 48: User Manual Settings box.

User Manual Settings (see Figure 48) can partially be acquired through the **Acquire Functions** and/or changed manually before being written to the D5293S/D5294S module through the **“Write to Module”** button on the Menu Bar.

User Manual Settings include:

- **Load Supply Voltage RMS (V)**
indicates the RMS voltage that is actually applied (in ON State, load energized) or that will be applied (in OFF State, load de-energized) to the load.
- **Load Current RMS (A)**
represents the RMS current that is flowing through the load (hence it will be zero in OFF state).
- **Load OFF Resistance (Ω)**
is the load resistance measured in OFF State. In ON State, this value will remain at the saturation value (5 k Ω)
- **Isolation Resistance (k Ω)**
shows the leakage resistance to earth. Also the Isolation Resistance is measured only in OFF State; during ON State, it goes to the saturation value of 3 M Ω
- **Coil Integrity**
monitors the status of the relay coil in ON State: “FAIL” indicates that a relay coil is in short-circuit
- **Driver Status**

indicates whether the load has been energized ("ON") or not ("OFF")

User Manual Settings specify nominal values and limits that will activate the fault indication (red LED and two fault relay contacts). See Section 3.10.1.4 for more details.

Remember that only after pressing the "**Write to Module**" button on the Menu Bar **User Manual Settings** and **Fault Conditions Monitoring** become effective.

See Section 3.10.1.4 for an explanation of the color indicators on the left.

3.10.1.4 Fault Conditions Monitoring




Figure 49: Fault Conditions Monitoring box.

Fault Conditions Monitoring (see Figure 49) indicate which subset of the User Manual Settings shall activate the fault. Therefore:

- If *Load Supply Voltage* is enabled, a measured *Load Supply Voltage RMS* outside the specified limits will activate the fault.
- If *Load Current* is enabled, a measured *Load Current RMS* outside the specified limits will activate the fault.
- If *Load OFF Resistance* is enabled, a measured *Load OFF Resistance* outside the specified limits shall activate the fault.
- If *Isolation Resistance* is enabled, only a measured *Isolation Resistance* below the specified limit shall activate the fault.
- If *Coil Integrity* is enabled, a coil short circuit in ON state shall activate the fault.

Note that, by activating the monitoring of a fault condition, the related color indicator on the left side becomes brighter together with the corresponding measured value and user manual settings. This color policy allows a fast identification of the quantities that contribute to the fault activation.

Fault Conditions Monitoring are combined with the **Driver Status**. While the *Load Supply Voltage RMS* can always be effective, the *Load Current RMS* and *Coil Integrity* can be active only during the ON State, whereas the *Load OFF Resistance* and the *Isolation Resistance* only during the OFF State.

Note also that only after pressing the "**Write to Module**" button on the Menu Bar the **User Manual Settings** and the **Fault Conditions Monitoring** will be saved onto the module, hence becoming effective.

3.4.1.5 Fault Activation

The fault is activated if at least one of the following conditions are met:

- *Load Supply Voltage* Monitoring is enabled AND
((*Load Supply Voltage RMS* < *Load Supply Voltage RMS* Nominal – *Supply Voltage Limits*) OR
(*Load Supply Voltage RMS* > *Load Supply Voltage RMS* Nominal + *Supply Voltage Limits*))
- *Load Current* Monitoring is enabled AND the load is Activated AND
((*Load Current RMS* < *Load Current RMS* Nominal - *Load Current Limits*) OR
(*Load Current RMS* > *Load Current RMS* Nominal + *Load Current Limits*))
- *Load OFF Resistance* Monitoring is enabled AND the load is De-activated AND
((*Load OFF Resistance* < *Load OFF Resistance* Nominal – *Load OFF Resistance Limits*) OR
(*Load OFF Resistance* > *Load OFF Resistance* Nominal + *Load OFF Resistance Limits*))

- *Isolation Resistance Monitoring* is enabled AND the load is De-activated AND (*Isolation Resistance* < *Isolation Resistance Nominal* - *Isolation Resistance Limit*)
- *Coil Integrity Monitoring* is enabled AND the load is Activated AND *Coil Integrity* is *FAIL*.

Active Monitoring	Driver Status					
	OFF State			ON State		
Load Supply Voltage	$V_{\text{meas}} < V_{\text{nom}} - V_{\text{lim}}$	$V_{\text{nom}} - V_{\text{lim}} \leq V_{\text{meas}}$ or $V_{\text{meas}} \leq V_{\text{nom}} + V_{\text{lim}}$	$V_{\text{nom}} + V_{\text{lim}} < V_{\text{meas}}$	$V_{\text{meas}} < V_{\text{nom}} - V_{\text{lim}}$	$V_{\text{nom}} - V_{\text{lim}} \leq V_{\text{meas}}$ or $V_{\text{meas}} \leq V_{\text{nom}} + V_{\text{lim}}$	$V_{\text{nom}} + V_{\text{lim}} < V_{\text{meas}}$
Load Current	Not applicable			$I_{\text{meas}} < I_{\text{nom}} - I_{\text{lim}}$	$I_{\text{nom}} - I_{\text{lim}} \leq I_{\text{meas}}$ or $I_{\text{meas}} \leq I_{\text{nom}} + I_{\text{lim}}$	$I_{\text{nom}} + I_{\text{lim}} < I_{\text{meas}}$
Load OFF Resistance	$R_{\text{meas}} < R_{\text{nom}} - R_{\text{lim}}$	$R_{\text{nom}} - R_{\text{lim}} \leq R_{\text{meas}}$ or $R_{\text{meas}} \leq R_{\text{nom}} + R_{\text{lim}}$	$R_{\text{nom}} + R_{\text{lim}} < R_{\text{meas}}$	Not applicable		
Isolation Resistance	$R_{\text{meas}} < R_{\text{nom}} - R_{\text{lim}}$	$R_{\text{nom}} - R_{\text{lim}} \leq R_{\text{meas}}$		Not applicable		
Coil Integrity	Not applicable			FAIL		OK

Table 1: Combination of Monitoring functions activation with Driver Status.

Table 1 shows how the activation of the various Monitoring functions combines with the Driver Status: a red cell indicates that the fault can be activated, while a green cell indicates that the fault cannot be activated.

Note again that only after pressing the “**Write to Module**” button on the Menu Bar, the **User Manual Settings** and **Fault Conditions Monitoring** will be exported to the module, hence becoming effective.

When the fault is activated, the red LED is lighted and the two fault relays open. On the Application Window the **Measured Values** that caused the fault turn red.

3.10.1.5 Acquire Functions




Figure 50: Acquire Functions box.

The **Acquire Functions** (see Figure 50) allows the user to acquire the **Measured Values** to the **User Manual Settings**. These functions ease the user's task, while avoiding that the technical details (supply voltage, load current, load resistance, etc.) of the application are necessary for the module configuration. If the load is de-energized (OFF State), the “**Acquire OFF parameters**” button will copy the *Load Supply Voltage RMS* and the *Load OFF Resistance* to the corresponding **User Manual Settings**. If the load is energized (ON State), the “**Acquire ON parameters**” button will copy the *Load Supply Voltage RMS* and the *Load Current RMS* to the corresponding **User Manual Settings**.

Note that the data acquisition button can be pressed only when the continuous scan is active, hence avoiding to acquire outdated field values.

3.10.2 Monitor

3.10.2.1 Measured Values




Figure 51: Monitor Tab.

Measured Values (see Figure 51) are periodically acquired from the field, when the Start/Stop is activated (odometer running in the Bottom Bar). When the Start/Stop button is deactivated, the **Measured Values** remain frozen to the last field acquisition value.

Measured Values include:

- **Load Supply Voltage RMS (V)**
indicates the RMS voltage that is actually applied (in ON State, load energized) or that will be applied (in OFF State, load de-energized) to the load.
- **Load Current RMS (A)**
represents the RMS current that is flowing through the load (hence it will be zero in OFF state).
- **Load OFF Resistance (Ω)**
is the load resistance measured in OFF State. In ON State, this value will remain at the saturation value (5 kΩ)
- **Isolation Resistance (kΩ)**
shows the leakage resistance to earth. Also the Isolation Resistance is measured only in OFF State; during ON State, it goes to the saturation value of 3 MΩ
- **Coil Integrity**
monitors the status of the relay coil in ON State: "FAIL" indicates that a relay coil is in short-circuit
- **Driver Status**
indicates whether the load has been energized ("ON") or not ("OFF")

See Section 3.10.1.4 for the explanation of the color indicators on the left.

3.10.2.2 Graph

It is possible to show the value of a variable on a graph. To do so, start acquisition by pressing the Start button and then select the desired variable by checking the corresponding checkbox.

Note that only one variable can be seen at a time.

3.10.3 Examples and Applications

Detailed examples of D5293S and D5294S configurations and applications can be found in a dedicated application note APN0036 which can be found on our website [GM International](http://www.gmi.it)

3.11 D5293S (software revisions 1 and 2) *

Note: Software revision of the module can be found by clicking on “Module > Show identification > Software revision”.

The D5293S is a relay module suitable for the switching of safety related circuits, up to SIL 3 level according to IEC 61508:2010 Ed.2, for high risk industries.

The Application Window user interface is organized into the following areas:

- **Configuration**
- **Monitor**
- **Data Logger**

3.11.1 Configuration




Figure 52: D5293S Configuration screen.

Configuration parameters can be read and written from the module or from saved file.

It is also possible to reset the module configuration to factory default settings.

A report sheet containing complete configuration can be printed.

User Manual Settings:

Load Supply Voltage RMS

- Voltage Upper Limit (V): Maximum allowed load RMS voltage
- Voltage Lower Limit (V): Minimum allowed load RMS voltage

Load Current RMS

- Current Upper Limit (A): Maximum allowed load RMS current
- Current Lower Limit (A): Minimum allowed load RMS current

FAULT CONDITIONS MONITORING:

(Command Status [ON]): Faults contributing to the output cumulative fault when the driver is on.

FAULT CONDITIONS MONITORING:

(Command Status [OFF]): Faults contributing to the output cumulative fault when the driver is off.

- Load Supply Voltage: When checked, the load supply voltage can activate the cumulative fault.
- Load Current: When checked, the load current can activate the cumulative fault.
- Coil Integrity: When checked, the short circuit of any coil can activate the cumulative fault (only until **software revision 1**).

* For software revision n. 2, it is not possible to disable hysteresis and to check coil integrity.

TAG: Identification of the specific operating loop of the module.

ACQUIRE FUNCTIONS: Acquisition and saving of the diagnostics field parameters.

- Acquire OFF parameters: The currently measured OFF parameters are copied to the USER MANUAL SETTINGS (available only when the driver is OFF).
- Acquire ON parameters: The currently measured ON parameters are copied to the USER MANUAL SETTINGS (available only when the driver is ON).

CONTINUOUS SCAN: Continuous measurement of the field parameters.

- Start/Stop: Activates/de-activates the measurement of the field parameters.

INVERT FAULT RELAY: When not checked, the output fault contacts open in case of fault. When checked, the output fault contacts close in case of fault.

ADVANCED OPTIONS:

Advanced options for configuration can be found by clicking on the “Module > Advanced Options” entry of the main menu.




Figure 53: Advanced configuration options.

Load Interruption:




Figure 54: Bipolar (on the left) and unipolar (on the right) load interruption.

- Bipolar: Load is disconnected by removing connection to both AC/DC lines
- Unipolar: Load is disconnected only from one AC/DC line.

Input impedance:

- Mirror: The fault in the field is directly mirrored to the PLC DO.
- Always OFF: Input impedance seen by the PLC with Pulse Testing is always HIGH.

- Always ON: Input impedance seen by the PLC with Pulse Testing is always LOW.

3.11.1.1 Hysteresis (always visible since software revision 2):

Load Supply Voltage RMS		Load Current RMS	
- Voltage Upper Limit (V)	260.0	- Current Upper Limit (A)	4.000
- High hysteresis	20.0	- High hysteresis	0.200
- Voltage Lower Limit (V)	10.0	- Current Lower Limit (A)	0.005
- Low hysteresis	1.0	- Low hysteresis	0.001

Figure 55: D5293S with Hysteresis enabled.

- ON:**
 - Upper Fault condition is activated when signal is higher than Upper Limit and deactivates when lower than Upper Limit – High Hysteresis value.
 - Lower Fault condition is activated when signal is lower than Lower Limit and deactivates when higher than Lower Limit + Low Hysteresis value.
- OFF:** No hysteresis is present and fault conditions are triggered exactly when signal is higher or lower than defined limits.

3.11.2 Monitor

The SWC5090 is able to continuously scan the module and display real-time values on screen. Note that while the module is being monitored, configuration screens are disabled.




Figure 56: D5293S Monitor screen.

Measured Values (see Figure 56) are periodically acquired from the field, when the Start/Stop is activated (odometer running in the Bottom Bar). When the Start/Stop button is deactivated, the **Measured Values** remain frozen to the last field acquisition value.

Measured Values include:

- Load Supply Voltage RMS (V)**
indicates the RMS voltage that is actually applied (in ON State, load energized) or that will be applied (in OFF State, load de-energized) to the load.
- Load Current RMS (A)**
represents the RMS current that is flowing through the load (hence it will be zero in OFF state).

- **Coil Integrity**
monitors the status of the relay coil in ON State: “FAIL” indicates that a relay coil is in short-circuit
- **Driver Status**
indicates whether the load has been energized (“ON”) or not (“OFF”)

3.11.2.1 Graph

It is possible to show the value of a variable on a graph. To do so, start acquisition by pressing the Start button and then select the desired variable by checking the corresponding checkbox.

Note that only one variable can be seen at a time.

3.11.3 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals.

By changing the parameters, the user can decide the duration of the recording period and the frequency of readings.

After pressing “Start” button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format.

Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.




Figure 57: Data Logger screen.

PARAMETERS SETUP:

- **Days:** Number of days to acquire
- **Hours:** Number of hours to acquire
- **Minutes:** Number of minutes to acquire
- **Scan rate:** Frequency interval for acquisitions

3.12 D5294S, D5295S (software revisions 1 and 2) *

Note: Software revision of the module can be found by clicking on “Module > Show identification > Software revision”.

D5294S and D5295S are relay module suitable for the switching of safety related circuits, up to SIL 3 level according to IEC 61508:2010 Ed.2, for high risk industries.

The Application Window user interface is organized into the following areas:

- **Configuration**
- **Monitor**
- **Data Logger**

* For software revision n. 2, it is not possible to disable hysteresis.

3.12.1 Configuration




Figure 58: D5294S (on the left) and D5295S (on the right) configuration screen (software revision 1).




Figure 59: D5294S (on the left) and D5295S (on the right) configuration screen (software revision 2).

Configuration parameters can be read and written from the module or from saved file. It is also possible to reset the module configuration to factory default settings. A report sheet containing complete configuration can be printed.

User Manual Settings:

- Load Supply Voltage RMS
 - Voltage Upper Limit (V): Maximum allowed load RMS voltage
 - Voltage Lower Limit (V): Minimum allowed load RMS voltage
- Load Current RMS
 - Current Upper Limit (A): Maximum allowed load RMS current
 - Current Lower Limit (A): Minimum allowed load RMS current
- Load OFF Resistance
 - Resistance Upper Limit (Ω): Maximum allowed load OFF resistance
 - Resistance Lower Limit (Ω): Minimum allowed load OFF resistance
- Isolation Resistance
 - Resistance Lower Limit (k Ω): Minimum allowed load-to-earth isolation resistance

FAULT CONDITIONS MONITORING (Command Status [ON]):

Faults contributing to the output cumulative fault when the driver is on.

- Load Supply Voltage:
 - When checked, the load supply voltage can activate the cumulative fault.

- **Load Current:** (only for D5294S)
When checked, the load current can activate the cumulative fault.
- **Coil Integrity:**
When checked, the short circuit of any coil can activate the cumulative fault.
- **Load OFF Resistance:** (only for D5295S)
When checked, the load OFF resistance can activate the cumulative fault.
- **Isolation Resistance:** (only for D5295S)
When checked, the load-to-earth isolation resistance can activate the cumulative fault.

FAULT CONDITIONS MONITORING (Command Status [OFF]):

Faults contributing to the output cumulative fault when the driver is off.

- **Load Supply Voltage:**
When checked, the load supply voltage can activate the cumulative fault.
- **Load Current:** (only for D5295S)
When checked, the load current can activate the cumulative fault.
- **Load OFF Resistance:** (only for D5294S)
When checked, the load OFF resistance can activate the cumulative fault.
- **Isolation Resistance:** (only for D5294S)
When checked, the load-to-earth isolation resistance can activate the cumulative fault.

TAG: Identification of the specific operating loop of the module.

ACQUIRE FUNCTIONS: Acquisition and saving of the diagnostics field parameters.

- **Acquire OFF parameters:** The currently measured OFF parameters are copied to the USER MANUAL SETTINGS (available only when the driver is OFF).
- **Acquire ON parameters:** The currently measured ON parameters are copied to the USER MANUAL SETTINGS (available only when the driver is ON).

CONTINUOUS SCAN: Continuous measurement of the field parameters.

- **Start/Stop:** Activates/de-activates the measurement of the field parameters.

INVERT FAULT RELAY: When not checked, the output fault contacts open in case of fault. When checked, the output fault contacts close in case of fault.




Figure 60: D5294S, D5295S Advanced configuration options.

ADVANCED OPTIONS:

Advanced options for configuration can be found by clicking on the “Module > Advanced Options” entry of the main menu.

Load Type:

- **Auto:** automatically selects Load type between Generic Load and Solenoid.

- **Generic Load:** any load up to 50 k Ω resistance.
- **Solenoid:** specific for Solenoid loads up to 10 k Ω ; resistance is calculated even in presence of series connected diodes.

Load Interruption:




Figure 61: Bipolar (on the left) and unipolar (on the right) load interruption.

- **Bipolar:** Load is disconnected by removing connection to both AC/DC lines
- **Unipolar:** Load is disconnected only from one AC/DC line.

Input impedance:

- **Mirror:** The fault in the field is directly mirrored to the PLC DO.
- **Always OFF:** Input impedance seen by the PLC with Pulse Testing is always HIGH.
- **Always ON:** Input impedance seen by the PLC with Pulse Testing is always LOW.

3.12.1.1 Hysteresis (always visible since software revision 2):

User Manual Settings

Load Supply Voltage RMS

- Voltage Upper Limit (V) - High hysteresis

- Voltage Lower Limit (V) - Low hysteresis

Load OFF Resistance

- Resistance Upper Limit (Ω) - High hysteresis

- Resistance Lower Limit (Ω) - Low hysteresis

Load Current RMS

- Current Upper Limit (A) - High hysteresis

- Current Lower Limit (A) - Low hysteresis

Isolation Resistance

- Resistance Lower Limit (K Ω) - Low hysteresis

Figure 62: D5294S, D5295S with Hysteresis enabled.

- **ON:**
 - Upper Fault condition is activated when signal is higher than Upper Limit and deactivates when lower than Upper Limit – High Hysteresis value.
 - Lower Fault condition is activated when signal is lower than Lower Limit and deactivates when higher than Lower Limit + Low Hysteresis value.
- **OFF:**
 - No hysteresis is present and fault conditions are triggered exactly when signal is higher or lower than defined limits.

3.12.2 Monitor

The SWC5090 is able to continuously scan the module and display real-time values on screen.
Note that while the module is being monitored, configuration screens are disabled.




Figure 63: D5294S, D5295S Monitor screen.

Measured Values (see Figure 63) are periodically acquired from the field, when the Start/Stop is activated (odometer running in the Bottom Bar). When the Start/Stop button is deactivated, the Measured Values remain frozen to the last field acquisition value.

Measured Values include:

- **Load Supply Voltage RMS (V)**
indicates the RMS voltage that is actually applied (in ON State, load energized) or that will be applied (in OFF State, load de-energized) to the load.
- **Load Current RMS (A)**
represents the RMS current that is flowing through the load (hence it will be zero in OFF state).
- **Load OFF Resistance (Ω)**
is the load resistance measured in OFF State. In ON State, this value will remain at the saturation value (5 kΩ)
- **Isolation Resistance (kΩ)**
shows the leakage resistance to earth. Also the Isolation Resistance is measured only in OFF State; during ON State, it goes to the saturation value of 3 MΩ
- **Coil Integrity**
monitors the status of the relay coil in ON State: "FAIL" indicates that a relay coil is in short-circuit
- **Driver Status**
indicates whether the load has been energized ("ON") or not ("OFF")

3.12.2.1 Graph

It is possible to show the value of a variable on a graph. To do so, start acquisition by pressing the Start button and then select the desired variable by checking the corresponding checkbox.

Note that only one variable can be seen at a time.

3.12.3 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals.

By changing the parameters, the user can decide the duration of the recording period and the frequency of readings.

After pressing “Start” button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format.

Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.




Figure 64: Data Logger screen.

PARAMETERS SETUP:

- **Days:** Number of days to acquire
- **Hours:** Number of hours to acquire
- **Minutes:** Number of minutes to acquire
- **Scan rate:** Frequency interval for acquisitions

3.13 D5264S

D5264S is Load Cell/Strain Gauge Bridge Isolating Converter module suitable for applications requiring SIL 2 level (according to IEC 61511) in safety related systems for high risk industries.

The Application Window user interface is organized into the following areas:

- **Configuration**
 - Input
 - Output
 - Alarm
- **Monitor**
- **Data Logger**

3.13.1 Configuration

3.13.1.1 Input / Output




Figure 65: D5264S Input / output configuration screen.

INPUT

Conversion speed (Input data acquisition time):

- Slow: 100 ms
- Fast: 12.5 ms

Tag: 16 alphanumeric characters

Maximum weight: configurable from 0 to 100000 divisions. Higher values lead to greater resolutions.

Reference weight: weight used for calibration. Configurable from 0 to selected maximum weight.

Acquire Zero: press button to start the zero acquiring procedure.

Acquire Reference: press button to start reference acquiring procedure

Input range:

- Unipolar: the input scale ranges from 0 to the maximum value. This scale is particularly indicated to measure a weight.
- Bipolar: the input scale ranges from – to + maximum value. This scale is particularly indicated for other sensors, i.e. strain gauges.

OUTPUT

Type:

- 0-20 mA Sink
- 4-20 mA Sink
- Custom Sink
- 0-20 mA Source
- 4-20 mA Source
- Custom Source

All Output parameters are fully customizable.

All Output parameters are fully customizable.

Downscale: analog output downscale in normal working condition (range 0 to 24 mA)

Upscale: analog output downscale in normal working condition (range 0 to 24 mA)

Under range: analog output downscale in under range condition (range 0 to 24 mA)

Overrange: analog output downscale in overrange condition (range 0 to 24 mA)

3.13.1.2 Alarm




Figure 66: D5264S Alarm configuration screen.

ALARM

Configuration:

- None alarm is disabled
- Low alarm is triggered when source descends below “Low Set”
- High alarm is triggered when source ascends over “High Set”
- Window alarm is triggered below “Low Set” and above “High Set”

Contact position in case of alarm:

- Open: alarm output is closed under regular working conditions, and it opens in case of alarm
- Closed: alarm output is open under regular working conditions and it closes in case of alarm

Low Set: source value below which the alarm is triggered (in Low, Window)

Low Hysteresis: hysteresis on the low set value

High Set: source value above which the alarm is triggered (in High, Window)

High Hysteresis: hysteresis on the high set value

On Delay: time for which the source variable has to be in alarm condition before the alarm output is triggered; configurable from 0 to 1000 seconds in steps of 100 ms

Off Delay: time for which the source variable has to be in normal condition before the alarm output is deactivated; configurable from 0 to 1000 seconds in steps of 100 ms

3.13.2 Monitor

The SWC5090 is able to continuously scan the module and display real-time values on screen.

Note that while the module is being monitored, configuration screens are disabled.




Figure 67: D5264S Monitor screen.

The display shows Input and Theoretical Output values, fault and alarm status and a graph of chosen variable.

3.13.2.1 Input

Input variable is shown as it is detected by the module.

3.13.2.2 Output

This value represents the theoretical output. During certain conditions, this value may differ from the measured value at output terminal blocks.

3.13.2.3 Alarm status

Alarm status is represented by a LED, which is RED when activated.

The LED status reflects the status of the Alarm exactly as configured.

3.13.2.4 Graph

The graph can show only one variable that must be chosen from the checkboxes above.

3.13.3 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals.

By changing the parameters, the user can decide the duration of the recording period and the frequency of readings.

After pressing "Start" button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format.

Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.




Figure 68: Data Logger screen.

3.14 D5254S/D6254S

D5254S / D6254S is Power Supply Repeater and Trip Amplifier.

The Application Window user interface is organized into the following areas:

- **Configuration**
 - Input
 - Output
 - Alarm
- **Monitor**
- **Data Logger**

3.14.1 Configuration

3.14.1.1 Input / Output




Figure 69: D5254S / D6254S Input / output configuration screen.

INPUT

Input Type:

- current
- voltage

Range:

- 0/4-20 mA represents the allowed input current ranges
- ± 12 V represents the allowed input voltage ranges

Input conversion:

- Linear the module repeats in linear scale the input to the output
- Square root the module converts in square root scale the input to output

Out of range:

- Low threshold input value below which the fault is triggered
- High threshold input value above which the fault is triggered

Tag: 16 alphanumeric characters

OUTPUT

Type:

- 0-20 mA Sink
- 4-20 mA Sink
- Custom Sink all Output parameters are fully customizable
- 0-20 mA Source
- 4-20 mA Source
- Custom Source all Output parameters are fully customizable

Downscale

analog output downscale in normal working condition (range 0 to 24 mA)

Upscale

analog output upscale in normal working condition (range 0 to 24 mA)

Under range

analog output value in under range condition (range 0 to 24 mA)

Over range

analog output value in over range condition (range 0 to 24 mA)

Fault Output Value

analog output value in case of fault condition (range 0 to 24 mA)

Fault in case of

analog output is forced to "Fault Output Value" when input is out of configured range

3.14.1.2 Alarm




Figure 70: D5254S / D6254S Alarm configuration screen.

ALARM

Type:

- None alarm is disabled
- Low alarm is triggered when input descends below “Low Set”
- High alarm is triggered when input ascends above “High Set”
- Window alarm is triggered below “Low Set” and above “High Set”

Alarm Lock:

alarm is inhibited until source ascends above or descends below the configuration parameters, and then, it behaves as standard configuration.

NO contact position in case of alarm:

- Open alarm output is closed under regular working conditions and it opens in case of alarm
- Closed alarm output is open under regular working conditions and it closes in case of alarm

Low Set:

input value below which the alarm is triggered (in Low, Window)

Low Hysteresis:

hysteresis on the low set value

High Set:

Input value above which the alarm is triggered

High Hysteresis:

hysteresis on the high set value

On Delay:

time for which the input has to be in alarm condition before the alarm output is triggered; configurable from 0 to 1000 seconds in steps of 100 ms.

Off Delay:

time for which the input has to be in normal condition before the alarm output is deactivated; configurable from 0 to 1000 seconds in steps of 100 ms.

FAULT

Alarm is triggered when input is out of configured range

In case of fault:

- Ignore alarm is affected

- Lock status remains in the same status as it was before Fault occurred
- Alarm active alarm is triggered
- Alarm inactive alarm is deactivated

Alarm acknowledgement:

- Ignore alarm is automatically reset
- Active high a voltage source of 24 Vdc must be applied, at the relative terminals, to reset alarm
- Alarm active a voltage source of 0 Vdc must be applied, at the relative terminals, to reset the alarm

3.14.2 Monitor

The SWC5090 is able to continuously scan the module and display real-time values on screen.
Note that while the module is being monitored, configuration screens are disabled.




Figure 71: D5254S / D6254S Monitor screen.

The display shows Input and Theoretical Output values, fault and alarm status and a graph of chosen variable.

3.14.2.1 Input

Input variable is shown as it is detected by the module.

3.14.2.2 Output

This value represents the theoretical output. During certain conditions, this value may differ from the measured value at output terminal blocks.

3.14.2.3 Alarm status

Alarm status is represented by a LED, which is RED when activated.
The LED status reflects the status of the Alarm exactly as configured.

3.14.2.4 Fault

Fault status is represented by a LED, which is RED when activated.

3.14.2.5 Graph

The graph can show only one variable that must be chosen from the checkboxes above.

3.14.3 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals.
By changing the parameters, the user can decide the duration of the recording period and the frequency of readings.
After pressing "Start" button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format.
Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.




Figure 72: Data Logger screen.

3.15 D5212Q/D6212Q

D5212Q / D6212Q is Quadruple Repeater Power Supply.

The Application Window user interface is organized into the following areas:

- **Configuration**
 - Input
 - Output
 - Alarm
- **Monitor**
- **Data Logger**

3.15.1 Configuration

3.15.1.1 Input / Output




Figure 73: D5212Q / D6212Q Input / output configuration screen.

INPUT

Out of range:

- Low threshold: input value below which the fault is triggered
- High threshold: input value above which the fault is triggered

Tag: 16 alphanumerical characters

OUTPUT

Type:

- 0-20 mA Source
- 4-20 mA Source
- Custom Source all output parameters are fully customizable

Downscale:

analog output downscale in normal working condition (range 0 to 24 mA)

Upscale:

analog output upscale in normal working condition (range 0 to 24 mA)

Under range:

analog output value in under range condition (range 0 to 24 mA)

Over range:

analog output value in over range condition (range 0 to 24 mA)

Fault output value:

analog output value in case of fault condition (range 0 to 24 mA)

Fault in case of:

analog output is forced to "Fault Output Value" when input is out of configured range

When the advanced settings button is clicked, the following settings box is shown.

Figure 74: D5212Q / 6212Q advanced settings details.

Input A selector:

- Input 1: output represent Input1
- Input 2: output represent Input2
- Input 3: output represent Input3
- Input 4: output represent Input4

Output operations:

- None: output operations are disabled.
- Subtraction: analog output represents the subtraction of the two selected input channels.
- Sum: analog output represents the sum of the two selected input channels.
- Maximum: analog output represents the higher of the two selected input ch.
- Minimum: analog output represents the lower of the two selected input channels.

Input B selector: (it is shown when the output operations selected is not None)

- Input 1: represents the second operand used for the output operation.

- Input 2: represents the second operand used for the output operation.
- Input 3: represents the second operand used for the output operation.
- Input 4: represents the second operand used for the output operation.

3.15.1.2 Alarm




Figure 75: D5212Q / D6212Q Alarm configuration screen.

ALARM

Type:

- None: alarm is disabled
- Low: alarm is triggered when input descends below “Low Set”
- High: alarm is triggered when input ascends above “High Set”
- Window: alarm is triggered below “Low Set” and above “High Set”

Alarm lock:

alarm is inhibited until source ascends above or descends below the configuration parameters, and then, it behaves as standard configuration.

Input A selector:

- Input 1: alarm is triggered on Input1
- Input 2: alarm is triggered on Input2
- Input 3: alarm is triggered on Input3
- Input 4: alarm is triggered on Input4

Output operations:

- None: output operations are disabled.
- Subtraction: analog output represents the subtraction of the two selected input ch.
- Sum: analog output represents the sum of the two selected input channels.
- Maximum: analog output represents the higher of the two selected input channels
- Minimum: analog output represents the lower of the two selected input channels

Input B selector: (it is shown when the output operations selected is not None)

- Input 1: represents the second operand used for the output operation
- Input 2: represents the second operand used for the output operation
- Input 3: represents the second operand used for the output operation
- Input 4: represents the second operand used for the output operation

NO contact position in alarm:

- Open: alarm output is closed under regular working conditions, and it opens in case of alarm
- Closed: alarm output is open under regular working conditions, and it closes in case of alarm

Low Set:

input value below which the alarm is triggered (in Low, Window)

Low Hysteresis:

hysteresis on the low set value

High Set:

Input value above which the alarm is triggered

High Hysteresis:

hysteresis on the high set value

On Delay:

time for which the input has to be in alarm condition before the alarm output is triggered, configurable from 0 to 1000 seconds in steps of 100 ms

Off Delay:

time for which the input has to be in normal condition before the alarm output is deactivated, configurable from 0 to 1000 seconds in steps of 100 ms.

FAULT:

alarm is triggered when input is out of configured range

In case of fault:

- Ignore: alarm is not affected
- Lock status: remains in the same status as it was before fault occurred
- Alarm active: alarm is triggered
- Alarm inactive: alarm is deactivated

3.15.2 Monitor

The SWC5090 is able to continuously scan the module and display real-time values on screen.
Note that while the module is being monitored, configuration screens are disabled.




Figure 76: D5212Q / D6212Q Monitor screen.

The display shows Input and Theoretical Output values, fault and alarm status and a graph of chosen variable.

3.15.2.1 Input

This value represents the value read from field.

3.15.2.2 Output

This value represents the theoretical output value.

3.15.2.3 Alarm status

Alarm status is represented by a LED, which is RED when activated.
The LED status reflects the status of the Alarm exactly as configured.

3.15.2.4 Fault

Fault status is represented by a LED, which is RED when activated.

3.15.2.5 Graph

The graph can show only one variable that must be chosen from the checkboxes above.

3.15.3 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals.
By changing the parameters, the user can decide the duration of the recording period and the frequency of readings.
After pressing “Start” button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format.
Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.




Figure 77: Data Logger screen.

3.16 5700, 5700-110

5700 / 5700-110 is HART® Multiplexer Modem.

3.16.1 Configuration

To configure 5700 / 5700-110 module, connect the device to PC through PPC5092, then click on “**Load from device**” button.

Figure 78: 5700 / 5700-110 Parameters screen.

DEVICE PARAMETERS

- **Polling address:** device address (from 0 to 62).
- **Master type:** primary or secondary master type.
- **Baud rate:** data transmission speed (from 1200 to 115200 bit/s).

SCAN

- **Scan mode:** when 'Scan mode' is active mux continuously sends the command configured in 'Scan Command' to the field devices.
- **Scan Command:** HART commands #1, #2 and #3 are supported.

COMMUNICATION

- **Retry on busy:** number of retries when the device replies busy.
- **Retry on error:** number of retries when the device replies with errors.
- **Search mode:** building only polling address 0 (Channel 0) or from polling address 0 to 15 (All Channels) on each loop. Note that the search mode from 0 to 15 can be much slower.

MESSAGE

- **Message:** 32-character message string stored in the device.
- **Default preambles to device:** default number of preambles sent to the field device.

DEVICE

- **Tag:** identification of the specific module (maximum 8 alphanumerical characters).
- **Descriptor:** 16-character descriptor string stored in the device.
- **Long Tag:** 32-character long tag string stored in the device.
- **Default preambles to device:** default number of preambles sent to the field device.

3.17 D5232Q/D6232Q and D5233Q/D6233Q

D5232 and D5233 are modules suitable for applications requiring SIL 2 level in safety related systems for high risk industries. These units can be configured for switches or proximity detectors, located in Hazardous Area, and repeats the input state to a relay contact in case of D5232 module, or to an open-collector transistor for a D5233 module, in Safe Area. The selectable fault detection circuit is available for proximity sensors or switches equipped with end-of-line resistors. Input-to-output function can be inverted, and signals can be duplicated.

The Application Window user interface is organized into the following areas:

- **Configuration**
- **Monitor**

- **Data Logger**

3.17.1 Configuration




Figure 79: D5232Q / D6232Q or D5233Q / D6233Q input and output configuration screen.

Configuration parameters can be read and written from the module or from saved file. It is also possible to reset the module configuration to factory default settings. A report sheet containing complete configuration can be printed.

INPUTS 1 to 4:

- **Sensor Type:**
 - Proximity
 - Dry Contact

Note: To enable line diagnostic on Voltage free contacts, follow instructions in Section “Operation” of Instruction Manual ISM0659 for D5232Q module, or ISM0660 for D5233Q module, and configure sensor as “Proximity”.

TAGS 1 to 4:

16 alphanumerical characters

OUTPUTS 1 to 4:

- **Source:**
 - Input 1 Output represents Input 1
 - Input 2 Output represents Input 2
 - Input 3 Output represents Input 3
 - Input 4 Output represents Input 4
 - Cumulative fault: Output represents OR function of selected inputs fault conditions
- **Contact: normal condition of output contact**
 - Open
 - Closed
- **In case of fault:**
 - Ignore
 - Open
 - Closed
- **Fault repeater:** Output represents Input Fault status

3.17.2 Monitor

The SWC5090 is able to continuously scan the module and display real-time values on screen. Note that while the module is being monitored, configuration screens are disabled.




Figure 80: D5232Q / D6232Q or D5233Q / D6233Q Monitor screen.

INPUT STATUS:

- The status of each input is shown
 - Open circuit Open circuit fault (only for Proximity Inputs)
 - Off Off
 - On On
 - Short circuit Short circuit fault (only for Proximity Inputs)

OUTPUT STATUS:

- The status of each output contact is shown
 - Open
 - Closed

3.17.3 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals.

By changing the parameters, the user can decide the duration of the recording period and the frequency of readings.

After pressing “Start” button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format.

Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.

3.18 D5274S

The Temperature Converter & Trip Amplifier D5274S accepts a low level dc signal from millivolt/thermocouple or 2-3-4 wire resistance/RTD or potentiometer sensors, located in Hazardous Area, and converts, with isolation, the signal to drive a Safe Area load, suitable for applications requiring SIL 2 level in safety related systems for high risk industries. Output signal can be direct or reverse. Front trimmers allow easy zero & span current adjustment.

Cold junction compensation can be programmed as automatic, using an internal or external temperature sensor or fixed to a user customizable temperature value. D5274S offers two independent trip amplifiers via two SPDT output relays, whose thresholds are fully programmable. Extended power supply range guarantees functionality at 24 Vdc as well as 12 Vdc nominal voltage.

The Application Window user interface is organized into the following areas:

- **Configuration**
 - **Input**
 - **Output**
 - **Alarm**
- **Monitor**

- **Data Logger**

3.18.1 Configuration

3.18.1.1 Input




Figure 81: D5274S Input configuration screen.

INPUT

Sensor Family:

- TC
- RTD
- Potentiometer
- Voltage
- Resistance

Sensor connection: 2, 3, 4 wires selection for RTD/Resistance inputs
2 wires or External compensator selection for TC
3 wires selection for potentiometer

Burnout:

- Inactive: input sensor interruption is not detected from module
- Active: input sensor interruption is detected from module

Cold Junction Source: reference junction compensation type (thermocouple only)

- Off: no compensation
- Fixed: programmable temperature compensation at fixed temperature
- Internal: via internal compensator

Cold Junction Reference: fixed temperature compensation value (Cold Junction type Fixed only), range from -60 to +100 °C.

Cable resistance: available only for RTD and resistance sensors. Configurable from 0 to 50 Ω

Multiplier: input multiplication value

Tag: 16 alphanumeric characters

Common parameters: *Configure* button is enable when sensor family is configured as RTD and sensor type as Callendar-Van Dusen

3.18.1.2 Output




Figure 82: D5274S Output configuration screen.

OUTPUT

Drive: Source, Sink mode.

Type:

- 4-20 mA Low
- 4-20 mA High
- 0-20mA High
- 4-20 mA NE43 Low, NAMUR RECOMMENDATION
- 4-20 mA NE43 High, NAMUR RECOMMENDATION
- Custom Scale: all Output parameters are fully customizable

Downscale: analog output downscale in normal working condition (range 0 to 24 mA)

Upscale: analog output downscale in normal working condition (range 0 to 24 mA)

Input Downscale: input value of measuring range corresponding to defined low output value

Input Upscale: input value of measuring range corresponding to defined high output value

Under range: analog output downscale in under range condition (range 0 to 24 mA)

Overrange: analog output downscale in overrange condition (range 0 to 24 mA)

Fault Output Value: analog output value in case of fault condition (range 0 to 24 mA)

Damping factor: causes conventional single-pole low pass filtering which is similar to an R-C network. Although high damping values will greatly suppress noise and make the output signal stable, it causes a slow response time.

Zero Trimmer Minimum Variation: determines the minimum zero trimmer variation (*) below the "Input Downscale"

Zero Trimmer Maximum Variation: determines the maximum zero trimmer variation (*) above the "Input Downscale"

Span Trimmer Minimum Variation: determines the minimum span trimmer variation (*) below the "Input Upscale"

Span Trimmer Maximum Variation: determines the maximum span trimmer variation (*) above the "Input Upscale"

Output Trimmer Enable: activates the usage of the two trimmers for zero and span output current adjustment.

(*) Referring to the "INPUT RANGE" (= INPUT UPSCALE – INPUT DOWNSCALE)

3.18.1.3 Alarm




Figure 83: D5274S alarm configuration screen.

ALARM

Type:

- None: alarm is disabled
- Low: alarm is triggered when source descends below “Low Set”
- High: alarm is triggered when source ascends over “High Set”
- Window: alarm is triggered below “Low Set” and above “High Set”
- Burnout Repeater: alarm output reflects Burnout status

Alarm Lock: alarm is inhibited until source ascends over “Low Set or descends below “High Set, and then it behaves as a standard “Low” or “High” configuration

NO Contact position in alarm:

- Open alarm output is normally energized when deactivated
- Closed alarm output is normally de-energized when deactivated

In case of input burnout:

- Ignore: alarm is not affected
- Lock: alarm remains in the same status as it was before Burnout condition occurred
- Alarm Active: alarm is triggered
- Alarm Inactive: alarm is deactivated

Low Set: source value at which the alarm is triggered (in Low, Low Lock, Window)

Low Hysteresis: triggered Low alarm deactivates when source value reaches Low Set + Low hysteresis (0-500 °C, 0-50 mV, 0-50 %)

High Set: source value at which the alarm is triggered (in High, High Lock, Window)

High Hysteresis: triggered High alarm deactivates when source value reaches High Set - High hysteresis (0-500 °C, 0-50 mV, 0-50 %)

On Delay: time for which the source variable has to be in alarm condition before the alarm output is triggered; configurable from 0 to 1000 seconds in steps of 100 ms

Off Delay: time for which the source variable has to be in normal condition before the alarm output is deactivated; configurable from 0 to 1000 seconds in steps of 100 ms

3.18.2 Monitor

he SWC5090 is able to continuously scan the module and display real-time values on screen.

Note that while the module is being monitored, configuration screens are disabled.




Figure 84: D5274S Monitor screen.

The display shows Input and Theoretical Output values, fault and alarm status and a graph of chosen variable.

3.18.2.1 Input

Input variable is shown as it is detected by the module, after having applied configured calculations (Offset, Multiplier) and conversions.

Cold Junction Temperature shows the value of the internal Cold Junction; this value will influence the Output measure when Cold Junction configuration is set to "Automatic".

3.18.2.2 Output

This value represents the theoretical output. During certain conditions, this value may differ from the measured value at output terminal blocks.

3.18.2.3 Alarm status

Alarm status is represented by a LED, which is RED when activated.

The LED status reflects the status of the Alarm exactly as configured.

3.18.2.4 Faults

Each Fault status is represented by a LED, which is RED when activated.

Note that the LED status does not take into account the current module configuration, therefore it only indicates the existence of the fault condition, independently from any configured behavior in case of fault.

3.18.2.5 Graph

The graph can show only one variable that must be chosen from the checkboxes above.

3.18.3 Data Logger

The SWC5090 can monitor and record data from the module at constant configurable time intervals.

By changing the parameters, the user can decide the duration of the recording period and the frequency of readings.

After pressing "Start" button, the SWC5090 will prompt for a filename where the values will be stored in .CSV format.

Note that while the module is being recorded, Configuration screens are disabled, while Monitoring remains active.




Figure 85: Data Logger screen.

PARAMETERS SETUP:

- **Days:** Number of days to acquire
- **Hours:** Number of hours to acquire
- **Minutes:** Number of minutes to acquire
- **Scan rate:** Frequency interval for acquisitions

4. Monitor

The SWC5090 is able to continuously scan the module and display real-time values on screen. A graph of the chosen variable (Input or Output) can also be displayed. Please refer to modules specific chapters for more details on this feature.

5. Data Logger

The SWC5090 can monitor and record data from them module at constant time intervals. Data is stored on a Comma Separated Value file (.CSV). Please refer to modules specific chapters for more details on this feature.

6. Configuration File

Each time the main User Interface window is closed, a configuration file (SWC5090.ini) is saved in the installation directory. The configuration file contains the last COM port used for the configuration and other parameters related to the software.

7. Report sheet

The SWC5090 can print the full configuration set in A4 format. Below an example configuration report.

 Configuration Report	
Model: D5273S\ID6273S Serial: Date: 2017 May 29	
Input 1	
Tag	Channel 1
Sensor Connection	TC
Sensor Type	TC J
Downscale (°C)	0.0
Upscale (°C)	1000.0
Cold Junction Source	Automatic
Cold Junction Reference (°C)	0.0
Integration Speed	slow
Mains Frequency	50 Hz
Offset	0
Multiplier	1
Output 1	
Function	Input 1
Type	4-20 mA Source
Downscale (µA)	4000
Upscale (µA)	20000
Under Range (µA)	3800
Over Range (µA)	20800
Fault Output Value	22000
Faults	
Burnout	Active
Internal Fault	Inactive
Sensor Out Of Range	Inactive
Out Saturation	Inactive
Module Out Of Temperature Range	Inactive

 Configuration Report	
Model: D5273S\ID6273S Serial: Date: 2017 May 29	
Input 1	
Tag	Channel 1
Sensor Connection	TC
Sensor Type	TC J
Downscale (°C)	0.0
Upscale (°C)	1000.0
Cold Junction Source	Automatic
Cold Junction Reference (°C)	0.0
Integration Speed	slow
Mains Frequency	50 Hz
Offset	0
Multiplier	1
Output 1	
Function	Input 1
Type	4-20 mA Source
Downscale (µA)	4000
Upscale (µA)	20000
Under Range (µA)	3800
Over Range (µA)	20800
Fault Output Value	22000
Faults	
Burnout	Active
Internal Fault	Inactive
Sensor Out Of Range	Inactive
Out Saturation	Inactive
Module Out Of Temperature Range	Inactive

Figure 86: Configuration Report example.

8. Installation and quick start

After having checked the requirements at Section 1.2, it is possible to proceed with the installation.

8.1 Installing the PPC5092 USB-to-Mini USB Adapter driver

To install the adapter the user has the choice between:

- running the PPC5092.exe file located in the SWC5090 drivers directory;
- clicking on the "Install PPC5092" link in the "Programs Menu/SWC5090" directory;
- clicking on "Install PPC5092 drivers" voice inside the "?" menu in the SWC5090 software.

Please install PPC5092 drivers before inserting the adapter into an USB port of the PC.

After the installation has completed, insert the adapter in any available USB port.

8.2 Installing the SWC5090 Configuration Software

In case a previous version of the SWC5090 Configuration Software was installed on the system, it is preferable to uninstall it before continuing.

Launch the installer Setup.exe and follow the instructions.

An icon (SWC5090) will be added to the program startup menu and to the Desktop at the end of the process.

Document subject to change without notice, please refer to web site for latest update