

INDEX



A

AC Drives - Purpose; 1–3
Accel 1 to Accel 2 Frequency Transition; 4–16
Acceleration S-Curve; 4–14
Acceleration Time; 4–13
Accessories; 2–12, A–1
AFD - Adjustable Frequency Drive; 1–3
Agency Approvals; 1–8, 2–7
Air Flow; 2–3
Ambient Conditions; 1–8, 2–2
Amps/Current
 Motor Nameplate Amps; 4–11
 Over-Current Stall Prevention; 4–47
 Overload; 4–43
Analog Input
 Examples; 4–34
 Gain; 4–33
 Loss of ACI Signal; 4–40
 Offset; 4–33
 Offset Polarity; 4–32
 Reverse Motion Enable; 4–33
Analog Output; 4–40
 Gain; 4–40
 Signal; 4–40
Analog Parameters; 4–32
Applicable Codes; 2–7
Auto Adjustable Accel/Decel; 4–46
Auto Restart After Fault; 4–44

Auto Voltage Regulation; 4–45
Auto-torque Boost; 4–20

B

Base-Block Time for Speed Search; 4–48
Block Transfer Parameters; 4–58, 5–29
Braking Resistors; 2–12, A–8

C

Cables
 Configuration Cables; A–25
 Keypad Cables; A–25
CE; 1–8
CEC; 2–7
Circuit Connections Warnings & Notes; 2–6
Communicating with DirectLogic PLCs; 5–12
Communicating with Third-party Devices; 5–30
Communication Address; 4–56
Communication Connections to DL PLCs; 5–12
Communication Distribution Blocks; A–26
Communication Parameters; 4–56
Communication Protocol; 4–56
Communication Transmission Speed; 4–56
Compatibility, GS2 and Direct LOGIC PLCs; B–2
Configuration Cable; A–25
Configuration Software; A–22
 Configuration Cable; A–25

Configuring/Programming the AC Drive

Keypad Configuration; 3–5

Software Configuration; A–22

Configuration Cable; A–25

Contactor; 2–6, 2–12

Contents of Drive Package; 1–3

Control Terminals & Wiring; 1–4, 2–10, 2–11

cUL; 1–8, 2–7

Current/Amps

Motor Nameplate Amps; 4–11

Over-Current Stall Prevention; 4–47

Overload; 4–43

D

DC Injection

Current Level; 4–18

during Start-up; 4–18

during Stopping; 4–18

Start-point; 4–18

Decel 1 to Decel 2 Frequency Transition; 4–16

Deceleration S-Curve; 4–15

Deceleration Time; 4–14

Default, Restore Parameters; 4–57

Desired Current; 4–31

Desired Frequency; 4–31

Dimensions; 2–4

Direction Command

Digital Input FWD/REV; 4–22

Keypad FWD/REV; 3–3

Serial Comm Direction Command; 4–59

DirectLOGIC Modbus PLC Programming; 5–16

DirectLOGIC PLCs; B–2

DirectLogic PLCs, Communicating with; 5–12

Disable

Digital Input Disable; 4–23, 4–29

Disable PID; 4–23

Disconnect switch; 2–6

Display; 3–2

Display Parameters; 4–55

Display Frequency Scale Factor; 4–55

Display Function; 4–55

Distribution Blocks, Communication; A–26

E

Electro-Magnetic Interference; 2–7

EMI; 2–7

EMI Filters; 2–12, A–10

Enclosure Rating; 1–8, 2–2

Environmental Conditions; 1–8, 2–2

Error Codes; 5–9, 6–3

Ethernet Interface; A–20

Examples

Analog Input Examples; 4–34

DL PLC Program Example for Modbus; 5–16

External Fault

External Fault, Digital Input; 4–23, 4–24

External Fault, Serial Comm; 4–60

External Parts; 1–4

Cover - lower terminals; 1–4

Cover - upper terminals; 1–4

DIP Switches; 1–4

Keypad; 1–4

Mounting Screw Holes; 1–4

Nameplate Label; 1–4

Terminals - control wiring; 1–4

Terminals - power input wiring; 1–4

Terminals - power output wiring; 1–4

Ventilation Slots; 1–4

F

Fault Codes; 6–3

Fault Record; 4–50

Fault Reset

External DI Fault Reset; 4–23, 4–24

Keypad Fault Reset; 3–3

Serial Comm Fault Reset; 4–60

Fault, External; 4–23, 4–24, 4–60

Filters

EMI Filters; 2–12, A–10

RF Filters; A–16

Frequency

- Jog Frequency; 4-41
- Mid-point Frequency; 4-20
- Minimum Output Frequency; 4-21
- Motor Base Frequency; 4-12
- PID Output Frequency Limit; 4-54
- PWM Carrier Frequency; 4-21
- Source of Frequency Command; 4-32
- Volts/Hertz Parameters; 4-19

Frequency Command / Speed Reference

- Serial Comm Speed Reference; 4-59
- Source of Frequency Command; 4-32

Function Keys; 3-3

Fuses; 2-12, A-17

G

Ground Loops; 2-6

Grounding Resistance; 2-6

GS Series Number; 4-60

GS-EDRV Ethernet Interface; A-20

GSOFT Configuration Software; A-22

- Configuration Cable; A-25

I

Inspection; 6-2

- Annual; 6-2
- Monthly; 6-2

Installation; 2-3

- Air Flow; 2-3
- Dimensions; 2-4
- Minimum Clearances; 2-3

Inverter; 1-3

J

Jog Command

- Digital Input Jog Command; 4-23, 4-25
- Serial Comm Jog Command; 4-60

Jog Frequency; 4-41

K

Keypad; 3-2

Keypad Cables; A-25

Keypad, Spare; A-25

L

Label, Nameplate Information; 1-3

LED Display; 3-2

LED Indicators; 3-2

Lower Bound

- of Output Frequency; 4-49

M

Maintenance; 6-2

Manufacturer Model Information; 4-61

Maximum Allowable Power Loss Time; 4-48

Maximum Speed Search Current Level; 4-48

Memory Addresses for Parameters; 5-4

Mid-point Frequency; 4-20

Mid-point Voltage; 4-20

Minimum Clearances; 2-3

Minimum Output Frequency; 4-21

Minimum Output Voltage; 4-21

Modbus ASCII; 5-30

Modbus Communication with Third-Party Devices; 5-30

Modbus Communications; 5-1

Modbus Connections to DL PLCs; 5-12

Modbus Control, PLC Programming; 5-16

Modbus RTU; 5-30

Model Information; 4-61

Model Number Explanation; 1-3

Momentary Power Loss; 4-44

Motor Base Frequency; 4-12

Motor Base RPM; 4-12

Motor Maximum RPM; 4-12

Motor Nameplate Amps; 4-11

Motor Nameplate Voltage; 4-11

Motor Parameters; 4-11

Motors

- Single-Phase; 2–7
- Three-Phase; 1–3
- Mounting Screw Holes; 1–4, 2–4
- Multi-Function Input Disable; 4–29
- Multi-function Input Terminals; 4–22
- Multi-function Output Terminals; 4–30
- Multi-Speed
 - Auto Voltage Regulation; 4–45
 - Digital Input Multi-Speed Bits; 4–23, 4–25
 - Multi-Speed Settings; 4–42

N

- Nameplate Label Information; 1–3
- NEC; 2–7
- NEMA Publications; 1–2

O

- Operation Command; 4–22
- Over-Current
 - Stall Prevention During Acceleration; 4–47
 - Stall Prevention During Operation; 4–47
- Overload; 4–43
- Over-Torque
 - Detection Level; 4–46
 - Detection Mode; 4–46
 - Detection Time; 4–46
- Over-Voltage
 - Stall Prevention; 4–45

P

- Parameter Lock; 4–57
- Parameter Memory Addresses; 5–4
- Parameter Summary; 4–2
- Parameters, Detailed Listings; 4–11
 - Restore Parameters to Default Settings; 4–57
- PID
 - PID Deviation Alarm; 4–30
 - PID Deviation Level; 4–31
 - PID Deviation Time; 4–31

- PID DI Setpoint Bits; 4–23, 4–25
- PID Deviation Alarm; 4–30
- PID Parameters; 4–51
 - Derivative Control; 4–53
 - Derivative Filter Time Constant; 4–54
 - Feedback Loss Operation; 4–54
 - Feedback Signal Loss Detection Time; 4–54
 - Input Terminal for PID Feedback; 4–51
 - Integral Control; 4–53
 - Keypad Setpoint; 4–52
 - Multi-setpoints; 4–52
 - Output Frequency Limit; 4–54
 - Proportional Control; 4–53
 - PV 100% Value; 4–52
 - PV Setpoint Source; 4–52
 - Upper Bound for Integral Control; 4–54
- PID SP Digital Inputs; 4–23
- PLC Module Typical Connections; B–7
- PLC Modules; B–2
- PLC Programming for Modbus Control; 5–16
- PLCs, DirectLOGIC, Communicating with; 5–12
- Potentiometer
 - Keypad Potentiometer; 3–3
 - Remote Potentiometer; 2–11
- Power Terminals & Wiring; 1–4, 2–7, 2–8, 2–9, 2–11
- Present Fault Record; 4–50
- Preset Parameters; 4–41
- Programming/Configuring the AC Drive
 - Keypad Configuration; 3–5
 - Software Configuration; A–22
 - Configuration Cable; A–25
- Protection Parameters; 4–43
- Purpose of AC Drives; 1–3
- PWM Carrier Frequency; 4–21

R

- Ramp Parameters; 4–13
- Reactors; 2–12, A–2
- Reset, Fault

- External DI Fault Reset; 4-23, 4-24
 - Keypad Fault Reset; 3-3
 - Serial Comm Fault Reset; 4-60
 - Resistors, Braking; 2-12, A-8
 - Restore Parameters to Default Values; 4-57
 - Reverse Operation Inhibit; 4-44
 - RF Filters; A-16
 - RPM
 - Motor Base RPM; 4-12
 - Motor Maximum RPM; 4-12
 - RS-232 Communication Interface; 5-12, 5-30
 - RS-232 Selector DIP Switches; 1-4, 5-12, 5-30
 - RS-232 to RS-485 Conversion; 5-13
 - Wiring Connections to DL PLCs; 5-12
 - RS-485 Communication Interface; 5-13, 5-14, 5-30
 - RS-232 to RS-485 Conversion; 5-13
 - RS-485 Comm Distribution Board; A-26
 - RS-485 Selector DIP Switches; 1-4, 5-13, 5-30
 - Wiring Connections to DL PLCs; 5-13, 5-14
 - Run Command
 - Digital Input Run Command; 4-22
 - Keypad Run; 3-3
 - Serial Comm Run Command; 4-59
- ## S
- Safety Codes; 2-7
 - Select method for 2nd Accel/Decel; 4-16
 - Serial Comm Speed Reference; 4-59
 - Short Circuit Withstand Current; 2-7
 - Single-Phase Motors; 2-7
 - Skip Frequency; 4-17
 - Skip Frequency Band; 4-17
 - Slip Compensation; 4-20
 - Software, Configuration; A-22
 - Configuration Cable; A-25
 - Source of Frequency Command; 4-32
 - Source of Operation Command; 4-22
 - Special Symbols; 1-2
 - Specifications; 1-5
 - Speed Reference / Frequency Command
 - Serial Comm Speed Reference; 4-59
 - Source of Frequency Command; 4-32
 - Status Addresses; 5-9
 - Status Monitor; 5-9, 5-10
 - Status of the AC Drive
 - Keypad; 3-4
 - Serial Comm; 5-9
 - Stop
 - Digital Input Stop; 4-22
 - Keypad Stop; 3-3
 - Stop Methods; 4-13
 - Supplemental Publications; 1-2
 - NEMA Publications; 1-2
- ## T
- Technical Support; 1-2
 - Three-Phase Motors; 1-3
 - Time Out Detection; 4-57
 - Time Out Duration; 4-57
 - Torque
 - Over-Torque Detection; 4-46
 - Torque, Constant; 3-6
 - Torque, Variable; 3-11
 - Transmission Fault Treatment; 4-57
 - Troubleshooting; 6-3
- ## U
- UL; 1-8, 2-7
 - Upper Bound
 - for PID Integral Control; 4-54
 - of Output Frequency; 4-49
- ## V
- Ventilation Slots; 1-4
 - VFD - Variable Frequency Drive; 1-3
 - Voltage
 - Mid-point Voltage; 4-20

Minimum Output Voltage; 4-21
Motor Nameplate Voltage; 4-11
Over-Voltage Stall Prevention; 4-45
Volts/Hertz Parameters; 4-19

Volts/Hertz Parameters; 4-19

W

Warning Messages; 6-6
Warnings & Notes - circuit connections; 2-6
Warnings & Notes - general; 1-2
Wiring & Circuit Connections; 2-6
 Basic Wiring Diagram; 2-11
 Control Circuit Wiring; 2-7, 2-10
 Main Circuit Wiring; 2-7, 2-8, 2-9, 2-11
 Serial Comm Wiring Connections; 5-12
 Shielded Wiring; 2-10
 Warnings; 2-6
 Wiring Notes; 2-6
Wiring Connections to DL PLC Modules; B-7