



5014152000 - 202304

**GS30 AC DRIVES INSTALLATION INSTRUCTIONS**

**SENSORLESS VECTOR CONTROL VARIABLE FREQUENCY MICRO-DRIVE**

- Please read this instruction sheet thoroughly before installation and retain for later reference.
- To ensure the safety of operators and equipment, only qualified personnel familiar with AC drives should install, wire, program, and operate the GS30 drive. Always read this instruction sheet thoroughly before using the GS30 drive, especially the WARNING, DANGER and CAUTION notes. If you have any questions, please contact AutomationDirect.

**PLEASE READ PRIOR TO INSTALLATION FOR SAFETY**

	<ul style="list-style-type: none"> <li>The ground terminal of the GS30 drive must be grounded correctly. The grounding method must comply with the laws of the country where the GS30 drive is to be installed.</li> <li>After power has been turned off, the capacitors in the GS30 drive may retain a charge for several minutes. To prevent personal injury, visually verify that the "CHARGE" LED has turned off. Then measure to confirm that the DC bus voltage level between terminals (+1) and (-) is less than 25VDC before touching any terminals. (Capacitor discharge will take at least 5 minutes for most GS30 models)</li> <li>The CMOS ICs on the internal circuit boards of the GS30 drive are sensitive to static electricity. Please DO NOT touch the circuit boards with your bare hands before taking anti-static measures. Never disassemble the internal components or circuits.</li> <li>If wiring changes must be made, turn off power to the GS30 drive before making those changes. Allow the internal DC bus capacitors in the GS30 drive sufficient time to discharge prior to making changes in power or control wiring. Failure to do so may result in short circuit and fire. To ensure personal safety, allow DC bus voltage to discharge to a safe level before making wiring changes to the GS30 drive.</li> <li>DO NOT install the GS30 drive in locations subject to high temperature, direct sunlight, or flammable materials.</li> </ul>
	<ul style="list-style-type: none"> <li>Never apply power to the output terminals U/T1, V/T2, W/T3 of the GS30 drive. If a fault occurs during operation of the GS30 drive, refer to the fault code descriptions and corrective actions to reset the fault before attempting to operate the GS30 drive.</li> <li>DO NOT use Hi-pot test for internal components. The semi-conductors in the GS30 drive are easily damaged by high voltage.</li> </ul>
	<ul style="list-style-type: none"> <li>Long motor lead lengths may result in reflective wave due to impedance mismatch between the motor cable and the motor. Reflective wave may damage the insulation of the motor. To avoid the possibility of reflective wave damage, use an inverter-rated motor with an insulation rating of 1600 volts. A load reactor or output filter installed between the GS30 drive and motor will help to mitigate reflective wave.</li> <li>Nominal supply voltage to the GS30 drive should be less than or equal to 240/480 volts AC depending on GS30 model.</li> <li>Nominal supply current capacity should be less than or equal to 100kA for Frame A-F models. For Frames G, H, and I, ratings vary from 5kA to 10kA – please see drive spec sheets.</li> <li>The GS30 drive must be installed in a clean, well-ventilated and dry location, free from corrosive gases or liquids.</li> <li>The GS30 drive must be stored within an ambient temperature range from -40°C to +85°C, and relative humidity range of 0% to 90% without condensation.</li> <li>Do not apply AC power to the GS30 drive with the front cover removed. Following a fault of the GS30 drive, wait 5 seconds before pressing the RESET key.</li> <li>To improve power factor, install a line reactor ahead of the GS30 drive. Do not install power correction capacitors in the main AC supply circuit to the GS30 drive to prevent drive faults due to over-current.</li> </ul>

**MINIMUM WIRING**

- For 3-phase models, AC input power to R/L1, S/L2, and T/L3. For 1-phase models AC input power to R/L and S/L2. (For applicability of 1-phase input power, please refer to Chapter 1 of the DURApulse GS30 AC Drives User Manual at [AutomationDirect.com](http://AutomationDirect.com).)
- Ground from the power supply
- Drive power to the motor (U, V, W on T1, T2, T3) (For use with 3-phase motors only!)
- Ground to the motor
- STO1 and STO2 (both must be wired through appropriate N.C. safety-rated contacts to DCM or the factory-installed jumpers must be left in place)

With this minimal wiring, the drive can be operated via the keypad to test the motor and drive installation. See the "Parameter Set Up" (page 4) section to configure the drive for keypad operation.

**RECOMMENDED SAFETY WIRING**

We strongly recommend that customers use the STO safety feature.

The Safe Torque Off (STO) function turns off the power supplied to the motor through the hardware, so that the motor cannot produce torque. This method of removing power from the motor is considered an emergency stop, also known as "coast to stop."


To use this feature, disconnect the appropriate factory-installed jumpers and wire a safety relay or safety PLC as shown. The E-Stop pushbutton should be wired through a Safety Relay or PLC to meet Category 3 safety requirements. See User Manual Appendix E for wiring the GS30 with STO.

**WIRING DIAGRAMS**


**RFI JUMPER REMOVAL**

If the power distribution system supplying the GS30 AC drive is a floating (IT) or an asymmetric ground system, the RFI jumper must be removed. Removing the RFI jumper uncouples the internal RFI capacitor (filter capacitor) between the GS30 drive frame and circuitry to avoid damaging those circuits and (according to IEC 61800-3) to reduce ground leakage current.

**GS30 Frame A through G**



**GS30 Frame H**



**GS30 Frame I**




**MAIN WIRING (POWER CIRCUIT)**

For main (power) wiring terminal specifications, Please refer to "Specifications for Wiring Terminals – Main-Circuit Terminals" (page 2).


**GS30 FRAMES A THROUGH G:**

\*Note that 1-phase drives do not have a T/L3 terminal.




**GS30 FRAMES H AND I:**


Input: three-phase power




**GS30 CONTROL TERMINAL WIRING (ALL FRAME SIZES)**

(See page 2 for Start/Stop wiring options)





- Tighten the wiring with a 2.5 mm (wide) x 0.4 mm (thick) slotted screwdriver.
- The ideal length of stripped wire at the connection side is 6–7 mm.
- When wiring bare wires, make sure they are perfectly arranged to go through the wiring holes.
- 4) The control circuit terminal uses a spring clamp terminal block:
  - Tighten the wiring with a 2.5 mm (wide) x 0.4 mm (thick) slotted screwdriver.
  - The ideal length of stripped wire at the connection side is 9 mm.



RECOMMENDED MODELS OR DIMENSIONS FOR FERRULE TERMINALS

Wire Gauge	Manufacturer	Model Name	A (MAX)	B (MAX)	D (MAX)	W (MAX)
0.25 mm <sup>2</sup> [24 AWG]	PHOENIX CONTACT	AI 0,25- 8 YE	12.5	8	2.6	1.1
0.34 mm <sup>2</sup> [22 AWG]	PHOENIX CONTACT	AI 0,34- 8 TQ	12.5	8	3.3	1.3
0.5 mm <sup>2</sup> [20 AWG]	PHOENIX CONTACT	AI 0,5 - 8 WH	14	8	3.5	1.4
	Z+F	V30AE000006	14	8	2.6	1.15

SPECIFICATIONS FOR WIRING TERMINALS – MAIN-CIRCUIT TERMINALS

Notes:

- If you install at Ta 50°C above environment (all frames) or 40°C (Frame H, I, with conduit box), please use copper wire with a 600V voltage rating and temperature resistance of 90°C or higher.
- For UL compliant installation, you must:
  - 1) Use 75°C temperature resistant copper wire or better. Do not reduce wire gauge when using higher temperature wire.
  - 2) Use the specific ring lug part listed in the table below.
  - 3) Use crimp tool KST2000D-1322 or IZUMI 5N18 for 22–8 AWG wire, or IZUMI 9H-60 for 6–4 AWG wire.




Figure 1.

Figure 2.

Drive Models	Max Wire Gauge	Min Wire Gauge	Screw Size	Torque (±10%)	Ring Lug Dimensions (mm)																														
Frame A	14AWG [2.5 mm <sup>2</sup> ]	14AWG [2.5 mm <sup>2</sup> ]	M3.5	9 kg-cm [7,8 lb-in.] [0.88 N-m]	<table border="1"> <thead> <tr> <th>Dimension</th> <th>Value</th> <th>Min/Max</th> </tr> </thead> <tbody> <tr><td>A</td><td>9.8</td><td>Max</td></tr> <tr><td>B</td><td>3.2</td><td>Max</td></tr> <tr><td>C</td><td>4.8</td><td>Min</td></tr> <tr><td>D</td><td>4.1</td><td>Max</td></tr> <tr><td>d2</td><td>3.7</td><td>Min</td></tr> <tr><td>E</td><td>13.0</td><td>Min</td></tr> <tr><td>F</td><td>4.2</td><td>Min</td></tr> <tr><td>W</td><td>6.6</td><td>Max</td></tr> <tr><td>t</td><td>0.8</td><td>Max</td></tr> </tbody> </table>	Dimension	Value	Min/Max	A	9.8	Max	B	3.2	Max	C	4.8	Min	D	4.1	Max	d2	3.7	Min	E	13.0	Min	F	4.2	Min	W	6.6	Max	t	0.8	Max
					Dimension	Value	Min/Max																												
					A	9.8	Max																												
					B	3.2	Max																												
					C	4.8	Min																												
D	4.1	Max																																	
d2	3.7	Min																																	
E	13.0	Min																																	
F	4.2	Min																																	
W	6.6	Max																																	
t	0.8	Max																																	
Frame B	12AWG [4 mm <sup>2</sup> ]	12AWG [4 mm <sup>2</sup> ]	M4	15 kg-cm [13,0 lb-in.] [1.47 N-m]	<table border="1"> <thead> <tr> <th>Dimension</th> <th>Value</th> <th>Min/Max</th> </tr> </thead> <tbody> <tr><td>A</td><td>12.1</td><td>Max</td></tr> <tr><td>B</td><td>3.6</td><td>Max</td></tr> <tr><td>C</td><td>6.1</td><td>Min</td></tr> <tr><td>D</td><td>5.6</td><td>Max</td></tr> <tr><td>d2</td><td>4.3</td><td>Min</td></tr> <tr><td>E</td><td>13.0</td><td>Min</td></tr> <tr><td>F</td><td>4.5</td><td>Min</td></tr> <tr><td>W</td><td>7.2</td><td>Max</td></tr> <tr><td>t</td><td>1</td><td>Max</td></tr> </tbody> </table>	Dimension	Value	Min/Max	A	12.1	Max	B	3.6	Max	C	6.1	Min	D	5.6	Max	d2	4.3	Min	E	13.0	Min	F	4.5	Min	W	7.2	Max	t	1	Max
					Dimension	Value	Min/Max																												
					A	12.1	Max																												
					B	3.6	Max																												
					C	6.1	Min																												
D	5.6	Max																																	
d2	4.3	Min																																	
E	13.0	Min																																	
F	4.5	Min																																	
W	7.2	Max																																	
t	1	Max																																	

SPECIFICATIONS FOR WIRING TERMINALS – MAIN-CIRCUIT TERMINALS (CONTINUED)

Drive Models	Max Wire Gauge	Min Wire Gauge	Screw Size	Torque (±10%)	Ring Lug Dimensions (mm)																														
Frame C	8AWG [10 mm <sup>2</sup> ]	8AWG [10 mm <sup>2</sup> ]	M4	20 kg-cm [17,4 lb-in.] [1.96 N-m]	<table border="1"> <thead> <tr> <th>Dimension</th> <th>Value</th> <th>Min/Max</th> </tr> </thead> <tbody> <tr><td>A</td><td>17.8</td><td>Max</td></tr> <tr><td>B</td><td>5.0</td><td>Max</td></tr> <tr><td>C</td><td>6.1</td><td>Min</td></tr> <tr><td>D</td><td>7.2</td><td>Max</td></tr> <tr><td>d2</td><td>4.3</td><td>Min</td></tr> <tr><td>E</td><td>13.0</td><td>Min</td></tr> <tr><td>F</td><td>5.5</td><td>Min</td></tr> <tr><td>W</td><td>10.5</td><td>Max</td></tr> <tr><td>t</td><td>1.2</td><td>Max</td></tr> </tbody> </table>	Dimension	Value	Min/Max	A	17.8	Max	B	5.0	Max	C	6.1	Min	D	7.2	Max	d2	4.3	Min	E	13.0	Min	F	5.5	Min	W	10.5	Max	t	1.2	Max
					Dimension	Value	Min/Max																												
					A	17.8	Max																												
					B	5.0	Max																												
					C	6.1	Min																												
					D	7.2	Max																												
d2	4.3	Min																																	
E	13.0	Min																																	
F	5.5	Min																																	
W	10.5	Max																																	
t	1.2	Max																																	
Frame D	8AWG [10 mm <sup>2</sup> ]	8AWG [10 mm <sup>2</sup> ]	M4	20 kg-cm [17,4 lb-in.] [1.96 N-m]	<table border="1"> <thead> <tr> <th>Dimension</th> <th>Value</th> <th>Min/Max</th> </tr> </thead> <tbody> <tr><td>A</td><td>17.8</td><td>Max</td></tr> <tr><td>B</td><td>5.0</td><td>Max</td></tr> <tr><td>C</td><td>6.1</td><td>Min</td></tr> <tr><td>D</td><td>7.2</td><td>Max</td></tr> <tr><td>d2</td><td>4.3</td><td>Min</td></tr> <tr><td>E</td><td>13.0</td><td>Min</td></tr> <tr><td>F</td><td>5.5</td><td>Min</td></tr> <tr><td>W</td><td>10.5</td><td>Max</td></tr> <tr><td>t</td><td>1.2</td><td>Max</td></tr> </tbody> </table>	Dimension	Value	Min/Max	A	17.8	Max	B	5.0	Max	C	6.1	Min	D	7.2	Max	d2	4.3	Min	E	13.0	Min	F	5.5	Min	W	10.5	Max	t	1.2	Max
					Dimension	Value	Min/Max																												
					A	17.8	Max																												
					B	5.0	Max																												
					C	6.1	Min																												
D	7.2	Max																																	
d2	4.3	Min																																	
E	13.0	Min																																	
F	5.5	Min																																	
W	10.5	Max																																	
t	1.2	Max																																	
Frame E	4AWG [25 mm <sup>2</sup> ]	4AWG [25 mm <sup>2</sup> ]	M5	25 kg-cm [21,7 lb-in.] [2.45 N-m]	<table border="1"> <thead> <tr> <th>Dimension</th> <th>Value</th> <th>Min/Max</th> </tr> </thead> <tbody> <tr><td>A</td><td>27.1</td><td>Max</td></tr> <tr><td>B</td><td>6.1</td><td>Max</td></tr> <tr><td>C</td><td>10.5</td><td>Min</td></tr> <tr><td>D</td><td>11.5</td><td>Max</td></tr> <tr><td>d2</td><td>5.3</td><td>Min</td></tr> <tr><td>E</td><td>13.0</td><td>Min</td></tr> <tr><td>F</td><td>6.5</td><td>Min</td></tr> <tr><td>W</td><td>12.6</td><td>Max</td></tr> <tr><td>t</td><td>1.7</td><td>Max</td></tr> </tbody> </table>	Dimension	Value	Min/Max	A	27.1	Max	B	6.1	Max	C	10.5	Min	D	11.5	Max	d2	5.3	Min	E	13.0	Min	F	6.5	Min	W	12.6	Max	t	1.7	Max
					Dimension	Value	Min/Max																												
					A	27.1	Max																												
					B	6.1	Max																												
C	10.5	Min																																	
D	11.5	Max																																	
d2	5.3	Min																																	
E	13.0	Min																																	
F	6.5	Min																																	
W	12.6	Max																																	
t	1.7	Max																																	
Frame F	2AWG [35 mm <sup>2</sup> ]	2AWG [35 mm <sup>2</sup> ]	M6	40 kg-cm [34,7 lb-in.] [3.92 N-m]	<table border="1"> <thead> <tr> <th>Dimension</th> <th>Value</th> <th>Min/Max</th> </tr> </thead> <tbody> <tr><td>A</td><td>35.0</td><td>Max</td></tr> <tr><td>B</td><td>9.0</td><td>Max</td></tr> <tr><td>C</td><td>13.3</td><td>Min</td></tr> <tr><td>D</td><td>14.0</td><td>Max</td></tr> <tr><td>d2</td><td>6.2</td><td>Min</td></tr> <tr><td>E</td><td>13.0</td><td>Min</td></tr> <tr><td>F</td><td>10</td><td>Min</td></tr> <tr><td>W</td><td>19.5</td><td>Max</td></tr> <tr><td>t</td><td>1.8</td><td>Max</td></tr> </tbody> </table>	Dimension	Value	Min/Max	A	35.0	Max	B	9.0	Max	C	13.3	Min	D	14.0	Max	d2	6.2	Min	E	13.0	Min	F	10	Min	W	19.5	Max	t	1.8	Max
					Dimension	Value	Min/Max																												
					A	35.0	Max																												
B	9.0	Max																																	
C	13.3	Min																																	
D	14.0	Max																																	
d2	6.2	Min																																	
E	13.0	Min																																	
F	10	Min																																	
W	19.5	Max																																	
t	1.8	Max																																	
Frame G	4AWG [25 mm <sup>2</sup> ]	4AWG [25 mm <sup>2</sup> ]	M8	80 kg-cm [69,4 lb-in.] [7.84 N-m]	<table border="1"> <thead> <tr> <th>Dimension</th> <th>Value</th> <th>Min/Max</th> </tr> </thead> <tbody> <tr><td>A</td><td>35.0</td><td>Max</td></tr> <tr><td>B</td><td>9.0</td><td>Max</td></tr> <tr><td>C</td><td>13.3</td><td>Min</td></tr> <tr><td>D</td><td>14.0</td><td>Max</td></tr> <tr><td>d2</td><td>6.2</td><td>Min</td></tr> <tr><td>E</td><td>13.0</td><td>Min</td></tr> <tr><td>F</td><td>10</td><td>Min</td></tr> <tr><td>W</td><td>19.5</td><td>Max</td></tr> <tr><td>t</td><td>1.8</td><td>Max</td></tr> </tbody> </table>	Dimension	Value	Min/Max	A	35.0	Max	B	9.0	Max	C	13.3	Min	D	14.0	Max	d2	6.2	Min	E	13.0	Min	F	10	Min	W	19.5	Max	t	1.8	Max
					Dimension	Value	Min/Max																												
					A	35.0	Max																												
B	9.0	Max																																	
C	13.3	Min																																	
D	14.0	Max																																	
d2	6.2	Min																																	
E	13.0	Min																																	
F	10	Min																																	
W	19.5	Max																																	
t	1.8	Max																																	
Frame H	3/0 AWG [95 mm <sup>2</sup> ]	4AWG [25 mm <sup>2</sup> ]	M8	80 kg-cm [69,4 lb-in.] [7.84 N-m]	<table border="1"> <thead> <tr> <th>Dimension</th> <th>Value</th> <th>Min/Max</th> </tr> </thead> <tbody> <tr><td>A</td><td>35.0</td><td>Max</td></tr> <tr><td>B</td><td>9.0</td><td>Max</td></tr> <tr><td>C</td><td>13.3</td><td>Min</td></tr> <tr><td>D</td><td>14.0</td><td>Max</td></tr> <tr><td>d2</td><td>6.2</td><td>Min</td></tr> <tr><td>E</td><td>13.0</td><td>Min</td></tr> <tr><td>F</td><td>10</td><td>Min</td></tr> <tr><td>W</td><td>19.5</td><td>Max</td></tr> <tr><td>t</td><td>1.8</td><td>Max</td></tr> </tbody> </table>	Dimension	Value	Min/Max	A	35.0	Max	B	9.0	Max	C	13.3	Min	D	14.0	Max	d2	6.2	Min	E	13.0	Min	F	10	Min	W	19.5	Max	t	1.8	Max
					Dimension	Value	Min/Max																												
A	35.0	Max																																	
B	9.0	Max																																	
C	13.3	Min																																	
D	14.0	Max																																	
d2	6.2	Min																																	
E	13.0	Min																																	
F	10	Min																																	
W	19.5	Max																																	
t	1.8	Max																																	

P02.00	External Terminal Control Circuits
<p><b>Setting value: 1</b> Two-wire operation control FWD / STOP REV / STOP</p>	
<p><b>Setting value: 2</b> Two-wire operation control RUN / STOP FWD / REV</p>	
<p><b>Setting value: 3</b> Three-wire operation control</p>	

SPECIFICATIONS FOR WIRING TERMINALS – CONTROL CIRCUIT

GS30 All Models; All Frame Sizes		
Terminal	Wire Gauge	Torque
Control	24–18 AWG [0.21–0.82 mm <sup>2</sup> ]	n/a (spring terminals)
Relay	24–16 AWG [0.21–1.31 mm <sup>2</sup> ]	5kg-cm [4.3 lb-in]

WIRING PRECAUTIONS

- 1) The factory default condition is +24V/STO1/STO2 shorted by jumper, as shown in the block 1 of the figure above. Refer to the wiring chapter of the User Manual for more details.
- 2) The +24 V power supply for safety function is only for STO use and cannot be used for other purposes.
- 3) The RELAY terminal uses the PCB terminal block:

SPECIFICATIONS FOR WIRING TERMINALS – MAIN-CIRCUIT TERMINALS (CONTINUED)																																			
Drive Models	Max Wire Gauge	Min Wire Gauge	Screw Size	Torque (±10%)	Ring Lug Dimensions (mm)																														
Frame I	GS33-2040	3/0 AWG [95 mm <sup>2</sup> ]	M8	80 kg-cm [69.4 lb-in.] [7.84 N-m]	<table border="1"> <thead> <tr> <th>Dimension</th> <th>Value</th> <th>Min/Max</th> </tr> </thead> <tbody> <tr><td>A</td><td>35.0</td><td>Max</td></tr> <tr><td>B</td><td>9.0</td><td>Max</td></tr> <tr><td>C</td><td>13.3</td><td>Min</td></tr> <tr><td>D</td><td>14.0</td><td>Max</td></tr> <tr><td>d2</td><td>6.2</td><td>Min</td></tr> <tr><td>E</td><td>13.0</td><td>Min</td></tr> <tr><td>F</td><td>10</td><td>Min</td></tr> <tr><td>W</td><td>19.5</td><td>Max</td></tr> <tr><td>t</td><td>1.8</td><td>Max</td></tr> </tbody> </table>	Dimension	Value	Min/Max	A	35.0	Max	B	9.0	Max	C	13.3	Min	D	14.0	Max	d2	6.2	Min	E	13.0	Min	F	10	Min	W	19.5	Max	t	1.8	Max
	Dimension					Value	Min/Max																												
	A	35.0				Max																													
	B	9.0				Max																													
C	13.3	Min																																	
D	14.0	Max																																	
d2	6.2	Min																																	
E	13.0	Min																																	
F	10	Min																																	
W	19.5	Max																																	
t	1.8	Max																																	
GS33-2050	2/0 AWG [70 mm <sup>2</sup> ]																																		
GS33-4075																																			
GS33-4100	3/0 AWG [95 mm <sup>2</sup> ]																																		

**DIGITAL KEYPAD FUNCTIONS AND INDICATIONS**

Description of the functions of the keys and indicators of the GS30 AC Drive Keypad.

**NOTE:** Drive default is Remote (AUTO) mode. There is no indication on the keypad of the mode. Local mode can be set by changing Parameter P00.21 via the keypad, GS4-KPD software.



Descriptions of LED Functions	
<b>RUN</b>	<b>Steady ON:</b> Drive is running. <b>Blinking:</b> Drive is stopping or in base block. <b>Steady OFF:</b> Drive is not running.
<b>FWD</b>	<b>Steady ON:</b> Drive is operating in Forward mode. <b>Blinking:</b> Drive is changing direction. <b>Steady OFF:</b> Drive is operating in Reverse mode.
<b>REV</b>	<b>Steady ON:</b> Drive is operating in Reverse mode. <b>Blinking:</b> Drive is changing direction. <b>Steady OFF:</b> Drive is operating in Forward mode.
<b>STOP</b>	<b>Steady ON:</b> Drive is stopped or in the process of stopping. <b>Blinking:</b> Drive is in standby (run but does not output). <b>Steady OFF:</b> Drive is not currently executing an operational (STOP) command. <i>NOTE: The ability to STOP the drive from the keypad is effective ONLY if the drive is configured to RUN and/or STOP from the keypad. Keypad STOP can be disabled by parameter 00.32, Digital Keypad STOP Function.</i>
<b>PLC</b>	<b>Steady ON:</b> PLC STOP (PLC 2) initiated. <b>Blinking:</b> PLC Run (PLC1) initiated. <b>Steady OFF:</b> No PLC functions implemented (PLC 0).

**KEYPAD NAVIGATION EXAMPLE**

Instruction	Press Key	Display Will Show
First screen to display after power up.	n/a	
Press MENU once from startup.	MENU	
Press MENU twice from startup.	MENU	
Press MENU three times from startup.	MENU	
Press MENU four times from startup. Displays Frd if the drive is currently configured for Forward operation. Scroll with the dial to change to Reverse. Press ENTER to confirm the change.	MENU, ENTER	 
Press MENU five times from startup. Displays the current PLC setting. Scroll with the dial to change the PLC setting, then press ENTER to confirm.	MENU, ENTER	
Press MENU six times from startup. Used to Read/Write parameters between the drive and the local keypad. Scroll with the dial to select READ or WRITE, FILE Number and Save	MENU, ENTER	
From the Frequency setting, Actual Frequency, User, Amps, or Frd/Rev screen, press ENTER to bring up the parameter number (Format XX.YY). Scroll with the dial to change the parameter number as needed, then press ENTER to alter the parameter value.	ENTER	
From the parameter number screen, press ENTER to bring up the current value of the selected parameter. Scroll with the dial to adjust the value. Press ENTER again to confirm the choice.	ENTER	
Once a desired parameter value has been set using the Dial, press ENTER to save the choice and display End message.	ENTER	
Displays when an external fault is detected.	n/a	
Displays when data is not accepted or the value exceeded	n/a	

Scroll sequentially through the suggested parameters (listed on page 4), and set those parameters as needed for your application. Consult User Manual for additional parameters.  
After changing all of the applicable parameters, press "MENU" key repeatedly to return to the Menu screen.

**GS30 FAULT CODES**

See Chapter 6 of the User Manual for more details.

Fault Codes	
0: No Error	49: External Fault input (EF)
1: Overcurrent during Accel (ocA)	50: Emergency Stop (EF1)
2: Overcurrent during Decel (ocd)	51: External Base Block (bb)
3: Overcurrent during constant speed (ocn)	52: Password Error (Pcod)
4: Ground Fault (GFF)	54: Communication Error (CE1)
6: Overcurrent during Stop (ocS)	55: Communication Error (CE2)
7: Overvoltage during Accel (ovA)	56: Communication Error (CE3)
8: Overvoltage during Decel (ovd)	57: Communication Error (CE4)
9: Overvoltage during constant speed (ovn)	58: PC Communication Time Out (CE10)
10: Overvoltage during Stop (ovS)	61: Y-Delta connection Error (ydc)
11: Low voltage during Accel (LvA)	62: Decel Energy Backup Error (dEb)
12: Low voltage during Decel (Lvd)	63: Slip Error (oSL)
13: Low voltage during constant speed (Lvn)	72: STO loss 1 (STL1)
14: Low voltage during Stop (LvS)	76: Safety Torque Off (STO)
15: Input phase loss (OrP)	77: STO loss 2 (STL2)
16: IGBT Overheat 1 (oH1)	78: STO loss 3 (STL3)
17: Internal Key Parts Overheating (oH2)	79: U Phase over current before run (Aoc)
18: Thermistor 1 open (tH1o)	80: V Phase over current before run (boc)
19: Capacitor hardware error (tH2o)	81: W Phase over current before run (coc)
21: Drive over-load (oL)	82: U Phase output phase loss (oPL1)
22: Electronics thermal relay protection 1 (EoL1)	83: V Phase output phase loss (oPL2)
23: Electronics thermal relay protection 2 (EoL2)	84: W Phase output phase loss (oPL3)
24: Motor Overheat-PTC (oH3)	87: Drive overload in low frequency (oL3)
26: Over Torque 1 (ot1)	89: Initial rotor position detection error (roPd)
27: Over Torque 2 (ot2)	111: InrCOM time-out error (InrCOM)
28: Under current (uc)	121: Internal communication error (CP20)
29: Limit error (LiT)	123: Internal communication error (CP22)
31: Memory read-out error (cF2)	124: Internal communication error (CP30)
33: U phase current sensor detection error (cd1)	126: Internal communication error (CP32)
34: V phase current sensor detection error (cd2)	127: Internal communication error (CP33)
35: W phase current sensor detection error (cd3)	128: Over-torque 3 (ot3)
36: Clamp current detection error (Hd0)	129: Over-torque 4 (ot4)
37: Over-current detection error (Hd1)	134: Electronics thermal relay 3 protection (EoL3)
40: Auto tuning error (AuE)	135: Electronics thermal relay 4 protection (EoL4)
41: PID Feedback loss (AFE)	140: GFF detected when power on (Hd6)
42: PG feedback error (PGF1)	141: GFF occurs before run (b4GFF)
43: PG feedback loss (PGF2)	142: Auto tuning error 1 (AUE1)
44: PRG feedback stall (PGF3)	143: Auto tuning error 2 (AUE2)
45: Encoder slip error (PGF4)	144: Auto tuning error 3 (AUE3)
48: Analog current input loss (ACE)	

**INTRODUCTION – HOW TO GET STARTED**

Automationdirect.com would like to thank you for your purchase of the Durapulse GS30 AC drive. The GS30 drive is a state-of-the-art, full-featured AC drive. The Quick-Start Guide below will introduce you to many of the GS30 drive features and help you configure the GS30 drive in a minimum amount of time.

STO (Safe Torque Off) / Emergency Stop

The GS30 drive offers Safe Torque Off (STO) functionality, instead of a standard Emergency Stop circuit. STO provides the ability to immediately turn off the output of the GS30 drive in the event of an emergency, without the need for an emergency stop contactor between the drive and motor.

Please see the Control-Circuit Wiring diagrams (page 1) for how to wire the STO circuit. From the factory, the GS30 STO terminals are jumpered and the STO circuitry of the drive is bypassed. STO is recommended for personnel safety.

After wiring the drive (but before applying power), the first thing you should do is press the E-stop button (or otherwise break the safety circuit) and verify that the circuit between the STO1/STO2 terminals and the STO +24V terminal is not connected. If these circuits are open, the STO feature will stop all power from going to the motor and there will be no danger of unexpected movement when you power up the drive.

Powering Up the GS30 Drive

Apply AC line power to the GS30 drive, but don't engage the safety circuit yet (keep the E-stop PB pushed in).

Starting, Stopping, and Controlling the Speed of the GS30 Drive

Out of the box GS30 drives are set to use the keypad buttons to RUN and STOP the drive and vary the drive speed. The drive can also be configured to run from potentiometers, external pushbuttons, Ethernet communication, etc.

Do not attempt to run the motor yet. Certain parameters (especially the motor protection parameters) must be set first.

Configure the Drive

The tables below list those parameters typically used in most applications. You can navigate to any of these parameters through the keypad. (Refer to page 3 for information and instructions for using the Digital Keypad.)

All applications need to configure the parameters in the "Quick Configuration" table. At minimum, you MUST configure these motor parameters before operating the drive:

- 01.00 Motor1 Max Output Frequency (this will typically be 50Hz or 60Hz)
- 01.02 Motor1 Max Output Voltage (this will typically be either 230V or 460V)
- 05.01 Motor1 Rated Amps (depends on the motor)

The main configuration parameters required to get your drive up and running are included in this guide. For more advanced configuration options, please see the User Manual. Your application will dictate which parameters need to be configured. It is NOT necessary to configure every parameter listed in the tables in the User Manual, use only those you need.

Parameter Groups

Group Number	Group Category
00	Drive Config
01	Basic Config
02	Digital I/O Config
03	Analog I/O Config
04	Multi-Step Speed Config
05	Motor Config
06	Protection Config
07	Special Parameters
08	PID Config
09	Communications Config
10	Speed Control Config
11	Advanced Config
12	Tension Config
13	Macro Config
14	Protection (2) Config

After configuring the minimum settings, you can now engage the safety circuit. The RUN and STOP/RESET buttons should Start and Stop the drive. To adjust the output frequency, press the MENU button repeatedly until the "F xx" appears for "Frequency Setpoint". Use the Digital Dial to adjust the frequency.

**PARAMETER SET UP**

DURAPULSE GS30 AC Drives offer parameter setup from the keypad for some of the most common drives applications. Choose parameters from the table below, then set the applicable parameters for that application as shown.

To Configure Parameters:

From the power up screen:

- 1) Press **MENU** until you see **H 0.00** (this is the actual drive frequency) and press **ENTER**.
- 2) Use the **Dial** to select the parameter group you want and press **ENTER**.
- 3) Use the **Dial** to select the parameter number you want within that group and press **ENTER**.
- 4) Change the value of the parameter using the **Dial** and press **ENTER**.
- 5) Press **MENU** to exit back to the main menu.
- 6) Repeat as needed until all required parameters are configured.



Please refer to the user manual if you need more detailed information about the parameters.

DURAPULSE GS30 Parameter Settings – Quick Configuration*					
Parameter Group	#	Description	Range	Default	User
00	00	GS30 Model ID	Read Only	n/a	
00	01	Displays AC drive rated current	Displays amperage	n/a	
00	02	Restore to default**	0=No function 1=Parameter write protect 5=Reset kWh display to 0 6=Reset PLC 7=Reserved 8=Keypad doesn't respond 9=Reset 50Hz defaults 10=Reset 60Hz defaults 11=Reset 50Hz defaults (keep user config) 12=Reset 60Hz defaults (keep user config)	0	
00	06	Firmware Version	Read Only	n/a	
00	10	Control Method	0=Speed mode 2=Torque mode	0	
00	11	Velocity Mode	0=VF Open Ctrl 1=VF Enc Close Ctrl 2=SVC Sensorless 3=IM FOC Enc Ctrl 4=PM FOC Enc Ctrl 5=FOC Sensorless 6=Reserved 7=IPM Sensorless	0	
00	16	Duty Selection	0=Variable Torque 1=Constant Torque	1	
00	20	Frequency Command Source	0=Digital keypad 1=RS-485 comm 2=External UP/DWN key 4=Enc Ref w/o Dir 5=Enc Ref with Dir 8=Comm card 9=PID	0	
00	21	Operation Command Source	0=Digital keypad 1=External terminals 2=Communication RS-485 input 5=Communication card	0	
00	22	Stop Method	0=Ramp to stop 1=Coast to stop	0	
00	23	Motor Direction Control	0=Enable forward/reverse 1=Disable reverse 2=Disable forward	0	
01	00	Motor 1 Max Frequency	0.00-599.00 Hz	60	
01	01	Motor 1 Base Frequency	0.00-599.00 Hz	60	
01	02	Motor 1 Rated Voltage	110V/230V: 0.0~255.0, 460V: 0.0~510.0V	220.0 440.0	
01	09	Startup Frequency	0.00-599.0 Hz	0.5	
01	10	Output Frequency Upper Limit	0.00-599.0 Hz	599.0	
01	11	Output Frequency Lower Limit	0.00-599.0 Hz	0.00	
01	12	Acceleration Time 1		10.00 10.00	
01	13	Deceleration Time 1		10.00 10.00	
01	20	Jog Acceleration Time	P01.45=0: 0.00-600.0 sec P01.45=1: 0.00-6000.0 sec	10.00 10.00	
01	21	Jog Deceleration Time		10.00 10.00	
01	22	Jog Frequency	0.00-599.0 Hz	0.5	

\* Assumes default V/Hz mode with no feedback. To change control modes see complete parameter listing in User manual.  
\*\* Reboot drive after resetting defaults.  
**Note:** Drive default is Auto mode and cannot be changed from the keypad. For Local/Hand, use Discrete input configuration settings (P02.00–P02.07) and P00.29–P00.31.

(table continued next column)

DURAPULSE GS30 Parameter Settings – Quick Configuration (continued)					
Parameter	Description	Settings	Default	User	
02	00	2-wire / 3-wire Control	0=No function 1=2-wire mode 1, power on for operation control (M1: FWD/STOP, M2: REV/STOP) 2=2-wire mode 2, power on for operation control (M1: RUN/STOP, M2: REV/FWD) 3=3-wire, power on for operation control (M1: RUN, M2: REV/FWD, M3: STOP) 4=2-wire mode 1, fast start up (M1: FWD/STOP, M2: REV/STOP) 5=2-wire mode 2, fast start up (M1: RUN/STOP, M2: REV/FWD) 6=3-wire, fast start up (M1: RUN, M2: REV/FWD, M3: STOP) <b>Note:</b> In fast start up mode, the drive skips detecting IGBT signal and will run immediately. When using fast start up mode: Terminal output stays in ready status and drive responds to commands immediately. The output terminal will have higher voltage if the drive is short circuited an OC error will display when running up	1	
02	01	DI1 Assignment Select 1 (FWD/DI1)		0	
02	02	DI2 Assignment Select 2 (REV/DI2)		0	
02	03	DI3 Assignment Select 3 (DI3)		1	
02	04	DI4 Assignment Select 4 (DI4)	See "Multi-function Input Selections" on page 5	2	
02	05	DI5 Assignment Select 5 (DI5)		3	
02	06	DI6 Assignment Select 6 (DI6)		4	
02	07	DI7 Assignment Select 7 (DI7)		0	
02	13	Relay 1 Function Select (R1)		11	
02	16	DO1 Assignment Select 2 (DO1)	See "Multi-function Output Selections" on page 5	0	
02	17	DO2 Assignment Select 3 (DO2)		0	
02	35	Auto-run on Power-up (includes after a Fault reset)	0: Disable 1: Drive Runs on Run Command after Fault Reset or Power Up	0	
03	00	Analog Input Selection (AI1)	See "AI Multi-function Input Selections" on page 5	1	
03	01	Analog Input Selection (AI2)		0	
03	20	Multi-function Output (AO1)	See "AO1 Multi-function Output Selections" on page 5	0	
03	28	AI1 terminal input selection	0=0–10 V 3=-10–10 V	0	
03	29	AI2 terminal input selection	0=4–20 mA 1=0–10 V 2=0–20 mA	0	
05	00	Auto-tuning selection	0=No function 1=IM rotary tuning 2=IM static tuning 4=Permanent magnet static pole angle 5=Permanent magnet rotary tuning 12=SVC inertia estimation 13=Permanent magnet static tuning	0	
05	01	Motor 1 Full Load Amps (FLA)	10-120% of drive rated current	###	
05	02	Motor 1 Rated Power	0.00–655.35 kW	Based on model	
05	03	Motor 1 Rated RPM	0-65535	1710	
05	04	Motor 1 Number of poles	2-20	4	
06	06	Over-torque Detection Selection (Motor 1)	0=Disable 1=Continue operation after over-torque detection during constant speed operation 2=Stop after over-torque detection during constant speed operation 3=Continue operation after over-torque detection during RUN 4=Stop after over-torque detection during RUN	0	
06	07	Over-torque Detection Level (Motor 1)	10–250% (100% corresponds to the rated current of the drive)	120	
06	08	Over-torque Detection Time (Motor 1)	0.1–60.0 seconds	0.1	
06	13	Motor 1 Electronic Thermal Overload Relay	0=Inverter motor (with external forced cooling) 1=Standard motor (motor with fan on the shaft) 2=Disabled <b>Note:</b> A value of 0 or 1 is recommended to protect the motor in most applications.	1	
06	14	Motor 1 Electronic Thermal Relay Time	30.0-600.0	60	
06	55	Drive Derating Method	0=Carrier Freq Derate 1=Current Derate 2=Carrier Freq Derate W.O Constant Current	0	

(table continued next page)

DURAPULSE GS30 Parameter Settings – Quick Configuration (continued)					
Parameter Group	#	Description	Range	Default	User
07	10	Restart after fault action	0=Stop operation 1=Speed tracking by current speed 2=Speed tracking by minimum output frequency	0	
07	11	Number of times to attempt auto-restart after fault	0-10	0	
07	19	Fan cooling control*	0=Fan is always ON 1=Fan is OFF after the AC motor drive stops for one minute 2=Fan is ON when the AC motor drive runs, fan is OFF when the AC motor drive stops 3=Fan turns ON when temperature (IGBT) reaches approximately 60°C	3	
08	00	PID Feedback terminal selection	0=Disabled 1=Negative PID feedback: by analog input (P03.00) 2=Negative PID feedback: by single-phase pulse input (DI7), without direction (P10.02) 3=Negative PID feedback: by single -phase pulse input (DI7), with direction (P10.02) 4=Positive PID feedback: by analog input (P03.00) 5=Positive PID feedback: by single -phase pulse input (DI7), without direction (P10.02) 6=Positive PID feedback: by single -phase pulse input (DI7), with direction (P10.02) 7=Negative PID feedback: by communication protocol 8=Positive PID feedback: by communication protocol	0	
08	01	Proportional gain (P)	0.0-1000.0 (When P08.23 bit 1=0) 0.00-100.00 (When P08.23 bit 1=1)	1.00	
08	02	Integral time (I)	0.00-100.00 sec.	1.00	
08	03	Differential time (D)	0.00-1.00 sec.	0.00	
08	04	Upper limit of integral control	0.0-100.0%	100.0	
08	05	PID output command limit (positive limit)	0.0-110.0%	100.0	
08	06	PID feedback value by communication protocol	-200.00-200.00%	0.00	
08	07	PID delay time	0.0-2.5 sec.	0.0	
08	08	Feedback signal detection time	0.0-3600.0 sec.	0.0	
08	09	Feedback signal fault treatment	0=Warn and Keep Run 1=Fault and Ramp Stop 2=Fault and Coast Stop 3=Warn and Keep Freq	0	
08	65	PID target value source	0=Freq Cmd 1=From Pr08-66 2=RS485 Comm 3=Analog Input 6=Comm Card	0	
13	00	Application Selection	00=Disabled 01=User parameter 02=Compressor 03=Fan 04=Pump 05=Conveyor 06=Machine tool 07=Packing 08=Textiles 10=Logistics 11=Tension PID function 12=Tension PID master/aux frequency function	0	

\* Note, not all drives come standard with fans

Multi-function Input Selections		
0=No function	23=Counter input (DI6)	52=Selection for PLC mode bit 1
1=Multi-step speed command 1	24=FWD JOG command	56=Local / Remote selection
2=Multi-step speed command 2	25=REV JOG command	70=Force auxiliary frequency return to 0
3=Multi-step speed command 3	26=TRQ / Field Oriented Control (FOC) mode selection	71=Disable PID function, force PID output return to 0
4=Multi-step speed command 4	27=ASR1 / ASR2 selection	72=Disable PID function, retain the output value before disabled
5=Reset	28=Emergency stop (EF1) (optional)	73=Force PID integral gain return to 0, disable integral
6=JOG [by external control or GS4-KPD (optional)]	29=Signal confirmation for Y-connection	74=Reverse PID feedback
7=Acceleration / deceleration speed inhibit	30=Signal confirmation for Δ-connection	78=Multi-step position confirmation
8=1st and 2nd acceleration / deceleration time selection	31=High torque bias (P11.30)	79=Position/speed mode switching (0=Speed mode, 1=Position mode)
9=3rd and 4th acceleration / deceleration time selection	32=Middle torque bias (P11.31)	80=Location command source switching (increase) (0=Internal register, 1=External pulse input)
10=External Fault (EF) Input (P07.20)	33=Low torque bias (P11.32)	83=Multi-motor (IM) selection bit 0
11=Base Block (B.B.) input from external source	38=Disable writing EEPROM function	84=Multi-motor (IM) selection bit 1
12=Output stop	39=Torque command direction	86=Enable initial reel diameter
13=Cancel the setting of auto-acceleration / auto-deceleration time	40=Force coasting to stop	87=Initial reel diameter 1
15=Frequency command from AI1	41=HAND switch	88=Initial reel diameter 2
16=Frequency command from AI2	42=AUTO switch	89=PID integration reset
18=Forced to stop (P07.20)	43=Enable resolution selection (P02.48)	90=Stop calculating the reel diameter
19=Frequency up command	44=Negative limit switch (NL)	91=Winding mode selection
20=Frequency down command	45=Positive limit switch (PL)	92=Enable tension control
21=PID function disabled	46=Homing (ORG)	93=Pause tension PID function
22=Clear the counter	48=Mechanical gear ratio switch	94=Enable to auto switch the reel
	49=Enable drive	
	50=Slave dEb action to execute	
	51=Selection for PLC mode bit 0	

Multi-function Output Selections		
0=No function	19=External interrupt B.B. input (Base Block)	42=Crane function
1=Indication during RUN	20=Warning output	43=Motor speed detection
2=Operation speed reached	21=Over-voltage	44=Low current output (use with P06.71-06.73)
3=Desired frequency reached 1 (P02.22)	22=Over-current stall prevention	45=UVW output electromagnetic valve switch
4=Desired frequency reached 2 (P02.24)	23=Over-voltage stall prevention	46=Master dEb output
5=Zero speed (Frequency command)	24=Operation mode	51=Analog output control for RS-485 interface
6=Zero speed including STOP (Frequency command)	25=Forward command	52=Output control for communication cards
7=Over-torque 1 (P06.06-06.08)	26=Reverse command	66=SO output logic A
8=Over-torque 2 (P06.09-06.11)	29=Output when frequency ≥ P02.34	67=Analog input level reached
9=Drive is ready	30=Output when frequency < P02.34	68=SO output logic B
10=Low voltage warning (Lv) (P06.00)	31=Y-connection for the motor coil	69=Maximum reel diameter reached
11=Malfunction indication	32=Δ-connection for the motor coil	70=Empty reel diameter reached
13=Overheat warning (P06.15)	33=Zero speed (actual output frequency)	71=Broken belt detection
14=Software brake signal indicator (P07.00)	34=Zero speed including STOP (actual output frequency)	72=Tension PID feedback error
15=PID feedback error (P08.13, P08.14)	35=Error output selection 1 (P06.23)	73=Over-torque 3
16=Slip error (oS/L)	36=Error output selection 2 (P06.24)	74=Over-torque 4
17=Count value reached, does not return to 0 (P02.20)	37=Error output selection 3 (P06.25)	75=Forward RUN status
18=Count value reached, return to 0 (P02.19)	38=Error output selection 4 (P06.26)	76=Reverse RUN status
	39=Position reached (P10.19)	
	40=Speed reached (including STOP)	

AI Multi-function Input Selections		
0=No function	7=Positive torque limit	14=Tension PID feedback signal
1=Frequency command	8=Negative torque limit	15=Line speed
2=Torque command (torque limit under speed mode)	9=Regenerative torque limit	16=Reel diameter
3=Torque compensation command	10=Positive / negative torque limit	17=Tension PID target value
4=PID target value	11=PT100 thermistor input value	18=Tension setting value
5=PID feedback signal	12=Auxiliary frequency input	19=Zero-speed tension
6=Thermistor (PTC) input value	13=PID compensation value	20=Tension taper
		21=VF5M V source

AO1 Multi-function Output Selections		
0=Output frequency (Hz)	8=Output torque	16=Vq-axis voltage command
1=Frequency command (Hz)	9=A11 percent	17=Vd-axis voltage command
2=Motor speed (Hz)	10=A12 percent	18=Torque command
3=Output current (rms)	12=Iq current command	19=PG2 (DI7) frequency command
4=Output voltage	13=Iq feedback value	21=RS-485 analog output
5=DC bus voltage	14=Id current command	22=Communication card analog output
6=Power factor	15=Id feedback value	23=Constant voltage output (P03.32)

**ENVIRONMENT FOR OPERATION, STORAGE, AND TRANSPORTATION**

DO NOT expose the GS30 drive to environments that contain dust, direct sunlight, corrosive/inflammable gases, high humidity, liquids, or high vibration. The salt in the air must be less than 0.01 mg/cm<sup>2</sup> throughout the year.

<b>Installation Location</b>	IEC60364-1/IEC60664-1 Pollution degree 2, Indoor use only		
<b>Surrounding Temperature</b>	Operation	IP20/UL Open Type	-20°C to +50°C -20°C to +60°C (with derating)
		IP40/NEMA 1/UL Open Type	-20°C to +40°C -20°C to +50°C (with derating)
		Installed side-by-side	
	Storage: -40°C to +85°C	Transportation: -20°C to +70°C	
	No condensation, non-frozen		
<b>Rated Humidity</b>	Operation: Max. 90%		Storage/Transportation: Max. 95%
	No condensed water		
<b>Air Pressure</b>	Operation/Storage: 86 to 106 kPa		Transportation: 70 to 106 kPa
<b>Pollution Level</b>	IEC 60721-3		
	Operation:	Class 3C2; Class 3S2	Storage: Class 2C2; Class 2S2
			Transportation: Class 1C2; Class 1S2
	No concentrate		
<b>Altitude</b>	Operable at altitudes of 0~1000m. If installed at altitudes greater than 1000m, derating is required.		
<b>Package Drop</b>	Storage	ISTA procedure 1A (according to weight) IEC60068-2-31	
	Transportation		
<b>Vibration</b>	Operating	1.0mm, peak-to-peak value range from 2Hz to 13.2 Hz; 0.7G~1.0G range from 13.2Hz to 55Hz; 1.0G range from 55Hz to 512 Hz. Comply with IEC 60068-2-6.	
	Non-operating	2.5 G peak, 5Hz~2kHz; 0.015" maximum displacement.	
<b>Impact</b>	Operating	IEC/EN60068-2-27: 15G, 11ms	
	Non-operating	30G	
<b>Protection Level</b>	IP20 or IP40 depending on drive. Please see the GS30 User Manual for details.		


To prevent personal injury, please make sure that the case and wiring are installed according to these instructions. The figures in these instructions are only for reference. They may be slightly different from the one you have, but it will not affect your customer rights.

These installation instructions may be revised without prior notice. The most recent edition can be downloaded from the AutomationDirect web site at any time: <http://www.automationdirect.com/static/manuals/index.html>.

**MINIMUM MOUNTING CLEARANCES**

When installing your GS30 drive, please keep the following in mind:

- Prevent fiber particles, scraps of paper, shredded wood, saw dust, metal particles, etc., from adhering to the heat sink.
- Install the AC motor drive in a metal cabinet. When installing one drive below another one, use a metal separation between the AC motor drives to prevent mutual heating and to prevent the risk of accidental fire.
- Install the AC motor drive in Pollution Degree 2 environments only: normally only nonconductive pollution occurs and temporary conductivity caused by condensation is expected.
- In Pollution Degree 2 environments, install drives in an IP54 cabinet or in a pollution-controlled environment. Pollution Degree 2 defines an environment in which dew can form causing temporary electrical conduction. Electrical equipment in the control panel and thermostatic chamber only causes non-conductive pollution.



**GS30 FRAMES A-F**

Installation Method	A (mm)	B (mm)	C (mm)	Operation Temperature	
				Max (w/out derating)	Max (Derating)
Single drive installation	50	30	-	50	60
Side-by-side horizontal installation	50	30	30	50	60
Zero stack installation	50	30	0	40	50

**GS30 FRAMES G-I**

Installation Method	A (mm)	B (mm)	C (mm)	Operation Temperature	
				Max (w/out derating)	Max (Derating)
Single drive installation	100	50	-	50	60
Side-by-side horizontal installation	100	50	50	50	60
Zero stack installation	100	50	0	40	50

**BLANK PAGE**