



Ethernet Communications Modules

Manual Number H24–ECOM–M



WARNING

Thank you for purchasing automation equipment from **Automationdirect.com™**. We want your new **DirectLOGIC™** automation equipment to operate safely. Anyone who installs or uses this equipment should read this publication (and any other relevant publications) before installing or operating the equipment.

To minimize the risk of potential safety problems, you should follow all applicable local and national codes that regulate the installation and operation of your equipment. These codes vary from area to area and usually change with time. It is your responsibility to determine which codes should be followed, and to verify that the equipment, installation, and operation are in compliance with the latest revision of these codes.

At a minimum, you should follow all applicable sections of the National Fire Code, National Electrical Code, and the codes of the National Electrical Manufacturer's Association (NEMA). There may be local regulatory or government offices that can also help determine which codes and standards are necessary for safe installation and operation.

Equipment damage or serious injury to personnel can result from the failure to follow all applicable codes and standards. We do not guarantee the products described in this publication are suitable for your particular application, nor do we assume any responsibility for your product design, installation, or operation.

*Our products are not fault-tolerant and are not designed, manufactured or intended for use or resale as on-line control equipment in hazardous environments requiring fail-safe performance, such as in the operation of nuclear facilities, aircraft navigation or communication systems, air traffic control, direct life support machines, or weapons systems, in which the failure of the product could lead directly to death, personal injury, or severe physical or environmental damage ("High Risk Activities"). **Automationdirect.com™** specifically disclaims any expressed or implied warranty of fitness for High Risk Activities.*

For additional warranty and safety information, see the Terms and Conditions section of our Desk Reference. If you have any questions concerning the installation or operation of this equipment, or if you need additional information, please call us at 770-844-4200.

This publication is based on information that was available at the time it was printed. At **Automationdirect.com™** we constantly strive to improve our products and services, so we reserve the right to make changes to the products and/or publications at any time without notice and without any obligation. This publication may also discuss features that may not be available in certain revisions of the product.



Trademarks

This publication may contain references to products produced and/or offered by other companies. The product and company names may be trademarked and are the sole property of their respective owners. **Automationdirect.com™** disclaims any proprietary interest in the marks and names of others.

**Copyright 2002, Automationdirect.com™ Incorporated
All Rights Reserved**

No part of this manual shall be copied, reproduced, or transmitted in any way without the prior, written consent of **Automationdirect.com™** Incorporated. **Automationdirect.com™** retains the exclusive rights to all information included in this document.

AVERTISSEMENT

Nous vous remercions d'avoir acheté l'équipement d'automatisation de **Automationdirect.com™**. Nous tenons à ce que votre nouvel équipement d'automatisation **DirectLOGIC™** fonctionne en toute sécurité. Toute personne qui installe ou utilise cet équipement doit lire la présente publication (et toutes les autres publications pertinentes) avant de l'installer ou de l'utiliser.

Afin de réduire au minimum le risque d'éventuels problèmes de sécurité, vous devez respecter tous les codes locaux et nationaux applicables régissant l'installation et le fonctionnement de votre équipement. Ces codes diffèrent d'une région à l'autre et, habituellement, évoluent au fil du temps. Il vous incombe de déterminer les codes à respecter et de vous assurer que l'équipement, l'installation et le fonctionnement sont conformes aux exigences de la version la plus récente de ces codes.

Vous devez, à tout le moins, respecter toutes les sections applicables du Code national de prévention des incendies, du Code national de l'électricité et des codes de la National Electrical Manufacturer's Association (NEMA). Des organismes de réglementation ou des services gouvernementaux locaux peuvent également vous aider à déterminer les codes ainsi que les normes à respecter pour assurer une installation et un fonctionnement sûrs.

L'omission de respecter la totalité des codes et des normes applicables peut entraîner des dommages à l'équipement ou causer de graves blessures au personnel. Nous ne garantissons pas que les produits décrits dans cette publication conviennent à votre application particulière et nous n'assumons aucune responsabilité à l'égard de la conception, de l'installation ou du fonctionnement de votre produit.

Nos produits ne sont pas insensibles aux défaillances et ne sont ni conçus ni fabriqués pour l'utilisation ou la revente en tant qu'équipement de commande en ligne dans des environnements dangereux nécessitant une sécurité absolue, par exemple, l'exploitation d'installations nucléaires, les systèmes de navigation aérienne ou de communication, le contrôle de la circulation aérienne, les équipements de survie ou les systèmes d'armes, pour lesquels la défaillance du produit peut provoquer la mort, des blessures corporelles ou de graves dommages matériels ou environnementaux ("activités à risque élevé"). La société **Automationdirect.com™** nie toute garantie expresse ou implicite d'aptitude à l'emploi en ce qui a trait aux activités à risque élevé.

Pour des renseignements additionnels touchant la garantie et la sécurité, veuillez consulter la section Modalités et conditions de notre documentation. Si vous avez des questions au sujet de l'installation ou du fonctionnement de cet équipement, ou encore si vous avez besoin de renseignements supplémentaires, n'hésitez pas à nous téléphoner au 770-844-4200.

Cette publication s'appuie sur l'information qui était disponible au moment de l'impression. À la société **Automationdirect.com™**, nous nous efforçons constamment d'améliorer nos produits et services. C'est pourquoi nous nous réservons le droit d'apporter des modifications aux produits ou aux publications en tout temps, sans préavis ni quelque obligation que ce soit. La présente publication peut aussi porter sur des caractéristiques susceptibles de ne pas être offertes dans certaines versions révisées du produit.

Marques de commerce


La présente publication peut contenir des références à des produits fabriqués ou offerts par d'autres entreprises. Les désignations des produits et des entreprises peuvent être des marques de commerce et appartiennent exclusivement à leurs propriétaires respectifs. **Automationdirect.com™** nie tout intérêt dans les autres marques et désignations.

Copyright 2002, **Automationdirect.com™** Incorporated

Tous droits réservés

Nulle partie de ce manuel ne doit être copiée, reproduite ou transmise de quelque façon que ce soit sans le consentement préalable écrit de la société **Automationdirect.com™** Incorporated. **Automationdirect.com™** conserve les droits exclusifs à l'égard de tous les renseignements contenus dans le présent document.

Manual Revisions



If you contact us in reference to this manual, be sure and include the revision number.

Title: Ethernet Communication Modules

Manual Number: H24–ECOM–M

| Issue | Date | Description of Changes |
|-----------------------|------|--|
| Original | 4/98 | Original Issue |
| 1st Edition, Rev A | 8/02 | Added DL250–1 and DL260 references Removed DL250 references Minor changes (Note: DL250 has the same functionality as the DL250–1 except for local expansion capability.) |

Table of Contents

Chapter 1: Introduction

| | |
|---|------------|
| Manual Overview | 1-2 |
| The Purpose of this Manual | 1-2 |
| Other Reference Materials | 1-2 |
| Who Should Read this Manual | 1-2 |
| Quality Technical Manuals and Technical Support | 1-2 |
| Chapters | 1-3 |
| Appendices | 1-3 |
| Other Resources | 1-3 |
| ECOM Module Introduction | 1-4 |
| ECOM Communication Possibilities | 1-4 |
| Your Network PC | 1-5 |
| Frequently Asked Questions | 1-6 |

Chapter 2: Setup and Installation

| | |
|--|-------------|
| ECOM Network Identifiers | 2-2 |
| Module ID | 2-3 |
| Name | 2-3 |
| IP Address | 2-4 |
| Ethernet Address | 2-4 |
| Using Multiple Network Identifiers | 2-4 |
| Setting the Module ID with the DIP Switch | 2-5 |
| The H2-ECOM (-F) DIP Switch | 2-5 |
| The H4-ECOM (-F) DIP Switch | 2-6 |
| Running NetEdit Software | 2-7 |
| Operating System Requirements | 2-7 |
| The NetEdit Screen | 2-7 |
| Features of the NetEdit Screen | 2-8 |
| Protocol | 2-8 |
| Adding Network Protocol Support to Your PC | 2-9 |
| Module | 2-9 |
| Module Information | 2-10 |
| Ethernet Stats | 2-10 |
| Configuration | 2-10 |
| RX/WX Settings | 2-11 |
| Using <i>Direct</i> SOFT32 for ECOM Setup | 2-12 |
| Inserting the ECOM Module in the PLC Base | 2-13 |
| DL205 Slot Choices | 2-13 |
| H2-ECOM (-F) Module Installation | 2-13 |
| DL405 Slot Choices | 2-14 |
| H4-ECOM (-F) Module Installation | 2-15 |

| | |
|--|-------------|
| ECOM Network Layouts | 2-15 |
| Network Cabling | 2-17 |
| ECOM Supports Two Standards | 2-17 |
| 10BaseT Networks | 2-17 |
| 10BaseT Connections | 2-18 |
| UTP Cable | 2-18 |
| 10BaseFL Connections | 2-18 |
| Fiber Optic Cable | 2-18 |
| Fiber Optic Module ST Connector | 2-18 |
| Maximum Cable Length | 2-19 |
| Maximum Number of ECOM Modules on the Network | 2-20 |

Chapter 3: RLL Programming for Communications

| | |
|---|-------------|
| PLC-to-PLC Communications | 3-2 |
| How RLL is Used for Communications | 3-2 |
| Network Instructions | 3-3 |
| Read (RX) and Write (WX) Instructions | 3-3 |
| Building the Read (RX) or Write (WX) Routine | 3-3 |
| The First LD Instruction | 3-3 |
| The Second LD Instruction | 3-4 |
| The LDA Instruction | 3-4 |
| Write (WX) Instruction | 3-5 |
| Addressing the Different Memory Types | 3-6 |
| Bit Memory | 3-6 |
| Word Memory and Aliases | 3-6 |
| <i>Direct</i> SOFT is Flexible | 3-7 |
| D2-240 CPU | 3-7 |
| D2-250-1 CPU | 3-7 |
| D2-260 CPU | 3-8 |
| D4-430 CPU | 3-9 |
| D4-440 CPU | 3-9 |
| D4-450 CPU | 3-10 |
| Special Relays for Communications | 3-11 |
| Example Program with One Read Instruction | 3-13 |
| Program for the Initiating PLC | 3-13 |
| Program for the Responding PLC | 3-13 |
| Rung 1 | 3-14 |
| Rung 2 | 3-14 |
| Rung 3 | 3-14 |
| Rung 4 | 3-14 |
| Program for the Responding PLC | 3-14 |
| Example Program with One Write Instruction | 3-15 |
| Program for the Initiating PLC | 3-15 |
| Program for the Responding PLC | 3-15 |
| Rung 1 | 3-16 |
| Rung 2 | 3-16 |
| Rung 3 | 3-16 |

| | |
|---|-------------|
| Rung 4 | 3-16 |
| Program for the Responding PLC | 3-16 |
| Integrating Multiple Read and Write Instructions | 3-17 |
| Interlocking Relays | 3-17 |
| First RX/WX Instruction | 3-18 |
| Second RX/WX Instruction | 3-19 |
| Third RX/WX Instruction | 3-19 |
| Returning to the First RX/WX Instruction | 3-19 |
| Shift Register | 3-20 |
| Store If Equal | 3-20 |
| First RX/WX Instruction | 3-21 |
| Second RX/WX Instruction | 3-21 |
| Third RX/WX Instruction | 3-21 |

Chapter 4: Maintenance and Troubleshooting

| | |
|--|------------|
| Isolating a Communication Problem | 4-2 |
| Diagnostic "Tools" | 4-2 |
| Troubleshooting Chart | 4-2 |
| ECOM Module Diagnostic LEDs | 4-4 |
| ECOM LEDs | 4-4 |
| Link Good Indicator | 4-4 |
| ACT Indicator | 4-4 |
| Error Indicator | 4-4 |
| Using NetEdit for Troubleshooting | 4-5 |
| Select a Module | 4-5 |
| Module Information | 4-5 |
| Change Protocol | 4-6 |
| Ethernet Stats | 4-6 |
| RX/WX Settings | 4-6 |
| Record the Module Settings | 4-7 |
| Replacing the ECOM Module | 4-7 |
| Diagnosing Network Cable Problems | 4-8 |

Appendix A: General Specifications

| | |
|-------------------------------------|------------|
| General Specifications | A-2 |
| ECOM Specifications | A-2 |
| Ethernet Standards | A-3 |

Index

Introduction

In This Chapter. . . .


- Manual Overview
- ECOM Module Introduction
- Frequently Asked Questions

Manual Overview

The Purpose of this Manual

This manual describes how to use the **Ethernet Communication (ECOM) Modules**. You will find information about:

- Setting up the ECOM module
- Network layouts
- PC-to-PLC communications
- PLC-to-PLC communications
- RLL programming examples
- Maintenance and troubleshooting



Other Reference Materials

Other **Direct**LOGIC™ manuals may be useful for your application.

User Manuals

- DL205 User Manual part number D2–USER–M
- DL405 User Manual part number D4–USER–M
- **Direct**SOFT User Manual (with part number PC–PGMSW v2.3 or later)
- DSData Server User Manual (with part number PC–DSDATA–M)

Who Should Read this Manual

If you need a high-speed communications link between your **Direct**LOGIC PLC and PCs or other **Direct**LOGIC PLCs and you understand the basics of installing and programming PLCs, this is the right manual for you. This manual gives you the information you need to set up and install a communication link to an ECOM module.

Quality Technical Manuals and Technical Support

We strive to make our manuals the best in the industry. We rely on your feedback to let us know if we are reaching our goal. If you cannot find the solution to your particular application, or, if for any reason you need additional assistance, please call us at **770-844-4200**. Our technical support group is glad to work with you in answering your questions. They are **available weekdays from 9:00 a.m. to 6:00 p.m. Eastern Time**. You can also contact us on the **web** at:

<http://www.automationdirect.com>

- **Table of Contents** – chapter and section listing of contents, in the front of this manual
- **Quick Guide to Contents** – chapter summary listing on the next page
- **Appendix** – module specifications and Ethernet standards
- **Index** – alphabetical listing of key words at the end of this manual

If you have a comment or question about any of our products, services, or manuals please fill out and return the 'Suggestions' card that came with this manual.

Conventions Used



When you see the “light bulb” icon in the left–hand margin, the paragraph to its immediate right will give you a **special tip**.
The word **TIP:** in boldface will mark the beginning of the text.




When you see the “notepad” icon in the left–hand margin, the paragraph to its immediate right will be a **special note**.
The word **NOTE:** in boldface will mark the beginning of the text.



When you see the “exclamation mark” icon in the left–hand margin, the paragraph to its immediate right will be a **warning**. This information could prevent injury, loss of property, or even death (in extreme cases).
The word **WARNING:** in boldface will mark the beginning of the text.

Key Topics for Each Chapter

The beginning of each chapter will list the key topics that can be found in that chapter.



ECOM Module Introduction

Four Ethernet Communication (**ECOM**) modules are currently available for use with DL205 and DL405 PLC systems. The four ECOM modules are shown below. These modules provide a low-cost, high-speed Ethernet link for PLC systems. The modules are easy to set up and install on 10BaseT (twisted pair, copper wire) or 10BaseFL (fiber optic) Ethernet networks.

LEDs on the face of each module give vital information about the status of the module and the communication link. The 10BaseT modules use standard RJ45 modular connectors, and the 10BaseFL modules use ST style bayonet connectors.

H2-ECOM



H2-ECOM-F



H4-ECOM



H4-ECOM-F



NOTE: We recommend using a dedicated network for your PLC control applications. For more information see Chapter 2, Setup and Installation.

ECOM Communication Possibilities

You can use the ECOM modules to share data between two or more **DirectLOGIC** PLCs or between **DirectLOGIC** PLCs and personal computers. Communication between PLCs is accomplished by using the Read/Write (RX/WX) instructions which are available in the **DirectSOFT32** Programming Software. Chapter 3 explains the use of RX/WX instructions.

You can also use a personal computer running **DirectSOFT32** Programming Software to program your PLCs over the Ethernet network. It is just like programming through the programming port on the CPU, but with the convenience of doing it from a single location.

Use catalog number PC-PGMSW to program the complete **DirectLOGIC** family of PLCs (only the DL205 series and the DL405 series can be programmed over Ethernet). You can use catalog number PC-PGM-205 for programming just the 205 series. You will need version 2.3 (or newer) of **DirectSOFT** software to recognize the ECOM module. Chapter 2 lists the CPUs which can be used with the ECOM modules.

Your Network PC

PCs running our DSData Server software can establish Ethernet links for exchanging information with **Direct**LOGIC 205/405 PLCs.

You can use a personal computer equipped with a 10BaseT or 10BaseFL network adapter card and NetEdit software to configure the ECOM module over the network. You can also use NetEdit for troubleshooting certain communication problems. The NetEdit utility is included with this manual and is available for download at <http://www.automationdirect.com>.



Frequently Asked Questions

Q. What is Ethernet?

A. Ethernet is a communication specification which defines cable type and signalling methods to be used in a local-area-network (LAN). An Ethernet network transmits *packets* of information between computers at speeds of 10 to 100 million bits per second (Mbps). Currently the most widely used version of the Ethernet standard is 10BaseT. Using the Ethernet standard allows products from many vendors to communicate using common software protocols and hardware.

Q. Will my PC communicate with the ECOM without the use of special software?

A. No, you must use a compatible software package. Popular Windows-based spreadsheet and database software or Human Machine Interface (HMI) software can share data via our DSData software. The DSData Server offers ready-to-use software drivers. Also, **DirectSOFT** V2.3 (or later) programming software will allow *online setup* of the ECOM modules and *programming* of the **DirectLOGIC** PLCs.

Q. Which protocols are supported by the ECOM module?

A. A protocol is a set of rules that allows computers to connect with one another specifying the format, timing, sequencing, and error checking for data packet transmission. The ECOM module supports Novel IPX and UDP/IP (Universal Datagram Protocol/Internet Protocol) in addition to a proprietary high-performance ECOM Ethernet protocol.

Q. Which Ethernet packets are recognized by the ECOM module?

A. The Ethernet Communication Module supports IEEE 802.2, IEEE 802.3, Ethernet 2, and SNAP Ethernet packets. The module will respond to IPX or UDP/IP messages which are initiated using compatible interface software. Using off-the-shelf Windows-based OPC/DDE-compliant software or HMI software and our DSData software, you can link to your PLC and access PLC data.

Q. How do I connect to an Ethernet network?

A. Ethernet devices can be directly connected to a Local Area Network or they can be connected using media adapter products. Media adapters (or transceivers) provide interconnection between different types of Ethernet cabling.

Q. Can I use the ECOM module to allow two PLCs to exchange data with each other?

A. You can use the ECOM to make it possible for two (or more) PLCs to exchange data (contents of memory locations) with each other.

The initiating PLC sends a Read/Write (RX/DX) request that says to the other PLC, "I want to tell you something" or "I want to ask you something." Once the data has been exchanged, the communication channel is closed, and the PLCs resume their program execution.

Q. Can I create multiple networks by putting more than one ECOM in a single PLC base?

A. Yes, but be sure to consult Chapter 2 for important installation information, and be sure not to exceed the PLC power budget (see the module specifications in Appendix A and the PLC User Manual).

Q. What does it mean to “set up” the ECOM module?

A. The ECOM module must have a network identifier in order for other PLCs or PCs to find it on the network. The network identifier can be set using a DIP switch or using software utilities (see Chapter 2).

Q. Are Ethernet specification documents required to install an ECOM system?

A. No. Detailed Ethernet specifications are not necessary for connecting the ECOM module to an Ethernet network. If you want more information about Ethernet networks, many books are available which give guidelines for implementing Ethernet 10BaseT or 10BaseFL networks.

Q. Which LAN technology should I use?

A. ECOM modules are available for connecting to 10BaseT or 10BaseFL (fiber optic) networks. The cable distances and environmental conditions often dictate which media type should be used. The most popular and flexible technology currently is 10BaseT, but 10BaseT is susceptible to electrical noise and is limited to relatively short cable runs. On the other hand, it is very simple and inexpensive, and repeaters can be used to extend its cable length limitations. 10BaseFL allows much longer cable runs with immunity to electrical noise. The fiber optic cable and hubs are currently more expensive than those for 10BaseT.

Setup and Installation

In This Chapter. . . .

- ECOM Network Identifiers
 - Setting the Module ID with the DIP Switch
 - Running NetEdit Software
 - Features of the NetEdit Screen
 - Inserting the ECOM Module in the PLC Base
 - ECOM Network Layouts
 - Network Cabling
 - Maximum Cable Length
 - Maximum Number of ECOM Modules on the Network
-

ECOM Network Identifiers

This section describes the various methods of assigning a network identifier to the ECOM module. Each module must be assigned at least one unique identifier to make it possible for PCs or other ECOMs to recognize it on the network. Four methods of identifying the ECOM module give it the flexibility to fit most networking schemes.

The four ECOM identifiers are:


- Module ID
- Name
- IP (Internet Protocol) Address
- Ethernet Address

The first three are user-selectable. The last one is set at the factory. Each of the identifiers is discussed below (also see the chart on page 2-11). If you have more than a few ECOMs on your network, consider making a chart or spreadsheet of network IDs, as shown below:

| Ethernet Address | Module ID | Name | IP Address |
|-------------------|-----------|----------------|-----------------|
| 00 E0 62 20 01 20 | 3 | PumpStationTwo | 192.168.100.005 |
| 00 E0 62 20 01 58 | 8 | Effluent | 255.255.255.255 |
| 00 E0 62 20 01 8D | 17 | BldgThree | 192.168.100.001 |
| 00 E0 62 20 01 94 | 2 | PumpStationOne | 192.168.100.002 |
| 00 E0 62 20 01 DE | 61 | | 192.168.100.003 |
| 00 E0 62 20 01 F1 | 33 | | 192.168.100.004 |
| 00 E0 62 20 01 FB | 1 | Control Room | 255.255.255.255 |
| 00 E0 62 20 01 F0 | 5 | Mixer | 192.168.100.006 |

The decision about which type of identifier to use is an important one. Much of the decision depends on the requirements of your particular application. PC-to-PLC communications are generally better accommodated with one type of identifier while PLC-to-PLC communications require a different type. Ease of maintenance and troubleshooting also must be considered before deciding which type to use.

The identifiers are used to **link** your PC to your PLC or one PLC to another PLC. The flexible design of the module allows you to use different identifiers for different links to the same module. This is particularly important if you require both PC-to-PLC and PLC-to-PLC communications on the same network.




Module ID

A Module ID is *required* for PLC-to-PLC communications, and it can be set either of two ways. You can assign the Module ID:

- using the DIP switches on the module.
- using the configuration tools in NetEdit, **DirectSOFT32** or our DSData Server.


Use the DIP switch if you want the ability to install or change modules *without using a PC* to set the Module ID. Set the module's DIP switch, insert the module in the base, and connect the network cable. Your Module ID is set on powerup, and your ECOM is ready to communicate on the network. We step through setting the DIP switch on pages 2-5 and 2-6.



If you prefer to be able to set or change all Module IDs on your network from a single PC, use the tools in NetEdit, **DirectSOFT32** or our DSData Server software. Starting on page 2-7, we step through the use of NetEdit and the network identifier options.

Name

A Name makes it easy to recognize the PLC by its function. An example of a Name is "PumpStationOne." The Name can be up to 32 alphanumeric characters in length. A Name can be assigned using NetEdit, **DirectSOFT32** or our DSData Server. See page 2-10 to learn how to assign a Name to an ECOM module.



NOTE: Some HMI software products will not accept Names with numbers as the first character, spaces or certain other non-alphanumeric ASCII characters. Also, your HMI product may not accept Names longer than 16 characters. Consult your HMI product documentation about its naming conventions.

IP Address IP Netmask

An IP Address can be assigned to the ECOM module if your network requires one. Usually, the IP Address is required in cases where PLCs are sharing the same network with PCs, and some of the PCs are carrying out functions unrelated to PLC control. Normally, a network administrator will assign an IP Address and to each device on the network. If you have a separate dedicated network for your PLCs, you do not have to use the IP Address, unless you are using the UDP/IP protocol (see page 2-8). You can use the Module ID or a Name for each communication link.

You can use NetEdit, *DirectSOFT32*, or our DSData Server to give your ECOM module an IP Address. See page 2-10 to learn how to change an IP Address.

The module ships from the factory with an IP Address of 255.255.255.255. This is not a usable IP Address for normal communications. It only serves as a default setting which can be changed using NetEdit, *DirectSOFT32* or our DSData Server. The **valid settings** are **0 through 254**. You do not have to change the default IP Address unless you are using the IP Address to link to your ECOM module. The default setting does not cause conflicts with other network communications.

If you change the default IP Address for linking to other network devices, you must change all four "255" fields. If any field contains **the number 255 and other fields have been changed, the module will *not* be recognized on the network.**

Example

Valid IP Address: 192.168.100.002

No! ~~255.168.100.002~~




WARNING: It is extremely important not to have duplicate IP Addresses on your network. If you are using the IP Address to link the ECOM to **any** network devices (PCs or PLCs), the ECOM must have a unique number.

Ethernet Address

A unique Ethernet Address is assigned to each module at the factory and will not change. It is printed on a label attached to each ECOM module. The Ethernet Address is recognized by NetEdit, *DirectSOFT32* and our DSData Server. The Ethernet Address is a twelve digit number with no deliberate relationship to your network or functional areas of your plant. It does not usually serve as a convenient and easily remembered identifier for your ECOM.

Factory-assigned Ethernet Address




Using Multiple Network Identifiers

You can use the IP Address to satisfy network requirements, a Name for PCs running HMI software and the Module ID for PLCs to share data among themselves. Using one type of identifier does not limit your use of the other identifier types.


The Module ID equals the *sum* of the binary values of the slide switches set in the ON position. For example, if you set slide switches 1, 2, and 3 to the ON position, the Module ID will be 14. This is found by adding $8+4+2=14$. The maximum value you can set on the DIP switch is $32+16+8+4+2+1=63$. This is achieved by setting switches 0 through 5 to the ON position.

The H4-ECOM (-F) DIP Switch

The H4-ECOM DIP switch contains eight individual slide switches, but only six of these are active. Two are not used. Notice that the individual slide switches are labeled 1 through 8 on the body of the DIP switch. You will also find that the printed circuit board is labeled 0 (zero) through 7 (as shown in the figure below). We use the labeling *on the printed circuit board* in describing how to set the switch. The numbers on the printed circuit board indicate the power of 2 represented by each slide switch. For example, switch 0 represents 2^0 (or 1), switch 1 is 2^1 (or 2), switch 2 is 2^2 (or 4), and so on. The figure below shows the binary value of each switch in parentheses ().



The Module ID equals the *sum* of the binary values of the slide switch set in the ON position. For example, if you set slide switches 0, 1, and 3 to the ON position, the Module ID will be 11. This is found by adding $8+2+1=11$. The maximum value you can set on the DIP switch is $32+16+8+4+2+1=63$. This is achieved by setting switches 0 through 5 to the ON position.



NOTE: When all the switches are set to OFF (Module ID = 0), the Module ID can be set using the software utilities in NetEdit and **DirectSOFT32**. **Do not use Module ID “0” for normal communications.** It is okay to leave the Module ID set at zero if you are using the Name or IP Address for communications.

Running NetEdit Software

NetEdit is a software utility that can be used to set network identifiers (Module ID, Name, and IP Address) for the ECOM modules, and it can be used for diagnostic and troubleshooting tasks. NetEdit came prepackaged with this manual on 3.5" floppy disk. When **DirectSOFT32** programming software is installed on your PC, NetEdit installs into the PLC>Tools menu directly from the **DirectSOFT32** CD. It is also available for download from Host Engineering's web site www.hosteng.com. You can also use **DirectSOFT32** programming software or DSDData Server Link Wizard to set network identifiers, but these products lack the troubleshooting aids of NetEdit.

Operating System Requirements

You can run NetEdit on Windows 98/NT/2000/XP. There are several ways to run NetEdit:

1) To run the NetEdit program, insert the NetEdit 3.5" floppy disk into drive A: (or the appropriate drive if you are not using drive A:). Click on the **Start** button and select **Run...** from the pop-up menu. Within the **Run** window, enter the letter of the drive, colon, backslash and the name NetEdit, and click OK.



2) If you prefer, you can copy the NetEdit files from the 3.5" floppy disk to your hard drive. In Explorer, locate the following three files on the floppy disk:


- Hei32_2.dll
- Netedit.exe
- Netedlib.dll

Copy all three files to a single directory on your hard drive, and start NetEdit by double clicking on NetEdit.exe.

3) NetEdit can also be launched from **DirectSOFT32** by clicking on PLC>Tools>NetEdit.

The NetEdit Screen

Either method of starting NetEdit brings up this screen. All NetEdit functions are accessed from this one screen. We examine each portion of this screen in the pages that follow.



Features of the NetEdit Screen

In this section, we will step through the features of the NetEdit screen. To see the full screen, you can start NetEdit as described on page 2-7, or you can refer to the figure at the bottom of page 2-7. If you examine the NetEdit screen, you will find five boxes on the screen outlined in gray:

- Protocol
- Module
- Module Information
- Ethernet Stats
- Configuration


We describe the function of each box below.

Protocol

In the upper left corner of the NetEdit screen, you will find a box labeled Protocol. In the box, there are two choices: IPX and UDP/IP. The ECOM module understands IPX *and* UDP/IP protocols. Both protocols are *permanently resident* in the firmware of the module. Select the protocol you want your PC to use to communicate with the ECOM module. IPX is a Novell standard in widespread use, and UDP/IP is a popular protocol supported by the TCP/IP suite of protocols in your PC.

One network device can send a message in IPX protocol to the ECOM module, and another device can send a message in UDP/IP protocol. The ECOM module understands both messages without changing the configuration of the module.

The figure to the right shows the Protocol selection box in the upper left corner of the NetEdit screen. The choice you make here tells **your PC** which protocol to send to the ECOM to link NetEdit to the module. You are not selecting which protocol the ECOM understands. It understands both. You could use IPX protocol to link NetEdit or **Direct**SOFT32 to your ECOM module, and you could use UDP/IP to link an HMI software product. The ECOM would understand both transmissions.




NOTE: We strongly recommend you load IPX protocol on your PC and use it for your PLC links. Use UDP/IP in your application, if required, but also add IPX to your list of active protocols. Having IPX loaded on your PC gives you a backup for troubleshooting communication problems.

Adding Network Protocol Support to Your PC

You may have already set up your PC with selected networking protocols for Ethernet communications. If not, you will need to select the protocols now for communication with the ECOM module. We strongly recommend that you include the IPX protocol. The description below applies to Windows 2000 (Windows 98/NT have slightly different steps). If you are not familiar with this procedure, you may need to have your Network Administrator perform this task.

For Windows 2000, go from My Computer on your Windows desktop to Control Panel. Double click on Network and Dial-up Connections, then double click on the desired Network Device to see the installed Protocols. If IPX is not listed among the protocols already loaded, add it now by clicking on the Install button. For Windows XP, go from Start>Settings>Control Panel. The steps are the same as Windows 2000 from this point.

Add the TCP/IP protocol if it is necessary for your application. Choose the TCP/IP selection to get UDP/IP support. Also add the IPX protocol if it is not already active.




Module

The lower left corner of the NetEdit screen displays the Ethernet Address of the modules currently on the network.

If modules are added or removed from the network, click on the Query Network button to update the list. Notice that the Ethernet Address is the factory-assigned address that is on the permanent label on the module. See page 2-4.

Select a specific module here by clicking on the Ethernet Address or by using the arrow keys. The selected module is highlighted.




NOTE: The Module box lists the Ethernet Addresses of ECOM modules and Ethernet Base Controllers (EBCs).



Module Information

The Module Information box gives the ECOM module Type, firmware Version, Booter firmware version and the address DIP switch setting.



| Module Information | |
|--------------------|----------|
| Type: | H4-ECOM |
| Version: | 1.0.197 |
| Booter: | 3.0.92 |
| DIP: | 00000000 |


NOTE: The module information and settings on this page apply to the selected (highlighted) module. To select a module, click on its Ethernet Address in the Module box. See page 2-9 for more information about selecting a module.



Ethernet Stats

The Ethernet Stats are statistics related to communication errors. These statistics are explored in Chapter 4, Maintenance and Troubleshooting.

Click on the Clear Stats button to reset all categories to 0 (zero).



| Ethernet Stats | |
|----------------|---|
| Missed Frames: | 0 |
| TX Collisions | 0 |
| Lost Packets: | 0 |
| Bad Packets: | 0 |
| Unknown Type: | 0 |
| Send Errors: | 0 |
| Clear Stats | |

Configuration


The Configuration box allows you to assign network identifiers and a description to the ECOM module. Use the up/down buttons to set the **Module ID** to a number between one and ninety (if you are using the ECOM for PLC-to-PLC communications). Module IDs must be unique for each PLC, but they do not have to be in sequence.

The **Name** field accepts 32 alphanumeric characters and can be used by most HMI software packages to identify the ECOM module.

The Description field accepts 32 alphanumeric characters of free-form descriptive information.

To set an **IP Address**, highlight the number in each of the four boxes, and overwrite the number. Use the number assigned to the ECOM module by your network administrator.

The Update Module button sends all entries to the module's flash memory. The Advanced Settings button displays a pop-up window described on the next page.



| Configuration | |
|----------------------|-----------------------|
| Module ID: | 2 |
| Name: | PumpStationOne |
| Description: | DL405 Ethernet Module |
| IP Address: | 192.168.100.2 |
| Update Module | |
| Advanced Settings... | |

See pages 2-2 through 2-4 for more information about **Module IDs**, **Names** and **IP Addresses**.

The following table summarizes NetEdit's Network Identifiers and their uses:

| | How to Set | Format | Communication | Restrictions/Notes |
|-------------------------|--------------------------------|--|-------------------------|---|
| Module ID | DIP Switch | Number 1-63 | PLC-to-PLC or PC-to-PLC | Disables Module ID in NetEdit, DirectSOFT32 , DSDData Server |
| | NetEdit or DirectSOFT32 | Number 1-90 | PLC-to-PLC or PC-to-PLC | DIP Switch must be set to "0" |
| | NetEdit or DirectSOFT32 | Number 1-999,999,999 | PC-to-PLC Only | > 90 (Not for PLC-to-PLC) |
| Name | NetEdit or DirectSOFT32 | 32 Alphanumeric Characters | PC-to-PLC Only | HMI Software may have restrictions |
| IP Address | NetEdit or DirectSOFT32 | 4 Three-digit Numbers xxx.xxx.xxx.xxx (See Page 2-4) | PC-to-PLC Only | See Your Network Administrator, Only for UDP/IP |
| Ethernet Address | Set at Factory | 12 Hex digits | PC-to-PLC Only | Factory-assigned, for IPX |

RX/WX Settings

The Advanced Settings button in the Configuration box of Net Edit (page 2-10) brings up the ECOM Advanced Settings window.


RX/WX – Settings box in this window provides a place to make changes that affect PLC-to-PLC communications.

ACK Timeout – sets the time limit for receiving the acknowledge (ACK) response to an RX or WX instruction. The ECOM sends a message across the LAN. The acknowledge response comes back directly from the ECOM module receiving the transmission. This timeout is the maximum for transmission and acknowledgement from ECOM to ECOM across the LAN. It is not dependent on the PLC scan time.

Resp. Timeout – sets the maximum time for the receiving PLC CPU to respond to the ECOM that initiated the communication. The instruction has travelled from the initiating PLC CPU to the initiating ECOM, across the Ethernet LAN to the receiving ECOM, then to the receiving PLC CPU, and back again to the initiating ECOM. Multiple PLC scans may be required to execute an RX/WX instruction so the Resp. Timeout should allow for multiple scans. Also, communication errors may result in retries which require more time. Your response timeout setting must accommodate retries as well.


The **Retries** field shows the number of times the transmission is to be retried if the first attempt is unsuccessful. The Update Module button loads the communication settings in the ECOM module's flash memory. The Exit button takes you back to the main NetEdit screen.

The **IP Broadcast Address** field is used to allow for non-standard broadcast address configurations. Some older Unix based systems did not use 255.255.255.255 for their broadcast address. This would prevent ECOMs from responding to network broadcast queries. Only change this value when using something other than 255.255.255.255 for broadcasts.




Using *DirectSOFT32* for ECOM Setup

If you are planning to use *DirectSOFT32* to set network identifiers in your ECOM module, refer to the *DirectSOFT32* User Manual for more information. Briefly, you can begin by right clicking on Comm Links at the Launch Window>Add Link. Use Link Wizard to select the Ethernet port. Click on **Next >**. Select your Transport and Transport Protocol. Again, click on **Next >**. You will see the screen below. Now, click on the **Setup...** button, and you will see a screen that looks like the one at the bottom of this page.



To make changes, select a module in the Devices box. Make the desired changes, and click on **Update Module**. When you have finished setting the network identifiers and updating the module, click on **Exit** to return to the Link Wizard. Click on **Next >**, and name your Link, then click on **Finish**.





NOTE: When all the slide switches on the DIP switch are set to OFF (Module ID = 0), the Module ID can be set using the software utilities in NetEdit and *DirectSOFT32*. **Do not use Module ID "0"** for normal communications. See pages 2-5 and 2-6 for more information about the DIP switches.

Inserting the ECOM Module in the PLC Base

DL205 Slot Choices


The DL205 system supports placement of the ECOM module in the **CPU-base only** (not in local expansion bases or remote I/O bases). It does not support installation of the ECOM in remote bases. The number of usable slots depends on how many slots your base has. The module does not work in slot 0 of the DL205 series PLCs, the slot next to the CPU. The D2-240, D2-250-1 and DL260 CPUs support the ECOM modules. The D2-230 CPU does not.



WARNING: Your system can be damaged if you install or remove system components before disconnecting the system power. To minimize the risk of equipment damage, electrical shock, or personal injury, always disconnect the system power before installing or removing any system component.

| Module Type | CPU | CPU-Base | Usable Slots |
|--------------|---------------------------|------------------------------------|---------------------|
| H2-ECOM (-F) | DL240 DL250-1 DL260 | D2-03B-1, D2-03BDC1-1, D2-03BDC-2 | 1 |
| | | D2-04B-1, D2-04BDC1-1, D2-04BDC-2 | 1, 2 |
| | | D2-06B-1, D2-06BDC1-1, D2-06BDC2-1 | 1, 2, 3, 4 |
| | | D2-06B-1, D2-06BDC1-1, D2-06BDC2-1 | 1, 2, 3, 4, 5, 6, 7 |

H2-ECOM (-F) Module Installation



To install the ECOM module, line up the module's printed circuit board with the grooves in the base and push the module until it is flush with face of the DL205 base power supply. If you feel more than moderate resistance when you push the module into the base, the circuit board may not be aligned with the grooves in the base. When the module is firmly seated in the slot, depress the top and bottom retaining clips to lock the module in place.




NOTE: When adding modules to your PLC always confirm that your **power budget** will accommodate the added module. See the User Manual for your PLC for more information about calculating the power budget. See Appendix A for the power consumption of the ECOM modules.

DL405 Slot Choices

For PLC systems with D4-430 and D4-440 CPUs, the ECOM modules can reside in any I/O slot but **only** in the CPU-base. The D4-450 CPU allows the installation of the ECOM module in the CPU-base or in **local expansion** bases.

If the ECOM module is used in a local expansion base, *all bases in the system* must be the “-1” type bases. The valid part numbers for these bases are D4-04B-1, D4-06B-1, and D4-08B-1. The “-1” on the end of the part number indicates that the base supports specialty modules including the ECOM. The “-1” bases can be connected as **local expansion** bases or **remote** bases. They are not the same thing. Remote bases **do not** support the ECOM modules!



WARNING: Your system can be damaged if you install or remove system components before disconnecting the system power. To minimize the risk of equipment damage, electrical shock, or personal injury, always disconnect the system power before installing or removing any system component.

| Module Type | CPU | Base | Usable CPU-Base Slots | Usable Expansion Base Slots |
|--------------|------------|------------------|------------------------|-----------------------------|
| H4-ECOM (-F) | D4-430/440 | D4-04B, D4-04B-1 | 0, 1, 2, 3 | N/A |
| | | D4-06B, D4-06B-1 | 0, 1, 2, 3, 4, 5 | N/A |
| | | D4-08B, D4-08B-1 | 0, 1, 2, 3, 4, 5, 6, 7 | N/A |
| H4-ECOM (-F) | D4-450 | D4-04B | 0, 1, 2, 3 | N/A |
| | | D4-06B | 0, 1, 2, 3, 4, 5 | N/A |
| | | D4-08B | 0, 1, 2, 3, 4, 5, 6, 7 | N/A |
| H4-ECOM (-F) | D4-450 | D4-04B-1 | 0, 1, 2, 3 | 0, 1, 2, 3* |
| | | D4-06B-1 | 0, 1, 2, 3, 4, 5 | 0, 1, 2, 3, 4, 5* |
| | | D4-08B-1 | 0, 1, 2, 3, 4, 5, 6, 7 | 0, 1, 2, 3, 4, 5, 6, 7* |

* You must use the “-1” base for the CPU-base and all local expansion bases.




NOTE: Before installing the ECOM module, confirm that your **power budget** will accommodate the added module. See the **DL205** or **DL405 User Manual** for your PLC for more information about calculating the power budget. See Appendix A for the power consumption of the ECOM modules.

H4-ECOM (-F) Module Installation

To insert the ECOM module in a DL405 base, place the bottom tab of the module into the notch at the bottom of the base. Pivot the module toward the base as shown below. Ensure that each module is tightly seated and secured with the captive screw at the top of the module.

DL405 Base




Disconnect power before installing module!


ECOM Network Layouts

The ECOM Ethernet network is a peer-to-peer network. Using Read or Write instructions, any PLC on the network can initiate communications with any other PLC on the network. A PC running our DSData Server can also initiate communications with any ECOM that is on the same network, but a PLC cannot initiate communication with the PC. A PLC cannot literally broadcast to all other PLCs at the same time, but a PLC can sequence through communication connections with each other PLC on the network, one at a time.


The ECOM products inherently support two network layouts: point-to-point and star. The point-to-point layout can be used to link together two PLCs or a PC and a PLC. A hub or repeater connects multiple networkable devices into a star topology. Multiple hubs or repeaters are used to modify the star topology so that it becomes a star-bus-star topology. See the figures below and on the next page.

Point-to-Point





Hubs or repeaters can connect together to make it possible to connect more devices to the network or to extend the range of the network.




NOTE: Hubs or repeaters often designate one port for *uplinks* to another hub. This port cannot be used to connect to a PLC. If the uplink port is used to connect to another hub, it may disable the adjacent port.


Network Cabling

ECOM Supports Two Standards

Two types of ECOMs are available. One type supports the 10BaseT standard, and the other supports the 10BaseFL standard. The 10BaseT standard uses twisted pairs of copper wire conductors, and the 10BaseFL standard is for fiber optic cabling.



10BaseT Networks The cable used to connect a PLC (or PC) to a hub or repeater is called a **patch** (straight-through) **cable**. The cable used to connect together two PLCs, or a PC and a PLC or two hubs is a **crossover cable**. We recommend that you purchase cables pre-assembled with connectors for convenient and reliable networking.



This diagram illustrates the standard wire positions in the RJ45 connector. We recommend all ECOM 10BaseT cables to be **Category 5**, UTP cable.

10BaseT Connections

Most 10BaseT hubs or repeaters use a **patch** (straight-through) cable for connecting the network devices (PLCs or PCs). For hub-to-hub connections a **crossover** type cable is commonly required. The figures on page 2-17 show pin assignments and insulation color codes for patch (straight-through) and crossover type Ethernet cables.

UTP Cable

The ECOM has an eight-pin modular port that accepts RJ45 type connectors. UTP (Unshielded Twisted-Pair) cable is rated according to its data-carrying ability (bandwidth) and is given a “category” number. We strongly recommend using a category 5 cable for all ECOM connections.



NOTE: See page 2-19 for 10BaseT distance limitations.

10BaseFL Connections

Each module has two bayonet ST-style connectors. The ST-style connector uses a quick release coupling which requires a quarter turn to engage or disengage. The connectors provide mechanical and optical alignment of fibers.


Each cable segment requires two strands of fiber: one to transmit data and one to receive data. The ST-style connectors are used to connect the H2-ECOM-F or H4-ECOM-F module to another H2-ECOM-F or H4-ECOM-F module or a fiber optic hub or repeater.

Fiber Optic Cable

The H2-ECOM-F and H4-ECOM-F modules accept 62.5/125 multimode fiber optic (MMF) cable. The glass core diameter is 62.5 micrometers and the glass cladding is 125 micrometers. The fiber optic cable is highly immune to noise and permits communications over much greater distances than 10BaseT.



Fiber Optic Module ST Connector

Multimode Fiber Optic (MMF) Cable



62.5/125 MMF cable with bayonet ST-style connectors


Fiber cross-section




NOTE: See page 2-19 for 10BaseFL distance limitations.

Maximum Cable Length

The **maximum distance** per **10BaseT** cable segment is **100 meters** or **328 feet**. Repeaters extend the distance. Each cable segment attached to a repeater can be 100 meters. Two repeaters connected together extend the total range to 300 meters.



The **maximum distance** per **10BaseFL** cable segment is **2,000 meters** or **6,560 feet**. Repeaters extend the distance. Each cable segment attached to a repeater can be 2,000 meters. Two repeaters connected together extend the total range to 6,000 meters.



Maximum Number of ECOM Modules on the Network

The maximum number of nodes that can be connected to a 10BaseT or 10BaseFL network is a function of the topology used in constructing the network. Therefore, it is not possible to state an absolute maximum number of nodes that would apply in all cases.

The IEEE 802.3 specification defines the maximum node limit for an Ethernet *segment* in terms of the ability to detect and avoid data collisions. A “legal” network can have any number of devices provided that they can:


- detect all data collisions that may occur during the communication process *and*
- respond to these collisions appropriately.

You must take into consideration the network limitations imposed by all cabling and network devices. Consider the limitations imposed on your network if your network uses:


- a combination of cabling standards, such as 10BaseT and 10Base2, or
- intermediate devices, such as switches or routers.

Each ECOM module can be assigned a Module ID ranging from 1 to 999,999,999. Theoretically, you could have this many Ethernet modules coexisting on a single network. Other network limitations would restrict the network size before reaching this limit. For the majority of network PLC applications there is practically no limit to the number of ECOM modules you can access from the **DirectSOFT32** Programming software or the **DirectSOFT32** DSData Server.

There *is* a node limit for PLC-to-PLC communications. The network Read and Write instructions performed by the initiating (master) PLC are only capable of accessing PLCs with Module IDs of 1 through 90. This effectively sets the maximum number of nodes available for PLC-to-PLC communications at 90.



WARNING: We recommend against connecting Ethernet modules to the same network that serves as your primary office network. While Ethernet networks can handle a very large number of data transmissions, and normally handle them very quickly, heavy Ethernet traffic can adversely affect the reliability and speed of the network.



WARNING: Your system can be damaged if you install or remove system components before disconnecting the system power. To minimize the risk of equipment damage, electrical shock, or personal injury, always disconnect the system power before installing or removing any system component.

RLL Programming for Communications

In This Chapter. . . .

- PLC-to-PLC Communications
 - How RLL is Used for Communications
 - Network Instructions
 - Addressing the Different Memory Types
 - Special Relays for Communications
 - Example Program with One Read Instruction
 - Example Program with One Write Instruction
 - Integrating Multiple Read and Write Instructions
-

PLC-to-PLC Communications


This chapter steps you through the development of a Relay Ladder Logic (RLL) program to enable one PLC to communicate with another PLC. For the experienced programmer of **Direct**LOGIC PLCs, the communication programs presented in this chapter will be simple to follow. If you have never programmed a **Direct**LOGIC PLC, you may want to refer to the **Direct**SOFT32 Programming Software User Manual and the User Manual for your PLC for additional information.



NOTE: The programs described in this chapter are not used for communication between a PC and a PLC. For PC-to-PLC communications, please see the product documentation for the PC software you are using. If you are using our DSData Server software, the manual you will need is the **Direct**SOFT32 DSData Server User Manual.

How RLL is Used for Communications

DirectSOFT32 Programming Software provides **Read** and **Write** instructions (RX/WX) for PLC-to-PLC communication over a network. The Read and Write instructions are part of the ladder logic program running in the CPU of the *initiating*, or master, PLC. These instructions tell the initiating CPU to send a message over the Ethernet network to a *responding*, or slave, PLC. The ECOM module is the connecting point to the network for each PLC. The initiating PLC's Read or Write communication finds its destination by the **Module ID** of the responding PLC's ECOM module. See Chapter 2 for information about assigning Module IDs.



In the figure above, the initiating PLC sends a Read or Write message to the responding PLC's ECOM module which is designated as "Module ID 14." The responding PLC processes the message. Any one of the PLCs could initiate communication with any one of the others.

Network Instructions


Read (RX) and Write (WX) Instructions

The Read (**RX**) and Write (**WX**) instructions are used by the initiating PLC to Read a block of data *from* another PLC or Write a block of data *to* another PLC. To perform their functions, the RX and WX *boxes* must be **preceded** in the ladder logic program by two Load instructions and one Load Address instruction.

The Load and Load Address instructions load communication parameters into the **accumulator** and the first and second level of the **accumulator stack**. The RX or WX instruction takes these parameters from the stack and the accumulator and prepares the data to be sent over the network. If you need to know more about the function of the accumulator and the accumulator stack, refer to the User Manual for your PLC.


Building the Read (RX) or Write (WX) Routine

For network communications, you build the Read (RX) or Write (WX) instructions into a **routine** which requires the four instructions you see to the right. The function of each of these instructions is explained below or on the next page. They must be used in the sequence shown.



The first Load (LD) instruction accepts either a constant or a variable. Use a “K” to designate the number as a constant. Use a “V” if you are entering the address of a register. The contents of that register perform the same function as the constant shown below. For example, you could use V2000 in place of K0114. If the contents of V2000 is the number “114,” the function would be the same. Using a variable allows changing parameters while the program is running.



The First LD Instruction



The Second LD Instruction

The second Load (LD) instruction determines the length of the data block to be transmitted during the Read or Write communication. This instruction will also accept two data types. Use a “K” to designate the number as a constant. Use a “V” if you are entering the address of a register.

For Word Memory data, you must use a multiple of two bytes between 2 and 128. For Bit Memory data, you can use any multiple of one byte between 1 and 128. For more information about addressing Word and Bit Memory, see page 3-6.





The LDA Instruction



The Load Address (LDA) instruction specifies the V-memory address of the *beginning* memory register in the **initiating**, or master, PLC. The data block to be transmitted will begin at this address and extend the number of bytes specified in the preceding LD instruction. The leading “O” indicates this is an octal number. Simply substitute the letter “O” for the “V” in the V-memory designation. For example, V40600 becomes O40600.

Read instructions copy the data block from the responding PLC memory into the initiating PLC memory.



Write instructions copy the data block from the initiating PLC memory into the responding PLC memory.



In this example, the eight byte block of data beginning at C100 and ending at C177 in the *responding*, or slave, PLC is read (copied) into the initiating PLC's memory beginning at V40600.



In the example, the 8-byte block of data beginning at V40600 and ending at V40603 in the *initiating*, or master, PLC is written (copied) into the responding PLC's memory beginning at C100 and ending at C177.



Addressing the Different Memory Types

Some data types are inherently 16 bits long, for example timer and counter current values. Other data types are 1 bit long, for example: discrete inputs and outputs. Word-length and bit-length data are mapped into Word Memory, also known as V-memory, which allows you to address *any* of the different memory types as 16-bit words.

Bit Memory

Bit memory can be addressed in Read and Write instructions by the name of the first bit of any byte. If your second LD instruction contains the constant K8, eight bytes will be transmitted. If you use C0 in your RX or WX instruction, you will transmit the eight bytes from C0 through C77.


Word Memory and Aliases

In the example below, V40600 is the V-memory designation for the sixteen bits from C0 through C17. *Aliases* are a convenient substitute for V-memory designations, and can be used interchangeably in Read and Write instructions. VC0 is the alias for V40600. Either nomenclature addresses the same 16 bits.

The alias is simply the name of the first bit in a group of sixteen bits, with V added as a prefix. For example, VC0 represents the 16 bits beginning with C0. Word Memory, Bit Memory and Aliases all use the **octal** numbering system.

| | | | | | | | | | | | | | | | | |
|---|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Word Memory Address V40600 = VC0 (Alias) | C17 | C16 | C15 | C14 | C13 | C12 | C11 | C10 | C7 | C6 | C5 | C4 | C3 | C2 | C1 | C0 |
| V40601 = VC20 | C37 | C36 | C35 | C34 | C33 | C32 | C31 | C30 | C27 | C26 | C25 | C24 | C23 | C22 | C21 | C20 |
| V40602 = VC40 | C57 | C56 | C55 | C54 | C53 | C52 | C51 | C50 | C47 | C46 | C45 | C44 | C43 | C42 | C41 | C40 |
| V40603 = VC60 | C77 | C76 | C75 | C74 | C73 | C72 | C71 | C70 | C67 | C66 | C65 | C64 | C63 | C62 | C61 | C60 |

The following Write routines are all equivalent. **DirectSOFT** gives you the flexibility to identify the responding PLC's memory area in three different ways, as shown below.



DirectSOFT32 is Flexible

You can address the different data types by any available convention shown in the tables that follow. The largest block of data that can be sent in a single Read or Write operation is 128 bytes. The smallest block of data is one byte for Bit Memory types and two bytes, or one word for Word Memory types. The **octal** numbering system is used for all addresses in these tables.

D2-240 CPU



NOTE: The D2-230 CPU does not support the ECOM modules.

| D2-240 CPU | | | |
|------------------------|------------------------------|------------------------------------|----------------------------------|
| Data Types | Bit Memory | Word Memory | Alias |
| Timer Current Values | None | V0 – V177 | TA0 – TA177 |
| Counter Current Values | None | V1000 – V1177 | CTA0 – CTA177 |
| User Data Words | None | V2000 – V3777 V4000 – V4377 | None |
| Input Points | X0 – X477 | V40400 – V40423 | VX0 – VX460 |
| Output Points | Y0 – Y477 | V40500 – V40523 | VY0 – VY460 |
| Control Relays | C0 – C377 | V40600 – V40617 | VC0 – VC360 |
| Special Relays | SP0 – SP137 SP540 – SP617 | V41200 – V41205 V41226 – V41230 | VSP0 – VSP120 VSP540 – VSP600 |
| Timer Status Bits | T0 – T177 | V41100 – V41107 | VT0 – VT160 |
| Counter Status Bits | CT0 – CT177 | V41040 – V41147 | VCT0 – VCT160 |
| Stages | S0 – S777 | V41000 – V41037 | VS0 – VS760 |

D2-250-1 CPU

| D2-250-1 CPU | | | |
|------------------------|-------------|----------------------------------|---------------|
| Data Types | Bit Memory | Word Memory | Alias |
| Timer Current Values | None | V0 – V377 | TA0 – TA377 |
| Counter Current Values | None | V1000 – V1377 | CTA0 – CTA377 |
| User Data Words | None | V1400 – V7377 V10000 – V17777 | None |
| Input Points | X0 – X777 | V40400 – V40437 | VX0 – VX760 |
| Output Points | Y0 – Y777 | V40500 – V40537 | VY0 – VY760 |
| Control Relays | C0 – C1777 | V40600 – V40677 | VC0 – VC1760 |
| Special Relays | SP0 – SP777 | V41200 – V41237 | VSP0 – VSP760 |
| Timer Status Bits | T0 – T377 | V41100 – V41117 | VT0 – VT360 |
| Counter Status Bits | CT0 – CT177 | V41140 – V41147 | VCT0 – VCT160 |
| Stages | S0 – S1777 | V41000 – V41077 | VS0 – VS1760 |

D2-260 CPU

| D2-260 CPU | | | |
|------------------------|------------------------------|---|----------------------------------|
| Data Registers | Bit Memory | Word Memory | Alias |
| Timer Current Values | None | V0 – V377 | TA0 – TA377 |
| Counter Current Values | None | V1000 – V1377 | CTA0 – CTA377 |
| User Data Words | None | V400 – V777 V1400 – V7377 V10000 – V37777 | None |
| Input Points | X0 – X1777 | V40400 – V40477 | VX0 – VX1760 |
| Output Points | Y0 – Y1777 | V40500 – V40577 | VY0 – VY1760 |
| Control Relays | C0 – C3777 | V40600 – V40777 | VC0 – VC3760 |
| Special Relays | SP0 – SP137 SP320 – SP717 | V41200 – V41205 V41215 – V41234 | VSP0 – VSP120 VSP320 – VSP700 |
| Timer Status Bits | T0 – T377 | V41100 – V41117 | VT0 – VT360 |
| Counter Status Bits | CT0 – CT377 | V41140 – V41157 | VCT0 – VCT360 |
| Stages | S0 – S1777 | V41000 – V41077 | VS0 – VS1760 |
| Remote I/O | GX0 – GX3777 GY0 – GY3777 | V40000 – V40177 V40200 – V40377 | VGX0 – VGX3760 VGY0 – VGY3760 |

D4-430 CPU

| D4-430 CPU | | | |
|------------------------|----------------------------|------------------------------------|----------------------------------|
| Data Registers | Bit Memory | Word Memory | Alias |
| Timer Current Values | None | V0 – V177 | TA0 – TA177 |
| Counter Current Values | None | V1000 – V1177 | CTA0 – CTA177 |
| User Data Words | None | V1400 – V7377 | None |
| Input Points | X0 – X477 | V40400 – V40423 | VX0 – VX460 |
| Output Points | Y0 – Y477 | V40500 – V40523 | VY0 – VY460 |
| Control Relays | C0 – C737 | V40600 – V40635 | VC0 – VC720 |
| Special Relays | SP0 – 137 SP320 – SP617 | V41200 – V41205 V41215 – V41230 | VSP0 – VSP120 VSP320 – VSP600 |
| Timer Status Bits | T0 – T177 | V41100 – V41107 | VT0 – VT160 |
| Counter Status Bits | CT0 – CT177 | V41140 – V41147 | VCT0 – VCT160 |
| Stages | S0 – S577 | V41000 – V41027 | VS0 – VS560 |
| Remote I/O | GX0 – GX777 | V40000 – V40037 | VGX0 – VGX760 |

D4-440 CPU

| D4-440 CPU | | | |
|------------------------|----------------------------|------------------------------------|----------------------------------|
| Data Registers | Bit Memory | Word Memory | Alias |
| Timer Current Values | None | V0 – V377 | TA0 – TA377 |
| Counter Current Values | None | V1000 – V1177 | CTA0 – CTA177 |
| User Data Words | None | V1400 – V7377 V10000 – V17777 | None |
| Input Points | X0 – X477 | V40400 – V40423 | VX0 – VX460 |
| Output Points | Y0 – Y477 | V40500 – V40523 | VY0 – VY460 |
| Control Relays | C0 – C1777 | V40600 – V40677 | VC0 – VC1760 |
| Special Relays | SP0 – 137 SP320 – SP717 | V41200 – V41205 V41215 – V41234 | VSP0 – VSP120 VSP320 – VSP700 |
| Timer Status Bits | T0 – T377 | V41100 – V41117 | VT0 – VT360 |
| Counter Status Bits | CT0 – CT177 | V41140 – V41147 | VCT0 – VCT160 |
| Stages | S0 – S1777 | V41000 – V41077 | VS0 – VS1760 |
| Remote I/O | GX0 – GX1777 | V40000 – V40077 | VGX0 – VGX1760 |

D4–450 CPU

| D4–450 CPU | | | |
|------------------------|------------------------------|------------------------------------|----------------------------------|
| Data Registers | Bit Memory | Word Memory | Alias |
| Timer Current Values | None | V0 – V377 | TA0 – TA377 |
| Counter Current Values | None | V1000 – V1377 | CTA0 – CTA377 |
| User Data Words | None | V1400 – V7377 V10000 – V37777 | None |
| Input Points | X0 – X1777 | V40400 – V40477 | VX0 – VX1760 |
| Output Points | Y0 – Y1777 | V40500 – V40577 | VY0 – VY1760 |
| Control Relays | C0 – C3777 | V40600 – V40777 | VC0 – VC3760 |
| Special Relays | SP0 – SP137 SP320 – SP717 | V41200 – V41205 V41215 – V41234 | VSP0 – VSP120 VSP320 – VSP700 |
| Timer Status Bits | T0 – T377 | V41100 – V41117 | VT0 – VT360 |
| Counter Status Bits | CT0 – CT377 | V41140 – V41157 | VCT0 – VCT360 |
| Stages | S0 – S1777 | V41000 – V41077 | VS0 – VS1760 |
| Remote I/O | GX0 – GX3777 GY0 – GY3777 | V40000 – V40177 V40200 – V40377 | VGX0 – VGX3760 VGY0 – VGY3760 |

Special Relays for Communications


The **Direct**LOGIC PLCs provide internal contacts (bits) for monitoring the status of communications. The internal contacts are called Special Relays (there are other Special Relays used for other purposes). There are two Special Relays for each slot in the base that will accept the ECOM module. The two relays perform the following functions:

- **Communication Busy** – This bit is on when the communication module is busy transmitting or receiving. You must use this bit, or relay contact, to prevent overwriting your Read or Write (RX/WX) instructions.
- **Communication Error** – This bit is on when an error occurred in the last RX or WX communication. This error automatically clears (the bit resets to zero) when another RX or WX instruction executes.


For example, Special Relays SP124 and SP125 correspond to an ECOM module in **slot 2** of the PLC base.

The Special Relay SP125 is used in the example to energize the output Y50, indicating a **communication error** has occurred. This Special Relay must appear earlier in the program than your RX or WX instruction because it is turned off (reset to zero) when a subsequent Read or Write instruction is executed.

The Special Relay SP124 indicates the ECOM is **busy**. When SP124 is on, the normally closed contact opens to prevent executing another RX or WX instruction until the last one is completed.




| DL240, DL250-1 and DL260 Special Purpose Communication Relays | | | | | | | |
|---|--------|--------|--------|--------|--------|--------|--------|
| CPU-Base | Slot 1 | Slot 2 | Slot 3 | Slot 4 | Slot 5 | Slot 6 | Slot 7 |
| Communication busy | SP122 | SP124 | SP126 | SP130 | SP132 | SP134 | SP136 |
| Communication error | SP123 | SP125 | SP127 | SP131 | SP133 | SP135 | SP137 |



D4-430 and D4-440 Special Purpose Communication Relays

| CPU-Base | Slot 0 | Slot 1 | Slot 2 | Slot 3 | Slot 4 | Slot 5 | Slot 6 | Slot 7 |
|---------------------|--------|--------|--------|--------|--------|--------|--------|--------|
| Communication busy | SP120 | SP122 | SP124 | SP126 | SP130 | SP132 | SP134 | SP136 |
| Communication error | SP121 | SP123 | SP125 | SP127 | SP131 | SP133 | SP135 | SP137 |


**D4-450 Special Purpose Communication Relays**

| CPU-Base | Slot 0 | Slot 1 | Slot 2 | Slot 3 | Slot 4 | Slot 5 | Slot 6 | Slot 7 |
|---------------------|--------|--------|--------|--------|--------|--------|--------|--------|
| Communication busy | SP120 | SP122 | SP124 | SP126 | SP130 | SP132 | SP134 | SP136 |
| Communication error | SP121 | SP123 | SP125 | SP127 | SP131 | SP133 | SP135 | SP137 |
| Expansion Base 1 | Slot 0 | Slot 1 | Slot 2 | Slot 3 | Slot 4 | Slot 5 | Slot 6 | Slot 7 |
| Communication busy | SP140 | SP142 | SP144 | SP146 | SP150 | SP152 | SP154 | SP156 |
| Communication error | SP141 | SP143 | SP145 | SP147 | SP151 | SP153 | SP155 | SP157 |
| Expansion Base 2 | Slot 0 | Slot 1 | Slot 2 | Slot 3 | Slot 4 | Slot 5 | Slot 6 | Slot 7 |
| Communication busy | SP160 | SP162 | SP164 | SP166 | SP170 | SP172 | SP174 | SP176 |
| Communication error | SP161 | SP163 | SP165 | SP167 | SP171 | SP173 | SP175 | SP177 |
| Expansion Base 3 | Slot 0 | Slot 1 | Slot 2 | Slot 3 | Slot 4 | Slot 5 | Slot 6 | Slot 7 |
| Communication busy | SP200 | SP202 | SP204 | SP206 | SP210 | SP212 | SP214 | SP216 |
| Communication error | SP201 | SP203 | SP205 | SP207 | SP211 | SP213 | SP215 | SP217 |


Program with One Read Instruction

The Ladder View screen below is the program development screen in **DirectSOFT32** Programming Software. This four rung program is explained in detail on page 3-14. This is a complete program although its function is very limited. There is also a two rung program that runs in the responding PLC, and it is also explained on page 3-14.


Program for the Initiating PLC



Program for the Responding PLC



When the toggle switch input to the *responding* PLC is turned on (transitions from 0 to 1), the C0 bit in the *initiating* PLC transitions from 0 to 1. The program in the initiating PLC causes Y0 to turn on in response to the C0 bit.




For the purpose of these example programs, both the initiating PLC and the responding PLC must be in **RUN Mode**.

Rung 1



In our example, the normally open contact labeled **C0** is an internal control relay. When C0 is on, discrete output **Y0** is energized.

**Rung 2**

The second rung uses a Special Relay to identify a communication error. In the example, **SP123** is on if a communication error is present for *slot one*. Use different Special Relays if your ECOM module is in a different slot (see page 3-10 and 3-11). We use SP123 to turn on an indicator light connected to a discrete output.

**Rung 3**

The Special Relay labeled SP122 is on when slot 1 is busy transmitting or receiving. The Read instruction may take longer than one PLC scan to complete. Use this Special Relay to prevent overwriting the previous Read instruction with each PLC scan.




Number of bytes to be transferred.
Max = 128 bytes.

Beginning address in the initiating PLC,
expressed as an octal number.


Beginning address in the responding PLC.

Rung 4

All **Direct**LOGIC PLCs use an END statement to identify the final rung of the main body of the program.

**Program for the Responding PLC**


This two-rung program resides in the responding PLC's CPU. Its function is simply to use the X0 contact to turn on the internal control relay, C100.




Example Program with One Write Instruction

The Ladder View screen below is the program development screen in **DirectSOFT32** Programming Software. This four-rung program is explained in detail on page 3-16. This is a complete program although its function is very limited. There is also a two-rung program that runs in the responding PLC. It is also explained on page 3-16.


Program for the Initiating PLC



Program for the Responding PLC




When the toggle switch input to the *initiating* PLC is turned on (transitions from 0 to 1), the C100 bit in the *responding* PLC also transitions from 0 to 1. The program in the responding PLC causes Y0 to turn on in response to the C100 bit.




For the purpose of these example programs, both the initiating PLC and the responding PLC must be in **RUN Mode**.

Rung 1



In our example, the normally open contact labeled **X0** is a toggle switch input to a discrete input module. When X0 is on, Control Relay **C0** is energized.

**Rung 2**

The second rung uses a Special Relay to identify a communication error. In the example, **SP123** is on if there is a communication error present *in slot one*. Use different Special Relays if your ECOM module is in a different slot (see page 3-11 and 3-12). We use SP123 to turn on an indicator light connected to a discrete output.

**Rung 3**

The Special Relay labeled SP122 is on when slot 1 is busy transmitting or receiving. The Write instruction may take longer than one PLC scan to complete. Use this Special Relay to prevent overwriting the previous Write instruction with each PLC scan.




Number of bytes to be transferred.
Max = 128 bytes.

Beginning address in the initiating PLC,
expressed as an octal number.


Beginning address in the responding PLC.

Rung 4

All **Direct**LOGIC PLCs use an END statement to identify the final rung of the main body of the program.

**Program for the Responding PLC**

This two-rung program resides in the responding PLC's CPU. Its function is simply to take the C100 contact and convert it to a real output, Y0.



Integrating Multiple Read and Write Instructions

Multiple Read and Write instructions require *interlocks* for sequencing because only one RX/WX instruction can be processed per CPU scan. Using interlocks, one RX/WX instruction is processed in each scan until all RX/WX instructions have been executed. After the last instruction, the sequence then begins again at the first RX/WX instruction.

Without interlocks, the RX/WX instructions would be executed in an unpredictable order, and some might be executed many times before others are executed once. The interlocks serve to *open* (disconnect) the ladder circuits for all Read and Write instructions except the one that should be processed on the current CPU scan.

We show two methods of creating the interlocks necessary for sequencing multiple Read and Write instructions:

- Sequenced Internal Control Relays
- Shift Register

We will step you through the development of the interlocks using both methods. The two examples shown perform the same function. Only the interlocks are different.



NOTE: To fully understand the material in this section, you will first need to understand the Example Programs on pages 3-13 and 3-15, as well as the material in the Network Instructions section, beginning on page 3-3.

The following program segment sequences through three RX/WX instructions (two Write instructions and one Read instruction). You can develop your own program incorporating either of the two interlocking control strategies and expanding the number of interlocks to accommodate the number of RX/WX instructions in your program.

Interlocking Relays

It is easy to see the function of the interlocking relays if we construct a *truth table* first.

Across the top of the truth table we show internal control relays that we are considering using for our sequencing strategy. We have used C50 through C52 for our chart, but any contacts that are not used for other purposes in your program will work just as well.

Down the left side of the chart, we list the number of RX/WX instructions we may want to use in our RLL program.

The three contacts in this truth table will accommodate as many as eight Read or Write instructions. Our program only has three RX/WX instructions so we only need to use two contacts (see why on page 3-18). We will use C50 and C51. One additional contact (C53) would give us 32 combinations since the number of combinations expands as the power of 2.

| Truth Table | C52 | C51 | C50 |
|---------------|-----|-----|-----|
| First RX/WX | 0 | 0 | 0 |
| Second RX/WX | 0 | 0 | 1 |
| Third RX/WX | 0 | 1 | 0 |
| Fourth RX/WX | 0 | 1 | 1 |
| Fifth RX/WX | 1 | 0 | 0 |
| Sixth RX/WX | 1 | 0 | 1 |
| Seventh RX/WX | 1 | 1 | 0 |
| Eighth RX/WX | 1 | 1 | 1 |

Our three RX/WX instructions can be sequenced by the two contacts C50 and C51. Two contacts provide four different binary states:

- both off
- C50 on and C51 off
- C50 off and C51 on
- both on

We only need to use three of the four binary states (circled) since we only have three RX/WX instructions to sequence.


| Truth Table | C52 | C51 | C50 |
|---------------|-----|-----|-----|
| First RX/WX | 0 | 0 | 0 |
| Second RX/WX | 0 | 0 | 1 |
| Third RX/WX | 0 | 1 | 0 |
| Fourth RX/WX | 0 | 1 | 1 |
| Fifth RX/WX | 1 | 0 | 0 |
| Sixth RX/WX | 1 | 0 | 1 |
| Seventh RX/WX | 1 | 1 | 0 |
| Eighth RX/WX | 1 | 1 | 1 |

First RX/WX Instruction

C50 and C51 are interlocking contacts. They are normally closed in this rung to permit power flow to the first WX instruction. Both bits are off, corresponding to the first row of the truth table.

After the WX instruction is executed C50 is SET (turned on) which opens the contact in this rung and closes the C50 contact in the next rung.

C51 is RESET (turned off) which leaves the C51 contact closed for the next rung.




Second RX/WX Instruction

C50 is normally open and C51 is normally closed. For this rung to be executed, the C50 bit must be on and the C51 bit must be off, corresponding to the second row of the truth table. C50 was turned on in the previous rung. C51 was turned off in the previous rung.

After the WX instruction is executed C50 is RESET (turned off) which opens the C50 contact in this rung and closes it in the next rung.


C51 is SET (turned on), which closes the normally open C51 contact in the next rung.

**Third RX/WX Instruction**

In this last rung, C50 is normally closed and C51 is normally open. For this rung to be executed, the C50 bit must be off and the C51 bit must be on, corresponding to the third row of the truth table. C51 was turned on in the previous rung.

After the RX instruction is executed, C50 is RESET which opens the C50 contact in this rung and allows it to close in preparation for repeating the first communication rung on the next CPU scan (page 3-18).

C51 is also RESET, which allows the C51 contact to close in preparation for repeating the first communication rung on the next CPU scan (page 3-18).

**Returning to the First RX/WX Instruction**

At the end of the third RX/WX instruction, we cycle back to the top row of the truth table on page 3-18. Both C50 and C51 are off, and the next CPU scan executes the first RX/WX instruction.


Shift Register

The Shift Register can be used for creating interlocks, as an alternative to using control relays. For a complete explanation of the function of the Shift Register, see the User Manual for your PLC. If you have more than a few RX/WX instructions, using control relays can become cumbersome. The Shift Register allows a single contact to be used in each communication rung as an interlock.

The data input to the Shift Register (SR) is Special Relay SP1. SP1 is the always-on bit. Combined with a normally closed contact it sends zeros to the Shift Register data input.

The clock input to the Shift Register is SP122, the communication busy bit. Each time one of the RX/WX instructions executes, the Shift Register moves the set bit over one place.

C63 is used in this example to reset the Shift Register to all zeros.



| | | | | | | | | | | | | | | | |
|----------------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| C77 | C76 | C75 | C74 | C73 | C72 | C71 | C70 | C67 | C66 | C65 | C64 | C63 | C62 | C61 | C60 |
| Shift Register after first scan. | | | | | | | | | | | | | | | |

| | | | | | | | | | | | | | | | |
|-----------------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| C77 | C76 | C75 | C74 | C73 | C72 | C71 | C70 | C67 | C66 | C65 | C64 | C63 | C62 | C61 | C60 |
| Shift Register after second scan. | | | | | | | | | | | | | | | |

| | | | | | | | | | | | | | | | |
|-----------------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| C77 | C76 | C75 | C74 | C73 | C72 | C71 | C70 | C67 | C66 | C65 | C64 | C63 | C62 | C61 | C60 |
| Shift Register after first RX/WX. | | | | | | | | | | | | | | | |

| | | | | | | | | | | | | | | | |
|------------------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| C77 | C76 | C75 | C74 | C73 | C72 | C71 | C70 | C67 | C66 | C65 | C64 | C63 | C62 | C61 | C60 |
| Shift Register after second RX/WX. | | | | | | | | | | | | | | | |




| | | | | | | | | | | | | | | | |
|-----------------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| C77 | C76 | C75 | C74 | C73 | C72 | C71 | C70 | C67 | C66 | C65 | C64 | C63 | C62 | C61 | C60 |
| Shift Register after third RX/WX. | | | | | | | | | | | | | | | |

| | | | | | | | | | | | | | | | |
|---|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| C77 | C76 | C75 | C74 | C73 | C72 | C71 | C70 | C67 | C66 | C65 | C64 | C63 | C62 | C61 | C60 |
| Shift Register after third RX/WX plus one scan. | | | | | | | | | | | | | | | |

Store If Equal

The Store If Equal instruction detects when the Shift Register is reset to zeros. When that condition is true the C60 bit is SET by this rung. The C60 bit becomes the high bit shifted by the Shift Register until each RX/WX instruction is executed in turn.



First RX/WX Instruction**Second RX/WX Instruction****Third RX/WX Instruction**

After this rung is executed, the Shift Register shifts the high bit from C62 to C63 on the next CPU scan. C63 resets the Shift Register to zeros, the Store If Equal sets the C60 bit, and the CPU executes the first RX/WX instruction.

Maintenance and Troubleshooting

In This Chapter. . . .

- Isolating a Communication Problem
 - Troubleshooting Chart
 - ECOM Module Diagnostic LEDs
 - Using NetEdit for Troubleshooting
 - Replacing the ECOM Module
-

Isolating a Communication Problem

If you are experiencing a problem communicating with an ECOM module, the problem can usually be isolated to one of four components of the communication link:

- the ECOM module itself (hardware or firmware)
- the communication program or the setup of the ECOM module
- the cabling and connections
- other external influences, such as electrical noise, heavy communication traffic on the network or exceeding the PLC power budget

Diagnostic Tools and Techniques










Several available tools and techniques can help you isolate a communication problem:
















- The LEDs on the face of the module indicate the status of the link, the module, and the network communications.
- Replacing the module may determine whether the problem is in the module.
- NetEdit displays a list of the active modules on the network and their protocol and configuration settings.
- Cable testing devices can pinpoint short or open circuits or diagnose attenuation problems and other cabling problems.

Troubleshooting Chart

The following chart summarizes the different types of communication failures you could experience. In each case the **CPU PWR LED** must be **on**, and you must be attempting to communicate with the ECOM in question. You must be attempting to send or receive RX/WX instructions or you must be attempting to link to the ECOM using our DDE Server or other software driver.

The meaning of the **diagnostic LEDs** is explained on page 4-4.

| Troubleshooting Chart | |
|---|--|
| Legend:  Off  On  Flash | |
| ECOM Module LEDs | Corrective Action |
| LINKGD  OR LINKGD  ACT  ACT  ERROR  ERROR  | 1. Cycle power to the PLC. This will clear the ERROR if it was due to a transient condition. 2. Replace ECOM module |


| Troubleshooting Chart (Continued) | |
|---|---|
| Legend:  Off  On  Flash | |
| ECOM Module LEDs | Corrective Action |
| LINKGD  ACT  ERROR  | <ol style="list-style-type: none"> 1. Try another cable that you know works. Check pinouts (see page 2-17). 2. Try another port on the hub or another hub. 3. Replace ECOM module. |
| LINKGD  ACT  ERROR  | <ol style="list-style-type: none"> 1. Are PLCs in RUN mode? Some communications require initiating and responding PLCs to be in RUN mode. 2. Try another cable between PC and hub or the other communicating ECOM and hub. 3. Try another port on the hub or another hub. 4. Make sure you have not exceeded the recommended cable length for your network cable. The link signal could arrive with sufficient strength even though the data transmission does not. 5. Could be related to Windows configuration. Consult Windows documentation. |
| <div> <div> Note: This is also the indication of proper operation! Troubleshoot only if you are failing to exchange data. </div> <div> LINKGD  ACT  ERROR  </div> <div>OR</div> <div> LINKGD  ACT  ERROR  </div> </div> | |
| | <ol style="list-style-type: none"> 1. Try another cable between PC and hub or other ECOM and hub. 2. Try another port on the hub or another hub. 3. Confirm that ECOM module is in a usable slot in the PLC base (see pages 2-13 and 2-14) and that the CPU and CPU firmware support the ECOM module. 4. Look for errors in the setup of the ECOM module or in the communication program. |

ECOM Module Diagnostic LEDs

ECOM LEDs

The ECOM module has three indicator lights which show the status of the following:

- signal path between the ECOM and the hub (or between ECOMs)
- signal between ECOMs or between a PC and an ECOM
- ECOM module hardware



Link Good Indicator

The **green** Link Good (**LINKGD**) LED is **steady on** when the ECOM module is correctly connected to an active device on the network and is receiving 5VDC operating voltage from the PLC power supply. The LINKGD LED verifies that the proper cables are connected, and the ECOM module is functioning correctly. If a mismatch with the 10BaseT or 10BaseFL connections occurs this LED will not be illuminated.

ACT Indicator

The **red** Activity (**ACT**) LED **flashes** to indicate that the module sees data travelling on the network. If any network device is sending or receiving data, the ACT LED will be illuminated. In idle mode (no network traffic) this LED is OFF. During heavy communication loads this LED will be **steady on**.

Error Indicator

If the ECOM module's **red ERROR** indicator is **flashing** or **steady on**, a fatal error has occurred. The error may be in the ECOM module itself, or a network problem may be causing this symptom. The ERROR indication can be caused by a faulty ground, an electrical spike or other types of electrical disturbances. Cycle power to the system to attempt clearing the error.

Using NetEdit for Troubleshooting

NetEdit is a software utility which came with this manual. To review the procedures for running and using NetEdit, see pages 2-7 through 2-11. NetEdit allows you to:

- See active modules on the network.
- Examine and change the modules' configuration settings.
- See the firmware revision number.
- Review statistical information about communication errors by type.


If you can see the ECOM module on the list in the Module box (described below), you are *linking* to the module from your PC. If you are linking to the module but failing to communicate with the module, you can conclude that:

- The module is working.
- The cabling is satisfactory from the PC to the hub and from the hub to the ECOM module.
- The hub is working.
- The problem is in one of the other components of the communication link.

Select a Module

The Module box shows the Ethernet Addresses of all modules which are currently linked to the NetEdit utility. If your ECOM module is not on this list, try the following:


- Change Protocol selection and click on Query Network. See **Change Protocol** on the next page.
- Confirm that your PC has IPX or TCP/IP protocol loaded.
- Confirm that the ECOM module's LINKGD LED is on.



NOTE: The Ethernet Address is permanently assigned at the factory, and it is recorded on a label on the side of the ECOM module. See page 2-4 if you need help locating the label.


Module Information

The Module Information box gives the ECOM module Type, firmware Version, Booter firmware version and the address DIP switch setting. Verify that all modules of the same type have the same firmware version.



Change Protocol

If you are experiencing a problem communicating from your PC to a module that *does not* appear on the list of active modules, try changing the protocol and clicking on Query Network. You may be able to link to your module with the other protocol.



If you are not sure which protocol you have loaded on your PC, refer to pages 2-8 and 2-9, as well as your Windows documentation. This protocol selection is only for PC-to-PLC communications and has no effect on PLC-to-PLC communications.

Ethernet Stats

If you are able to see the *problem* module on the list of modules currently active on the network, you can **select** the module to see the Ethernet Stats for that module. Select the module by clicking on the Ethernet Address in the Module box (see page 2-9).

To begin a new statistical record, click the Clear Stats button.

The diagnostic information available in the Ethernet Stats box is:

- Missed Frames – frames lost due to unavailability of buffer space.
- TX Collisions – detected when RXD+ and RXD– become active during a data transmission. Two devices are trying to communicate at the same time.
- Lost Packets – packets that overflow the queue.
- Bad Packets – packets that fit the Ethernet standard but are not in the right format for the ECOM module.
- Unknown Type – a foreign command was received and could not be interpreted. This will probably happen only during software driver development.
- Send Errors – the Ethernet standard number of retries were attempted for a transmission.

RX/WX Settings

The RX/WX Settings box in this window provides a place to make changes that affect PLC-to-PLC communications *only*.

Change these settings only if:

- The LINKGD LED is on.
- The ACT LED is flashing.
- You have explored the module configuration and RLL programming for possible errors.

The **IP Broadcast Address** field is used to allow for non-standard broadcast address configurations. Some older Unix based systems did not use 255.255.255.255 for their broadcast address. This would prevent ECOMs from responding to network broadcast queries. Only change this value when using something other than 255.255.255.255 for broadcasts.

Record the Module Settings

If you are replacing an existing module, record the existing network identifier settings in the Configuration box. Set up the replacement module by linking to it with NetEdit and inserting the same network identifiers in the Configuration box. Click on Update Module to store the settings in the ECOM module's flash memory.

Each module on the network must have a unique network identifier.


Replacing the ECOM Module

If you are experiencing a communication problem, and you think the ECOM may be defective, try replacing the ECOM module with a new one or one that you know is working properly. If that corrects the problem, then the original module is probably defective (assuming the replacement module was set up the same as the original and no changes have been made to the communication program or other network components). The diagnostic LEDs will help you determine which applies in this case. If replacing the module does not correct the problem, then the problem is probably not in the module.

If you are replacing an existing ECOM module with a new one, you need to set up the new module with the same network identifiers as the module you are replacing. If you used the **DIP switch** to set the **Module ID**, you will need to set the DIP switch on the replacement module to the same Module ID. See pages 2-5 or 2-6 to review the procedure for setting the Module ID using the DIP switch.

If you set up your original ECOM module using one of the **software utilities**, you will need to refer to your record of the module's network identifiers (see page 2-2) and duplicate the settings in the new module using the same procedures. See page 2-8 through 2-12 to review the procedures for using the software utilities.

To replace the ECOM module, disconnect power from the PLC and remove the original module. Insert the replacement ECOM module, connect the module to your network and apply power to the PLC. Links to other network devices will automatically be reestablished and communications between devices will resume.



WARNING: Your system can be damaged if you install or remove system components before disconnecting the system power. To minimize the risk of equipment damage, electrical shock, or personal injury, always disconnect the system power before installing or removing any system component.

Diagnosing Network Cable Problems

If you are experiencing communication problems, swapping cables is one of the simplest diagnostic procedures you can perform. If the network operates correctly with a different cable, you have isolated and cured the problem. If possible, use a short run of cable to test the network because problems with longer cable runs can be more difficult to diagnose and are more often intermittent.

If you are unable to swap cables, verify the proper operation of all other network components. You probably have a cable problem if you have verified that your:

- ECOM module is working correctly.
- ECOM module configuration is correct.
- RLL program or PC program is correct.
- hubs are working correctly.
- Windows configuration is correct.
- network adapter card is the correct type, and it is working correctly.

It is a good maintenance practice to test network cables periodically and maintain a permanent record of cable characteristics. A number of cable test instruments are available to test 10BaseT and 10BaseFL networks. These instruments will check the electrical or optical characteristics of your cabling, including:

- Continuity – This is a check to make sure the communication pairs are wired correctly, and that the wires are continuous from end to end. In the case of fiber optic network this is a test to be sure light is transmitted from one end of the cable to the other.
- Attenuation – This refers to the amount of signal loss over the cable segment at the signal frequency of interest. The 10BaseT specification allows for a maximum signal loss of 11.5 decibels (dB) for the entire link at the signal frequency used by 10Mbps Ethernet. The 10BaseFL specification calls for the optical loss in link segment to be no greater than 12.5 dB.
- Crosstalk – Crosstalk occurs when a signal in one pair of wires is electromagnetically coupled to an adjacent pair. This is critical for 10BaseT networks which are susceptible to noise interference. 10BaseFL networks are virtually immune to noise interference.



NOTE: Any significant difference between the cable characteristics of the transmitter and receiver can cause communication errors.

Ethernet devices continually monitor the receive data path for activity as a means of verifying their link is working correctly. When the network is idle, each network device (including the ECOM module) sends a periodic *link test* signal to verify that the network is working. If the link test signal or other network activity is not received periodically, the LINKGD LED on the ECOM module is turned off.

Appendix A

General Specifications

In This Appendix

- H2-ECOM and H4-ECOM Specifications
 - H2-ECOM-F and H4-ECOM-F Specifications
 - Ethernet Standards
-

General Specifications

ECOM Specifications

| H2-ECOM / H4-ECOM General Specifications | |
|--|--|
| Module Type | Intelligent Data Communications Module |
| Quantity of Modules Per Base | Defined by CPU and base configuration |
| Diagnostics | LEDs/Network Monitoring Software (NetEdit) |
| Communications | 10BaseT Ethernet |
| Data Transfer | 10 Million bits per second |
| Extension Port | RJ45 |
| Link Good Indicator (LINKGD) | Green LED |
| Activity Indicator (ACT) | Red LED |
| Error Indicator (ERROR) | Red LED |
| Power Consumption | 320 mA (Supplied by DL205/DL405 base) |
| Operating Temperature | 32° to 140° F (0° to 60° C) |
| Storage Temperature | –4° to 158° F (–20° to 70° C) |
| Relative Humidity | 30% – 95% RH (non-condensing) |
| Environmental Air | No corrosive gases permitted |
| Networking Protocols Supported | TCP/IP, IPX |
| Manufacturer | Host Automation Products |
| Link Distance | 100 meters (328 feet) |

| H2-ECOM-F / H4-ECOM-F General Specifications | |
|--|---|
| Module Type | Intelligent Data Communications Module |
| Quantity of Modules Per Base | Defined by CPU and base configuration |
| Diagnostics | LEDs, Network Monitoring Software (NetEdit) |
| Communications | 10BaseFL Ethernet (fiber optic) |
| Data Transfer | 10 Million bits per second |
| Extension Port | ST-style fiber optic connector |
| Link Good Indicator (LINKGD) | Green LED |
| Activity Indicator (ACT) | Red LED |
| Error Indicator (ERROR) | Red LED |
| Power Consumption | 450 mA (Supplied by DL205/DL405 base) |
| Operating Temperature | 32° to 140° F (0° to 60° C) |
| Storage Temperature | –4° to 158° F (–20° to 70° C) |
| Relative Humidity | 30% – 95% RH (non-condensing) |
| Environmental Air | No corrosive gases permitted |
| Networking Protocols Supported | TCP/IP, IPX |
| Manufacturer | Host Automation Products |
| Link Distance | Up to 2,000 meters (2Km), 6,560ft (1.2 miles) |

Ethernet Standards

Various institutes and committees have been involved in establishing Ethernet data communication standards. These specification standards assure Ethernet network compatibility for products from a broad variety of manufacturers.

The ECOM module complies with American National Standards Institute (ANSI) and Institute of Electrical and Electronic Engineers standard ANSI/IEEE 802.3, Carrier Sense Multiple Access with Collision Detection (CSMA/CD) Access Methods and Physical Layer Specifications. This standard has been adopted by the International Organization for Standardization (ISO) as document ISO/IEC 8802-3.

The Electronic Industries Association (EIA) and Telecommunications Industries Commercial Building Telecommunications Wiring Standard designated EIA/TIA-568A defines implementation of 10BaseT (twisted pair) and 10BaseF (fiber optics) for Ethernet communications.

The same two organizations produced EIA/TIA TSB40—Additional Transmission Specifications for Unshielded Twisted-Pair Connecting Hardware. The purpose of this document is to specify transmission performance requirements and connecting hardware requirements.

Index

Numbers

10BaseFL, 2–17
10BaseT, 2–17
62.5/125 MMF, 2–17

A

ACT LED, 4–4
Advanced Settings, 2–11
Aliases, 3–6

B

Bulletin Board Service, 1–3

C

Cables, 2–17
 10BaseFL, 2–18
 10BaseT, 2–17
 crossover, 2–17
 distance limitations, 2–18
 fiber optic, 2–18
 length, 2–19
 patch, 2–17
 recommended 10BaseT, 2–18
 straight-through, 2–17
Communication status bits
 busy, 3–11
 error, 3–11
Configuration box, 2–11

Connectors

 10BaseFL, 2–17
 10BaseT, 2–17
 RJ45, 2–17
 ST bayonet, 2–17
CPU, use with ECOM, 2–11, 2–13, 2–14, 2–20

D

Data types, 3–7
DSData Server, 1–6
DIP switch
 H2–ECOM (–F), 2–5, 2–17
 H4–ECOM (–F), 2–6
DirectSOFT32
 for setting Network Identifiers, 2–12
 programming software, 1–4

E

ECOM Module, inserting in PLC base, 2–13
ECOM Modules, maximum number, 2–20
ERROR LED, 4–4
Ethernet, 1–6
 address, 2–2, 2–9, 2–10, 2–11
 standards, A–3
 stats box, 2–10
Expansion bases, 2–14

F

Fiber Optic, cables, 2–18
Flash memory, 2–11

H

Hubs, 2–16

I

Interlocks, for RX/WX instructions, 3–17

IP Address, 2–2, 2–10, 2–11

L

LEDs, for troubleshooting, 4–2

Link, 2–2

LINKGD, 4–4

Load Address instruction, 3–3

Load instruction, 3–3

Local expansion bases, 2–14

M

Memory Types, 3–6

Module ID, 2–2, 2–10, 2–11

Module Information Box, 2–10

Multimode Fiber Optic, 2–17, 2–18

Multiple Read and Write Instructions, 3–17

N

Name identifier, 2–2, 2–10

NetEdit

features, 2–8

running, 2–7

setting Network Identifiers, 2–10

troubleshooting, 4–5

Network, 2–2, 2–15

cabling, 2–17

identifiers, 2–2

layouts, 2–11, 2–15

table of identifiers, 2–11

O

Octal numbering system, 3–6

P

Patch cable, 2–17

PLC-to-PLC Communications, 2–10, 3–2

Power budget, 2–13

Programming Examples

multiple Read/Write instructions, 3–17

one Read instruction, 3–13

one Write instruction, 3–15

Protocols, 1–6

adding in your PC, 2–9

IPX, 2–8

UDP/IP, 2–8

Q

Query Network, 2–9

R

Read/Write instructions, 3–2, 3–3

References, 1–2

Repeaters, 2–16

RJ45, 2–17

RLL, 3–2

S

Sequencing

RX/WX instructions, 3–17

using control relays, 3–17

using shift register, 3–17, 3–20

Slot 0, 2–13

Slot table

H2-ECOM, 2–13

H4-ECOM, 2–14

Special Relays, 3–10

Specifications, A–2

ST, connectors, 2–17

T

Tables

- data types, 3–7
- network identifiers, 2–11
- special relays, 3–10
- usable slots, 2–13, 2–14

Technical support, 1–2

Topology, 2–15

- star, 2–15

Troubleshooting

- chart, 4–2
- using diagnostic LEDs, 4–2, 4–4

Truth table, 3–17

U

Update Module, 2–10

W

Web site, 1–2
