

# MAINTENANCE AND TROUBLESHOOTING

---



# CHAPTER 7

## In This Chapter...

Isolating a Communication Problem .....	7-2
Troubleshooting Chart .....	7-2
ECOM Module Diagnostic LEDs.....	7-4
Network Server (Slave) Operation .....	7-5
Using NetEdit3 for Troubleshooting.....	7-7
Replacing the ECOM Module .....	7-10
Diagnosing Network Cable Problems .....	7-11



Troubleshooting Chart (Continued)	
Legend: <input type="checkbox"/> Off <input checked="" type="checkbox"/> On <input style="background-color: #cccccc;" type="checkbox"/> Flash	
ECOM Module LEDs	Corrective Action

<p><b>ECOM100</b></p> <p>OK / STATUS <input checked="" type="checkbox"/></p> <p>LINKGD/LINK <input type="checkbox"/></p> <p>ACTIVE/ACT <input type="checkbox"/></p> <p>ERROR/ERR <input type="checkbox"/></p>	<p><b>ECOM(-F)</b></p> <p>LINK/LINKGD <input type="checkbox"/></p> <p>ACT <input type="checkbox"/></p> <p>ERROR/ERR <input type="checkbox"/></p>
---	--

1. Try another cable that you know works. Check pinouts (see page 2-12).
2. Try another port on the hub or another hub.
3. Replace ECOM module.

<p><b>ECOM100</b></p> <p>OK / STATUS <input checked="" type="checkbox"/></p> <p>LINKGD/LINK <input checked="" type="checkbox"/></p> <p>ACTIVE/ACT <input type="checkbox"/></p> <p>ERROR/ERR <input type="checkbox"/></p>	<p><b>ECOM(-F)</b></p> <p>LINK/LINKGD <input checked="" type="checkbox"/></p> <p>ACT <input type="checkbox"/></p> <p>ERROR/ERR <input type="checkbox"/></p>
--	---

1. Are PLCs in RUN mode? Some communications require initiating and responding PLCs to be in RUN mode.
2. Try another cable between PC and hub or the other communicating ECOM and hub.
3. Try another port on the hub or another hub.
4. Make sure you have not exceeded the recommended cable length for your network cable. The link signal could arrive with sufficient strength even though the data transmission does not.
5. Could be related to Windows configuration. Consult Windows documentation.

Note: This is also the indication of proper operation! Troubleshoot only if you are failing to exchange data.

<p><b>ECOM(-F)</b></p> <p>LINK/LINKGD <input checked="" type="checkbox"/></p> <p>ACT <input style="background-color: #cccccc;" type="checkbox"/> OR</p> <p>ERROR/ERR <input type="checkbox"/></p>	<p><b>ECOM(-F)</b></p> <p>LINK/LINKGD <input checked="" type="checkbox"/></p> <p>ACT <input checked="" type="checkbox"/></p> <p>ERROR/ERR <input type="checkbox"/></p>
<p><b>ECOM100</b></p> <p>OK / STATUS <input checked="" type="checkbox"/></p> <p>LINKGD/LINK <input checked="" type="checkbox"/> OR</p> <p>ACTIVE/ACT <input style="background-color: #cccccc;" type="checkbox"/></p> <p>ERROR/ERR <input type="checkbox"/></p>	<p><b>ECOM100</b></p> <p>OK / STATUS <input checked="" type="checkbox"/></p> <p>LINKGD/LINK <input checked="" type="checkbox"/></p> <p>ACTIVE/ACT <input checked="" type="checkbox"/></p> <p>ERROR/ERR <input type="checkbox"/></p>

1. Try another cable between PC and hub or other ECOM and hub.
2. Try another port on the hub or another hub.
3. Confirm that ECOM module is in a usable slot in the PLC base (see pages 2-7 to 2-9) and that the CPU and CPU firmware support the ECOM module.
4. Look for errors in the setup of the ECOM module or in the communication program.

## ECOM Module Diagnostic LEDs

### H0 Series Indicators

The H0 series ECOM module has four status indicators. The table below explains the status for each indicator.

Indicator	Status	Description
OK (H0-ECOM only)	ON - Green	Module is powered up and functional
	OFF	Module power-up failed
LINK	ON - Green	Properly connected to network
	OFF	Not connected to network or incorrect configuration
ACT	ON or Flashing Red	Active network data
	OFF	Network idle
ERR	ON or Flashing Red	A fatal error has occurred
	OFF	No error present
100 (H0-ECOM100 only)	ON - Green	Ethernet data is detected at 100 Mbit
	OFF	(with ACT LED ON) - Ethernet data is detected at 10 Mbit

### OK Indicator

The **green OK** LED on the H0-ECOM module is ON steady after a successful powerup. If the LED fails to turn on, the module failed to powerup. It may not be properly installed or it may be defective.

### LINK Indicator

The **green LINK** (link good) LED is ON **steady** when the ECOM module is correctly connected to an active device on the network and is receiving 5VDC operating voltage from the PLC power supply. The LINK LED verifies that the proper cables are connected, and the ECOM module is functioning correctly. If a mismatch with the 10/100BaseT connections occurs this LED will not be illuminated.

### ACT Indicator

The **red ACT** (activity) LED **flashes** to indicate that the module sees data traveling on the network. If any network device is sending or receiving data, the ACT LED will be illuminated. In idle mode (no network traffic) this LED is OFF. During heavy communication loads this LED will be **steady ON**.

### ERR Indicator

If the ECOM module's **red ERROR** indicator is **flashing** or ON **steady**, a fatal error has occurred. The error may be in the ECOM module itself, or a network problem may be causing this symptom. The ERROR indication can be caused by a faulty ground, an electrical spike or other types of electrical disturbances. Cycle power to the system to attempt clearing the error.

### 100MBIT Indicator

The **green 100** (100MB) LED is ON **steady** when Ethernet data is detected at 100BaseT frequency. (H0- ECOM100 only)

## Network Server (Slave) Operation

### H24-ECOM-(F) Indicators

The table below describes the three status indicators on the H24- ECOM modules.

Indicator	Status	Description
LINKGD	ON - Green	Properly connected to network
	OFF	Not connected to network or incorrect configuration
ACT	Flashes Red	Active network data
	OFF	Network idle
ERR	ON or Flashing Red	A fatal error has occurred
	OFF	No error present

### LINKGD Indicator

The **green LINKGD** (link good) LED is ON steady when the H24-ECOM-(F) module is correctly connected to an active device on the network and is receiving 5VDC operating voltage from the PLC power supply. The LINKGD LED verifies that the proper cables are connected, and the H24-ECOM-(F) module is functioning correctly. If a mismatch with the 10BaseT or 10BaseFL connections occurs this LED will not be illuminated.

### ACT Indicator

The **red ACT** (activity) LED **flashes** to indicate that the module sees data travelling on the network. If any network device is sending or receiving data, the ACT LED will be illuminated. In idle mode (no network traffic) this LED is OFF. During heavy communication loads this LED will be steady ON.

### ERROR Indicator

If the H24-ECOM-(F) module's **red ERROR** indicator is **flashing** or **steady ON**, a fatal error has occurred. The error may be in the H24-ECOM-(F) module itself, or a network problem may be causing this symptom. The ERROR indication can be caused by a faulty ground, an electrical spike or other types of electrical disturbances. Cycle power to the system to attempt clearing the error.

### H2/H4-ECOM100 Indicators

The H2/H4 -ECOM100 module has several status indicators. The table below explains the status for each indicator.

Indicator	Status	Description
STATUS (H2-ECOM only)	ON - Green	Module is powered up and functional
	OFF	Module power-up failed
LINKGD	ON - Green	Properly connected to network
	OFF	Not connected to network or incorrect configuration
ACTIVE	ON or Flashing Red	Active network data
	OFF	Network idle
ERROR	ON or Flashing Red	A fatal error has occurred
	OFF	No error present
100 Mbit (H0-ECOM100 only)	ON	Ethernet data is detected at 100 Mbit
	OFF	(with ACT LED ON) - Ethernet data is detected at 10 Mbit

#### STATUS

The **green OK** LED on the H2-ECOM100 module is **steady ON** after a successful powerup. If the LED fails to turn on, the module failed to powerup. It may not be properly installed or it may be defective.

#### LINKGD Indicator

The green LINK (link good) LED is **steady ON** when the H2/H4-ECOM100 module is correctly connected to an active device on the network and is receiving 5VDC operating voltage from the PLC power supply. The LINK LED verifies that the proper cables are connected, and the H2/H4-ECOM100 module is functioning correctly. If a mismatch with the 10/100BaseT or 10BaseFL connections occurs this LED will not be illuminated.

#### ACTIVE Indicator

The red ACTIVE (activity) LED **flashes** to indicate that the module sees data travelling on the network. If any network device is sending or receiving data, the ACT LED will be illuminated. In idle mode (no network traffic) this LED is OFF. During heavy communication loads this LED will be **steady ON**.

#### ERROR Indicator

If the H2/H4-ECOM100 module **red ERROR** indicator is **flashing** or **steady ON**, a fatal error has occurred. The error may be in the H2-ECOM100 module itself, or a network problem may be causing this symptom. The ERROR indication can be caused by a faulty ground, an electrical spike or other types of electrical disturbances. Cycle power to the system to attempt clearing the error.

#### 100MBIT Indicator

The **green 100M** (100MB) LED is **steady ON** when Ethernet data is detected at 100BaseT frequency.

## Using NetEdit3 for Troubleshooting

NetEdit3 is the software utility used to configure and troubleshoot Host Ethernet based devices. To review the procedures for running and using NetEdit3, see pages 3-5 through 3-12. NetEdit3 allows you to:

- See active modules on the network.
- Examine and change the modules' configuration settings.
- See the firmware revision number.
- Review statistical information about communication errors by type.

If you can see the ECOM module on the list in the Module box (described below), you are linking to the module from your PC. If you are linking to the module but failing to communicate with the module, you can conclude that:

- The module is working.
- The cabling is satisfactory from the PC to the hub and from the hub to the ECOM module.
- The hub is working.
- The problem is in one of the other components of the communication link.

### Select a Module

The Module box shows the Ethernet (MAC) Addresses of all modules which are currently linked to the NetEdit3 utility. If your ECOM module is not on this list, try the following:

- Change Protocol selection and click on Scan Network (See Change Protocol on the next page).
- Confirm that your PC has IPX or TCP/IP protocol loaded.
- Confirm that the ECOM module's LINKGD LED is on.
- If there is more than one network adapter installed in the PC, from the menu, select Network -> Adapter, to select the network adapter used to connect to your devices.



---

**NOTE:** The Ethernet (MAC) Address is permanently assigned at the factory, and it is recorded on a label on the side of the ECOM module. See page 2-4 if you need help locating the label.

---

### Module Information

The Module Information box gives the ECOM module Type, firmware Version, Booter firmware version and the address DIP switch setting. Verify that all modules of the same type have the same firmware version.

### Change Protocol

If you are experiencing a problem communicating from your PC to a module that does not appear on the list of active modules, try changing the protocol and clicking on Scan Network. You may be able to link to your module with the other protocol.

If you are not sure which protocol you have loaded on your PC, refer to Chapter 3, as well as your Windows documentation. This protocol selection is only for PC-to-PLC communications and has no effect on PLC-to-PLC communications.




### Ethernet Stats

If you are able to see the problem module on the list of modules currently active on the network, you can select the module to see the Ethernet Stats for that module. Select the module by clicking on the Ethernet (MAC) Address in the Module box.

To begin a new statistical record, click the Clear Stats button.

The diagnostic information available in the Ethernet Stats box is:

- Missed Frames - frames lost due to unavailability of buffer space.
- TX Collisions - detected when
- RXD+ and RXD- become active during a data transmission. Two devices are trying to communicate at the same time.
- Lost Packets - packets that overflow the queue.
- Bad Packets - packets that fit the Ethernet standard but are not in the right format for the ECOM module.
- Unknown Type - a foreign command was received and could not be interpreted. This will probably happen only during software driver development.
- Send Errors - the Ethernet standard number of retries were attempted for a transmission.





## RX/WX Settings

The RX/WX Settings box in this window provides a place to make changes that affect PLC-to-PLC communications only.

Change these settings only if:


- The LINK/LINKGD LED is on.
- The ACT LED is flashing.
- You have explored the module configuration and RLL programming for possible errors.



## Record the Module Settings

If you are replacing an existing module, record the existing network identifier settings in the Configuration box. Set up the replacement module by linking to it with NetEdit3 and inserting the same network identifiers in the Configuration box. Click on Update Module to store the settings in the ECOM module's flash memory.

Each module on the network must have a unique network identifier.



### Replacing the ECOM Module

If you are experiencing a communication problem, and you think the ECOM may be defective, try replacing the ECOM module with a new one or one that you know is working properly. If that corrects the problem, then the original module is probably defective (assuming the replacement module was set up the same as the original and no changes have been made to the communication program or other network components). The diagnostic LEDs will help you determine which applies in this case. If replacing the module does not correct the problem, then the problem is probably not in the module.

If you are replacing an existing ECOM module with a new one, you need to set up the new module with the same network identifiers as the module you are replacing. If you used the DIP switch to set the Module ID, you will need to set the DIP switch on the replacement module to the same Module ID. See Chapter 2 to review the procedure for setting the Module ID using the DIP switch.

If you set up your original ECOM module using one of the software utilities, you will need to refer to your record of the module's network identifiers in Chapter 2 and duplicate the settings in the new module using the same procedures. See Chapter 3 to review the procedures for using the software utilities.

To replace the ECOM module, disconnect power from the PLC and remove the original module. Insert the replacement ECOM module, connect the module to your network and apply power to the PLC. Links to other network devices will automatically be reestablished and communications between devices will resume.



**WARNING:** Your system can be damaged if you install or remove system components before disconnecting the system power. To minimize the risk of equipment damage, electrical shock, or personal injury, always disconnect the system power before installing or removing any system component.

---

## Diagnosing Network Cable Problems

If you are experiencing communication problems, swapping cables is one of the simplest diagnostic procedures you can perform. If the network operates correctly with a different cable, you have isolated and cured the problem. If possible, use a short run of cable to test the network because problems with longer cable runs can be more difficult to diagnose and are more often intermittent.

If you are unable to swap cables, verify the proper operation of all other network components. You probably have a cable problem if you have verified that you:

- ECOM module is working correctly.
- ECOM module configuration is correct.
- RLL program or PC program is correct.
- Hubs are working correctly.
- Windows configuration is correct.
- Network adapter card is the correct type, and it is working correctly.

It is a good maintenance practice to test network cables periodically and maintain a permanent record of cable characteristics. A number of cable test instruments are available to test 10/100BaseT and 10BaseFL networks. These instruments will check the electrical or optical characteristics of your cabling, including:

- Continuity - This is a check to make sure the communication pairs are wired correctly, and that the wires are continuous from end to end. In the case of fiber optic network this is a test to be sure light is transmitted from one end of the cable to the other.
- Attenuation - This refers to the amount of signal loss over the cable segment at the signal frequency of interest. The 10/100BaseT specification allows for a maximum signal loss of 11.5 decibels (dB) for the entire link at the signal frequency used by 10Mbps Ethernet. The 10BaseFL specification calls for the optical loss in link segment to be no greater than 12.5 dB.
- Crosstalk - Crosstalk occurs when a signal in one pair of wires is electromagnetically coupled to an adjacent pair. This is critical for 10BaseT networks which are susceptible to noise interference. 10BaseFL networks are virtually immune to noise interference.



**NOTE:** Any significant difference between the cable characteristics of the transmitter and receiver can cause communication errors.

---

Ethernet devices continually monitor the receive data path for activity as a means of verifying their link is working correctly. When the network is idle, each network device (including the ECOM module) sends a periodic link test signal to verify that the network is working. If the link test signal or other network activity is not received periodically, the LINK/LINKGD LED on the ECOM module is turned off.