

TABLE OF CONTENTS



Chapter 1: Getting Started

Manual Overview	1-2
Available Models	1-3
Receiving and Inspection	1-10
Reshipping	1-11
Long Term Storage	1-11
Warranty	1-11

Chapter 2: Mounting & Initial Startup

Safety Information	2-2
Motor Dimensions	2-3
Terminal Diagrams	2-6
Motor Mounting	2-7
Proper Installation Conditions	2-8
Coupling Alignment	2-8
Motor Nameplate & Starter Information	2-9
Inspection Before Startup	2-10
Initial Startup Inspection	2-11

Chapter 3: Preventative Ongoing Maintenance

Routine Maintenance	3-2
Bearing Size Information	3-3

Chapter 4: Accessories

Capacitors and Centrifugal Switches	4-2
C-Flange Kits	4-3
STABLE Slide Bases	4-5

Chapter 5: Reference

Using IronHorse Motors with AC Drives	5-2
Double Punched Motors	5-3
F1 and F2 Mounting	5-4
Junction Box Dimensions	5-5
Minimum Sheave Diameters	5-6
Decibel Levels	5-7
Shipping Crate Dimensions and Weights	5-8