

## **HIGH SPEED COUNTER USER MANUAL**

XBF-HO02A XBF-HD02A



This manual is written and maintained by LS Electric and hosted on AutomationDirect.com to support the LS Electric PLC product line. AutomationDirect is not responsible for any errors, omissions, or typos contained in this manual.

The right choice for the ultimate yield!

LS ELECTRIC strives to maximize your profits in gratitude for choosing us as your partner.

## **Programmable Logic Control**

# **High Speed Counter Module**

XGB Series

## **User Manual**

XBF-HO02A XBF-HD02A





- Read this manual carefully before installing, wiring, operating, servicing or inspecting this equipment.
- Keep this manual within easy reach for quick reference.



### Before using the product ...

For your safety and effective operation, please read the safety instructions thoroughly before using the product.

- Safety Instructions should always be observed in order to prevent accident or risk with the safe and proper use the product.
- ► Instructions are divided into "Warning" and "Caution", and the meaning of the terms is as follows.

Warning This symbol indicates the possibility of serious injury or death if some applicable instruction is violated

## 

This symbol indicates the possibility of severe or slight injury, and property damages if some applicable instruction is violated

Moreover, even classified events under its caution category may develop into serious accidents relying on situations. Therefore we strongly advise users to observe all precautions properly just like warnings.

► The marks displayed on the product and in the user's manual have the following meanings.

Provide the second seco

 $\overline{4}$ Be careful! Electric shock may occur.

The user's manual even after read shall be kept available and accessible to any user of the product.

## Safety Instructions for design process

- Please install a protection circuit on the exterior of PLC so that the whole system may operate safely regardless of failures from external power or PLC. Any abnormal output or operation from PLC may cause serious problems to safety in whole system.
  - Install protection units on the exterior of PLC like an interlock circuit that deals with opposite operations such as emergency stop, protection circuit, and forward/reverse rotation or install an interlock circuit that deals with high/low limit under its position controls.
  - If any system error (watch-dog timer error, module installation error, etc.) is detected during
     CPU operation in PLC, all output signals are designed to be turned off and stopped for safety.
     However, there are cases when output signals remain active due to device failures in Relay and
     TR which can't be detected. Thus, you are recommended to install an addition circuit to monitor
     the output status for those critical outputs which may cause significant problems.
- Never overload more than rated current of output module nor allow to have a short circuit.
   Over current for a long period time maycause a fire .
- Never let the external power of the output circuit to be on earlier than PLC power, which may cause accidents from abnormal output oroperation.
- Please install interlock circuits in the sequence program for safe operations in the system when exchange data with PLC or modify operation modes using a computer or other external equipments Read specific instructions thoroughly when conducting control operations with PLC.

## Safety Instructions for design process

## 

I/O signal or communication line shall be wired at least 100mm away from a high-voltage

cable or power line. Fail to follow this

## Safety Instructions on installation process

## 

- Use PLC only in the environment specified in PLC manual or general standard of data sheet. If not, electric shock, fire, abnormal operation of the product may be caused.
- Before install or remove the module, be sure PLC power is off. If not, electric shock or damage on the product may be caused.
- Be sure that every module is securely attached after adding a module or an extension connector. If the product is installed loosely or incorrectly, abnormal operation, error or dropping may be caused. In addition, contact failures under poor cable installation will be causing malfunctions as well.
- Be sure that screws get tighten securely under vibrating environments. Fail to do so will put the product under direct vibrations which will cause electric shock, fire and abnormal operation.
- Do not come in contact with conducting parts in each module, which may cause electric shock, malfunctions or abnormal operation.

## Safety Instructions for wiring process

## 

- Prior to wiring works, make sure that every power is turned off. If not, electric shock or damage on the product may be caused.
- After wiring process is done, make sure that terminal covers are installed properly before

its use. Fail to install the cover may cause electric shocks.

- Check rated voltages and terminal arrangements in each product prior to its wiring process. Applying incorrect voltages other than rated voltages and misarrangement among terminals may cause fire or malfunctions.
- Secure terminal screws tightly applying with specified torque. If the screws get loose, short circuit, fire or abnormal operation may be caused. Securing screws too tightly will cause damages to the module or malfunctions, short circuit, and dropping.
- Be sure to earth to the ground using Class 3 wires for FG terminals which is exclusively used for PLC. If the terminals not grounded correctly, abnormal operation or electric shock may be caused.
- Don't let any foreign materials such as wiring waste inside the module while wiring, which may cause fire, damage on the product or abnormal operation.
- Make sure that pressed terminals get tighten following the specified torque. External connector type shall be pressed or soldered using proper equipments.

## Safety Instructions for test-operation and maintenance

## 

- > Don't touch the terminal when powered. Electric shock or abnormal operation may occur.
- Prior to cleaning or tightening the terminal screws, let all the external power off including
   PLC power. If not, electric shock or abnormal operation may occur.
- Don't let the battery recharged, disassembled, heated, short or soldered. Heat, explosion or ignition may cause injuries or fire.
- Caution
  Do not make modifications or disassemble each module. Fire, electric shock or abnormal operation may occur.
  Prior to installing or disassembling the module, let all the external power off including PLC power. If not, electric shock or abnormal operation may occur.
  Keep any wireless equipment such as walkie-talkie or cell phones at least 30cm away from PLC. If not, abnormal operation may be caused.
  When making a modification on programs or using run to modify functions under PLC operations, read and comprehend all contents in the manual fully. Mismanagement will cause damages to products and accidents.
  Avoid any physical impact to the battery and prevent it from dropping as well. Damages to battery may cause leakage from its fluid. When battery was dropped or exposed under strong impact, never reuse the battery again. Moreover skilled workers are needed when exchanging

batteries.

## Safety Instructions for waste disposal



• Product or battery waste shall be processed as industrial waste. The waste may discharge

toxic materials or explode itself.

Γ

## **Revision History**

٦

Version	Date	Remark	Page
V 1.0	2012.05	First Edition	-
		1. Domain name changed	-
V 1.1	2015.07	<ol> <li>Changed</li> <li>General specifications changed by reason of</li> </ol>	-
		changed IEC Specifications	2-1
V 1.2	2016.03	1. Smart Link Connection Diagram added and changed	2-8~12
V1.3	2020.06	1. Changed company name to LS ELECTRIC	-
V1.4	2022.09	1. Changed domain to Is-electric.com	-
V1.5	2024.07	1. Changed quality warrnty period	-

% The number of User's manual is indicated right part of the back cover.

© LS ELECTRIC Co., Ltd 2012 All Rights Reserved.

## **About User's Manual**

Congratulations on purchasing PLC of LS ELECTRIC Co.,Ltd.

Before use, make sure to carefully read and understand the User's Manual about the functions, performances, installation and programming of the product you purchased in order for correct use and importantly, let the end user and maintenance administrator to be provided with the User's Manual.

The User's Manual describes the product. If necessary, you may refer to the following description and order accordingly. In addition, you may connect our website (<u>http://www.ls-electric.com/</u>) and download the information as a PDF file.

Title	Description	No. of User's Manual
XG5000 User's Manual (for XGK, XBC,XBM)	XG5000 software user manual describing online function such as programming, print, monitoring, debugging by using XGB(MK language) CPU	10310000511
XG5000 User's Manual (for XGI, XGR, XEC)	XG5000 software user manual describing online function such as programming, print, monitoring, debugging by using XGB(IEC language) CPU	10310000746
XGK/XGB Instructions & Programming User's Manual	User's manual for programming to explain how to use instructions that are used PLC system with XGK, XGB CPU.	10310000509
XGI/XGR/XEC Instructions & Programming User's Manual	User's manual for programming to explain how to use instructions that are used PLC system with XGI, XGR, XEC CPU.	10310000739
Ultimate Performance XGB Unit(MK/IEC)	It describes how to use XGB main unit, system configuration,mechanism,program function ,input/output function, Built-in High-speed Counter, Datalog, PID Control, Built-in Communication function, Built-in Position, Built-in Analog input/output	10310000893, 10310001406
XGB hardware	It describes power, IO, extension specification and system configuration, built-in high speed counter of XGB main unit.	10310000893, 10310000981
XBC Standard / Economic Type Main Unit(MK/IEC)	It describes power, IO, extension specification and system configuration, built-in high speed counter of XGB standard / economic type main unit.	10310001090, 10310001273

Relevant User's Manuals

## O Table of Contents

٦

٦

Chapter	1	Overview	 1-1

Chapter 2 Specifications	. 2-1 ~ 2-27
2.1 GENERAL SPECIFICATIONS	
2.2 PERFORMANCE SPECIFICATIONS	2-2
2.2.1 Performance specifications	2-2
2.2.2 Pulse input specification	2-3
2.2.3 Preset/Gate input specification	2-3
2.2.4 Comparision output specification	2-3
2.3 Part Names	2-4
2.3.1 Part Names	2-4
2.3.2 Specification of interface with external devices	
2.4 FUNCTIONS	
2.4.1 Pulse input mode	2-9
2.4.2 Counter mode	2-16
2.4.3 Preset	2-19
2.4.4 Compared output	2-20
2.4.5 Carry signal	2-24
2.4.6 Borrow signal	2-24
2.4.7 Auxiliary mode	

Chapter 3 Installation and Wiring	3-1 ~ 3-7
3.1 INSTALLATION	
3.1.1 Installation environment	3-1
3.1.2 Handling precautions	3-1
3.2 WIRING PRECAUTIONS	3-2
3.2.1 Example of DC5V voltage output wiring	3-3
3.2.2 Example of DC12V NPN Open Collector output wiring	3-4
3.2.3 Example of DC24V PNP Open Collector output wiring	3-6
3.2.4 Example of Line Driver output wiring	

Chapter 4 Operation Procedures and Monitoring (XG5000)	4-1 ~	- 4-12
4.1 Operation Method		4-1
4.1.1 Execution of XG5000		4-1

4.2 PARAMETERS SETTING	
4.2.1 Parameters setting screen	
4.3 MONITORING AND TEST	
4.3.1 Monitoring/Test screen	
4.4 REGISTER U DEVICES	
4.4.1 View variables	
4.4.2 Register U Devices	
4.5 REGISTRATION OF SPECIAL MODULE VARIABLE	
4.5.1 Global/Direct Variables screen	
4.5.2 Registration of the special module variables	

Г

## Chapter 5 Internal Memory & I/O Signals ...... 5-1 ~ 5-3

5.1	INTERNAL MEMORY	5-1
5.1	.1 Configuration of the internal memory	5-1
5.1	.2 Details & Data configuration	5-2
5.2	I/O SIGNALS	5-3

## 

6.1 0	GLOBAL CONSTANT	6-1
6.1.1	The configuration of Global Constant	6-1
6.1.2	The Configuration and Contents of Data	6-2
6.2 0	GLOBAL VARIABLE	6-4

## Chapter 7 Programming ...... 7-1 ~ 7-29

7.1 INSTRUCTION AND FUNCTION BLOCK	7-1
7.1.1 Instruction of XGK series	7-1
7.1.2 Function Block of XGI/XGR	7-4
7.2 PROGRAM	7-7
7.2.1 Count mode setting	7-7
7.2.2 Pulse input mode setting	7-10
7.2.3 Counter check	7-11
7.2.4 Preset value setting and enable preset	7-12
7.2.5 Enable counter	7-13
7.2.6 Carry/borrow detection reset	7-13
7.2.7 Auxiliary mode setting and Enable auxiliary function	7-14
7.2.8 Up/down count selection	7-20
7.2.9 Use of external preset signal	7-20
7.2.10 Use of external auxiliary function signal	7-21
7.2.11 Type of comparison and comparison value setting	7-22
7.2.12 Enable comparison, Enable comparison output, Comparison agreement reset	7-24
7.2.13 Comparison output status setting	7-25
7.2.14 Input pulse active level setting	7-26

7.2.15 Error status and error code7	' <b>-</b> 27
7.2.16 Hold count when power fails7	' <b>-</b> 28

٦

## Chapter 8 Troubleshooting ...... 8-1 ~ 8-9

8.1 Error code	8-1
8.2 TROUBLESHOOTING	8-2
8.2.1 LED display status of HS counter module	8-2
8.2.2 Counter status of HS counter module	8-2
8.2.3 Output status of HS counter module	8-2
8.3 TROUBLESHOOTING SEQUENCE	8-3
8.3.1 RDY LED Off	8-3
8.3.2 RDY LED Blinks	8-4
8.3.3 Counter operation error	8-5
8.3.4 Counter value error	8-6
8.3.5 Output operation error	8-7
8.3.6 Module status check through XG5000 system monitoring	

Appendices	Appendix -1 ~ Appendix -2
Appendix 1 Terminology	Appendix 1
Appendix 2 Dimensions	Appendix 2

## Warranty and Environmental Policy

## Chapter 1. Overview

XGB High Speed counter modules are designed for XGB(XBM/XBC/XEC) series and used with XGT PLC CPU. And XBF-HO02A(Open Collector type), XBF-HD02A(Line Drive type) modules are available.

#### 1.1 Characteristic

High Speed Counter modules can count the high speed pulses which can not be processed by CPU module's counter instructions (CTU, CTD, CTUD etc.), up to binary value of 32 bits (-2,147,483,648 ~ 2,147,483,647).

High Speed counter modules have the following functions.

- (1) XGB PLC is available.
- (2) Three kinds of pulse inputs function
  - (a) 1-phase input: Increasing/Decreasing function Program or by means of the B-phase input (1-multiplier, 2-multiplier)
  - (b) 2-phase is input: Increasing/Decreasing function by means of the difference in phase.( 1-multiplier, 2-multiplier, 4-multiplier)
  - (c) CW/CCW is input: Increasing/Decreasing function by means of A-phase or B-phase.(1-multiplier)
- (3) Preset and Gate function by means of the applicable program or external input signal
- (4) 6 additional functions are available such as Count Clear, Count Latch, Sampling Count, Input frequency Measure, Revolution Measure per unit time and Count Disable.
- (5) 7 kinds of compared signals can be outputted at output contact of the built-in transistor through compared based value (Min compared value, Max compared value) and current count value.
- (6) Provided Low Active and High Active mode.
- (Preset and Gate input is only available a high active mode.)
- (7) Currently user manual of HSC module is written based on the following version.

XGB Main Unit		Version		
XBM	XBM-D	V3.20 or above		
	XBC-DoooH	V2.10 or above		
XBC	XBC-D	V1.20 or above		
	XBC-D	V1.20 or above		
	XBC-D	Unavailable		
VEO	XEC-D	V1.40 or above		
XEC	XEC-D	V1.00 or above		
PADT	XG5000	V3.64 or above		

## **Chapter 2 Specifications**

## **2.1 General Specifications**

#### General specifications of XGT series

No.	ltem		Related specifications								
1	Ambient temperature		0°C∼+55°C								
2	Storage temperature		-25℃~+70℃								
3	Ambient humidity			5~95%RH (No	on-condensing)		-				
4	Storage humidity			5~95%RH (No	on-condensing)		-				
			Occas	ional vibration		-	-				
		Frequency	Ac	cceleration	Amplitude	How many times					
		5≤f<8.4 Hz		-	3.5 mm						
F	Vibration registeres	<b>8.4 ≤ f ≤ 150</b> Hz	9.	8 m/s² (1G)	-						
5	VIDIATION resistance		For conti	nuous vibration		10 times each directions	IEC61131-2				
		Frequency		cceleration	Amplitude	(X, Y and Z)					
		5≤f<8.4 Hz	5≤f<8.4 Hz - 1.75 mm		1						
		<b>8.4≤f≤150</b> Hz	8.4≤f≤150 Hz 4.9 m/s² (0.5G) -								
		<ul> <li>Peak acceleration: 147</li> </ul>	Peak acceleration: 147 m/s <sup>2</sup> (15G)								
6	Shock resistance	<ul> <li>Duration: 11ms</li> </ul>	. ,				IEC61131-2				
		• Half-sine, 3 times each	direction per e	ach axis							
		Square wave			AC: ± 1,500V		LS ELECTRIC				
		Impulse noise			DC: ± 900V		standard				
		Electrostatic discharge		Voltage	e : 4kV (contact dischar	ging)	IEC 61131-2, IEC 61000-4-2				
7	Noise resistance	Radiated electromagnetic field noise		80 ~ 1,000 MHz, 10V/m							
		Fast transient	Segment	IEC 61131-2, IEC 61000-4-4							
		/DUST TOISE	Voltage								
8	Environment		Free f	rom corrosive gass	es and excessive dust		-				
9	Altitude			Up to 2,0	00 ms		-				
10	Pollution degree			Less than e	equal to 2		-				
11	Cooling		Air-cooling								

#### Notes

1) IEC(International Electrotechnical Commission):

An international nongovernmental organization which promotes internationally cooperated standardization in electric/electronic fields, publishes international standards and manages applicable estimation system related with.

2) Pollution degree:

An index indicating pollution level of the operating environment which decides insulation performance of the devices. For instance, Pollution level 2 indicates the state generally that only non-conductive pollution occurs. However, this state contains temporary conduction due to dew produced.

## 2.2 Performance Specifications

Specifications of High Speed counter module's basic performance, preset/gate input and transistor output are as described below.

## 2.2.1 Performance specifications

Γ

Specification								
π	em	XBF-HO02A XGF-HD02A						
Ocurat	Signal	A-phase, B-phase						
	Input type	Voltage input (Open Collector) Differential input (Line Drive):						
Input signal	Signal level	DC 5/12/24V	RS-422A Line Drive/HTL LEVEL Line Drive					
Maximum co	efficient speed	200kpps 500kpps (HTL input : 250kpps)						
Number	of channels	2 Channels						
Coeffici	ent range	Signed 32-bit (-2,147,483,648 ~ 2,147,483,647	<i>(</i> )					
		Linear Count (When 32-bit range exceeded, Ca	arry/Borrow occurs, the count value stopped)					
Cour	it mode	Ring Count (repeated count within setting range	e)					
		1-phase input						
Input pu	ulse mode	2-phase input						
1 - 1 -		CW/CCW input						
	1 ale and insert	Increasing/decreasing operation setting by B-pl	hase input					
Lip/down	1-pnase input	Increasing/decreasing operation setting by proc	gram					
Setting	2-phase input	Automatic setting by difference in phase						
Cotting	CW/CCW	A-phase input: increasing operation						
B-pnase input: decreasing operation								
Multiplication	1-phase input	1/2 multiplication						
function								
	Signal	Preset instruction input auxilian/mode instructi	on input					
Control input	Signal level	DC 51//121//241/ (by terminal selection) input type						
Control in por	Signal type	Voltage						
	Output points	2-point/channel (for each channel): terminal out	tput available					
External output	Type	Select single-compared (>, >=, =, << ) or section compared output (included or excluded)						
	Output type	Open collector output (Sink)						
Operation	Input Signal	A-phase input, B-phase input, Preset instructi	on input, auxiliary mode instruction input					
Status Display	Output Signal	External output 0, External output 1						
Status Display	Busy Status	Module Ready						
Count	t Enable	To be set through program (count available only	y in enable status)					
Preset	function	To be set through terminal or program						
		Count clear,						
		Count latch,						
	a da function	Section count(time setting value: 0~60000ms),						
auxiliary m	iode function	Measurement of input frequency(for respective i	nput phase),					
		Measurement of counts per hour(time setting va	lue: 0~60000ms)					
		Count prohibited function	,					
Ter	minal	40 pin connector						
I/O occu	pied points	Fixed point: 64						
Internal con	sumed current	200mA	260mA					
W	eight	90g						

## 2.2.2 Pulse input specification

ltom	Specification							
item		Line driver						
	DC 24V	DC 12V	DC 5V					
input volatage	(17.0V~26.4V)	(9.8V~13.2V)	(4.5V~5.5V)					
Input current	7mA~11mA 7mA~11mA 7mA~11mA		RS-422A line driver					
Min. On guaranteed	47.0\/	0.0)/	4 414	(5V level)/HTL line				
voltage	17.00	9.80	4.1V	Driver(24V level)				
Max. Off guarateed	4 5)/	2.01/	4 7/					
voltage	4.5V	3.00	1.7V					

٦

## 2.2.3 Preset, auxiliary function input specification

ltem	Specification					
laput volotogo	DC 24V	DC 12V	DC 5V			
input volatage	(17.0V~26.4V)	(9.8V~13.2V)	(4.5V~5.5V)			
Input current	7mA~11mA	7mA~11mA	7mA~11mA			
Min. On guarateed voltage	17.0V	9.8V	4.1V			
Max. Off guarateed voltage	4.5V	3.0V	1.7V			
On delay time	1 ms or less					
Off delay time	1 ms or leess					

## 2.2.4 Comp. output specification

ltem	Specification			
Output type	Transistor sink			
Rated output	ted output DC 24V, 100 mA/point			
Leakage current	0.1 mA or less			
Saturated area voltage	1.3 V or less			
On delay time	0.1 ms or less			
Off delay time	0.1 ms or less			

## 2.3 Part Names

Γ

#### 2.3.1 Part Names



No.	Name	Contents		
		On: relevant channel pulse inputting, Preset/Auxiliary function signal inputting,		
	Run LED	Commparison outputting		
	(ФА, ФВ, P, G, O0, O1)	Off: No input of relevant channel pulse, No input of preset/auxiliary function signal, No output		
1		of comparison		
		On: HSC module normal		
	Ready signal (RDY)	Off: Power off or CPU module reset, HSC module error		
		Flicker: HSC module error		
2	External wiring connector	Connector to conect with external I/O		

## 2.3.2 Specification of interface with external devices

## 1. Arrangement of connector pins

### (1) XBF-HO02A

Din errengement	В	Α	Cignal name	
Pin arrangement	CH1	CH0		Signai name
	20	20	A24V	A phase pulse input 24V
	19	19	A12V	A phase pulse input 12V
	18	18	A5V	A phase pulse input 5V
	17	17	ACOM	A phase pulse input COM
	16	16	B24V	B phase pulse input 24V
	15	15	B12V	B phase pulse input 12V
	14	14	B5V	B phase pulse input 5V
	13	13	BCOM	B phase pulse input COM
	12	12	P24V	Preset input 24V
	11	11	P12V	Preset input 12V
09 0 0	10	10	P5V	Preset input 5V
	09	09	PCOM	Preset input COM
	08	08	G24V	Auxiliary function input 24V
04 0 0	07	07	G12V	Auxiliary function input 12V
	06	06	G5V	Auxiliary function input 5V
	05	05	GCOM	Auxiliary function input COM
	04	04	OUT0	Comp. output 0
	03	03	OUT1	Comp. output 1
	02	02	24V	External power input 24V
	01	01	24G	External power input GND

٦

#### (2) XBF-HD02A

Din orrongement	В	Α		Signal name
Finanangement	CH1	CH0	Signarhame	
	20	20	A   +	A   phase differentiation input +
	19	19	A   -	A   phase differentiation input -
	18	18	A  +	A    phase differentiation input +
	17	17	A  -	A    phase differentiation input -
	16	16	B   +	B   phase differentiation input +
	15	15	B   -	B   phase differentiation input -
17 0 0	14	14	B  +	B    phase differentiation input +
	13	13	B  -	B    phase differentiation input -
	12	12	P24V	Preset input 24V
	11	11	P12V	Preset input 12V
	10	10	P5V	Preset input 5V
	09	09	PCOM	Preset input COM
	08	08	G24V	Auxiliary function input 24V
04 0	07	07	G12V	Auxiliary function input 12V
	06	06	G5V	Auxiliary function input 5V
	05	05	GCOM	Auxiliary function input COM
	04	04	OUT0	Comp. output 0
	03	03	OUT1	Comp. output 1
	02	02	24V	External power input 24V
	01	01	24G	External power input GND

#### 2. Internal circuit

Γ

Describes internal circuit of HSC module to connect HSC module with external device

#### (1) XBF-HO02A

1/0	Internal circuit	No Torminal		Pin	No.	Signal name
w0		NO.	Terrinia	CH0	CH1	Signai name
		1	A24V	B20	A20	A phase pulse input 24V
		2	A12V	B19	A19	A phase pulse input 12V
		3	A5V	B18	A18	A phase pulse input 5V
		4	ACOM	B17	A17	A phase pulse input COM
		1	B24V	B16	A16	B phase pulse input 24V
		2	B12V	B15	A15	B phase pulse input 12V
		3	B5V	B14	A14	B phase pulse input 5V
loout		4	BCOM	B13	A13	B phase pulse input COM
input		(5)	P24V	B12	A12	Preset input 24V
		6	P12V	B11	A11	Preset input 12V
		(7)	P5V	B10	A10	Preset input 5V
		8	PCOM	B09	A09	Preset input COM
		(5)	G24V	B08	A08	Auxiliary function input 24V
		6	G12V	B07	A07	Auxiliary function input 12V
		(7)	G5V	B06	A06	Auxiliary function input 5V
		8	GCOM	B05	A05	Auxiliary function input COM
Output		9	OUT0	B04	A04	Comp. output 0
		10	OUT1	B03	A03	Comp. output 1
		(1)	24V	B02	A02	External power input 24V
		(12)	24G	B01	A01	External power input GND

#### Notes

External power (24V: A02, B02, 24G: A01, B01) is power source to output comparison output to terminal (A03, B03, A04, B04). Connect when using comparison output.

(2) XBF-HD02A

1/0	Internal circuit	No	No Torminal		No.	Signal
10		INO.	Terminal	CH0	CH1	Oighai
	<u>()</u>	1	Al+	B20	A20	A   phase differentiation input +
		2	All+	B19	A19	A    phase differentiation input +
		3	Al-	B18	A18	A   phase differentiation input -
		4	All-	B17	A17	A    phase differentiation input -
		1	BI+	B16	A16	B   phase differentiation input +
		2	BII+	B15	A15	B    phase differentiation input +
		3	Bl-	B14	A14	B   phase differentiation input -
loout		4	BII-	B13	A13	B    phase differentiation input -
input		5	P24V	B12	A12	Preset input 24V
		6	P12V	B11	A11	Preset input 12V
		7	P5V	B10	A10	Preset input 5V
		8	PCOM	B09	A09	Preset input COM
		5	G24V	B08	A08	Auxiliary function input 24V
		6	G12V	B07	A07	Auxiliary function input 12V
		$\overline{O}$	G5V	B06	A06	Auxiliary function input 5V
		8	GCOM	B05	A05	Auxiliary function input COM
Output		9	OUT0	B04	A04	Comp. output 0
		10	OUT1	B03	A03	Comp. output 1
		(1)	24V	B02	A02	External power input 24V
		(12)	24G	B01	A01	External power input GND

٦

## Notes

(1) Al+, Al-, Bl+, Bl- are line driver input terminal of 5V level.

(2) All+, All-, Bll+, Bll- are line driver input terminal of 24V level.

#### (3) Example Input/Output wiring by using Smart Link Board

Г

(a) When using HSC module, easy wiring is available by connecting the I/O connector with Smart Link Board. The available Smart Link Board and I/O cable are as follows.

Model	Specification	No. of Pin
XBF-H002A	HSC Module(Open collector)	40 Pin Connector × 1
XBF-HD02A	HSC Module(Line Drive)	40 Pin Connector × 1

 (b) The company prepares smart link products for the convenience of using our Connector type HSC modules. For further information, please refer to the data sheet contained in a Smart Link product. (Refer to (d) Connection Diagram to confirm the differences between TG7-1H40CA and TG7-1H40S)

	Model	Cable	Length of Cable
Terminal		C40HH-05SB-XBI	0.5m
		C40HH-10SB-XBI	1m
	TG7-1H40S	C40HH-15SB-XBI	1.5m
		C40HH-20SB-XBI	2m
		C40HH-30SB-XBI	3m
Doard		C40HH-05SB-XBI	0.5m
		C40HH-10SB-XBI	1m
	IG7-1H40CA (20Pin Common Added)	C40HH-15SB-XBI	1.5m
		C40HH-20SB-XBI	2m
		C40HH-30SB-XBI	3m

(C) Smart Link Connection



(d) Smart Link Connection Diagram

- TG7-1H40S



#### - TG7-1H40CA

Γ



- (e) Smart Link Specifications and Dimensions
  - TG7-1H40S
    - i) Specifications

Rated Voltage	AC, DC 125V
Rated Current	1A
Withstanding Voltage	600V 1min
Insulation resistance	100MΩ (DC 500V)
Applicable Wire	1.25 <sup>mm<sup>2</sup></sup> /MAX
T/B Screw	M3 X 10L
Screw Torque	1.2N • m(12Kgf • cm)
Case	Modified PPO(Noryl)(UL 94V-0)

ii) Dimensions(mm)





#### - TG7-1H40CA

Γ

### i) Specifications

Rated Voltage		125V AC / 24V DC			
Rated Current	IO	1A			
	Common	10A (Total)			
Insulation resista	ance	100MΩ (DC 500V)			
Withstanding Vo	ltage	AC500V 1min			
Applicable Wire		AWG22-16 (MAX / 1.5mm)			
Contact Screw		M3 X 10L			
Screw Torque		1.2N • m(12Kgf • cm)			
Ambient Tempe	rature	-10°C ~+50°C (Non-condensing)			
Terminal Block &	& Cover	Modified PPO			
Protective Cover		Polycarbonate			
PCB		Epoxy 1.6t			

### ii) Dimensions(mm)



## 2.4 Function

#### 2.4.1 Input pulse type

1.1 phase input

#### (1) Up/Down operation by program setting

(a) 1 phase 1 input 1 multiplication input

When input pulse of A phase is rising, count operates and up/down count operation is set by program

#### 1)High Active Mode



pulse			<b>↓</b> ,		$\downarrow$ $\Box$		┥
Up/Down					l I On I		1
Count setting	i	Off			i i	Off	1
Count	10	11	12	13	12	11	12
					— Down—		-Up

#### (b) 1 phase 1 input 2 multiplication input

Г

When input pulse of A phase is rising and falling, count operates and up/down count operation is set by program



#### (2) Up/Down count operation by B phase input signal

(a) 1 phase 2 input 1 multiplication input

When input pulse of A phase is rising, count operates and up/down count operation is set by level of B phase input pulse.High Active Mode

Up/Down coun	t class	ification	A phase puls	e rising	A phase	pulse falling	]		
B phase inp	ut puls	e Off	Up count (+1)		-				
B phase inp	ut puls	e On	-		Down	count (-1)			
A phase input pulse							,		
B phase input		I I I Off				On I		Off	
Count	10	   11	12	   13		12	1	1	12
			Up	>	$\leftarrow$	—Down—	>	<	Up

#### 2) Low Active Mode

Up/Down count classification	A phase pulse rising	A phase pulse falling		
B phase input pulse Off	Down count (-1)	-		
B phase input pulse On	-	Up count (+1)		

A phase input pulse						,	<b>↓</b>		
B phase input		Off		   		On		Off	
pulse				1	l		1	1	
Count	10	9	8	7	i	8	9	i	8
			Down	>	<	——Up——	>	<de< td=""><td>own</td></de<>	own

#### (b) 1 phase 2 input 2 multiplication input

When input pulse of A phase is rising and falling, count operates and up/down count operation is set by level of B phase input pulse.

1)	High Active Mode
----	------------------

Г

<i>,</i> 3					
Up/Down count classifi	cation	A phase p	oulse rising	A phase pul	se falling
B phase input pulse	Off	Up count (+1)		Up count (+1)	
B phase input pulse	On	Down c	count (-1)	Down count (-1)	
A phase input		T	T I	T I	Т

pulse		,	V		7						,		,		7
B phase input			     	1     		1     		1     On 							
puise								 							
Count	10	i ! 11	12	13	14	15	16	15	14	13	12	11	10	   11	12
				-Up			$\times$			Down			$\times$		
				- 1-										- 1-	

#### 2) Low Active Mode

Up/Down count classification	A phase pulse rising	A phase pulse falling		
B phase input pulse Off	Down count (-1)	Down count (-1)		
B phase input pulse On	Up count (+1)	Up count (+1)		



#### 2. 2 phase input

(1) 2 phase 1 multiplication input

1) High Active Mode

When input pulse of A phase is ahead of B phase input pulse, at rising edge of A phase input pulse, Up count is operated. When input pulse of B phase is ahead of A phase input pulse, at falling edge of A phase input pulse, Down count is operated.



#### 2)Low Active Mode

When input pulse of A phase is ahead of B phase input pulse, at falling edge of A phase input pulse, Up count is operated. When input pulse of B phase is ahead of A phase input pulse, at rising edge of A phase input pulse, Down count is operated.



#### (2) 2 phase 2 multiplication input

Г

When input pulse of A phase is ahead of B phase input pulse, at rising and falling edge of A phase input pulse, Up count is operated.

When input pulse of B phase is ahead of A phase input pulse, at rising and falling edge of A phase input pulse, Down count is operated.

When 2 phase 2 multiplication input mode, Low Active and High Active mode operation is same.



#### (3) 2 phase 4 nultiplication input

When input pulse of A phase is ahead of B phase input pulse, at rising and falling edge of A and B phase input pulse, Up count is operated.

When input pulse of B phase is ahead of A phase input pulse, at rising and falling edge of A and B phase input pulse, Up count is operated.

When 2 phase 4 multiplication input mode, Low Active and High Active mode operation is same.

Up/Down count classification	A phase pulse rising	A phase pulse falling	A phase pulse rising	A phase pulse falling	
Phase of A and B (A-B)	Up count (+1)	Up count (+1)	Up count (+1)	Up count (+1)	
Phase of A and B (B-A)	Down count (-1)	Down count (-1)	Down count (-1)	Down count (-1)	



## 3. CWCCW(ClockWise/Counter ClockWise) input

Count is operated at rising edge of A phase inpulse or B phase input pulse and Up/Down count operation is determined by level of A or B input pulse

1) High Active N	Node									
Up/Down count classification		A phase pulse rising		A phase pulse falling		B phase pulse rising		B phase pulse falling		
B phase input pulse Off		Up count (+1)		-		-		-		
A phase input pulse Off		-		-		Down count (-1)			-	
A phase input pulse							1	1		
B phase input pulse	     									
Count	ו 10 ו	11	12		13	12	11	10		
Up>				Down-						
2) Low Active Mode										
Up/Down count classification A phase pulse rising		A phase pulse falling		B phase pulse rising		B phase pulse falling				
B phase input pulse On		-		Up count (+1)		-		-		
A phase input pulse On		-		-		-		Down count (-1)		



### 2.4.2 Count Mode

Г

- 1. Linear count
  - (1) Linear Count range: -2,147,483,648 ~ 2,147,483,647
  - (2) Up count

If count value reaches the maximum value while increased, Carry will occur, and Carry occurs, count stops and increasing is not available but decreasing is available.

(3) Down count

If count value reaches the minimum value while decreased, Borrow will occur and Borrow occurs, count stops and decreasing is not available but increasing is available



- 2. Ring count
  - (1) Count operation is executed within the user defined range repeatedly.
  - (2) Ring Count range: ring count min. value ~ ring count max. value
  - (3) Ring count display
    - If Ring Counted, minimum value of Ring Count is displayed as count, but the maximum value is not displayed as count.
  - (4) Ring count operation
    - (a) ring count min. value < Current count < ring count max. value
      - 1) Up count

If count value exceeds maximum value during increasing count, Carry only occurs and count is executed starting from min. value



#### 2) Down count

If count value reaches minimum value during decreasing count, Borrow only occurs and count is executed starting from max. value



(b)  $-2,147,483,648 \le \text{current count} < \text{ring count min. value or ring count max. value < current count $\le2,147,483,647$$ 

#### 1) Up count

If count reaches ring count max. value, it changes into ring count min value and carry occurs and count is executed until 2,147,483,647. If count exceeds 2,147,483,647, count is changed into -2,147,483,648 and executed repeatedly.


### 2) Down count

Г

If count reaches min. value, borrow occurs and count is changed into ring count max. value. Count is executed until 2,147,483,647. If count reaches -2,147,483,648, count is changed into 2,147,483,648 and executed again.



### Notes

When setting ring count max/min value, if current count is out of range of ring count, module assumes that that is mistake of user and LED flickers and error occurs. If the user executes preset operation and changes the current count to be within ring count range, LED is off and error disappears.

## 2.4.3 Preset

- (1) When Enable Preset is On, current count is changed into preset setting value. Only with setting of preset, current count is not changed and you have to execute the Enable Preset ot change the current count.
- (2) Operation method
- (a) Internal preset

Setting preset value  $\rightarrow$  Enable Preset On



#### (b) External preset

Setting preset value → External Preset selection command On→ External Preset Input signal On



# Notes

(1) To use preset function by external input signal, set Enable Preset as 1 (On), turn on external preset input signal.

(2) If you execute the preset by external input signal, external preset detection becomes 1 (On), When external preset detection is 1(On), external preset is not executed. In order to change external preset detection as 0 (Off), turn on external preset detection reset.

# 2.4.4 Compared output

Г

- (1) High Speed counter module has a compared output function used to compare present count value with compared value in size to output as compared.
- (2) Available compared outputs are 2 for 1 channel, which can be used separately.
- (3) Compared output conditions are 7 associated with <, <, =,  $\ge$ , >,  $\le$  <,  $\ge$   $\ge$
- (4) In order to make actual comparison enabled after compared output condition set, the compared enable signal is to be On, at this time, output is displayed only on program (U device or Global variable), and in order to send out the actual external output with LED turned On, the output enable signal is to be On.

### 1. Preset value < Compared value

If counted present value is less than compared value, output is sent out, and if present value increases to be equal to or greater than compared value, output is not sent out.

Count	123456	123457	123458	12345	9 123460	123461	123462
Compared value					123460	>	
Enable Comp.					   		
Enable Comp. output		'     			     		
Compared resu	ılt						
LED		'   					
Compared output		   				   	
Notes							
(1) Compared	result can	be chec	ked at U de	evice for XB	M,XBC, Global	l variable for	XEC
(2) Compared	output is a	a signal to	be output	at external	terminal (A03, A	A04, B03, B	04).

### 2. Count value ≤ Compared value

If present count value is less than or equal to compared value, output is sent out, and if count value increases to be greater than compared value, output is not sent out.

Count Compared value	123456	123457	123458	123459	123460 123460	123461 123462
Enable Comp.			1		<u> </u>   	<u> </u>
Enable Comp. output	   		 		   	
Compared resu	llt		   			   
LED	   					
Compared output						

### 3. Count value = Compared value

If present count value is equal to compared value, output is sent out, and even if count value increases to be greater or less than compared value, output is kept On. In order to turn the output Off, identical reset signal is to be On.

٦

Count Compared value	123456	123457	X	123458	X-K-	123459 123459	$\succ$	123460	$\times$	123461	$\times$	1234	462
Enable Comp.													
Enable Comp. output													
Compared resu	ilt				Ļ							   	
LED			i 1										
Compared			i										
Identical reset										   		1	

### 4. Count value ≥ Compared value

If present count value is greater than or equal to compared value, output is sent out, and if count value decreases to be less than compared value, output is not sent out.

Count Compared value	123456 123457	123458	123459	123460 123461	123462
Enable Comp.					
Enable Comp. output	     		     		
Compared resu	ılt i			   	
LED	   		   		
Compared output	   		   		

## 5. Count value > Compared value

Г

If present count value is greater than compared value, output is sent out, and if count value decreases to be less than or equal to compared value, output is not sent out.

Count 123456 123457 123458 123459 Compared value 123457 123458	123460 123461	123462
Enable Comp.		
Enable Comp. output		
Compared result		
LED		   
Compared		   

6. Compared value min.  $\leq$  Count value  $\leq$  Compared value max.

If present count value is greater than or equal to compared value 1 and less than or equal to compared value 2, output is sent out, and if count value increases/decreases to exceed compared value's range, output is not sent out.

Count	123456 123457 123458 123459 123460 123461	12	3462
Comp value mi Comp value ma	n. 123457 Ix. 123461		
Enable Comp			
Enable Comp output			   
Compared resu			
LED		i	   
Compared output		 	   

### 7. Count value $\leq$ Compared value min., Count value $\geq$ Compared value max.

If present count value is less than or equal to compared value 1 and greater than or equal to compared value 2, output is sent out, and if count value increases/decreases to exceed compared value's range, output is not sent out.

Count 123456 123457 123458	123459 123460 123461 123462
Comp value mi <del>n. 123458</del> Comp value ma <del>x.</del>	123460
Enable Comp	
Enable Comp output	
Compared resut	
LED	
Compared I	

8. When main unit plc stopped, output signal by compared value out status setting. When main unit plc stopped, you can select to keep an output or prohibit an output through compared output status setting

### Remark

- (1) The output is changed to Off regardless of compared value of compared output when basic unit is stopped if the present state can't output.
- (2) The output is changed to On→Off regardless of compared value of compared output when basic unit is stopped if the present state can't output.
- (3) The output is changed to compared flag On→Off at the active status mode of compared function compared value of compared output when basic unit is stopped if the present state can't output.

# 2.4.5 Carry Signal

- 1. Carry Signal occurs
  - (1) When count range maximum value of 2,147,483,647 is reached during Linear Count.
  - (2) When maximum value of Ring Count changed to the minimum value during Ring Count.
- 2. Count when Carry Signal occurs
  - (1) Count stops if Carry occurs during Linear Count.
  - (2) Count does not stop even if Carry occurs during Ring Count.
- 3. Carry reset

The Carry generated can be cancelled by Carry/Borrow reset signal On. As mentioned below, no cleared.

Count Mode	Decsription				
Linear Count	In case current count value 2,147,483,647				
Ring Count	Current count change to minimum value of ring count by occuring carry. it makes				
	present value keep.				

# 2.4.6 Borrow Signal

- 1. Borrow signal occurs
  - (1) When count range minimum value of -2,147,483,648 is reached during Linear Count.
  - (2) When minimum value of Ring Count changed to the maximum value during Ring Count user-defined Ring Count minimum value maximum value.
- 2. Count when Borrow signal occurs
  - (1) Count stops if Borrow occurs during Linear Count.
  - (2) Count does not stop even if Borrow occurs during Ring Count..
- 3. Borrow reset

The Borrow generated can be cancelled by Carry/Borrow reset signal On. As mentioned below, no cleared.

Count Mode	Decsription
Linear Count	In case current count value -2,147,483,648
Ding Count	Current count change to maximum -1 of value of ring count by occuring borrow. it makes
King Count	present value keep.

# 2.4.7 Auxiliary mode

High Speed counter module provides 6 auxiliary modes as well as basic count function and compared output function. In order to use the auxiliary modes, auxiliary mode enable signal is to be "On".

### Notes

(1) To use auxiliary function by program, turn off the external auxiliary mode and turn on Enable Auxiliary

(2) To use auxiliary function by an external signal, turn on the external auxiliary mode and turn on External auxiliary input signal (GATE).

### 1. Count clear

(1) When Auxiliary Mode enable signal is On, present count value is set to 0.

(2) Setting method

Set auxiliary mode setting mode to  $1 \rightarrow$  Auxiliary mode enable signal On.



# 2. Count Latch

Γ

(1) When auxiliary mode enable signal is On, present count value is latched

(2) Setting method

Set auxiliary mode setting mode to  $2 \rightarrow$  Auxiliary mode enable signal On



# 3. Sampling Count

(1) When auxiliary mode enable signal is On, it counts for a specified time.

(2) Setting method

Set auxiliary mode setting mode to  $3 \rightarrow$  Time setting  $\rightarrow$  Auxiliary mode enable signal On

(3) Display during auxiliary mode operation

Sampling Count function operates for a specified time when auxiliary mode enable signal is On, and the auxiliary mode in progress signal is On at the same time.



### 4. Input Frequency Measure

(1) While auxiliary mode enable signal is On, it indicates frequency of input pulse. Unit of input frequency conforms to setting of frequency unit.

(2) Setting method

Г

Set auxiliary mode setting mode to  $4 \rightarrow$  Set frequency unit  $\rightarrow$  Auxiliary mode enable signal On.

(3) Frequency input mode can be specified as below, whose update cycle and resolution will be decided based on the applicable mode.

Frequency unit setting	Unit [Hz]	Updated cycle [ms]
0	1	1000
1	10	100
2	100	10
3	1000	1

### (4) Display during auxiliary mode operation

While auxiliary mode enable signal is On, Now Running signal is on



X On the figure, unit is 1Hz and updated cycle is 1000msec.

### 5. Revolution/Unit time

- (1) While auxiliary mode enable signal is On, it calculates the number of input pulses for a specified time and indicates the revolution/unit time. To use this function, setting time and No. of pulse/revolution should be set.
- (2) Setting method
- Set auxiliary mode setting mode to 5 setting  $\rightarrow$  Time setting, No. of pulse/revolution  $\rightarrow$  Auxiliary mode enable signal On.
- (3) With the number of pulses per revolution input and time set to 1 minute (60000ms), the value of RPM is displayed.
- (4) Display during auxiliary mode operation

While auxiliary mode enable signal is On, Now Running signal is on



 $\times$  On the figure, the number of pulse/revolution is set to be 10.

# 6. Count Disable

Г

- (1) While auxiliary mode enable signal is On, count operation stops.
- (2) Setting method
  - Set auxiliary mode setting mode to  $6 \rightarrow$  Auxiliary mode enable signal On
- (3) Display during auxiliary mode operation

While auxiliary mode enable signal is On, Now Running signal is on



# **Chapter 3 Installation and Wiring**

# 3.1 Installation

### 3.1.1 Installation environment

This product is of high reliance regardless of installation environment. However, for the sake of reliance and stability of the system, please pay attention to those precautions described below.

- (1) Environmental conditions
  - (a) To be installed on the control panel waterproof and dustproof.
  - (b) No continuous shocks or vibration will be expected.
  - (c) Not to be exposed to the direct sunlight.
  - (d) No dew should be caused by rapid temperature change.
  - (e) Ambient temperature should be kept 0 55°C.

### (2) Installation work

- (a) No wiring waste is allowed inside PLC when wiring or drilling screw holes.
- (b) To be installed on a good location to work on.
- (c) Don't let it installed on the same panel as a high-voltage device is on.
- (d) Duct or surrounded module should be farther than 50cm from the HSC.
- (e) Make sure that the PE terminal is grounded.

## 3.1.2 Handling precautions

Precautions for handling High Speed counter module are as described below from the opening to the installation.

- (1) Don't let it dropped or shocked hard.
- (2)Don't remove PCB from the case. It will cause abnormal operation
- (3) Don't let any foreign materials including wiring waste inside the top of the module when wiring. Remove foreign materials if any inside.
- (4) Don't install or remove the module while powered On.

# **3.2 Wiring Precautions**

Γ

# 3.2.1 Wiring Precautions

- (1) Pay attention to do action about external noise during wiring for the pulse input of the high counter module.
- (2) Surely use twisted pair shielded cable, grounded with 3 class applied.
- (3) Keep away from power cable or  $\ensuremath{\text{I/O}}$  line which may cause noise.
- (4) Connect A-phase only for 1-phase input.
- (5) Please take the wiring with consideration the maximum output distance of pulse generator.

## 3.2.2 Example of DC5V voltage output wiring

- If the pulse generator is voltage output type, example of wiring with HSC is as shown below;
- The wiring will be the same if the pulse generator (Encoder or Manual pulse generator) of voltage output type is used through Totem Pole output.



# 3.2.3 Example of DC12V NPN Open Collector output wiring

Г

This is the wiring example which it used the pulse generator (Encoder or Manual pulse generator) of NPN Open Collector output type.



Remark

In case external line noise environment, Between pulse generator(encoder or manual pulse generator) and HSC wiring need to attach a resistance by noise to protect malfunction as below the wiring example. (External Pull Up Resistance use to adjust specification of external device.)



# 3.2.4 Example of DC24V PNP Open Collector output wiring

Г

This is the wiring example which it used the pulse generator (Encoder or Manual pulse generator) of PNP Open Collector output type.



### 3.2.5 Example of Line Driver output wiring

This is the wiring example which it used the pulse generator (Encoder or Manual pulse generator) of RS-422A Line Driver (5V level) output type.



### Remark

In case of 24V Level Line Driver, please connect to AII+, AII-, BII+, BII- terminal. Be careful wiring and you must consider maximum output distance of pulse generator.

# **Chapter 4 Operation Procedures and Monitoring**

Operation setting and monitor functions of XG5000 program will be described in this chapter among operation methods of High-speed counter module.

# 4.1 XG5000 Excution

- 4.1.1 Execution and Connection of XG5000
  - After XG5000 installed, click XG5000 execution icon to display the initial screen of XG5000 program as shown below.



2) On the [Project] menu, click [New Project] or  $\Box$  on the icon menu to display the screen as shown below. XGB CPU setting.



### 3) Project screen is as below.

#### Project screen of XBM series



#### Project screen of XBC series



### Project screen of XEC series

👒 XBF-HD02A - XG5000		
Project Edit Eind/Replace View Online Monitor	or Debug Iools Window Help	
D 🚅 (b. 🔒 🎒 (b)   4: 4: 15 🛤 🌉	■ ② □ ⊆ 以 軸 職 X   弓 X 2 2 2 1 1 1 1 1 1 2 2 3 3 3 2 3 1 1 2 3 1 3 1	
[ ◯ =   D = ⊗   B = 7   Ø = Ø	북 붉 꽃 붉 🎦 🖉 🖬 🖬 등 🕒 대 다 다 다 다 대 🔍 쓰 🖬 💵 💵 🖩 💷 🔜 🖉	7 臀臀
ESC 1 - 1 - 1/2 - 122 - 13	T \$3 \$4 \$4 \$4 \$7 \$7 \$7 \$7 \$7 \$7 \$7 \$8 \$1 \$1 \$1 \$1 \$1 \$2 \$2 \$3 \$1 \$1 \$1 \$1 \$1 \$2 \$2 \$2 \$2 \$2 \$2 \$2 \$2 \$2 \$2 \$2 \$2 \$2	90
Project Window v 🗙		1
Items	🖀 NewProgram[Program]	
□ 蹬 XBF-HD02A* □- 鋼 NewPLC(XGB-XECS)-Offline		
Global/Direct Variables		
Gillion Parameter		
······································		
Scan Program	13	
User Function/Function Block	14	
🧕 User Data Type		
C Project	NewProgram[Program]	
PLC Program Variable/Devic	rice Value Type Devi	
8		
uiw 6		
-i-u-	wopsa	
See 3	de xi	
Monitor 1 Monitor 2 Monitor	tor 3 λ Monitor 4 /	Used Devi
	NewPLC Offline Row 0, Column 0 Ove	erwrite

4) If a project is created, click [Online]-[Connection Settings] or on the icon menu to specify the connection method and connection stage, and then click [Settings] to specify the communication port and the communication speed(115,200).

Online Settings - NewPLC ? 🔀	Details ? 🗙
Connection settings     Iype:   FIS-232C   ✓   Settings     Depth:   Local   ✓   Preview     General   Timeout interval:   5 🔹 sec.	RS-232C Port number: COM1 Baud rate: 115200(XGT)
Hetrial times:   1     Read / Write data size in PLC run mode     Normal   Maximum     * Send maximum data size in stop mode     Connect   OK	Auto Detect Scan IP OK Cancel

5) After all settings complete, click [Online]-[Connect] or 🕒 on the icon menu. Click [Communication] tab on [Message Window] to check the connection.

×	2008-07-14 14:45:19	NewPLC : Connect to PLC
1	2008-07-14 14:45:20	NewPLC : Connected with the PLC
Message Window	Result À	Check Program $\lambda$ Find 1 $\lambda$ Find 2 $\lambda$ Communication $\langle$ Cross Reference $\lambda$ Used Device $\lambda$ Duplicate Coil

# 4.2 Parameters Setting

Г

This description is based on XG5000 Project of XBC series, because it is the same to parameter setting method of XBM/XBC/XEC series.

## 4.1.2 Parameters setting

- 1) Double-click [I/O parameters] on the [Project Window] to the left of the project created on XG5000.
- 2) If [I/O parameters setting] window is displayed, click the module area of the applicable slot to select the applicable module



3) Double-click the applicable slot selected to specify the parameters, or click [Details] to display the screen where parameters can be set.



4) Set parameters as necessary for operation on the parameters setting window.

Parameter	CHO	CH1
Counter mode	Ring	Linear
Pulse Input Mode	2-Phs x1	2-Phs x1
Preset	1000	0
Ring Counter Min.	0	0
Ring Counter Max.	100000	0
Comp Output 0 Mode	(Magnitude)<	(Magnitude)<
Comp Output 1 Mode	(Magnitude)<	(Magnitude)<
Comp Output 0 Min.	0	0
Comp Output 0 Max.	0	0
Comp Output 1 Min.	0	0
Comp Output 1 Max.	0	0
Cutput Status Setting	Output Enable	Output Enable
Auxiliary Mode	Count Clear	Revolution/Unit time
Range Value [ms]	0	1000
Pulse/Rev Value	1	200
Frequency Mode	1 Hz	1 Hz
Pulse Level	Low Active	High Active
	LUWACINE	ngnAcove

\* You must make the scan program to change parametter of the high speed counter module during CPU RUN mode.

# 4.3 Monitoring and Test

Г

This description is based on XG5000 Project of XBC series, because it is the same to parameter setting method of XBM/XBC/XEC series.

# 4.3.1 Monitoring and Test

1) After connected to PLC CPU through XG5000, click [Online]-[Special Module Monitoring] or an the icon menu to display the screen as shown below.

👒 XBF-HO02A - XG5000 - [NewProgra	im]					
Project Edit Find/Replace View Online	Monitor Debug Tools Window He	þ				- 8 ×
0 2 2 3 9 4 8 8	Start Monitoring	®× ∝⊁∴%	<b>M M 137 177</b> A →111   ≪	<b>B</b>		
🗵 🖀   🕑 💽 🗶 🗳 👘 🧭 🛗	Resume	) 🗷 🕼 🖿 🖉 🖴 🛛 (1)	ចាក ចោក 🖬 🖬 🥵	9 <b>4 5 8 8 8</b>	K B B B B	片臀臀
Esc 1 + 1/+ 1/+ 1/+ 1N+ → 1 → ★ 1/+ Esc 1 + 1/+ 1/+ 1/+ 1/+ 1/+ 1/+ 1/+ 1/+ 1/+	Pausing Conditions	64 C5 C6 🗈 🛅 🖉	🐼 F 📰 🚺 D	🚺 🔝 🕅 🍭 🤤 100 <sup>5</sup>	K 🔽 🦻 🕅 🖌	
Project Window	Change Current value					~
	System Monitoring					
KBF-HOUZA NewPLC(XGB-XBCS)-Stop/Warning	Device Monitoring					
Variable/Comment	Trend Monitoring					
Parameter	IDA PID Monitoring					
I/O Parameter	SOE Monitoring					
😟 🧖 Embedded Parameter	Custom Events					
Scan Program	Data Trages					
Croject	< fiii] NewProgram					
PLC Type C T PlC Type C Monitor 1 / Monitor 2 / M	Device/Variable Value		sult (Check Program ) Find	1 X Find 2 X Communicati	on 入 Cross Reference	λUsed Devi

2) On the module list dialog box, the special modules presently installed on PLC system will be displayed.

Special Modul	le Lis	st	×
Base		Slot	Module
🗊 Base O	Ð	Internal	High Speed Counter Module(Open-Collector, 8-CH)
🗂 Base O	Ð	Internal	Position Module (Open-Collector, 2-CH)
🗂 Base O	ß	Slot 2	XBF-HD02A (Line-Driver, 2-CH)
<			
Module Info.		Monitor	Close

- Select the applicable module and click the monitoring button to display the monitoring/ test screen as shown below, whose functions are as follows;
  - On the upper monitoring screen, each special module's monitoring item values are displayed.
  - On the bottom test screen, each module's parameter items can be changed individually. If you click TEST button, setting values is applied to current value.

XBF-HD02A (Line-Drive	er, 2-CH)	? 🔀
XBF-HD02A (Line-Driver, 2-0	CH)	
Item	СНО	СН1
Current count	0	
Lateb count	0	0
Panga count	0	0
	0 (* 1)	0 (* 1)
Revelution Des Unit	0(1)	0(1)
Revolution Per Unit	U	
Item		FLAG Monitor
-		
Parameter	Setting value	Current value
	ایا اند - مد	HU
Counter mode	Linear	Linear
Pulse Input Mode	LW/LLW	LW/LLW
Preset	U	0
Ring Counter Min.	U	0
Ring Lounter Max.	U Odaanihuda) (	0
Comp Uutput U Mode	(Magnitude)k	(Magnitude)<
Comp Output 1 Mode	(Maynicule)<	(Magnitude)<
Comp Output 0 Min.	0	
Comp Output 0 Max.	0	0
Comp Output 1 Min.	0	0
Comp Output 1 Max.	U Output Disable	U Dutput Disable
Auviliaru Modo	Count Disable	Count Disable
Range Value [me]	0	n n
Pulse/Bey Value	1	1
Erequency Mode	1 Hz	, 1 Hz
Pulse Level	High Active	High Active
1		
	Stop M	1onitoring Test
		Close

### Remark

(1) It is applied to only test operation to the parameter which changed by Test button. If test operation is concluded, the high speed counter module is operated by the parameter which was set by I/O parameter or by the scan program.
(2) If PLC CPU module is STOP mode, it is available to test operation and monitoring function. But in case of RUN mode, it is available only to monitoring function.

4) In order to monitor the I/O contact status, click the applicable channel's flag monitoring button to display the monitoring screen where each I/O contact status can be checked.

Γ

XBF-HD02A (Line-Driver, 2-CH)							
XBF-HD02A (Line-Driver, 2-CH)							
Item	CH0	CH1					
Counter status	Increment	Increment					
External Preset Command Flag	OFF	OFF					
CARRY	OFF	OFF					
BORROW	OFF	OFF					
Auxiliary function flag	OFF	OFF					
Comparator Output 0 Output	OFF	OFF					
Comparator Output 1 Output	OFF	OFF					
Command	СНО	CH1					
Counter enable							
Counter preset							
Dec. counter							
Aux. function	OFF	OFF					
Comp. function	OFF	OFF					
Comp. ouput's ext. output	OFF	OFF					
Comp. ouput 0 EQUAL reset	OFF	OFF					
Comp. ouput 1 EQUAL reset	OFF	OFF					
CARRY/BORROW reset	OFF	OFF					
External Preset Input Selection	OFF	OFF					
Aux-Func Ext. Input Selection	OFF	OFF					
Ext. Preset Detect Flag Reset	OFF	OFF					
1		Close					

# 4.4 Registration of U Devices

It is described to the method to register automatically U devices in XG5000 Project of XBC series.

## 4.4.1 Variable/Comment screen

If you double click [Variables/Comment] of [Project Window], variables and comments which was registered already are displayed.

🐐 XBF-H002A - XG5000 - [Variable/Comment]				
Project Edit Eind/Replace View Online Monitor Debug Tools Window Help				- 8 ×
D 🚅 🕼 🖶 👙 🖄 🔒 🍇 🧱 🖿 🛞 🦻 🗠 💈 🖕 🛍 🕅	l 🗙 🗟 🛠 🖧 🛠 🖌 🗛 🖗	° 🕷 🖓 斗 🖞 🕙 😁		
	uuuuu 🔤 🖴 🔯 🗗 õ õ õ	ጉ 🗤 🚛 🖓 📑		<b>荐</b> 蒋 翰
25 号 得 網 網 路 路 術 谷 義 義 古 西 郷 構 祥 岩 過	' 12' 1X' 🗈 📾 🖬 🖬		। 😼 🔍 🔍 100% 🔽 श्रिम 🖹	
Project Window				
tems	Jevice View Flag	Uned	Common!	I
■ ● ● KRH-HOUZA*   Variable     ■ ● ● WerkE(X)(SB-XBCS)-Stop/Warning   1     ■ ● ● Parameter   ● ● ● Parameter     ■ ● ● Parameter   ● ● ● Parameter     ● ● ● Parameter   ● ● ● Parameter     ● ● ● ● Parameter   ● ● ● ● Parameter     ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ● ●	iype Device	F	Comment	
				>
Project NewProgram	Variable/Comment			
PLC Type Device/Variable Value	×			
sopular Caratal And Carata A		ck Program ↓ Find 1 ↓ Fin	d 2 λ Communication λ Cross Referenc	e ) Used Devi
		Chan I I I	29. Wassing View Variable	0

# 4.4.2 Registration of U Devices

Г

- 5) Select [Edit]  $\rightarrow$  [Register U Device].
- (First, [Variable/Comment] window has to be executed.)

👒 XBI	F-HC	002A	- XG5000 - [Variabl	le/Comme	nt]									
🔛 Pro	oject	Edit	Find/Replace View On	iline <u>M</u> onito	or <u>D</u> ebug	<u>T</u> ools <u>W</u> indow <u>H</u> e	lp							_ 8 ×
I D o	26	2	Undo	(	Ctrl+Z	50× B	e × I	• <b>X</b> .3. 1	e I 🗛	44 82	8+0 S 10			
	a. I.	C	<u>R</u> edo	(	Ctrl+Y		and mut the		1.00.00					
1,00, 5	÷	*	Cu <u>t</u>	c	Ctrl+X	₩ ☞ 🗊 🖬 🕯			11111	• [] []	• •LJ   \$LJ 8	191 <b>555</b> 00	12 F3 F4 F5	F6 F7 F8 F9
Esc 1	计	2 B	<u>C</u> opy	C	Ctrl+C	\$P6 FT8 5F7 'c3'			🖾 🖸	ð F	iii 🗹		100% 🔽 🎗 🕅	
Project	Wind	8	Paste	(	Ctrl+V				1					
Items		$ \times $	Delete		Del		w Device	View Flag	<u> </u>					
= 픃	XBF		Select All	C	Ctrl+A	Variable	•	Туре	De	vice	Used		Comment	
		-6	Insert Line		Ctrl+L			<b></b> ]						
	•	1	Delete Li <u>n</u> e	(	Ctrl+D									
			Export Variables to File											
			Import Variables from File	·										
	÷		Register U Device		2									
			Add EXTERNAL Variable		v									
			Move Item Up											
			Move Item Down											
			Delete <u>A</u> ll unused variable	es/comment	s									
			Reallocate All Auto-alloca	tion <u>V</u> ariable	25									
					<				Ш					>
<b>■</b> ¢ P	rojec	t			100 A	NewProgram	<u>له</u> ۱	Variable/Comme	nt					
×	T	P	C Type	Device/	Variable	Value		×						
1			1,00	501007	( diable	Value		4						
8														
Winc														
<u>p</u>								8						
lonito								puş.						
ple 7							>	age						
Varia	€)		Monitor 1 Monitor 2	A Monitor ∶	3 ∖ Monit	or 4 /			Resul	t / Chec	k Program ∖	Find 1 $\lambda$ Find 2 $\lambda$ Commur	nication ∖ Cross Refer	ence 入Used Devi
Automat	ically	regis	ers comments in the U De	vices accord	ling to the	special module set in	the I/O para	ameter. No	ewPLC		Stop	L, USB, Warning	View Variable	Overwrite 🛒

6) Click [Yes] to complete the U device registration that is set at [I/O parameter setting]

XG5000	
2	Automatically register comments in the U Devices according to the special module set in the I/O parameter. The previous comments will be deleted. Continue?
	Yes No

🗞 XBF-H002A - XG5000 - [Variable/Comn	nent]						
Project Edit Eind/Replace View Online Mon	nitor <u>D</u> ebu	ig <u>T</u> ools <u>W</u> indow <u>H</u> elp					- 8 ×
D 🚅 🕼 🔲 🎒 🖄 🔜 📟	<u>o</u> 🤉	% ≞® ×	•e 🖹 🗄 🦮	🛛 🚳 🚳 🐝	a+0 2 _10 #4 A _11		
I 🗰 🎛 💽 💽 🖉 🖷 🖉				ឲាកព	1 +C] §C]	· • • · · · · · · · · · · · · · · · · ·	詩 髂 髀
■ みおおおお まん 魂 あおお	\$ \$ \$	8 8 6 5 V V V V		3 🛛 🖓 F	<b>F (1)</b>	D D D D U 😥 🗨 🗨 100% 🗸 🎗 🖓	
Project Window							
Items	VV	fiew Variable D View Device	View Flag	]			
E - ∰ XBF-HO02A *		Variable	Туре	Device	Used	Comment	<u>^</u>
NewPLC(XGB-XBCS)-Stop/Warning	1	_02_CH0_DN	BIT	U02.00.0	Г	HSC Module: CH0 Count Inc/Dec Flag	
Variable/Comment	2	_02_CH0_EXTPRE	BIT	U02.00.1	Г	HSC Module: CH0 External Preset Command Flag	
	3	_02_CH0_CRY	BIT	U02.00.3	Г	HSC Module: CH0 Carry	
B Basic Parameter	4	_02_CH0_BRW	BIT	U02.00.4	Г	HSC Module: CH0 Borrow	
Embedded Parameter	5	_02_CH0_AUXING	BIT	U02.00.5	Г	HSC Module: CH0 Auxliary Function Flag	
⊡ Enbedded rarameter	6	_02_CH0_CMPOUT0	BIT	U02.00.6	Г	HSC Module: CH0 Comparator Output0 Output	
New Program	7	_02_CH0_CMPOUT1	BIT	U02.00.7	Г	HSC Module: CH0 Comparator Output1 Output	
	8	_02_CH0_ERR	BIT	U02.00.E	Г	HSC Module: CH0 Error Flag	
	9	_02_RDY	BIT	U02.00.F	Г	HSC Module: Module Ready	
	10	_02_CH1_DN	BIT	U02.01.0	Г	HSC Module: CH1 Count Inc/Dec Flag	
	11	_02_CH1_EXTPRE	BIT	U02.01.1	Г	HSC Module: CH1 External Preset Command Flag	
	12	_02_CH1_CRY	BIT	U02.01.3	Г	HSC Module: CH1 Carry	
	13	_02_CH1_BRW	BIT	U02.01.4	Г	HSC Module: CH1 Borrow	
	14	_02_CH1_AUXING	BIT	U02.01.5	Г	HSC Module: CH1 Auxliary Function Flag	
	15	_02_CH1_CMPOUT0	BIT	U02.01.6	Г	HSC Module: CH1 Comparator Output0 Output	
	16	_02_CH1_CMPOUT1	BIT	U02.01.7	Г	HSC Module: CH1 Comparator Output1 Output	
	17	_02_CH1_ERR	BIT	U02.01.E	Г	HSC Module: CH1 Error Flag	
	18	_02_CH0_CNTEN	BIT	U02.23.0	Г	HSC Module: CH0 Counter Enable(Level) Command	
	19	_02_CH0_PREEN	BIT	U02.23.1	Г	HSC Module: CH0 Preset Enable(Edge) Command	
	20	_02_CH0_DWNCNT	BIT	U02.23.2	Г	HSC Module: CH0 Inc/Dec Count Setting(Level) Comr	mand
	21	_02_CH0_AUXEN	BIT	U02.23.3	Г	HSC Module: CH0 Auxiliary Function Enable(Edge,Le	vel) Com
	22	_02_CH0_CMPEN	BIT	U02.23.4	Г	HSC Module: CH0 Count Comparison Function Enabl	e(Level)
	23	_02_CH0_OUTEN	BIT	U02.23.5	Г	HSC Module: CH0 Comparator Output Enable(Level)	Commar
	24	_02_CH0_EQ0RST	BIT	U02.23.6	Γ	HSC Module: CH0 Comp-Output 0 EQUAL Reset(Edg	e) Comr 🗸
	<						>
■tå Project		NewProgram	Mariahla (Campan				
	9.0		vanable/Commer	L .			
× PLC Type Devic	e/Variable	Value	×				
1			* *				
line in the second s			lind				
Ξ			ge V				
Hanitar 1 (Manitar 2) Hanita	2 1 10-	pitor 4			k Drogram	Find 1 ) Find 2 ) Communication ) Cross Deferences	Llood Davi
	n a Vinior	110147	Eline	J/ Result A Chec	k Frogram /	Lend T Vend 2 V communication V cross Reference	V Osed Devi
			Nev	WPLC	Stop	L, USB, Warning View Variable	Overwrite

٦

# 4.5 Registration of Special module variable

It is described to the method to register automatically variables[Global variables/Constants] of high speed counter module in XG5000 Project of XEC series.

## 4.5.1 Global/Direct Variables screen

If you double click [Global/direct Variables] of [Project Window], variables and comments which was registered already are displayed.



### 4.5.2 Registration of the special module variables

- 7) Select [Edit]→ [Register Special Module variables].
- (First, [Global/Direct Variables] window has to be executed.)

👒 XBF-	HDO	2A - XG5000											
Project	Edit	Eind/Replace View Online Monitor	Debug Tools	Window Help									
İn 🖻	$\Box$	Undo	Ctrl+Z	C X 🗈	® ×		× Las as	310 310 ST	10				
	$\underline{\mathbb{C}}$	<u>R</u> edo	Ctrl+Y				Lana	a ana su			-	~	ent 1 - 1500 1500
1.11.39	Ж	Cut	Ctrl+X		an was r	r L C S	Ing m. c		n 📾 🖓 🖬 🖷		ш : <del>с</del> і	~ F3 F4 F5	F6 F7 F8 F9
E& 13		Copy	Ctrl+C	都 异 湯	12 12	N 🖹 📾	🖾 🖾	F 📰 🖽		1 16 🔍	⊇ 100%	🖌 શ્રિષ્ઠ 🖌	🖬 🖻 🍳 (
Project W	C.	Paste	Ctrl+V										
Items	X	Delete	Del	gram[Progr	am]								
	4	Select All	Ctrl+A	al/Direct Va	ariables								
l=8	-8	Insert Line	Ctrl+L	abal Variable		Wariable Comment	Elan	1					
	×	Delete Li <u>n</u> e	Ctrl+D			Vesiele la	Time	Address	Initial Value	Dataia	Used	CID.	
		Export Variables to File		Variable K	ind 🗸	variable	туре	Address	Initial value	Retain	Used		
		Import Variables from File											
		Register Special/Communication Module	Variables										
		Add EXTERNAL Variable		5									
		Move Item Up											
		Move Item Down											
		Delete All unused variables/comments.											
		Reallocate All Auto-allocation Variables											
			L) () ()			111						٤	
Pro Pro	ject		NewPro	gram[Program]	1	Global/Direct Vari	ables						
iable Moritori 🔸 🗙	F	PLC Program Variable/Device	Value	Туре	Devi	sage Windov 🔺 🗙							
		Monitor 1 / Monitor 2 / Monito	3 X Monitor 4	/			N]∖ Result /	Check Progra	m à Find 1 à Fin	d 2 ∖ Com	munication	n À Cross Refere	nce ∖Used Devi
Automatic	ally re	gisters comments in the U Devices accor	ding to the speci	al module set ir	the I/O p	arameter. N	ewPLC		Offline			Global Variable	Overwrite

٦

8) Click [Yes] to complete the special module variables registration that is set at [I/O parameter setting]

XG5000	
2	Automatically register comments in the U or L Devices according to the special/communication module set in the I/O parameter. The previous comments will be deleted. Continue?
	Yes No

E CA M CO O A CO A CO A CO A CO A CO A CO			61 102 102 IL G		17 0 00 00 00	n Asi 🛶 🖬 (Asi te na luca sen env			-	
	1		server in a				) (5) (5)		1002	- 15 14 15 16 17 18
F3 F4 sF1 sF2 F5 F6 sF5 sF9 F9 F11	1973 1974 19	FS 6F8 F10 6F7 C	of c5 of 10		1000 101 1886	time the two the	0.1961-1561	a a	100%	College de l'imperite
ect window 🗸 🛪	VG	lobal Variable	Direct Variable Commer	t Flag	1					
NS XRE-HD024 *		Variable Kind	Variable	Type	Address	Initial Value	Betain	Used	EIP	Com
CO NewPLC/XGB-XECS) Offine	64	VAR GLOBAL C	F0001 CH0 PL	LENT		01	[]]	-	1	HSC Module: CH0 pulse in
Global/Direct Variables	65	VAR GLOBAL C	F0001 CH0 PF	UINT		02	E	E .	E	HSC Module: CH0 preset vi
😑 🔂 Parameter	66	VAR GLOBAL C	F0001 CH0 RE	UINT		20	Ē		n	HSC Module: CH0 pulse pe
- 39 Basic Parameter	67	VAR GLOBAL C	F0001 CH0 RI	UINT		06	m	n i	H	HSC Module: CH0 ring cou
-10 I/O Parameter	68	VAR GLOBAL C	F0001 CH0 RI	UINT		04	Ē			HSC Module: CH0 ring cou
La La Empedded Parameter	69	VAR GLOBAL C	F0001 CH1 AL	UINT		43				HSC Module: CH1 auxiliary
(a) Scan Program	70	VAR GLOBAL C	F0001 CH1 CM	UINT		25				HSC Module: CH1 Counter
- B User Function/Function Block	71	VAR GLOBAL C	F0001 CH1 CF	UINT		37	E			HSC Module: CH1 company
User Data Type	72	VAR GLOBAL C	F0001 CH1 CF	UINT		35	E	E	E	HSC Module: CH1 company
	73	VAR GLOBAL C	F0001 CH1 CF	UINT		33	n		E	HSC Module: CH1 company
	74	VAR_GLOBAL_C	_F0001_CH1_CF	UINT		41				HSC Module: CH1 company
	75	VAR GLOBAL C	_F0001_CH1_CF	UINT		39				HSC Module: CH1 company
	76	VAR GLOBAL C	F0001 CH1 CF	UINT		34				HSC Module: CH1 company
	77	VAR_GLOBAL_C	_F0001_CH1_FF	UINT		46				HSC Module: CH1 frequent
	78	VAR_GLOBAL_C	_F0001_CH1_PE	UINT		44				HSC Module: CH1 period c
	79	VAR GLOBAL C	_F0001_CH1_PL	UINT		48				HSC Module: CH1 Definitio
	80	VAR GLOBAL C	F0001_CH1_PL	UINT		47			E	HSC Module: CH1 Input lev
	81	VAR GLOBAL C	_F0001_CH1_PL	UINT		26				HSC Module: CH1 pulse in
	82	VAR_GLOBAL_C	_F0001_CH1_PF	UINT		27		•		tHSC Module: CH1 preset v
	83	VAR_GLOBAL_C	_F0001_CH1_RE	UINT		45				HSC Module: CH1 pulse pe
	84	VAR_GLOBAL_C	_F0001_CH1_RI	UINT		31				HSC Module: CH1 ring cou
	85	VAR_GLOBAL_C	_F0001_CH1_RI	UINT		29				HSC Module: CH1 ring cou
	86	VAR_GLOBAL_C	_F0001_ERR_C	UINT		51				HSC Module: Error codes(c
	87	~								
	<		•							
Prosect	-		lik and							
		ewerogram(erogram)	Sill Global/Din	ect Vanables						
PLC Program Variable/Devi	e Vak	ue Type	Devi N							

# **Chapter 5 Internal Memory & I/O Signals**

# **5.1 Internal Memory**

High Speed Counter has the internal memory used for data "Write/Read" to/from PLC CPU. The commands used for "Write" from PLC CPU to High Speed Counter's internal memory are PUT and PUTP, and the commands used for "Read" are GET and GETP. Configuration of the internal memory and the data is as described below.

# 5.1.1 Configuration of the internal memory

Internal memory address			Data setting	
Channel 0	Channel 1	Details	range	
0	25	Select counter mode	0~1	
1	26	Select pulse input mode	0~7	
2	27	Set propertyclus	-2147483648~ 2147483648	
3	28	Set preset value		
4	29	Minimum value of Ping count	-2147483648~	
5	30		2147483648	
6	31	Maximum value of Ping count	-2147483648~	
7	32		2147483648	
8	33	Select OUT 0 type	0~6	
9	34	Select OUT 1 type	0~6	
10	35	OUT0 compared based value (single-compared)/	-2147483648~	
11	36	minimum setting value (section compared)	2147483648	
12	37	OUT0 compared based value maximum setting value	-2147483648~	
13	38	(section- compared)	2147483648	
14	39	OUT1 compared based value (single-compared)/	-2147483648~	
15	40	minimum setting value (section-compared)	2147483648	
16	41		-2147483648~	
17	42	COTT compared based value maximum setting value (section-compared)	2147483648	
18	43	Select auxiliary mode	0~6	
19	44	Sampling count time setting or Revolution/Unit time setting	0 ~ 60000	
20	45	Revolutions per hour function, pulses per revolution input	0~60000	
21	46	Select frequency display mode	0~3	
22	47	Select Low Active or High Active	0~1	
23	48	Define output status when PLC CPU stops	0~1	

# (1) Input setting area

### (2) Output area of error code

Internal memory address		Details	Command	
Channel 0	Channel 1		Command	
51		Error code (channel 0, channel 1 common)	GET	

# 5.1.2 Details & Data Configuration

Г

### (1) Count mode setting (CH0: 0 address, CH1: 25 address)

Setting value	Details
0	Linear count
1	Ring count

(2) Pulse input mode setting (CH0: 1 address, CH1: 26 address)

Setting value	Details	
0	2-phase 1-multiplication	
1	2-phase 2-multiplication	
2	2-phase 4-multiplication	
3	CW/CCW	
4	1-phase, 1-input, 1-multiplication	
5	1-phase, 1-input, 2-multiplication	
6	1-phase, 2-input, 1-multiplication	
7	1-phase, 2-input, 2-multiplication	

### (3) Comparison output types (CH0: 8, 9 address, CH1: 33, 34 address)

Setting value	Details
0	If present value < compared reference value, $OUT\Box$ is On
1	If present value =< compared reference value, $OUT$ is On
2	If present value = compared reference value, $OUT\Box$ is On
3	If present value $\geq$ compared reference value, OUT is On
4	If present value > compared reference value, $OUT\Box$ is On
5	If compared minimum value =< present value =< compared maximum value, $OUT \square$ is On
6	If compared minimum value >= present value, present value >= compared maximum value, OUT is On

#### $\times$ Here, $\Box$ means 0 or 1.

### (4) Auxiliary mode setting (CH0: 18 address, CH1: 43 address)

Setting value	Details	
0	Auxiliary mode is not used	
1	Count Clear	
2	Count Latch	
3	Sampling Count	
4	Input Frequency Measure	
5	Revolution/Unit time	
6	Count Disable	

### (5) Frequency mode setting (CH0: 21 address, CH1: 46 address)

Setting value	Details	
0	1 Hz unit displayed	
1	10 Hz unit displayed	
2	100 Hz unit displayed	
3	1000 unit displayed ( = 1kHz )	

### (6) Input pulse level setting (CH0: 22 address, CH1: 47 address)

Setting value	Details
0	Output disable
1	Output kept as it is

### (7) Output status setting at PLC stop (CH0: 23 address, CH1 : 48 address)

Setting value	Details
0	Output disable
1	Output kept as it is

# 5.2 I/O Signals

## (1) Input setting area

Channel 0	Channel 1	Details
Uxy.02 ~ Uxy.03	Uxy.12 ~ Uxy.13	Present count value
Uxy.04 ~ Uxy.05	Uxy.14 ~ Uxy.15	Latch count value
Uxy.06 ~ Uxy.07	Uxy.16 ~ Uxy.17	Sampling count value
Uxy.08 ~ Uxy.09	Uxy.18 ~ Uxy.19	Input frequency value
Uxy.10 ~ Uxy.11	Uxy.20 ~ Uxy.21	Revolutions per hour value

\* Here, 'xy' stands for the position High Speed Counter module is installed on. (xy => x:base no., y:slot no.)

(2) Operation status display and Operation command area

PLC <- High Speed Counter(Input)			PLC -> High Speed Counter(Output)			
СН	Signal	Details	Signal	Details		
U> U>	Uxy.00.0	Up/Down count status	Uxy.23.0	Count operation enable signal (Level)		
	Uxy.00.1	External preset input flag	Uxy.23.1	Preset enable signal (edge)		
	Uxy.00.2	-	Uxy.23.2	Up/Down count setting signal (Level)		
	Uxy.00.3	Carry flag	Uxy.23.3	Auxiliary function use command(edge/ level)		
	Uxy.00.4	Borrow flag	Uxy.23.4	Compared function use command(Level)		
	Uxy.00.5	Flag during auxiliary mode	Uxy.23.5	Compared output external terminal enabled signal(Level)		
	Uxy.00.6	OUT0 output signal	Uxy.23.6	OUT0 coincidence output reset signal (Edge)		
CHO	Uxy.00.7	OUT1 output signal	Uxy.23.7	OUT1 coincidence output reset signal (Edge)		
	Uxy.00.8	-	Uxy.23.8	-		
	Uxy.00.9	-	Uxy.23.9	-		
	Uxy.00.A	-	Uxy.23.A	Carry/Borrow reset signal (Edge)		
	Uxy.00.B	-	Uxy.23.B	Preset external input setting signal(Level)		
	Uxy.00.C	-	Uxy.23.C	External auxiliary function selection (Level)		
	Uxy.00.D	-	Uxy.23.D	External input preset flag reset signal(Edge)		
	Uxy.00.E	Error flag	Uxy.23.E	-		
	Uxy.00.F	Module Ready	Uxy.23.F	-		
	Uxy.01.0	Up/Down count status	Uxy.24.0	Count operation enable signal (Level)		
	Uxy.01.1	External preset input flag	Uxy.24.1	Preset enable signal (edge)		
	Uxy.01.2	-	Uxy.24.2	Up/Down count setting signal (Level)		
	Uxy.01.3	Carry flag	Uxy.24.3	Auxiliary function use command (edge/ level)		
	Uxy.01.4	Borrow flag	Uxy.24.4	Compared function use command (Level)		
	Uxy.01.5	Flag during auxiliary mode	Uxy.24.5	Compared output external terminal enabled signal (Level)		
	Uxy.01.6	OUT0 output signal	Uxy.24.6	OUT0 coincidence output reset signal (Edge)		
CH1	Uxy.01.7	OUT1 output signal	Uxy.24.7	OUT1 coincidence output reset signal (Edge)		
	Uxy.01.8	-	Uxy.24.8	-		
	Uxy.01.9	-	Uxy.24.9	-		
	Uxy.01.A	-	Uxy.24.A	Carry/Borrow reset signal (Edge)		
	Uxy.01.B	-	Uxy.24.B	Preset external input setting signal (Level)		
	Uxy.01.C	-	Uxy.24.C	External auxiliary function selection (Level)		
	Uxy.01.D	-	Uxy.24.D	External input preset flag reset signal(Edge)		
	Uxy.01.E	Error flag	Uxy.24.E	-		
	LIXV 01 F	-	LIXV 24 F	-		

%Here, the size of Uxy.ab is 1 word and the size of Uxy.ab.i is 1 bit.
# **Chapter 6 Global Constant and Global Variable**

It is described to global constant and global variable for XEC series.

#### Remark

It is terminology for XGB IEC type PLC series to Global constant(VAL\_GLOBAL\_CONST) and Global variable(VAL\_GLOBAL). In XBM/XBC series, global constant is equivalent to the internal memory, global variable is to input/output signal(U device).

## 6.1 Global Constant

CPU module of XEC series are sharing the global constant area for the data transmission and receiving. It is PUT\_### for the function block to transmit the data form XEC CPU module to the global constant area of the high speed counter module, the receiving function block is GET\_###. About PUT\_###, GET\_### function block, please refer to the 'chapter 7 Programming'.

## 6.1.1 The configuration of Global Constant

1. Input data

Channel 0	Const	Contents	Data setting range
	value		0 0
Fxy_CH0_CN1_MODE	00	Count types	0 or 1
Fxy_CH1_CNT_MODE	25		
Fxy_CH0_PLS_MODE	01	Pulse input types	0~7
Fxy_CH1_PLS_MODE	26		
_Fxy_CH0_PRESET	02	Preset value	-2147483648 ~
_Fxy_CH1_PRESET	27		2147483647
_Fxy_CH0_RING_MIN	04	Ring count minimum value	-2147483648 ~
_Fxy_CH1_RING_MIN	29		2147483647
_Fxy_CH0_RING_MAX	06	Ping count maximum value	-2147483648 ~
_Fxy_CH1_RING_MAX	31		2147483647
_Fxy_CH0_CP0_MODE	08	Type of comparison output 0	0 6
_Fxy_CH1_CP0_MODE	33		0~0
_Fxy_CH0_CP1_MODE	09	Time of comparison output 1	0 6
_Fxy_CH1_CP1_MODE	34	Type of companson output T	0~0
_Fxy_CH0_CP0_MIN	10	Comparison reference value of comparison output	-2147483648 ~
_Fxy_CH1_CP0_MIN	35	0(single comparison)/minimum value(section comparison)	2147483647
_Fxy_CH0_CP0_MAX	12	Maximum value of comparison output 0 (section	-2147483648 ~
_Fxy_CH1_CP0_MAX	37	comparison)	2147483647
_Fxy_CH0_CP1_MIN	14	Comparison reference value of comparison output	-2147483648 ~
_Fxy_CH1_CP1_MIN	39	1(single comparison)/minimum value(section comparison)	2147483647
_Fxy_CH0_CP1_MAX	16	Maximum value of comparison output 1 (section	-2147483648 ~
_Fxy_CH1_CP1_MAX	41	comparison)	2147483647
_Fxy_CH0_AUX_MODE	18	Time of additional function	0 6
_Fxy_CH1_AUX_MODE	43		0~0
_Fxy_CH0_PERIOD	19	Setting time of sampling count or of setting time	0 60000
_Fxy_CH1_PERIOD	44	"revolution per unit time"	0~60000
_Fxy_CH0_REV_UNIT	20	Dulas per 4 retation of "revelution per unit time"	0.0000
_Fxy_CH1_REV_UNIT	45	Puise per l'rotation of revolution per unit time	0~60000
_Fxy_CH0_FREQ_MODE	21	Fraguanay diaplay unit of "input fraguanay massy ra"	0.2
_Fxy_CH1_FREQ_MODE	46	requency display unit of input frequency measure	0~3
_Fxy_CH0_PLS_LVL	22	Salast Loui Astiva ar Llish Astiva	0 1
_Fxy_CH1_PLS_LVL	47	Select Low Active of High Active	0~1
_Fxy_CH0_PLCSTOP_OUT_EN	23	Define output status when DLC CDL stans	0 1
_Fxy_CH1_PLCSTOP_OUT_EN	48	Denne output status when PLC CPU stops	U~1

#### Remark

(1) 'Fxy': 'x' means the base number of the high speed counter module, 'y' means the slot number of it.

(2) Constant value can not be modified, because it is the address of input data area.

(3) Constant value is the same as the internal memory address of XBM/XBC series.

#### 2. Output area of the error code

Channel 0	Constant	Contonto	Function Block	
Channel 1	value	Contents		
_Fxy_ERR_CODE	51	Error code (channel 0, channel 1 common)	GET_###	

## 6.1.2 The Configuration and Contents of Data

1. Count types (channel 0: \_Fxy\_CH0\_CNT\_MODE, channel 1: \_Fxy\_CH1\_CNT\_MODE)

Setting value	Contents
0	Linear count
1	Ring count

2. Pulse input types (channel 0: \_Fxy\_CH0\_PLS\_MODE, channel 1: \_Fxy\_CH1\_PLS\_MODE)

Setting value	Contents				
0	2 phase 1 multiplier				
1	2 phase 2 multiplier				
2	2 phase 4 multiplier				
3	CW/CCW				
4	1 phase /1 input /1 multiplier				
5	1 phase /1 input /2 multiplier				
6	1 phase /2 input /1 multiplier				
7	1 phase /2 input /2 multiplier				

3. Comparison output types (channel 0: \_Fxy\_CH0\_CP\_\_MODE, channel 1: \_Fxy\_CH1\_CP\_\_MODE)

Setting value	Contents
0	In case of current count value < comparison reference value, OUT is On
1	In case of current count value ≤ comparison reference value, OUT□ is On
2	In case of current count value = comparison reference value, OUT is On
3	In case of current count value ≥ comparison reference value, OUT□ is On
4	In case of current count value > comparison reference value, OUT is On
5	In case of comparison minimum value $\leq$ current count value $\leq$ comparison maximum value, OUT $\Box$ is On
6	In case of comparison minimum value $\geq$ current count value, current count value $\leq$ comparison maximum value, OUT $\Box$ is On

※ Here, □ means 0 or 1.

4. Additional function types (channel 0: \_Fxy\_CH0\_AUX\_MODE, channel 1: \_Fxy\_CH1\_AUX\_MODE)

Setting value	Contents
0	Not used
1	Count clear
2	Count latch
3	Sampling count
4	Input frequency measure
5	Revolution measure per unit time
6	Count disable

#### 5. The frequency display unit of input frequency measure

(channel 0: \_Fxy\_CH0\_FREQ\_MODE, channel 1: \_Fxy\_CH1\_FREQ\_MODE)

Setting value	Contents
0	1Hz
1	10Hz
2	100Hz
3	1000Hz(=1kHz)

6. Setting area of comparison output status

Constant value	Contents	Default		
0	Low Active	Loux Activo		
1	High Active	LOW Active		

7. When XGB CPU module is STOP mode, comparison output status (channel 0: \_Fxy\_CH0\_PLCSTOP\_OUT\_EN, channel 1: \_Fxy\_CH1\_PLCSTOP\_OUT\_EN)

Constant value	Contents
0	Output disable
1	Ouput preservation

# 6.2 Global Variable

1.	The	range	of o	outpu	ut d	ata
----	-----	-------	------	-------	------	-----

Channel 0	Channel 1	Contents			
_xy_CH0_CNT	_xy_CH1_CNT	Current count value			
_xy_CH0_FRQ	_xy_CH1_FRQ	Count latch			
_xy_CH0_LTH	_xy_CH1_LTH	Sampling count			
_xy_CH0_RNG	_xy_CH1_RNG	Input frequency count			
_xy_CH0_RPU	_xy_CH1_RPU	Revolution per unit time			

## Remark

Г

(1) Here, 'x' means the base number which the high speed counter module is mounted, and 'y' means the slot number of it.(2) It is double word (dword) to the data type of the range of output data.

2.	The	display	y of c	operation	status	and the	range	of c	peration	command

Channel	Output (CPU Module	← High speed counter)	Input (CPU Module → High speed counter)			
Channel	Status	Contents	Command	Contents		
	_xy_CH0_DN	Count Up/Down status	_xy_CH0_CNTEN	Count enable (level)		
-	_xy_CH0_EXTPRE	Input detection of external preset	_xy_CH0_PREEN	Preset enable (edge)		
	_xy_CH0_CRY	Carry detection	_xy_CH0_DWNCNT	Up/Down count selection (level)		
	_xy_CH0_BRW	Borrow detection	_xy_CH0_AUXEN	Additional function enable(level/edge)		
	_xy_CH0_AUXING	In operation of additional function	_xy_CH0_CMPEN	Comparison enable (level)		
ChannelO	_xy_CH0_CMPOUT0	The status of comparison output 0	_xy_CH0_OUTEN	Comparison output enable (level)		
	_xy_CH0_CMPOUT1	The status of comparison output 1	_xy_CH0_EQ0RST	Equal (=) reset of comparison output 0 (edge)		
	_xy_CH0_ERR	Error detection	_xy_CH0_EQ1RST	Equal (=) reset of comparison output 1 (edge)		
	_xy_RDY	Module ready	_xy_CH0_CRTBRW_RST	Carry/Borrow reset (edge)		
	-	-	_xy_CH0_EXTPST_EN	External preset selection (edge)		
	-	-	_xy_CH0_EXTAUX_EN	Selection of external additional function (edge)		
	-	-	_xy_CH0_EXTPST_RST	Detection reset of external preset(edge)		
	_xy_CH1_DN	Count Up/Down status	_xy_CH1_CNTEN	Count enable (level)		
	_xy_CH1_EXTPRE	Input detection of external preset	_xy_CH1_PREEN	Preset enable (edge)		
	_xy_CH1_CRY	Carry detection	_xy_CH1_DWNCNT	Up/Down count selection (level)		
	_xy_CH1_BRW	Borrow detection	_xy_CH1_AUXEN	Additional function enable(level/edge)		
	_xy_CH1_AUXING	In operation of additional function	_xy_CH1_CMPEN	Comparison enable (level)		
Channell	_xy_CH1_CMPOUT0	The status of comparison output 0	_xy_CH1_OUTEN	Comparison output enable (level)		
	_xy_CH1_CMPOUT1	The status of comparison output 1	_xy_CH1_EQ0RST	Equal (=) reset of comparison output 0 (edge)		
	_xy_CH1_ERR	Error detection	_xy_CH1_EQ1RST	Equal (=) reset of comparison output 1 (edge)		
	-	-	_xy_CH1_CRTBRW_RST	Carry/Borrow reset (edge)		
	-	-	_xy_CH1_EXTPST_EN	External preset selection (edge)		
	-	-	_xy_CH1_EXTAUX_EN	Selection of external additional function (edge)		
	-	-	_xy_CH1_EXTPST_RST	Detection reset of external preset(edge)		

Remark

It is bool type to the data type of the display of operation status and the range of operation command.

# **Chapter 7 Programming**

Here describes how to program by using instruction (XBM/XBC series) or function block (XEC) at scan program of XG5000

# 7.1 Instruction and Function Block

Here describes instruction and function block to read and write data of HSC module at XGB CPU module.

#### Remark

There is difference on terminology used in XBM/XBC series and XEC series. The following table indicates the relation of terminology used in HSC module.

XBM/XBC series	XEC series
Instruction	Function Block
Internal memory	Global constant
I/O signal (U device)	Global variable
Device	Variable
F area	Flag

## 7.1.1 Instruction of XBM/XBC series

#### 1. GET/GETP instruction

It is an instruction used to read the details of High Speed counter module's internal memory to PLC CPU. The read data can be saved on PLC CPU memory (except F area).

#### (1) Operation of GET/GETP instruction

GET	Always executed with execution condition On []	Level
GETP	Executed with execution condition of operation start []	Edge

#### (2) Configuration of GET/GETP Instruction

Execut condit	ion GET n1 n2 n3	n4	
Туре	Description	Area Available	Туре
n1	Slot No. the special module is installed on	Integer	Hexadecimal is recommended
n2	Start address of special module's operation parameters setting area to read data	Integer	
n3	Device's start address with saved data to read	M, P, K, L, T, C, D, #D	
n4	Number of words data to read	Integer	

(a) How to set base and slot number

1) Basic base

Г



## (3) Use of GET/GETP instruction

(a) HSC module is installed at slot 8 of basic base and While M00000 is On, it transmits the data (data1, data2) of internal memory 5 and 6 to D00015 and D00016.

	XGB CPU module			HSC modu			
	D area		Inter	nal memory	Da	ata	
	D00015			5	Da	ta1	
	D00016	6			Da	ta2	
I	M00000						
$\vdash$			GET	h0008	5	D00015	2
		-					

(b) It transmits data at rising edge of M00000.

```
M00000
______GETP h0008 5 D00015 2 ____
```

(c) HSC module is installed at slot 4 of extension base stage 2. While M00001 is on, it transmits data of internal memory 10 ~ 15 to D00001 ~ D00006.

XBM/XBC CPU module		HSC module				
D area	1	Internal memo	ry	data		
D00001		10		Data 1		
D00002		11		Data 2		
D00003		12		data 3		
D00004		13		Data 4		
D00005		14		Data 5		
D00006	1	15		Data 6		
M00001	_					
	GE	ET h0024	10	D00001	(	

## 2. PUT/PUTP instruction

Instruction to write data from XGB CPU module to internal memory area

#### (1) PUT/PUTP instruction

PUT	Always executed with execution condition On []	Level
PUTP	Executed with execution condition of operation Start ( )	Edge

#### (2) Configuration of PUT/PUTP instruction

#### Execution

condition					
gonpillon	DIIT	n1	n?	n3	n/
	FUI		112	115	114
	-				-

Туре	Description	Available area	Reference
n1	Slot No. the special module is installed on	Integer	Hexadecimal is recommended
n2	Start address of special module's internal memory to write data.	Integer	
n3	Device's start address or integer with saved data to write.	M, P, K, L, T, C, D, #D	
n4	Number of words data to write	Integer	

(a) Base and slot number setting method

It is same with GET/GETP instruction

## (3) Use of PUT/PUTP instruction

(a) HSC module is equipped at 1 slot of basic base. While M0000 is On, it transmits data of D00000 (data1) to internal memory address 1



(b) It transmits data at the rising edge of M0000

MO	00	00					
			PUTP	h0001	1	D00000	

## 7.1.2 Function Block of XEC

## 1. GET function block

Г

Function Block to read data of Global constant area at XEC CPU module. That data can be saved at variable area of XEC CPU module (Except flag area).

(1) GET function block configuration

Function block			Classification	Variable	Description	
				REQ	Request execution	
	GET_###		la se st	BASE	Base where HSC module is equipped	
BOOL —	REQ	DONE	— BOOL	input	SLOT	Slot where HSC module is equipped
USINT -	BASE	STAT	— UINT		MADDR	Global constant area
USINT -	SLOT	DATA	— ###		DONE	Function Block execution status
UINT —	MADDR			Output	STAT	Error information
				DATA	Output data	

## Remark

(1) '###' means that WORD, DWORD, INT, UINT, DINT, UDINT type is available.

(2) For 'REQ', edge signal or level signal is available.

(3) For 'MADDR', Global constant or integer is available.

(4) 'Output data' is data read from Global constant.

(5) In case of XGR, HSC module should be equipped at extension base.

Function block is classified as follows according to output variable type.

Function Block	Output variable type	Operation description
GET_WORD	WORD	Reads WORD data from Global constant area (MADDR).
GET_DWORD	DWORD	Reads DWORD data from Global constant area (MADDR).
GET_INT	INT	Reads INT data from Global constant area (MADDR).
GET_UINT	UINT	Reads UINT data from Global constant area (MADDR).
GET_DINT	DINT	Reads DINT data from Global constant area (MADDR).
GET_UDINT	UDINT	Reads UDINT data from Global constant area (MADDR).

#### (2) Use of GET function block

(a) HSC module is equipped at slot 8 of basic base. While 'Read1' is on, it transmits data of '\_F01\_CH0\_CNT\_ MODE' to 'Output data1'

XEC CPU module	] [		HSC module				
			Input varia	able (MADDR)			
		Global variable		Constant value		Data	
Output data1		_F01_CH0_CNT_MODE		0		Data1	
Read1	GET_WORD	]	Read1		GET	r_word	
	REQ DONE	<b>_</b>			REQ	DONE	-
0 —	BASE STAT	·		0 –	BASE	STAT	—
1 —	SLOT DATA	- OutputData1		1 -	SLOT	DATA	OutputData1
_F01_CH0 _CNT_MODE	MADDR			0 -	MADE	DR	

#### Remark

(1) Results of above two examples are same.

(2) For detail of Global variable, refer to XG5000 user manual.

(b) It transmits data at the rising edge of execution condition



#### 2. PUT function block

Function Block to write the data into Global constant area at XEC CPU module.

(1) Configuration of PUT function block

	Function Block		classification	Variable	Description	
				REQ	Request execution	
		PUI_###			BASE	Base where HSC module is equipped
BOOL —	REQ	DONE	— BOOL	Input	SLOT	Slot where HSC module is equipped
USINT -	BASE	STAT	— UINT		MADDR	Global constant area
USINT -	SLOT				DATA	Input data
UINT —	MADDR			<b>Q</b> ( ) (	DONE	Function block execution status
### —				Output	STAT	Error information

## Remark

(1) '###' means that WORD, DWORD, INT, UINT, DINT, UDINT type is available.

(2) For 'REQ', edge signal or level signal is available.

(3) For 'MADDR', Global constant or integer is available.

(4) 'Output data' is data read from Global constant.

(5) In case of XGR, HSC module should be equipped at extension base.

Function block is classified as follows according to output variable type.

Function block	Input variable type	Operation description
PUT_WORD	WORD	Writes WORD data to Global constant area (MADDR).
PUT_DWORD	DWORD	Writes DWORD data to Global constant area (MADDR).
PUT_INT	INT	Writes INT data to Global constant area (MADDR).
PUT_UINT	UINT	Writes UINT data to Global constant area (MADDR).
PUT_DINT	DINT	Writes DINT data to Global constant area (MADDR).
PUT_UDINT	UDINT	Writes UDINT data to Global constant area (MADDR).

(2) Use of PUT function block

(a) HSC module is equipped at slot 10 of basic base. While 'Write1' is on, it transmits data (Data1) of 'InputData1' to '\_F0A\_CH0\_CNT\_MODE'.

Х	GB CPU module	]	HSC modu	le
Dete			Input variable (N	IADDR)
Data	Input variable (DATA)		Global constant	Constant value
Data1	InputData1		_F0A_CH0_CNT_MODE	0



## Remark

Г

- (1) Operations of above two examples are same.
- (2) For detail of Global variable, refer to 'XG5000 user manual'.
- (b) It transmits data at the rising edge of execution condition



# 7.2 Program

1. XGB system is explained referring to the following system HSC module is equipped at slot 1 of basic base.

## 7.2.1 Count mode setting

Example explaing how to set Ring Count Min. and Max. As for setting method by 'I/O Parameter', refer to Chapter 4.

#### 1. Setting content

Parameter	CH0	CH1		
Count mode	1: Ring counter	1: Ring counter		
Ring counter min.	0	0		
Ring counter max.	100000	100000		

## 2. Program

(1) Scan program of XBM/XBC series



#### (2) Scan program of XECseries.

Γ



#### Remark

(1) Since instruction PUT (Function Block PUT\_DWORD) is used at scan program example of XBM/XBC (XEC) series, while input contact point is On, data is transmitted into HSC module. So, if data is changed, it is transmitted into HSC module automatically.

(2) If you program as follows, its operation become different with program example.

Comment		СНО							
L19			INST6		INST7			INS	Т8
	CountMode Setting		PUT_DWO RD REQ DON		PUT_DW RD REQ DO	о м		PUT_I RI REQ	DWO D DON-
L20		0	-BAS STAT-	0	BAS ST	AT-	0	BAS	STAT-
L21		1	-SLO	1	E SLO		1	E SLO	
L22		_F0001_C H1_CNT_M		_F0001_C H1_RING_			_F0001_C H1_RING_		
L23		UDE 1	-MAD DR -DATA	міN 0	MAD DR DATA		MAX 100000	DR DR	
L24									

(a) If input contant point of function block is on and execution of function block is compete, 'DONE' becomes 1. Namely, front function block and back function block are not executed simutaneouly and from left to right, they are executed sequently.(b) If input variable of function block is set uncorrectoly and error occurs, 'DONE' doesn't become 1. Namely, if error occurs at

front function block, back function block is not executed.

(3) Integer can be inserted into 'MADDR' instead of global constant. The operation of the following program is same with that of the front example.



## 7.2.2 Pulse input mode setting

Program example setting pulse input mode

## 1. Setting contents

Parameter	CH0	CH1		
Pulse input mode	3: CW/CCW	3: CW/CCW		

## 2. Program

Г

(1) Scan program of XBM/XBC series





## 7.2.3 Counter check

Program example checking current counter and operation by auxiliary function.

## 1. Program

(1) Scan program of XBM/XBC series



#### (2) Scan program of XECseries



## Remark

In Scan program of XGI/XGR, the number of cell is changed by using icon R S or 'Change Columns' of 'View'

## 7.2.4 Preset value setting and enable preset

Program example about how to set preset value and enable preset

#### 1. Setting content

Parameter	CH0	CH1
Preset value	1000	1000

## 2. Program

Г

(1) Scan program of XBM/XBC series



## 7.2.5 Enable counter

Program example executing Enable counter

## 1. Program

(1) Scan program of XBM/XBC series



#### (2) Scan program of XECseries



#### 7.2.6 Carry/borrow detection reset

Program example resetting the detected carry/borrow signal

## 1. Program

(1) Scan program of XBM/XBC series



Comment		CH0=======					
L1	CarryBorro wReset						_0001_CH 0_CRYBR W_RST
Comment		CH1======	==	 	 	 	
L3	CarryBorro wReset						_0001_CH 1_CRYBR W_RST
L4							

## 7.2.7 Auxiliary mode setting and Enable auxiliary function

Program example setting auxiliary mode and executing Enable auxiliary function. You can check the operation result of auxiliary function at 7.2.3 Counter check.

## 1. Counter Clear

Г

When auxiliary function is on, change current counter as 0.

#### (1) Setting contents

Parameter	CH0	CH1
Auxiliary mode	1: Counter Clear	1: Counter Clear

#### (2) Program

(a) Scan program of XBM/XBC series

Comment	=====CH0======						
	M0000C	PUT	h0001	18	1	1	Auxiliary function setting (Count Clear)
7	M00000					U01.23.3	Enable auxiliary function
Comment	=====CH1======						
12	M0000C	PUT	h0001	43	1	1	Auxiliary function setting (Count Clear)
12	моооо — ТРТ					U01.23.4	Enable auxiliary function

#### (b) Scan program of XEC



## 2. Counter latch

When Enable auxiliary is on, it indicates current counter at counter latch.

#### (1) Setting contents

Parameter	CH0	CH1
Auxiliary mode	2: Counter latch	2: Counter latch

## (2) Program

(a) Scan program of XBM/XBC series





## 3. Sampling Count

Γ

Counter from when Enable auxiliary is on to setting time is indicated at sampling counter.

#### (1) Setting content

Parameter	CH0	CH1
Auxiliary mode	3: Sampling Count	3: Sampling Count
Range value	5000	5000

## (2) Program

(a) Scan program of XBM/XBC series





#### 4. Input Freq. Measure

While Enable auxiliary function is on, input pule is indicated at input frequency. Unit of input frequency is depending on setting of Frequency Mode.

٦

#### (1) Setting content

Parameter	CH0	CH1
Auxiliary mode	4: Input Freq. measure	4: Input Freq. measure
Frequency Mode	1:10Hz	1:10Hz

#### (2) Program

(a) Scan program of XBM/XBC series





## 5. Revolution/Unit time

Γ

While Enable auxiliary mode is on, input pulse is calculated and indicated at revolution/unit time. For revolution/unit time, Range value and Pulse/Rev value should be set.

#### (1) Setting contents

Parameter	CH0	CH1
Auxiliary mode	5: Revolution/Unit time	5: Revolution/Unit time
Range value	1000	1000
Pulse/Rev value	200	200

#### (2) Program

#### (a) Scan program of XBM/XBC series





## 6. Counter Disable

While Enable auxiliary is on, counting is not executed.

## (1) Setting contents

Parameter CH0		CH1
Auxiliary mode	6: Count Disable	6: Count Disable

## (2) Program

#### (a) Scan program of XBM/XBC series

CommentCH0 M00014 M00015 7 Comment	PUT	h0001	18	6	1 U01.23.3	AuxiliaryFunctionSettin g(Count Diable) EnableAuxiliaryFunctio n
M00014 11 H M00015 17 H	PUT	h0001	43	6	1 U01.24.3	AuxiliaryFunctionSettin g(Count Diable) EnableAuxiliaryFunctio n

٦

## (b) Scan program of XECseries



## 7.2.8 Up/down count selection

Program example selecting UP/Down count when input pulse is set as 1 phase 1 input 1 mutiplication/2 multiplication

## 1. Program

Г

(a) Scan program of XBM/XBC series

Comment	======CH0=======		
	M0001A	U01.23.2	UP/DOWNCountSelecti
1			on
Comment	=====CH1======		
	M0001A	U01.24.2	UP/DOWNCountSelecti
5		()	on
	1		l

#### (b) Scan program of XECseries

Comment	=CH0=	
L1	UpDownSe lection	_0001_CH 0_DWNCN T 
Comment	CH1	
L3	UpDownSe lection	_0001_CH 1_DWNCN T

11

## 7.2.9 Use of external preset signal

Program examples allowing Enable preset by external preset signal and executing reset when external preset signal is detected

## 1. Program

(a) Scan program of XBM/XBC series



Comment	=====CH0=======	
L1	EnableExte malPreset	_0001_CH 0_EXTPST EN
L2	ResetEder nalPresetD etection	_0001_CH 0_EXTPST _RST 
Comment	CH1	
L4	EnableExte malPreset	_0001_CH 1_EXTPST EN
L5	ResetEder nalPresetD etection	_0001_CH 1_EXTPST _RST
10		· · · · · · · · · · · · · · · · · · ·

## 7.2.10 Use of external auxiliary function signal

Program example allowing Enable auxiliary function by external auxiliary function signal

## 1. Program

(a) Scan program of XBM/XBC series



## 7.2.11 Type of comparison and comparison value setting

Program example explain type of comparison and comparison value setting

## 1. Setting content

Γ

Paramotor	CH0		CH	1
Falameter	Comp output 0	Comp output 1	Comp output 0	Comp output 1
Comp output mode	1:≤	5:≤≤	1:≤	5:≤≤
Comp output min.	10	150	10	150
Comp output max.	150(No meaning)	300	150(No meaning)	300

## 2. Program

(a) Scan program of XBM/XBC seires

					1	
ment =====CH0=======						
M00006	PUT	h0001	8	1	1	Comp Output 0 Mod
1	PLIT	60001	9	5	1	Comp Output 1 Mod
						Comp Output 1 Mod
			DMOV	10	D00012	Comp Output 0 Min.
			DMOV	100	D00014	Comp Output 0 Min.
			DMOV	150	D00016	Comp Output 1 Min
			DMOV	300	D00018	Comp Output 1 Max
	PUT	h0001	10	D00012	2	Comp Output 0 Min setting
	PUT	h0001	12	D00014	2	Comp Output 0 Min setting
	PUT	h0001	14	D00016	2	Comp Output 1 Min setting
	PUT	h0001	16	D00018	2	Comp Output 1 Max
ment ======CH1======						
ment ======CH1======	PUT	h0001	33	1	1	Comp Output 0 Mc
ment =CH1= M00006	PUT PUT	h0001	33 34	1	1	Comp Output 0 Ma
ment =CH1= M000006 1	PUT PUT	h0001 h0001	33 34 DMOV	1 5 10	1 1 D00012	Comp Output 0 Ma Comp Output 1 Ma Comp Output 1 Ma
ment =CH1= M000006 1	PUT PUT	h0001 h0001	33 34 DMOV DMOV	1 5 10 100	1 1 D00012 D00014	Comp Output 0 Mc Comp Output 1 Mc Comp Output 0 Mi Comp Output 0 Mi
ment =CH1= M000006 1	PUT PUT	h0001 h0001	33 34 	1 5 10 100 150	1 1 D00012 D00014 D00016	Comp Output 0 Mc Comp Output 1 Mc Comp Output 0 Mi Comp Output 0 Mi Comp Output 1 Mi
ment ======CH1====== 	PUT PUT	h0001	33 34 DMOV DMOV DMOV DMOV	1 5 10 100 150 300	1 1 D00012 D00014 D00016 D00018	Comp Output 0 Mc Comp Output 1 Mc Comp Output 0 Mi Comp Output 0 Mi Comp Output 1 Mi Comp Output 1 Mi
ment ======CH1====== M00006 1	PUT	h0001	33 34 DMOV DMOV DMOV DMOV 35	1 5 10 100 150 300	1 1 D00012 D00014 D00016 D00018 2	Comp Output 0 Ma Comp Output 1 Ma Comp Output 0 Mi Comp Output 0 Mi Comp Output 1 Mi Comp Output 1 Ma Comp Output 1 Ma
ment ======CH1====== M00006 	PUT PUT	h0001 h0001	33 34 DMOV DMOV DMOV DMOV 35	1 5 10 100 150 300 D00020	1 1 D00012 D00014 D00016 D00018 2	Comp Output 0 Mo Comp Output 1 Mo Comp Output 0 Mir Comp Output 0 Mir Comp Output 1 Mir Comp Output 1 Mir Comp Output 1 Mir setting Comp Output 0 Mir
ment ======CH1====== 	PUT PUT PUT PUT PUT	h0001 h0001 h0001 h0001	33 34 DMOV DMOV DMOV DMOV 35 37	1 5 10 100 150 300 D00020 D00022	1 1 D00012 D00014 D00016 D00018 2 2 2	Comp Output 0 Ma Comp Output 1 Ma Comp Output 0 Mi Comp Output 0 Mi Comp Output 1 Mi Comp Output 1 Ma Comp Output 1 Ma Setting Comp Output 0 Mi setting
ment ======CH1====== M00006 	PUT PUT PUT PUT PUT PUT PUT	h0001 h0001 h0001 h0001 h0001	33 34 DMOV DMOV DMOV DMOV 35 37 39	1 5 10 100 150 300 D00020 D00022 D00022	1 1 D00012 D00014 D00016 2 2 2 2 2	Comp Output 0 Mo Comp Output 1 Mo Comp Output 0 Mi Comp Output 0 Mi Comp Output 1 Mi Comp Output 1 Mi Comp Output 1 Mi setting Comp Output 0 Mi setting Comp Output 0 Mi setting

#### (b) Scan program of XECseries



٦



## 7.2.12 Enable comparison, Enable comparison output, Comparison agreement reset

Program example executing Enable comparison, Enable comparison output, Comparison agreement reset

## 1. Program

Г



Comment	=====CH0=======	
L1	EnableCom pandComp Output	_0001_CH 0_CMPEN
L2		_0001_CH 0_OUTEN
L3	CompAgree mentReset	_0001_CH 0_EQ0RST
L4		_0001_CH 0_EQ1RST
Comment	=CH1=	
<i>L6</i>	EnableCom pandComp Output	_0001_CH 1_CMPEN
L7		_0001_CH 1_OUTEN
L8	CompAgree mentReset	_0001_CH 1_EQ0RST
L9		0001 CH
		1_EQ1RST

## 7.2.13 Comparison output status setting

Program example setting status of comparison output when XGB (XBM/XBC/XEC) CPU module is STOP.

## 1. Setting content

Parameter	CH0, CH1
Comparison output status when XGB CPU module is STOP	1: Hold comparison output

## 2. Program

(a) Scan program of XBM/XBC series



## 7.2.14 Input pulse Active level setting

Program example input pulse active level setting of HSC module.

## 1. Setting content

Parameter	Active Level
CH0 Input pulse active level	High Active
CH1 Input pulse active level	Low Active

## 1. Program

Γ

(a) Scan program of XBM/XBC series



(b) Scan	n program	of XEC se	eries				
Comment		сно					
L15			INST2				
	PLS_Input_ Level Setti		PUT_WOR				
	ng		REQ DON-				
L16			E				
1.17		0	BAS STAT- E				
L1/		1	SLO				
L18		50001 C	Τ				
		H0_PLS_L					
L19		VL	DR				
		1	DATA				
L20							
Comment		CH1					
L22	DLC Invit		INST3				
	Level_Setti		PUT_WOR D				
			REQ DON				
L23		n					
L24			E				
		1	SLO				
L25		F0001 C					
		H1_PLS_L VL	MAD				
L26			DR				
107		0	DATA				
L27							

## 7.2.15 Error status and error code

Program example checking error status and error code occurred at HSC module

## 1. Program

(a) Scan program of XBM/XBC series





## 7.2.16 Hold count when power fails

Program example holding current count

To prepare when PLC power is off, current count is saved every scan and if PLC power restart, preset operation is executed with the saved count.

## 1. Program

Γ

#### (a) Scan program of XBM/XBC series

0	U01.00.F	M00020	PUT	h0001	2	K0000	2	Set count value of K0000 as preset value of CH0
			PUT	h0001	27	K0002	2	Set count value of K0002 as preset value of CH1
12	U01.00.F				TON	T0000	10	-
15	U01.00.F				TON	T0001	20	-
10	U01.00.F	T0000				1 1 1 1	U01.23.1	Enable CH0 preset
10							U01.24.1	Enale CH1 preset
			1			1 1 1	M00020	Stop preset value setting operation
	U01.00.F	T0001					U01.23.0	Enable CH0 count
							U01.24.0	Enable CH1 count
					DMOV	U01.02	K0000	Save CH0 current count at K0000 every scan
			 1		DMOV	U01.12	K0002	Save CH1 current count at K0002 every scan

#### (b) Scan program of XEC series



٦

sic parameter se	ttings		<u>? ×</u>	
asic Operation Setup	Retain Area Setting Error Operation Se	MODBUS Setup		
Basic operations of the second	tion settings period operation 10 ms (1 ~ 999ms): 10 ms g timer: 50 ms input filter: 3 v ms nod Restart • Warm Restart	Output control settings		
		Default OK	Cancel	
On scan prog ariable Addi	gram, set 'CH0 current cou tion/Edit	Default OK Int' and 'CH1 current count' as Retain v	Cancel ariable.	
On scan proç a <mark>riable Addi</mark> /ariable:	gram, set 'CH0 current cou tion/Edit CH0CurrentCount	Default OK	Cancel	
On scan proç a <b>riable Addi</b> /ariable: )ata Type:	gram, set 'CH0 current cou tion/Edit CH0CurrentCount DWORD	Default OK Int' and 'CH1 current count' as Retain v ?X OK Cancel	Cancel	
On scan proç a <b>riable Addi</b> /ariable: )ata Type: /ariable Kind:	gram, set 'CH0 current cou tion/Edit CH0CurrentCount DWORD VAR	Default OK Int' and 'CH1 current count' as Retain w ? X OK Cancel	Cancel ariable.	
On scan proç a <b>riable Addi</b> /ariable: )ata Type: /ariable Kind: \ddress:	gram, set 'CH0 current cou tion/Edit CH0CurrentCount DWORD VAR	Default OK Int' and 'CH1 current count' as Retain w ? X OK Cancel Settings	Cancel ariable.	
On scan prog a <b>riable Addi</b> /ariable: )ata Type: /ariable Kind: \ddress: nitial Value:	gram, set 'CH0 current cou tion/Edit CH0CurrentCount DWORD VAR	Default OK Int' and 'CH1 current count' as Retain w ? X OK Cancel Settings Intialization	Cancel ariable.	
On scan prog ariable Addi /ariable: /ariable Kind: /ariable Kind: Address: nitial Value: frigger:	gram, set 'CH0 current cou tion/Edit CH0CurrentCount DWORD VAR	Default OK Int' and 'CH1 current count' as Retain w Cancel Settings Intialization	Cancel ariable.	

Γ

# **Chapter 8 Troubleshooting**

How to shoot the troubles on the high speed counter module will be described. **Description** 

# 8.1 Error code

CH0	CH1	Description	RDY LED
	10	Module error (ASIC Reset error)	
	11	Module error (ASIC Memory error)	Blinks every
12 Module error (ASIC Register error)		Module error (ASIC Register error)	0.2000
20	120	Counter type range exceeded	
21	121	Pulse input type range exceeded	
22	122	Auxiliary Mode type range exceeded	
23	123	Sampling Count value range exceeded	
24	124	Compared output0 type range exceeded	
25	125	Compared output1 type range exceeded	
26	126	Preset value exceeded counter range	
27	127	Ring counter minimum. value $\geq$ Ring counter maximum value input	
28	128	Compared output 0 minimum value exceeded maximum input range	1 sec
29	129	Compared output 0 maximum value exceeded maximum input range	
30	130	Compared output 0 minimum value > compared output 0 maximum value set	
31	131	Compared output 1 minimum value exceeded maximum input range	
32	132	Compared output 1 maximum value exceeded maximum input range	
33	133	Compared output 1 minimum value > compared output1 maximum value set	
34	134	Pulses per revolution range exceeded	
35	135	Frequency input mode range exceeded	
36	136	Main unit stop Compared output retain parameter error	

#### Notes

(1) If the module is normal, RDY LED is On.

(2) If 2 or more errors occur, the module will save the first error code generated, and the displayed error will be first deleted to let the next error deleted.

(3) In case of serious error which makes RDY LED blinks every 0.2 sec., let power Off  $\rightarrow$ On to delete the error.

(4) In case of slight error which makes RDY LED blinks every 1 sec., the error can be deleted without power Off → On and the module can keep operating.

(5) In case of slight error which makes RDY LED blinks every 1 sec, the parameter value causing the applicable error is not set on the module, with the existing parameter value kept as it is.

# 8.2 Troubleshooting

Г

## 8.2.1 LED display status of the high speed counter module



## 8.2.2 Counter status of the high speed counter module


## 8.3 Troubleshooting sequence

### 8.3.1 RDY LED Off



٦



Γ



8.3.3 Counter operation error



#### 8.3.4 Counter value error

Г



#### 8.3.5 Output operation error



## 8.4 Module status check through XG5000 system monitoring

Module type, module information, OS version and module status of HSC module can be checked through XG5000 system monitoring function.

#### 8.4.1 Execution sequence

Г

[Monitor] -> [System Monitoring] -> and on the module screen, click the right mouse button to display [Module Information].

#### 8.4.2 Module information

- 1. Module Info: shows the information of the module presently installed.
- 2. OS version: shows the OS version information of the high speed counter module.
- 3. OS date: shows the OS prepared date of the high speed counter module.
- 4. Module status: shows the present error code.

#### 8.4.3 System Monitoring

Ð	🗊 NewPLC - System Monitoring - [Base 0]									
Ei Ei	Eile <u>Vi</u> ew <u>B</u> ase <u>P</u> LC <u>H</u> elp									
i d		30	<b>B A</b>	<u>a l</u> i						
				<u>~</u> [.						
									<u>^</u>	
	NG	=				XB	e- XBF- XBE Ry16A HDN2A	- RY16A	_	
						s	pecial Module Inform	ation ?	X	
			CH CH CH	0	~					
					٠		Displays the inform	nations of special module.		
				0	0				-	
	STOP	R S		0	•		Module Name	VPE-UD02A (Line-Driver, 2-CU)		
	🛎 ERR	4 r O	01.01	0	~		DS Ver	Ver. 0.09		
	-	ŝ. o			9		OS Update Date	2011-12-14	-	
	DC-0000			0			Module Status	Normal. (0)		
	n3 2020	S O		0						
	(Ca)	2 0	198.098							
		<sup>3</sup> 2 □ O	100 100							
		U		۲						
									×	
System information						Ł			Comment	
	Base 0 : XGB-M11B						J		Main Base(11 Slots) Standard CPLI Medule(I/O: Maximum 294 Pointe)	
								OK	Internal Criet Module, RS-232C/RS-485	
	Slot 0: XBC-DR30S, Input								DC 24V Input 18 Contacts	
Nop		ot 0: XBC-DF	R30S, Output				[P00040 ~ P0007F]		Relay Output 12 Contacts	
win	I Slot 1: XBE-RY16A						[P00080 ~ P0011F]		Relay Output, 16 Contacts (2A, No Varistor/Varistor)	
ation	3 Slot 3: XBE-RY16A						[P00120 * P0015F] [P00160 ~ P0019F]		Relay Output 16 Contacts (2A, No Varistor Varietor)	
ju n	4 Slot 4: Empty slot						[P00200 ~ P0023F]			
Modu	System									
Ready							XGB-XBCS	Online	L, USB, Warning	

## **Appendix 1 Terminology**

#### 1. Pulse

Used to turn voltage (current) On/Off for a short time, and pulse line is of continuous pulses

#### 2. Encoder

Used mainly in subo-detector in order to detect speed and position, whose basic principle is that if infrared ray from LED passes the slit disk and reaches the light receiving element, analog electric sign is output which will be converted by voltage comparator to digital sign to be output.



#### Encoder output

- (1) A phase: Basic output, signal of pulses is output as many as the number of resolutions for 1 revolution of shaft.
- (2) B phase: Signal with a specific phase difference from A phase, which can detect revolution direction of shaft
- (3) Z phase: 1 pulse is output for 1 revolution of shaft.

#### 3. MPG(Manual Pulse Generator)

A device that handle can be rotated by hand to generate pulses. If rotated + direction, forward pulses are generated, and if rotated – direction, reverse pulses are generated.

#### 4. Up Count

A counter value increases from -2,147,483,648 to 2,147,483,647 (for 32-bit counter).

#### 5. Down Count

A counter value decreases from 2,147,483,647 to -2,147,483,648 (for 32-bit counter).

#### 6. Ring Count

A counter that counter value increases/decreases between the maximum value and the minimum value of the Ring count that user has defined.

#### 7. 1-Phase Operation Mode

Mode used to count 1-phase input pulse.

#### 8. CW/CCW Operation Mode

Mode used to count another 1-phase if 1 phase is Low among 2-phase input pulses.

#### 9. 2-Phase Operation Mode

Mode used to count 2-phase input pulse.

10. Preset

Mode used to set present counter value to discretionary value.

#### 11. Gate

Signal used to enable additional function operation.

#### 12. Compared Value

Basic value used to compare counters in size.

#### 13. Carry

Г

Signal displayed when Linear count changes from 2,147,483,646 to 2,147,483,647 and when Ring count changes from the maximum value to the minimum value with increasing counter operation.

#### 14. Borrow

Signal displayed when Linear count changes from -2,147,483,647  $\rightarrow$  -2,147,483,648 and when Ring count changes from the minimum value to the maximum value with decreasing counter operation.

#### 15. External Preset Signal

External signal used to change present counter value to discretionarily specified value.

#### 16. External Gate Signal

External signal used to enable the additional function operation.

## **Appendix 2 Dimensions**

## Appendix 2 Dimensions

Unit: mm

٦



#### Remark

XBF-HO02A and XBF-HD02A are same size.

### Warranty

1. Warranty Period

The product you purchased is guaranteed for 36 months from the date of manufacture.

- 2. Scope of Warranty
  - (1) The initial diagnosis of faults is basically conducted by your company. However, upon your request, our company or our service network can undertake this task for a fee. If the cause of the fault lies with our company, this service will be provided free of charge.
  - (2) This warranty only applies if the product is used under normal conditions according to the specifications and precautions described in the handling instructions, user manuals, catalogs, and caution labels.
  - (3) Even within the free warranty period, the following cases will be subject to paid repairs:
    - 1) Replacement of consumable and life-limited parts (e.g., relays, fuses, electrolytic capacitors, fans, LCDs, batteries, etc.)
    - 2) Failures or damages caused by improper storage, handling, negligence, or accidents by the customer
    - 3) Failures resulting from the customer's hardware or software design
    - 4) Failures due to modifications without our consent

(Repairs will be refused, even for a fee, if recognized as modified or repaired outside our company)

- 5) Failures that could have been avoided if the customer's equipment, in which our product is incorporated, had safety devices required by legal regulations or common industry standards
- 6) Failures that could have been prevented if maintenance and replacement of consumable parts were performed normally according to the handling instructions or user manuals
- 7) Failures and damages to the product caused by using connected equipment or inappropriate consumables
- Failures caused by external factors such as fire, abnormal voltage, force majeure, and natural disasters such as earthquakes, lightning, salt damage, wind, and flood damage
- 9) Failures due to reasons that could not be predicted with the scientific and technical standards at the time of our shipment
- 10) Other failures, damages, or defects recognized as the responsibility of your company

## **Environmental Policy**

LS ELECTRIC Co., Ltd supports and observes the environmental policy as below.



1

Γ



## www.ls-electric.com

# LS ELECTRIC Co., Ltd.

Headquarter

- LS-ro 127(Hogye-dong) Dongan-gu, Anyang-si, Gyeonggi-Do, 14119, Korea Seoul Office
- LS Yongsan Tower, 92, Hangang-daero, Yongsan-gu, Seoul, 04386, Korea Tel: 82-2-2034-4033, 4888, 4703 Fax: 82-2-2034-4588 E-mail: <u>automation@ls-electric.com</u>

#### Overseas Subsidiaries

- LS ELECTRIC Japan Co., Ltd. (Tokyo, Japan) Tel: 81-3-6268-8241 E-Mail: japan@ls-electric.com
- LS ELECTRIC (Dalian) Co., Ltd. (Dalian, China) Tel: 86-411-8730-6495 E-Mail: china.dalian@lselectric.com.cn
- LS ELECTRIC (Wuxi) Co., Ltd. (Wuxi, China) Tel: 86-510-6851-6666 E-Mail: china.wuxi@lselectric.com.cn
- LS ELECTRIC Middle East FZE (Dubai, U.A.E.) Tel: 971-4-886-5360 E-Mail: middleeast@ls-electric.com
- LS ELECTRIC Europe B.V. (Hoofddorp, Netherlands)
- Tel: 31-20-654-1424 E-Mail: europartner@ls-electric.com
  LS ELECTRIC America Inc. (Chicago, USA)
- Tel: 1-800-891-2941 E-Mail: sales.us@lselectricamerica.com • LS ELECTRIC Turkey Co., Ltd.
  - Tel: 90-212-806-1225 E-Mail: turkey@ls-electric.com

- Overseas Branches
- LS ELECTRIC Tokyo Office (Japan)
- Tel: 81-3-6268-8241 E-Mail: tokyo@ls-electric.com
  LS ELECTRIC Beijing Office (China)
- Tel: 86-10-5095-1631 E-Mail: china.auto@lselectric.com.cn
  LS ELECTRIC Shanghai Office (China)
- Tel: 86-21-5237-9977 E-Mail: <u>china.auto@lselectric.com.cn</u> • LS ELECTRIC Guangzhou Office (China)
- Tel: 86-20-3818-2883 E-Mail: china.auto@lselectric.com.cn • LS ELECTRIC Chengdu Office (China)
- Tel: 86-28-8670-3201 E-Mail: china.auto@lselectric.com.cn
- LS ELECTRIC Qingdao Office (China) Tel: 86-532-8501-2065 E-Mail: china.auto@lselectric.com.cn
- LS ELECTRIC Nanjing Office (China) Tel: 86-25-8467-0005 E-Mail: china.auto@lselectric.com.cn
- LS ELECTRIC Bangkok Office (Thailand) Tel: 66-90-950-9683 E-Mail: thailand@ls-electric.com
- LS ELECTRIC Jakarta Office (Indonesia)
- Tel: 62-21-2933-7614 E-Mail: indonesia@ls-electric.com
  LS ELECTRIC Moscow Office (Russia)
  - Tel: 7-499-682-6130 E-Mail: info@lselectric-ru.com
- LS ELECTRIC America Western Office (Irvine, USA)
  - Tel: 1-949-333-3140 E-Mail: america@ls-electric.com

#### Disclaimer of Liability

LS ELECTRIC has reviewed the information in this publication to ensure consistency with the hardware and software described. However, LS ELECTRIC cannot guarantee full consistency, nor be responsible for any damages or compensation, since variance cannot be precluded entirely. Please check again the version of this publication before you use the product. © LS ELECTRIC Co., Ltd 2015 All Right Reserved.