# COMMUNICATIONS



# P3-550 Retired 06/2023

n This Chapter	
Communications: Capabilities	6-3
Communications: Ethernet	6-4
Communications: Remote I/O	6-5
Communications: GS Drive Devices	6-6
Communications (cont'd)	6-7
Communications: Modbus RTU	6-8
Communications: Modbus RTU	6-9
Communications: Modbus RTU	
Communications: Custom Protocol In and Out	6-11
Communications: Connectivity	6-12
Communications: Ethernet Port	6-13
Communications: Remote I/O Ethernet Port	6-14
Communications: USB OUT Port	6-15
Communications: USB OUT Port	6-16
Communications: RS-232 Port	6-17
Communications: RS-485 Port	6-18
Communications ASCII and Custom Protocol Functionality	6-19
Communications: Ethernet	6-22
Communications Modbus Functionality	6-26
EtherNet/IP for the Productivity Series	6-41
Communications: Remote I/O and GS-Drives	6-56
Communications: Port Configuration	6-64
Communications: Port Configuration	6-65

Communications: Port Configuration	.6-66
Remote Access Configuration	. 6-67
Communications: Error Codes	.6-72
P3000 EtherNet/IP Error Codes	.6-73

## **Communications: Capabilities**

### **Communication Ports**

The AutomationDirect P3000 CPUs are provided with several Communications Ports. Each of these ports are described in the sections below.



(a) USB IN: The USB IN programming port is a USB Type B style connector located on the upper left side of the CPU. It is used exclusively for connecting to a PC running the Productivity Suite Programming Software. Installing the programming software will install the USB driver as well. See Communications: Connectivity section for connection information.



NOTE: The USB IN port is NOT compatible with 1.0/1.1 full speed USB devices.

### **Communications: Ethernet**

- (b) Ethernet: The Ethernet port is 10/100 Base-T Ethernet with an RJ-45 style connector. It is used for:
  - Connection to a PC running the Productivity Suite programming software.
  - Modbus TCP Client connections (Modbus requests sent from the CPU).
  - Modbus TCP Server connections (Modbus requests received by the CPU).
  - Outgoing Email.
  - Modbus TCP Client connections: The CPU can connect to 32 Modbus TCP server devices concurrently by means of communications instructions in the ladder program (MRX, MWX, RX, WX). It is possible to connect to more than 32 Modbus TCP server devices, but not concurrently.
  - This is accomplished by having communications instructions for more than 32 devices in the ladder program and controlling the enabling and disabling of the instructions so that only 32 devices are enabled at a given time. To connect to non Productivity3000<sup>®</sup> devices, use the MRX (Modbus Read) and MWX (Modbus Write) instructions. To connect to other P3000 CPU's, use the RX (Network Read) and WX (Network Write) instructions.

#### Modbus TCP Client (MRX-MWX)

#### Modbus TCP Client (RX-WX)



 The greatest difference between the RX and the MRX is the RX Tag Name in the target CPU can be referenced directly and does not need a corresponding Modbus address. The way this is accomplished is by mapping local and remote tagnames together within the local CPU's RX instruction. Once the instruction is set up to read a remote project, the "Tags of Remote Project" or "Array Tags of Remote Project" drop down lists will be accessible. Map the Tag of the Remote project to a Tag in the Local project to read this data.

### **Communications: Remote I/O**

 Modbus TCP Server connections: The CPU can serve data back to 32 Modbus TCP Client devices concurrently. If 32 Modbus TCP Client devices are connected to the CPU, then any new TCP connection requests will be denied until one of the existing 32 devices drops its connection. If the Client device connecting to the CPU is not a Productivity3000<sup>®</sup> device, then a Modbus address must be assigned to the tag that is being requested. This is done in the Tag Database window. If the device connecting to the CPU is another P3000 CPU or C-more panel, no Modbus address is required. See Communications Port Configuration for port configuration, Communications: Connectivity section for connection information and Communications: Ethernet section for Ethernet set up.



#### **Remote I/O Slaves**

Remote I/O: The Remote I/O port is 10/100Base-T Ethernet with an RJ-45 style connector. It is used for connecting to a Remote I/O network consisting of P3-RS or P3-RX Remote Slaves and/or PS-AMC modules and/or GS Drives.

1	~	 - 1	i
	-	 - 1	
/		=1	l
/		_	l
_	-	_	

**NOTE:** GS Drives require an additional communication module (GS-EDRV100 for GS 1, 2 and 3 series) or Modbus TCP communications card (for GS4 and GS20 series) to communicate on the Productivity remote network.

 Remote Slaves: The P3-550(E) and P3-550E CPUs can connect with up to 16 P3-RS/RX Remote Slaves and 4 PS-AMC modules. The P3-550(E)/E will auto detect all remote units that are configured with unique station addresses (by means of two rotary switches on the front of the module). The configuration can be managed in the Hardware Configuration in the Productivity Suite Programming Software. See *Communications Remote I/O and GS Drives* for configuration information and *Communications: Connectivity* section for connection information.

# **Communications: GS Drive Devices**

GS Drive Devices: The P3-550(E) CPU can connect to up to 32 GS Drive communication modules/cards. The P3-550(E) will auto detect all GS Drive communication modules/ cards that have a unique address (configured by the bank of dipswitches on the module). The configuration can be managed in the Hardware Configuration in the Productivity Suite programming software. See Communications: Remote I/O and GS Drives section for configuration information and Communications: Connectivity section for connection information.

USB OUT: The USB OUT data port is the upper port of two USB 2.0 Type A connectors on the CPU. The USB OUT port uses a SDCZ4-2048-A10 Pen Drive (may work with other pen drives) for

data logging only in the P3-530 or for data logging and project transfers in the P3-550(E).

**NOTE:** The USB OUT port is NOT compatible with 1.0/1.1 full speed USB devices.

A	<del>33333</del>
	=
L	$\equiv$

- Project Transfer (P3-550(E) only): For security, this feature is disabled by default when creating a new project. It can be enabled in the Hardware Configuration panel for the P3-550(E). Once enabled, projects may be transferred between a CPU and Removable Storage Device, or between a Removable Storage Device and PC. Files stored on the Removable Storage Device by a P3-550(E) or the Productivity Suite programming software are stored under a default name, so only one project may be handled at a time on a Removable Storage Device. Existing projects on the Removable Storage Device will be overwritten without a prompt.
- Data Logging: The Data Logger tool allows setup of periodic or eventbased data logging of tag and System Errors to the Removable Storage Drive. Data Logger setup is accessed under the Monitor & Debug Menu. See Communications: Connectivity section for more information.



Remote GS1 (GS-EDRV100)

#### **USB Removable Storage Drive**



# Communications (cont'd)

EXP I/O OUT: The Expansion I/O port is the lower port of two USB 2.0 Type A connectors on the CPU. The EXP I/O Out port is only used for connections to local P3-EX modules in a Productivity3000<sup>®</sup> base with I/O. Expansion I/O is treated as local I/O by the CPU and is completely scan synchronous.

Except that PS-AMC modules run asynchronously with respect to the ladder scan, so AMC status bits should be used for interlocking logic if necessary.

The I/O is automatically detected on power up.



CAUTION: This port is ONLY for Expansion I/O. The signal pins on this port are NOT standard USB. DO NOT USE A USB REPEATER TO EXTEND THE RANGE OF THIS PORT. See Communications Connectivity for more information.

RS-232: The RS-232 port is an RJ-12 connector located on the right side of the CPU. This port can be used for:

- Modbus RTU Master connections.
- Modbus RTU Slave connections.
- ASCII Incoming and Outgoing communications.
- Custom Protocol Incoming and Outgoing communications.

Modbus RTU Master connections: The RS-232 port is intended to be used for point-to-point connections but it is possible to connect up to 128 devices on a network if a RS-232 to RS-485/422 converter is connected to the port (such as a FA-ISOCON). This is accomplished by using the communications instructions in the ladder project (MRX, MWX, RX, WX). If 4-wire RS-485 or RS-422 communications is needed, using this port with an FA-ISOCON is the best method. See Communications: Connectivity section for more information.

#### **P3-EX Expansion Network**





# **Communications: Modbus RTU**

Modbus RTU Slave connections: The RS-232 port is intended to be used for point-to-point connections but it is possible for the RS-232 port to be used on a Modbus RTU network by using a RS-232 to RS-485/422 converter. The port is addressable in the Hardware Configuration in the Productivity Suite programming software. It is important to note that the RS-232 port cannot be a Modbus RTU master and slave concurrently. If the port is set to Modbus RTU and there are no communications instructions (MRX, MWX, RX, WX) in the project, the CPU will automatically respond to Modbus requests from a Modbus master. See Communications: Connectivity section for more information.



**RS-232 ASCII In Communication** 

RS-232 Modbus RTU Slave Network Topology

ASCII Incoming and Outgoing communications: The RS-232 port can be used for sending and receiving non-sequenced String data. This feature is typically used for receiving bar code strings from a scanner or sending statistical data to a terminal or serial printer using the ASCII IN and ASCII OUT instructions. See Communications: Connectivity section for more information.



6-8 Productivity<sub>3000</sub>, Hardware User Manual, 4th Edition, Rev. V

**RS-232 ASCII In Communication** 

### **Communications: Modbus RTU**

Custom Protocol Incoming and Outgoing communications: The RS-232 port can be used for sending and receiving non-sequenced byte arrays to various devices. This function is typically used for communicating with devices that don't support the Modbus protocol but have another serial communications protocol. This is accomplished by using the Custom Protocol In and Custom Protocol Out instructions. The RS-232 port is intended to be used for point-topoint connections but it is possible for the RS-232 port to be used on a multi-node network by using a RS-232 to RS-485/422 converter. See Communications: Connectivity for more information.

**RS-232 Custom Protocol In and Out** 



- RS-485: The RS-485 port is a 3-pin removable terminal block. The RS-485 port can be used for:
  - Modbus RTU Master connections.
  - Modbus RTU Slave connections.
  - ASCII Incoming and Outgoing communications.
  - Custom Protocol Incoming and Outgoing communications.

Modbus RTU Master connections: The RS-485 network port is used for multi-node networks. The CPU can connect to 128 Modbus RTU slave devices on a network. This is accomplished by using the communications instructions in the ladder project (MRX, MWX, RX, WX). See Communications: Connectivity section or more information.

#### RS-485 Modbus RTU Master Network Topology



# **Communications: Modbus RTU**

Modbus RTU Slave connections: The RS-485 network port is used for multi-node networks. The port is addressable in the Hardware Configuration in the Productivity Suite programming software. If the port is set to Modbus RTU and there are no communications instructions (MRX, MWX, RX, WX) in the project, the CPU will automatically respond to Modbus requests from a Modbus master. See Communications Connectivity for more information.



 ASCII Incoming and Outgoing communications: The RS-485 port can be used for sending and receiving non-sequenced String data. If long distances are required between the ASCII device and the CPU, the RS-485 port is the better selection because of its increased distance support (1,000 meters). ASCII communications are typically used for receiving bar code strings from a scanner or sending statistical data to a terminal or serial printer using the ASCII IN and ASCII OUT instructions. See Communications: Connectivity section for more information.



#### **RS-485 ASCII In Communication**

#### **RS-485 ASCII Out Communication**

### **Communications: Custom Protocol In and Out**

Custom Protocol Incoming and Outgoing communications: The RS-485 port can be used for sending and receiving non-sequenced byte arrays to various devices. This function is typically used for communicating with devices that don't support the Modbus protocol but have another serial communications protocol. If long distances are required between the device and the CPU, the RS-485 port is the better selection because of its increased distance support (1,000 meters). This feature is accomplished by using the Custom Protocol In and Custom Protocol Out instructions. See Communications: Connectivity section for more information.



#### **RS-485 Custom Protocol In and Out**

# **Communications: Connectivity**

### **Communication Ports**

The AutomationDirect P3000 CPUs are designed with several Communications Ports, seven communications ports on the P3-550, six on P3-550E, and five communications ports on the P3-530. The connectivity for each of these ports is described in the sections below. The Communication Ports available are:

> (a) USB IN Port (P3-550 only): Programming port with a USB Type B female connector.





 This port requires a USB Type A-B cable (such as the P3-EX-CBL6 cable).



The USB Port is the simplest method of connecting the Productivity Suite programming software to the P3-550 CPU.

-45 2040

After the programming software has been installed, connect a USB

A to B cable from the PC to the CPU. Once the software has been opened, click on CPU and select the "Choose CPU" option. The dialog shown below will appear.

Highlight the CPU listed in the dialog box and click on "Connect". No configuration is required.

Servers Server and the Autput matters on ON	Attlarecter
No. No. P. Constanting Strengther	All Consultant
Several Rest Plan States, Structure	Losse ( secondaria
	. Aust Langton
	East Generative
	Start Stating STU (halter
	The Being Chubeler
	Drange DRU 19 Jacober



NOTE: The USB IN port is NOT compatible with older 1.0/1.1 full speed USB devices.

### **Communications: Ethernet Port**

Ethernet Port: Programming and Modbus TCP Client/Server port with 10/100 Base-T Ethernet RJ45 connector.



General Information:

- Crossover cables can be used to directly connect two endpoint Ethernet devices such as a PC network interface card and the CPU. Patch (or Straightthrough) cables are used to connect an endpoint Ethernet device to an Ethernet switch.
- The maximum distance for one cable or segment is 100 meters (328 feet). If the distance required between 2 devices is greater than 100 meters, add an Ethernet switch to extend the distance. An Ethernet switch can be added every 100 meters (or less) almost indefinitely. Each Ethernet switch added will incur some latency (actual amount differs between switches and manufacturers). So if a very long distance is needed between 2 Ethernet devices, it may be better to convert to fiber optics.
- The External Ethernet Port can be used as a programming port, a Modbus TCP Client port, a Modbus TCP Server port, or to communicate to other P3000 CPUs. The External Ethernet Port can also be used to send emails using the EMAIL instruction.
- Create а Connection: communicate with То Productivity the Suite programming software, connect a crossover Ethernet cable from the PC to the CPU External Ethernet Port or connect a patch (straight-through) Ethernet cable from the PC to an Ethernet switch and another patch cable from the Ethernet switch to the External Ethernet

seath Device was to the hughest pristeen (PL) (PL	Add Committee
MILE PORT IN SUL PORT INTERNAL AND AND AND	diff frameworks
Real Plan De Die Flant - Million - Annald - I	And Services
	Institute
	Ament Larve tion
	Dist Bridge Officiality
	The Berry Distriction
	Deep-DM Pyhere

Port. Once the software has been opened, click on CPU and select the "Choose CPU" option. The dialog shown below will appear.

# **Communications: Remote I/O Ethernet Port**

 Highlight the CPU that you wish to connect to and press the "Connect" button. You may see CPUs that are not on the same subnet as your PC within the CPU Connections dialog box, but this does not mean you can connect to them. To connect to the CPU, you must configure either your PC or your CPU to be in the same subnet. You can easily change the Ethernet settings of the CPU by highlighting it and selecting the "Change CPU IP/Name" button (shown below). Or if you prefer, the PC Setup section of this chapter contains information on configuring the Ethernet settings of your PC.



© Remote I/O Ethernet Port (P3-550(E) only): Ethernet RJ45 connector for P3-RS/RX Remote Slave, and/or PS-AMC modules and/or GS Drive with communications modules.



- Crossover cables can be used to directly connect endpoint Ethernet devices and the CPU. For example, connecting a P3-RS or P3-RX Remote Slave Module to the P3-550(E) CPU. Patch (or Straight-through) cables are used to connect an endpoint Ethernet device to an Ethernet switch.
- The maximum distance for one cable or segment is 100 meters (328 feet). If the distance required between 2 devices is greater than 100 meters, add an Ethernet switch to extend the distance. An Ethernet switch can be added every 100 meters (or less) almost indefinitely. Each Ethernet switch added will incur some latency (actual amount differs between switches and manufacturers). So if a very long distance is needed between 2 Ethernet devices, it may be better to convert to fiber optics.
- The Remote I/O Ethernet Port is used to communicate to the Remote I/O Network, consisting of Remote Slave bases (P3-RS/RX modules), PS-AMC modules, and GS Drives (with an additional Modbus TCP communications module/card). It is highly recommended that the network attached to this port be isolated from other networks and it is absolutely necessary that it be isolated from other Remote I/O networks. See Remote I/O and GS Drives topic for details.

# **Communications: USB OUT Port**



NOTE: USB Project Transfers are NOT supported by the P3-530 CPU.

USB OUT Port: USB Port for Data logging or project transfer with USB 2.0 Type A connector.

 This Port serves two purposes: Data logging with the P3-530 or data logging and project transfers with the P3-550(E), require a SDCZ4-2048-A10 Removable Storage Device (may work with other pen drives).



iva:	Siyw
4	- 45
2	-Data
1	+0469
4	OHD .



**NOTE:** The USB OUT port is NOT compatible with older 1.0/1.1 full speed USB devices.

- Data logging is set up in the Productivity Suite Programming Software Data Logger configuration window. See Data Logger Memory section of the previous chapter for setup instructions.
- Project Transfer to and from a USB drive can be accomplished several different ways:
- Transfer project to USB Drive from PC programming software.

Bittod bitton & Derritor Cherritoria Cheritoria Cherritoria Cherritoria Cherritoria Cheri	Constant interest to come memory interference, Statistic	n yan Cirila Ayyun (10) Bay Bay Bay Bay Provid A	en Contra an Innan
alaanaa ja viit	Tagratan Tarrag		

- Transfer project from USB Drive to PC programming software.
- Transfer project from USB Drive to P3-550(E) CPU.
- Transfer project from P3-550(E) CPU to USB Drive.



**NOTE:** You must first select the "Enable project transfer to/from USB drive" checkbox in the P3-550(E) CPU Module Configuration.



**NOTE:** Before transferring a project to the CPU via USB pen drive, ensure that you are NOT connected with the programming software either by USB or Ethernet. If you attempt the transfer with the software connected via USB or Ethernet, a PACCON Error will appear on the LCD of the P3-550(E).

# **Communications: USB OUT Port**

- To transfer a project to or from a USB Drive from the PC programming software, insert the USB Drive into a USB Port on the PC. Go to File and Transfer Project and select *To USB Drive* or From USB Drive.
- To transfer a project to or from a USB Drive on the P3-550(E) CPU, press Menu on the CPU display LCD and scroll down to the M8USB DRV option as seen on right.
- Select ">SAVE->PEN" to load the project that is currently on the CPU down to the connected USB Drive.
- Select ">LOAD->CPU" to load the project that is currently on the USB Drive to the CPU.

() Expansion I/O OUT Port: Expansion I/O Port with USB 2.0 Type A connector.











CAUTION: THE EXPANSION I/O PORT IS ONLY FOR CONNECTING TO OTHER PRODUCTIVITY3000® I/O BASES WITH A P3-EX MODULE IN THE CPU SLOT. THIS PORT IS NOT A STANDARD USB A PORT. NOTE THAT IN THE DIAGRAM ABOVE, PIN 1 IS USED FOR THE SYSTEM RESET SIGNAL AND IS NOT THE TYPICAL +5VDC VBUS SIGNAL ON MOST USB A PORTS. DO NOT USE EXTENDERS, CONVERTERS OR HUBS OF ANY SORT ON THIS PORT. A P3-EX-CBL6 cable ships with each P3-EX Module. It is not recommended to use any cable other than the one supplied.

 After this connection is made, power cycle the system and the CPU will automatically detect the expansion I/O units. They can be used once the Hardware Configuration has been read into the programming software. Up to 4 expansion I/O bases may be added to a CPU.

## **Communications: RS-232 Port**

(f) RS-232 Port: Serial RS-232 multipurpose communications port with RJ12 connector.



- The RS-232 Port can be connected to Modbus RTU master or slave devices, as well as devices that output non-sequenced ASCII strings or characters. The manner in which these devices are wired to the CPU depends whether the device is considered to be DTE (Data Terminal Equipment) or DCE (Data Communications Equipment).
- If two DTE devices are connected together, the RX and TX signals should cross or the RX of one device should go to the TX of the other device and the TX of one device should go to the RX of the other device (as shown below).



- The CPU is considered a DTE device. Most Modbus or ASCII devices being connected to the CPU will also be considered a DTE device and will need to swap TX and RX, but you should always consult the documentation of that device to verify. If a communication device, such as a Modem, is placed between the CPU and another Modbus or ASCII device it will most likely require connecting the signals straight across (TX to TX and RX to RX). Again, this can differ from manufacturer to manufacturer so always consult the documentation before wiring the devices together.
- The RTS signal on pin 5 of the RS-232 Port will turn on when the TX signal is turned on and the RTS signal will turn off when the TX signal turns off. The amount of time that the RTS signal turns on before the TX signal turns on and the amount of time that the RTS signal waits before turning off after the TX signal turns off is adjustable in the P3-550(E) or P3-530 CPU Module Configuration for the RS-232 Port. The RTS signal is very often required for media converters, such as a RS-232 to RS-422/485 converter (much like the FA-ISOCON).
- The RTS signal is sometimes required for use with Radio modems as well (Key on and off control).
- There is also +5VDC @ 210mA on pin 2 available for powering an external device such as the C-more Micro panel.

### **Communications: RS-485 Port**

Image: Image:



- The RS-485 Port is useful for connecting multiple Modbus and ASCII devices on one network and/or connecting devices to the CPU at distances greater than 50 feet (RS-232 limit). The RS-485 standard supports distances of up to 1000 meters without requiring a repeater. The RS-485 Port on the CPU can support up to 50 devices, depending on each device's load (this assumes a 19K Ohm load for each device). This number can be increased by placing an RS-485 repeater on the network, if necessary.
- This port only supports RS-485 2-wire connections. For 4-wire RS-485 or RS-422, a converter, such as an FA-ISOCON, should be used with the RS-232 Port.



• A 120 Ohm resistor is required at each end of the network for termination.

# **Communications ASCII and Custom Protocol Functionality**

Besides Modbus RTU, there are two additional functions supported on the serial ports in the Productivity3000<sup>®</sup> system.

- The first function is the ability to send and receive text-based data with devices such as bar code readers and serial printers.
- The second function is the ability to communicate serially with other devices that do not support the Modbus protocol and lack a Productivity3000 driver.

#### **ASCII Instructions**

The ASCII In/Out instructions use the String data type to send or receive text-based data through the serial port. The String data type is only intended for use with the "printable character set". This can include numbers, letters or special characters.

> With the ASCII In instruction, the CPU can receive a fixed length of characters or a variable length of characters with a termination code (an 'end of message' character).

RXET HAN		and a
Send Part Int AGE Send Part (undpred +	Seatestan	• 🗐
a huliash	Ranber of actes Received	• 🗐
Number of Characters 8	b Pogen	• 🖃
O lander langth	Circulate	
B 10este	Scient	• 64
() 10 estim	Proj Character	• 50
Transmon Calle 2, Inc. 8	(Her Character	- 10
Red Danation D (8 + Nord)	Deter	• 53
Inter Danaster Telenut Intervisi Interci D. (B. n. hana)		
Ann Long Links at the links long		
O Al Devices		
Convertibilit to be 20		
C Den Jedra Bon Cannett		
Bashr	DK Dec	

 The ASCII Out instruction sends text-based data out of the serial port to various devices for control, printing or display.

CO OVA IN	avn		-
Interior	Re. ALC: Smither Configures   +	p.hagaan	
1141	+ -	Complete	• 6
	In Termator     Internation     Internation     Tormation     Termation Label 1 Int     Termation Label 2 Int     Termation Label 2 Int     Termation Label 2 Int     Termation		
	Nyle Sons Spliter (K. Nyle Song (*) Al Sharaches (*) Al Naciol Sha	racters	
	Education [10] and	URL.	
E Per	Instruction Comment		
C Hands			

#### Full duplex Mode (P3-550(E)/530)

- 1. RS232 can be set to FulDuplex node. Half Duplex is selected by default. This cna be changed in the Hardware Configuration window for the CPU serial port.
- 2. AIN and AOUT instructions may be enabled at the same time.
- 3. AOUT may be enabled while AIN is already active, and vice versa.
- 4. The user may control treatment of buffered data before AIN is enabled using the checkbox mentioned above.
- 5. RTS mode must be either always on or always off. Assert during transmit is not available.

#### Half duplex Mode [default] (P3-550(E)/530)

The ASCII instruction limitations are that it is not advisable to use the ASCII Out instruction to send a String to a device that will respond (if the response is needed) and to use the ASCII IN (AIN) instruction to try to receive this data.

- 1. AIN and AOUT cannot be enabled at the same time on the same serial port.
- 2. When the AOUT completes, the AIN cannot be enabled until the next logic scan.
- 3. The user may control treatment of buffered data before AIN is enabled using the checkbox mentioned above.

#### **Custom Protocol Instructions**

The Custom Protocol is a HEX based protocol used to communicate with devices that do not have the standard Modbus RTU Protocol. There are two instructions used with Custom Protocol communication:

rotocol communication:

- Custom Protocol Out (CPO)
- Custom Protocol In (CPI)

#### **Custom Protocol Out**

The Custom Protocol Out instruction allows the user to send a 'byte formatted' packet of data out of the CPU serial port.

Constant values and/or Tag values can be used as the source for data transmitted. There are several formatting options including Byte Swap and Checksum.

votee Protect Dut (CPO)		100
terathet <u>An ACC beathet Configurat</u>		
Cflui Leigh Der 1 0 1 0 1 0 1 0 1 0 1 0 1 0 1 0	n bihayaa Conglean	:8
anter a construction of the second se		
Delastes ter Dis	-1 -1	
Nachrie ⊕ National Class Mation Class Mation	Coloring (4 actes Chickeye (5 514	
a ha terteratur O kDenster		
Termine Cold 3: In Termine Cold 3: In Termine Cold 7: In		
These betraches Connect	a Cen	

The Checksum option allows the user to select where in the packet the checksum should be inserted, what type of Checksum (CRC-8 bit, CRC-16 bit, CRC-32 bit, XOR-8 bit, XOR-16 bit and XOR 32 bit), which bytes of the data source should be used in the calculation of the checksum, what the byte order should be of the checksum (if greater than 8 bit) and how to preload the checksum calculation.

If the device requires a different Checksum calculation, this can be done outside of the instruction in other ladder code and the resulting Tag values can be inserted where appropriate in the packet.

Termination characters can also be specified when needed.

The Custom Protocol Out instruction is for transmission only. If information needs to be received from field devices, the Custom Protocol In instruction will have to be used. Unlike ASCII, the Custom Protocol will buffer the received data. When the Custom Protocol In instruction is executed, it will retrieve any data held in this buffer. Therefore, the lost responses found with ASCII communication do not occur with Custom Protocol communication.

#### **Custom Protocol In**

The Custom Protocol In instruction has similar formatting options to the Custom Protocol Out instruction.

The Custom Protocol In instruction will calculate the Checksum of the data packet received based on the criteria specified in the instruction and this will determine the state of the status bits assigned to the instruction. If the Checksum calculation passes based on the criteria specified in the instruction, the "Success" status bit will become true. If the Checksum calculation fails, the "Checksum Error" status bit will become true.

With the CPI instruction, the packet termination must be specified, either in terms of a termination character(s) or a packet length. If a Checksum is expected in the reply, be sure to include this in the Fixed Length value specified.

unon hotootle CM		-
Serie Port (he AGE) Serie Port Configuration		
Offset Langth Data	3: Paper	• 6
3 3	t Gruke	• 6
8 8	Second.	• 5
	Cedar Inv	• 6
	Reddaute	
2 2	The Caster	
1 5 5	Tarkit	- 60
2 R	+ Defer	· 10
themperior to define [1] Box Date (§ 1941 com (7 com 1949 [] Ondoor Polaci (Elicita + 19)	Omborn Tempt (2) Al (matters (: Bohn Temper (2n) 1, )	0
a feetungt . Anter of character	a interester	a la terret
Contempt metalecities	* Star Character	1.0.0
in 175e and	Press overval (new)	
the second se		
Secondard 1.1	w 4	
Data Trakethin Conned		

# **Communications: Ethernet**

#### TCP and UDP Port Numbers

When doing TCP/IP and UDP/IP communications, there is a Source Port number and Destination Port number for every message. The Client device must be aware of the Destination Port Number(s) that the Server device is expecting to see and the Server device must listen for this Destination Port number. After the Server device has received the message with the Destination Port Number that it is listening on, it will formulate the return message (if the applications require this) with the Source Port Number from the message sent as its Destination Port Number.

It is important to understand a little about the Port numbering concept because many Ethernet devices, such as routers with firewalls, will block messages with Destination Port numbers that are not configured for that device. Listed below are the default Port Numbers used in the Productivity3000® system. Some of these are configurable, allowing more flexibility when going through routers in many applications.

Port	Port Number (Decimal Format)	TCP or UDP	Configurable
Programming Software CPU Discovery	8888	UDP	No
Programming Software Connection and Project Transfer	9999	UDP	No
Modbus Client Connections (MRX, MWX, RX and WX instructions)	502	ТСР	Yes
Modbus Server Connections	502	TCP	Yes
GS-Drive Discovery	28784	UDP	No
GS-Drive Connection	502	TCP	No
Remote I/O Discovery	8887	UDP	No
Remote I/O Connection	8877	UDP	No
Email Instruction	25	TCP	No
Ethernet IP	44818	TCP	Yes
Ethernet IP	2222	UDP	No*
* Adapters may choose to respond using	another port number.		

### **IP Addressing and Subnetting**

IP Addresses (used in conjunction with the Subnet Mask and Default Gateway address) are used for network routing. This allows for easy and logical separation of networks.

It is outside of the scope of this help file to explain how IP Addresses and Subnet masks are configured for actual usage. There are many books, documents and tools (Subnet calculators) on the internet that provide this information. Each facility and network will incorporate their own rules and guidelines for how their networks are to be configured.

### PC Setup

For testing and verification purpose, it is recommended that the PC and the CPU be on an isolated Ethernet switch. Configure the PC's network interface card setting as described below.

 Go to Start, then Run, type ncpa.cpl in the Open field and click on OK to bring up the Network Connections dialog.

-	ate and the loss	off ones it for one	and, or biller and
	call and mentioned	the other s of him	
Daveni roq	reicpi		



**NOTE:** Many system settings on your computer require Administrative privileges. Consult with your IT department for necessary privileges and approvals.



NOTE: You should record initial settings prior to making any network configuration changes.

- 2. Network Connections
  - (a) Right click on the Network interface shown in the Network Connections dialog and select Properties. If there is more than one Network Interface on the PC, be sure to choose the one connected to the Ethernet Switch with the CPU on it.
  - From the Local Area Connection Properties window, highlight the Internet Protocol(TCP/IP) selection and click on Properties.



- 3. Internet Protocol (TCP/IP) Properties.
  - In the Properties window, select Use the following IP address.
  - b Enter an IP Address of 192.168.1.1 and Subnet Mask 255.255.255.0 and select OK. Select OK again on the Local Area Connection Properties window.

denet Professil Version # (70	2/2v8 Papenes
General	
To on pri 7 setting and the costsity. Otherway, sh for the appropriate 7 setting	ed autometically if your metwork supports a most to ask your network administrator a
C Dian a P alles as	towartially.
a ite the following P add	THE .
F aldens	O 101-101-1-1
Subret sushi	100 . 100 . 100 . A
Diefact (planny:	
C Orian Distancia sale	eel automaticate
· Ite the following Drd se	etues adalesses.
Preferred DRG services	34.1 M.S.M.
Alternate DNG servers	
Thiddle withings come	Abarel.
	OK Canoel

### **CPU Setup**

Now configure the CPU's network IP setting as shown below.

- 1. Select CPU from the Productivity3000<sup>®</sup> software Main Menu and then select Choose CPU from the drop down menu.
- 2. The CPU Connections window will open as shown below.

Convectiv D	Denke	NAC ID	User Assigned	IP Address	(P)	OU	Add Connection
68 2.0 P	1-550	00 50 c	P3-558	172.30.58	A.to	Avaiable	Edit Coinection
therest P	2-530	00.000	P7-33	172.30.58.,-	A/D	Autor	Delete Convectorio
							Import Connections
							- Export Convectors
							Start filming CPU Daplay
							Stop Sinting CPU Display
						- 1	Change CPU

- (a) Click to highlight the CPU connected to the Ethernet switch.
- (b) Select the "Change CPU IP/Name" button.
- 3. The Change IP Address/CPU Name window will open as shown below.
  - Enter an IP Address of 192.168.1.2 and Subnet Mask 255.255.0.0 for the CPU's network IP setting and select OK.

Assign the	following IP to CPU
Obtain Addres	a From DHCP
IP Address	198.168.1.2
Subnet Mask	255.255.0.0
Default Gateway	0.0.0.0
CPU Name	P3-550

The CPU is now configured with the correct IP Address for connectivity with the PC. The IP Address and Subnet Mask settings will very likely differ from what will be used in the actual application. Consult the Network Administrator of the facility where the CPU will be installed to get the appropriate settings for that network.

#### TCP Connection Behavior with Modbus TCP and Network Instructions

When performing communications over TCP, a Connection must be established before the applications can transfer data. The connection is typically maintained until the application decides that the connection is no longer needed and then the connection will be severed. Frequent connects and disconnects are not efficient for the Client or the Server and can add unnecessary network traffic. But maintaining connections needlessly is also costly to the Client and Server in terms of processing and memory so this should also be avoided.

The CPU allows user control of Client connections through enabling and disabling the rungs containing Modbus and Network instructions. The MRX, MWX, RX and WX instructions have two options for sending messages: Automatic Poll and Manual Poll.

Automatic Poll sends out messages at a specified rate. Enabling the instruction performs a TCP connect with the Server device. Once the connection is established, the instruction messages are sent at the rate entered in the poll rate field. This continues until the instruction is disabled. The TCP connection will automatically be severed five seconds after the instruction is disabled.

Manual Poll sends out a message each time the instruction is enabled. Enabling the instruction performs a TCP connect with the Server device and sends the message one time. The TCP connection will automatically be severed five seconds after receiving the reply from the Server device. If the instruction gets another positive edge enable within the five seconds, the message will be sent and the disconnect of the TCP connection will be delayed by an additional five seconds.

# **Communications Modbus Functionality**

### Master/Client Function Code and Data Type Support

The following table lists the Modbus data type, the function code and the CPU source data type that is supported when the CPU is the Client or Master on a Modbus TCP or serial connection.

### Modbus Client/Master Support (Using MRX and MWX Instructions)

	g min and			
Function Code	Function Name	Modbus 984 Addressing (Zero Based)	Modbus 984 Addressing	Productivity3000® Tag Types (Data designation or source)
				Discrete Output (DO)
01	Read Coil Status	000000 - 065535	000001 - 065536	Boolean (C )
				Boolean System (SBRW)
				Discrete Input (DI)
02	02 Read Coil Status	100000 - 165535	100001 - 165536	Boolean (C )
				Boolean System (SBRW)
				Integer 8 bit Unsigned (U8)
	Read Holding			Integer 16 bit (S16)
				Integer 16 bit Unsigned (U16)
02		400000 465525	400001 465526	Integer 16 bit BCD (B16)
Registers	400000 - 403535	400001-403550	Integer 32 bit (S32)	
				Integer 32 bit BCD (B32)
				Integer 32 bit Float (F32)
				Integer 16 bit System (SWRW)
				Integer 8 bit Unsigned (U8)
	Read Input	000000 005505	300001 -365536	Integer 16 bit (S16)
				Integer 16 bit Unsigned (U16)
				Integer 16 bit BCD (B16)
04	Registers	300000 - 365535		Integer 32 bit (S32)
				Integer 32 bit BCD (B32)
				Integer 32 bit Float (F32)
				Integer 16 bit System (SWRW)
				Discrete Input (DI)
				Discrete Output (DO)
05	Write Single Coil	000000 - 065535	000001 - 065536	Boolean (C )
				Boolean System (SBRW)
				Boolean System Read Only (SBR)

(Usin	(Using MRX and MWX Instructions) (continued)						
Function Code	Function Name	Modbus 984 Addressing (Zero Based)	Modbus 984 Addressing	Productivity3000® Tag Types (Data designation or source)			
				Integer 8 bit Unsigned (U8)			
	06 Write Single Register			Integer 16 bit (S16)			
				Integer 16 bit Unsigned (U16)			
				Integer 16 bit BCD (B16)			
06		400000 - 465535	400001 - 465536	Integer 32 bit (S32)			
				Integer 32 bit BCD (B32)			
				Integer 32 bit Float (F32)			
				Integer 16 bit System (SWRW)			
				Integer 16 bit System Read Only (SWR)			
	15 Write Multiple Coils	Multiple 000000 - 065535	000001 - 065536	Discrete Input (DI)			
				Discrete Output (DO)			
15				Boolean (C )			
				Boolean System (SBRW)			
				Boolean System Read Only (SBR)			
					Integer 8 bit Unsigned (U8)		
				Integer 16 bit (S16)			
				Integer 16 bit Unsigned (U16)			
				Integer 16 bit BCD (B16)			
16	Registers	400000 - 465535	400001 - 465536	Integer 32 bit (S32)			
	5			Integer 32 bit BCD (B32)			
				Integer 32 bit Float (F32)			
				Integer 16 bit System (SWRW)			
				Integer 16 bit System Read Only (SWR)			

# Modbus Client/Master Support

### Slave/Server Function Code and Data Type Support

The following table lists the Modbus data type, the function code and the CPU source data type that is supported when the CPU is the Server or Slave on a Modbus TCP or serial connection.

Modk	Modbus Server/Slave Support						
Function Code	Function Name	Modbus 984 Addressing	Productivity3000® Tag Types (Data designation or source)				
			Discrete Output (DO)				
01	Read Coil Status	000001 - 065536	Boolean (C )				
			Boolean System (SBRW)				
02	Read Coil Status	100001 - 165536	Discrete Input (DI)				
02		100001 - 100000	Boolean System Read Only (SBR)				
			Integer 8 bit Unsigned (U8)				
			Integer 16 bit (S16)				
			Integer 16 bit Unsigned (U16)				
	03 Read Holding Registers		Integer 16 bit BCD (B16)				
03		400001 - 465536	Integer 32 bit (S32)				
			Integer 32 bit BCD (B32)				
			Integer 32 bit Float (F32)				
			Integer 16 bit System (SWRW)				
			String				
		300001 -365536	Analog Input, Integer 32 bit (AIS32)				
04	Read Input Registers		Analog Input, Float 32 bit (AIF32)				
			Integer 16 bit System Read Only (SWR)				
			Discrete Output (DO)				
05	Write Single Coil	000001 - 065536	Boolean (C)				
			Boolean System (SBRW)				
			Integer 8 bit Unsigned (U8)				
			Integer 16 bit (S16)				
			Integer 16 bit Unsigned (U16)				
			Integer 16 bit BCD (B16)				
06	Write Single Degister	400001 465526	Integer 32 bit (S32)				
00		400001-405550	Integer 32 bit BCD (B32)				
			Integer 32 bit Float (F32)				
			Integer 16 bit System (SWRW)				
			Integer 16 bit System Read Only (SBR)				
			String				
			Discrete Output (DO)				
15	Write Multiple Coils	000001 - 065536	Boolean (C)				
			Boolean System (SBRW)				

Modbus Server/Slave Support (continued)						
Function Code	Function Name	Modbus 984 Addressing	Productivity3000® Tag Types (Data designation or source)			
	16 Write Multiple Registers	400001 - 465536	Integer 8 bit Unsigned (U8)			
			Integer 16 bit (S16)			
			Integer 16 bit Unsigned (U16)			
			Integer 16 bit BCD (B16)			
16			Integer 32 bit (S32)			
10			Integer 32 bit BCD (B32)			
			Integer 32 bit Float (F32)			
			Integer 16 bit System (SWRW)			
			Integer 16 bit System Read Only (SBR)			
			String			

#### Assigning Modbus Addresses to Tags

There are many different data types in the CPU. Because of this, the Modbus addresses need to be mapped to the various tag data types in the CPU.

There are two ways to map Modbus addresses to Tags in the Programming software: 1.) Modbus mapping in Tag Database window; 2.) Modbus mapping when creating Tags.

- 1. Modbus mapping in Tag Database window:
  - There are only two data sizes in the Modbus protocol: bits and words. In the CPU, there are multiple size types, so it is sometimes necessary to map multiple Modbus addresses to a single Tag entity. There are also array data structures in the CPU. When Modbus addresses are mapped to arrays, they will be mapped as a contiguous block of addresses. This is, in fact, the most efficient method to handle Modbus communications.
  - In the Tag Database window, there are two columns named "Mod Start" and "Mod End". To map a Modbus address to a tag in the Tag Database window, simply double-click in the Mod Start field for the Tag.

200-8	Billionele Separa Billionele Culpata	Analog Treats	Eringen E	honen hala 😢	independent on the sector of the		
Recei Prof. In Puo Prof. In Puo Prof. In Puo Prof. Standed Every Collect Scanded Every Scalabel Process Scalabel 1 Thinks Bit 2 Second R	Tare Endean, Sutan, Ras Badara, Sutan, Ras Badara, Sutan, Ras Badara, Sutan, Ras Badara, Sutan, Ras Badara, Sutan, Ras Badara, Sutan, Ras	~	her beeter	a talan Bad Bad	Wellis w_ WI	F. Balta. C.	00000000

When you do this, you will see two values appear in the field. The left most value is the Modbus data type. This is fixed based upon the tag data type. The chart below indicates the four different Modbus data types in the 984 addressing scheme.

Nod Start	Mod End
100001	100001
100003	100003
100002	100002
0000003	000001
000002	000002
000003	000003
000004	000004

Address Identifier	Modbus 984 Address Type
0xxxxx	Coil (Read/Write bit)
1xxxxx	Input (Read Only bit)
Зххххх	Input Register (Read Only 16 bit word)
4xxxxx	Holding Register (Read/Write 16 bit word)

The right most value that you see in the "Mod Start" field is the address offset (range is from 1 – 65535). You can accept the value that is pre-filled for you or the value can be changed. The software automatically pre-fills the address offset with the next available address.

Show Al	Discrete Inputs An	ing Inputs	Inte
Stvert	Discrete Outputs Arv	dog Outputs	Floa
ldtor			
Name	Type.	ModStart	Mod End
MST-0 1.2.1	Module Status Bit	190004	10000
MST-0.1.2.2	Module Status Bit	180005	10000
MST-0.1.2.3	Module Status Bit	310006	10000
MST-0.1.2.4	Module Status Bit	100007	10000
MST-0 1.2.5	Module Status Bit	180008	10003
MST-0.1.2.6	Module Status DI.	180009	10000
MST-0.1.2.7	Module Status Bit	100010	10001
MST-0.1.2.8	Module Status Bit	180011	10001
<b>INCIDEN</b>	Bosiean, System, Read Only	100012	10001
Always Off SR	Boolean, System, Read Only	100014	10001
First Scan Bt	Boolean, System, Read Only	190013	10001
Course Sale on Fred	Burlaux Suday Burd Cal	A DOMESTIC:	10000

- 2 Modbus mapping when creating Tags:
  - Modbus addresses can be assigned to Tags as they are created in the Tag Database.



• Type in the Modbus offset value when entering the Tag Name and Data Type. If the address is already assigned, a warning message will appear.



### **Modbus Options**

The Modbus protocol does not have a specific method outlined for data types outside of bits and 16-bit words. Most systems now have 32-bit data types. In order to transport 32-bit data types across Modbus, they must be placed into two Modbus 16-bit registers. Unfortunately, some devices do not support this and there are sometimes incompatibilities in the order of the 16-bit high word and low word handling between the devices.

In order to help alleviate this situation, there are some options for handling this in the programming software. To find the Modbus Address options, go to File and click on Project Properties and then click on the "Modbus Server Settings" tab.

neral Settions / Holbut Server Settings	
in a list which it is a set of the set	
[2] No exceptor reports for non-existing Moduls at $[2]$ Word scap 12 bit tage	dens requests
Analog Input, Integer, 32 Ist	
Map value to a single 15 bit Modbus register	
<ul> <li>Map value to two consecutive at bit Modbus registr</li> </ul>	ers -
Analog Output, Integer, 32 Bit	
O Hap value to a single 15 bit Hodous register	
# Mig value to two consecutive 35 bit Nodbus regation	
Sninger, 3280	
Map value to a single 16 bit Modive register	
Map value to two consecutive 36 bit Nodbus regists	1
Integer, 12/8r, 10/00 Array	
O Map value to a single 15 bit Modbus register	
· Map value to two consecutive 16 bit Norbus regate	19

(a) No exception response for non-existing Modbus address requests: Because the Modbus addresses can be manually assigned to tags, it is possible that gaps can occur in the Modbus address mapping. For example: Tag1 has Modbus address 400001 assigned to it and Tag 2 has Modbus address 400003 assigned to it.

Fags to show in th	e Editor			
Stow Al	Decrete Inputs	Analog Inp	uls 😨 lite	egers
-	Discrete Outputs	Analogicu	tputs Plan	øs .
Standard .				
3ivert	] =			
ldtor	] -	_	_	
laver.	Туря	Mod Start *	Mod End	1
Invert Idtor Name Tey 1	Type Meger, 100K	Mod Start * 400001	Mod End 400001	-

 Most Modbus Master/Client devices will attempt to optimize their data requests to a Modbus Slave/Server device by requesting blocks of data instead of individual registers. In the case mentioned previously, most Modbus masters would send one read request starting at 400001 and a size of three instead of sending two read requests starting at 400001 with size one and 400003 with size one as shown below.



- In the example shown above on left, a Modbus Slave/Server device should give an exception response since there is no Modbus Address of 400002 in the device. This method can cause a lot of inefficiencies. By selecting the "No exception response for non-existing Modbus address requests" option, the CPU will not give an exception response to the request. Note that if Modbus address 400002 by itself were requested it would give an exception response.
- Word swap option (S-32, AIS-32, AOS-32, F-32, FI-32, FO-32):
  - Word swap allows the word order of 32-bit tags to be changed when sending the values across Modbus. The default selection is on, which returns the data low word first.
  - Tag1 (Integer, 32-Bit) = 305,419,896 (hex = 0x12345678)

     Tag1 Modbus address = 400001, 400002

     Modbus reply for Tag1 (Word Swap ON ) = 01 03 04 56 78 12 34

      $\begin{bmatrix} Low \\ Word \\ First \end{bmatrix}$

Modbus reply for Tag1 (Word Swap OFF) = 01 03 04 12 34 56 78

Image of the standard strain (Image of the standard strain (Image of the strain (Image of

 This option allows for compatibility with devices that do not support 32-bit Modbus functionality. This option can be selected individually for the Analog Input and Output Signed 32 data types and the Internal Signed 32 data types, including the array form of these data types. This function is only useful when the value contained in a 32-bit tag does not exceed a signed 15-bit value (32,765).

Tag1 (Integer, 32-Bit) = 22136 (hex = 0x00005678)

• With "Map value to a single 16 bit Modbus register" turned OFF =

Tag1 Modbus address = 400001, 400002

- Modbus reply for Tag1 (Word Swap ON) = 01 03 04 56 78 00 00
- With "Map value to a single 16 bit Modbus register" turned ON = Tag 1 Modbus address = 400001
- Modbus reply for Tag1 = 01 03 02 56 78

(d) Map value to two consecutive 16-bit Modbus registers: Allows for 32-bit data types to be mapped to two consecutive 16-bit registers. This option is selected as default.

 All of the options in the "Modbus Address" tab of the Project Properties only apply to the Modbus Slave/Server functionality. Similar options are available for the Modbus Master/Client functions as well and are available in the MRX and MWX Modbus instructions.

#### **Modbus Instructions**

To read or set data in other Modbus Slave/Server devices, there are two instructions available in the programming software, Modbus Read and Modbus Write.

- The Modbus Read (MRX) instruction is used to read data from other Modbus devices into Tags of the CPU.
- The MRX instruction can be used for Modbus TCP or Modbus RTU. There are several status bits that can be used to determine whether the read message was successful and if it was not, the reason why.

			_		-
a standard outstand		2-Frag	-		ic
T Address		2 - C22		100	8
in a second second second					j)e
-Great Notes - No.	6202CSI	540	2000		36
slave toda humber 23	6 Defa/1-200				12
Chevelow martin		i - 23			8
a called a local	inher.	100	e	•	jł.
	Section 1	Freedor Street	eon ring		16
Adarek Millig	100 me	pilotier)	2 1000		
Storestan faulte speet	er bat 1	to bell			
The state of the	in Mad O Zen	Bun Desinal Addres Internet Mudhus Ad	period Desired		
The States in 1994	e Nei O dei e	ba Desine Akter Elevet Modus An	origi Desarg		
The 22M see to 31 M	e Ha O let Satist of Le	balleine killer slevel flaba ki	ing ingang		
The Scholar is to be Charles Cair <u>A Beal O</u> Charles Tay New Pacana	e Ho O Je Sector of Lo Te	ha Delina Alber olevel Moha An D []3393			
C Hay 22 M See to 10 He Notice Function Color <u>(Autom) (C</u> C Har Array Tag News Pacatra	e Hol O Jer Santar at ta Tag	ha Delina Alber Genel Yolka Al P (2009)			
© Hee S2 Money to S1 He Notice Function Costr <u>(a-Berni (3</u> ≪) Hee Arrie Fagitiene Placetry	a Ma O Ar Suntar of Ta Ta S	ka Delas Albe Sever Halka Al			
© Hen Statuten in Stine Nockun Function Costr <u>(Außers)</u> © There Arrie Tag Name Placetry	e Mai O Jen Norder of Ta S S S S S S S S S S S S S S S S S S S	ha feind Albe			
C Anny Accelers	a Had C Jen Senter of Ta Santar of Ta Santar of Ta Santar of Ta	ha Polas Alte clean Holas A P (1993)		S. Sul Laire	
C Anny Annehmer	a Mad O Jen Santar of Ta Santar of Ta Santar of Ta Santar of Ta	ba Desine Alber Steel Hodus Ab C (1914)		) fact takes [	
C Anny Annester Cole (Liferation)	an Had Colored Senter of Te Senter of Te Senter of Te	ba Desine Kilter I text Maka Aa a (1994) (1997) (19	erg httareg Links Links d Charakes hurber (htt)	g fact takes [	
C Anny Annumber Control (Linear) C Anny Annumber Control C Anny Annumber Control C Anny Annumber Control C Anny Annumber Control	in Had Color Harder of he States of he State	ba Pelad Albe Iner Hoha Ab r () i () factor (con	eng Hriening Links Characters Arthor (Hr)	§ Sul Laire []	

There is an "Automatic Polling" feature in the instruction to make it easier to read a device on a pre-determined poll rate. There is also a "poll offset" field that can be used when simultaneous instructions are enabled with the Automatic Polling feature to help stagger the flow of messages being sent to the network.

• The Modbus Write (MWX) instruction is very similar in layout and configuration to the MRX instruction. It is used to write values to a Modbus device from the tags in the CPU.

deus Winte (MWIO)		1000		
Eleventhet Old Didde.	-	2-Pogna		
2' Address		Complete		• 🖃
101PetRater 162		Same		•1
Sau Intelligite	217 (arise) - 215	Dear		•
Contraction (1911)		Treat		- 5
Save York Number	1 Outure C	Booglar Impose Diriy		• =
Admitching own	100 mec.	ad after	e)ne:	
Disesson forfers put	a that	cital		
	2007/01/20	a second a second		
12 when the set	Save Hada	a Deprod Addressing and Hothan Address	1.11	
y vortine Play Tristade to Miler Malas Fundar Code S. Miler	Sanc Hada Mada Down B	a Depend Addressing and Hodban Address	1.11	
V verdinas Prop Titul sale to Mile Madras Function Carlo (5.160m) O Non-Arma	Save Hada a Hada D 2018 M	a Decinal Addressing and Hodina Address (1966)	n,	
ge martinen Prop 12 ist som to Miller Mediser Franken Carlo <u>S. Miller</u> Örten Arm Tag Name Happing	Since Helds Helds Dentil Lunter of Tage 1 2 3 4 4 4 4 4 4 4 4 4 4 4 4 4	a Darind Aldread y Decind Aldread y and Hodbar Andrea (*****)	1) + 1	portant.
© Mattine Physical Carlos Carlos (2, Marc) Physical Carlos Carlos (2, Marc) Physical Carlos Tag Name Happing () Artary - main from [	Start Holds in Holds Donald Hander of Topp Tag Tag Tag Tag Tag Tag Tag Tag	a harden konsta a Decinal Aldread and Hiddau Aldread (1999) (199)	ng	2980
© martineo Phop Tital selas fa Mile Nation Fundar Carlo <u>S. Mare 1</u> Phop Area TagName Hapting D Area - Area Inno ■ (1995) String hore	Since Heads in	Decine Addresses     Decine Addresses     Decine Addresses     Decine Addresses     Decine Addresses     Decine Addresses	1 + 1 ng	298.4
© Martineo PhysiCial Sele & Mile Malas Fundas Cale <u>5, Marc</u> O Tap Same Hapting D Arger Intel Fund € (200) Integrates □ Selection	Since Heads in	Denne Alfredre Denne Alfredre Denne Alfredre Denne Denne Alfredre Denne Alfredre Denne Alfredre Denne Alfredre Denne Alfredre	e +1 ng 1 =4 1 =4 1 =4 1 =4 1 =4 1 =4	reite
<ul> <li>Martineo</li> <li>May Titul Jako &amp; Mile</li> <li>Make Pantas Cale &amp; Mile</li> <li>Mart Pantas Cal</li></ul>	Since Heads • Heads - Jone II Institute of Tage 1 2 3 4 - - - -	Denne Albrein Denne Albrein (2004) (2	1 +1 rg 1 1 =1 1 =1 2 =1 2 =1 2 =1 2 =1 2 =1 2	2000

- The MWX operates very similarly to the MRX instruction. There are also many status bits to indicate the success or reason of failure when sending a message.
- The Automatic Polling option is also available to the MWX instruction, although greater care should be taken when using this feature in this instruction. This is explained in better detail in the "Message Queue" section.
#### **Network Instructions**

The Network Read (RX) and Network Write (WX) instructions are used to communicate to other CPUs. They are very similar in operation to the MRX and MWX instructions but they target Tag Names instead of Modbus addresses in the other CPU. There is also a significant performance gain in using the RX and WX instructions when communicating to other CPUs as opposed to using the MRX and MWX instructions.

					1	-
· Correction	0.0.0		3.840			6
P Address			Cargo			è
10 Partituder	990		Set			č
and the second second	N					ĉ
Declarities	e lotte	10		-	_	10
			front	-	_	1
			Ampone St	ing	•	Ŀ
state united		1.0.00000000000000000000000000000000000				
		- Contraction				
a fan Arny	Togs of the respect	Tage of	functe maps 1	÷		
Billion Anno Channe - Anno 20	Tage of the Hegel	Tage of	Tancia Ingert	•	nin [	
a far key O key an	Tage of the treport	Tige of	farmer require for the local	· •	n (m. )	
	Tage of the Heapert		Sandra Hagart	1 3m3		
	Tage of the respect		france maps	1 (m) 1 1		
a Berdery O'Aras Ar O'Aras Ar O'Ar O'Ar O'Ar O'Ar O'Ar O'Ar O'Ar O'	Tage of the treget or Separation integral integral register of register of re		france report	1 1 1 1 1 1 1		

The same status bits are available in the RX instruction as in the MRX instruction and operate in the same manner. The greatest difference in the RX versus the MRX is that with the RX, the Tag Name in the target CPU can be referenced directly and does not need a corresponding Modbus address. The way this is accomplished is by mapping local and remote tag names together within the local CPU's RX instruction. Once the instruction is set up to read a remote project, the "Tags of Remote Project" or "Array Tags of Remote Project" drop down lists will be accessible. Map the Tag of the Remote project to a Tag in the Local project to read this data.

· frenthet a	NUTSER		Infrapers	
F Adven			Complete	
12Postsalar	901		furness	- 100
				• 10
C Sealer (0)	au .	100	1-w	•16
they have been	1.04	S28.011	firmea.c	• 10
			Exception Response Strong	• 6
Reacte Ingest		. Aret.	tories -	
il fan-Anav	Segnal The Project	f Taga al Kar	ata Popet	
			-	
C Male . An	winest (	- 127 144	-	ni inter i si
C 414 - 22	is legal	+	ra ( ) =	nd joiker []
C ANN IN THE REAL PROPERTY OF	to Trap of This post by Trap of the Respect	•	rg (rein () ) ng tein ()	ni inio ()
0 Ann 22 22 0 Ann 22	in Trap of Property In Trap of Internet	+ [] Met + [] Soci	ng train () = Ing train () = Ing train () ar of Dana Jose	nt looker ()
O Anny Ann Anny Ann Anny Ann Anny Anny Anny Anny Anny Anny Anny Anny	is log of Product of the of a nething of drog of drog of the period	+	eg pako [] = 1 Ing bako [] Ing bako [] Ing di Danasian []	ni (nie () 20
C Anno An The C Anno An C Anno An C Anno An C Anno Anno An C Anno Anno An C Anno Anno An C Anno Anno An C Anno Anno An C Anno Anno Anno Anno Anno Anno Anno Ann	in ling of Property in the perty in the perty ing Tag of ing	+ () 1844 + () 564 + () 1644	eg paleo [] = 3 leg baleo [] er al Denoires []	ni bite () 21_

The WX instruction operates in the same manner except that the data from the Local tags will be written into the Tags of the remote project. No Modbus mapping is required.



**NOTE:** The PC programming software project for the Remote CPU must be accessible by the PC running the programming software for the Local project.

# Automatic Poll versus Manual Polling and Interlocking

In many cases when performing multiple communications requests to other devices, the message flow must be explicitly controlled in ladder code so that a message is not sent while another one is in operation. This usually requires writing 'interlocking' code between the instructions which typically involves the use of timers and shift registers, etc. Sometimes this is necessary because of the application but in other cases where the CPU just wants to read changing values from other devices and the frequency of that update is not critical it would be much more efficient to skip the unnecessary code complexity of interlocking.

The desire to make it easier to communicate to other devices brought about the "Automatic Polling" feature and the "Message Queue" in the CPU. The Automatic Polling feature allows the user to choose the rate at which they desire to send messages without having to use a separate timer and enable logic. The 'Message Queue' allows the user to stage the messages from the ladder code to go out to each physical communications port without requiring interlocking logic.



The implementation of how the message queue works is slightly different based on whether the request is a read request or a write request.



Write requests will fill the queue much faster than read requests. That's why it is advisable to carefully choose when doing write requests whether to use the "Automatic Poll" feature or to manually send write requests only when needed (data to write has changed). When designing a system, it is important to know the total time it takes to send a request and get a reply for each target device. The Poll time should be longer than this time. The longer the poll time can be, within tolerance of the application, the better the overall network performance. So for efficiency in programming and for the best possible performance for the system, conservative poll rates should be used when utilizing the "Automatic Poll" feature.

There is also a "Poll offset" field in the communications instructions. This helps prevent the instructions from being queued all at the same time. When the CPU project starts, there is a master timer that begins. The ladder scan will look to see if the instruction is enabled. If it is enabled, it will begin the Automatic Poll timer at the specified poll offset value from the master time clock.

### Message Queue

If the application requires more explicit, orderly control of each message sent to the devices, turn off the "Automatic Poll" feature. Using the instruction's status bits, logically control each message as required.

All of the above explains how messages get into the "queue". There are several factors involved with how each queue (1 for each physical port) is emptied.

- Serial port queues: The serial port queues empty slower than the Ethernet port queues, not just because of the hardware speed itself but because of the nature of serial communications. Each request sent must wait for a response or a timeout (whichever comes first). Once the reply is received for a request or a timeout has occurred, the next item in the list can be sent. So the response time of the slave devices on the network will largely affect the speed at which the queue fills and empties.
- Ethernet port queues: The Ethernet port queue can empty faster because when sending requests to multiple devices, the CPU does not have to wait on a response from one device before sending a request to another device due to the inherent nature of the Ethernet hardware. However, sending multiple requests to the same Ethernet device does necessitate that the CPU waits for a response from the first request before sending another request to that same device.

Another difference in the Ethernet port queue versus the Serial port queue spawns from the TCP 'connection' based behavior of Modbus TCP. If a TCP connection is lost to a device and there are still requests in the queue for that device, those requests will be dropped from the queue. There are three ways this can happen:

- 1. If a TCP timeout occurs (server device fails to respond within specified timeout value), the TCP connection is lost.
- 2. If the server device closes the connection, then all of the requests will be dropped.
- 3. And, finally, if all rungs with communications instructions to a device are disabled for five seconds, the CPU will drop the TCP connection for that device in order to free up valuable resources that could be used elsewhere in the system.

This is another factor that should be considered when designing the system. If it is imperative that no message be lost when communicating to a device, each instruction should be explicitly handled one by one (interlocking logic).

# **EtherNet/IP for the Productivity Series**

#### **Terminology Definitions**

A lot of terminology associated with EtherNet/IP is not always clear. Some of these terms are listed below along with their respective definitions.

- Scanner: This is the term used to describe the device that initiates the EtherNet/IP sessions. The Scanner is sometimes referred to as the "Originator" as well. In more standard Ethernet terms, the Scanner would often be called the "Client".
- Adapter: This is the device that responds to the EtherNet/IP communications that are initiated by the Scanner. The Adapter is also known as the "Target" as well. Typically, the Adapter is an Ethernet "Server".
- Object: In EtherNet/IP, an Object is a representation of a defined set of Ethernet connections, behaviors, services and data attributes. There are standard objects and there are custom defined objects as well. See Object Modeling example below.
- Class: A Class is a set of Objects that are related in some fashion. See Object Modeling example below.
- Instance: An Instance is an actual, usable manifestation of an Object. See Object Modeling example below.
- Attributes: Attributes are the specific items within an Object Class. The category of Attributes should be the same for all Instances of an Object but the actual Attribute itself might vary. See Object Modeling example below.
- Connection Point: A Connection Point value is the "Class Code" reference for a data block. This value is required for access to input and output data in IO Messaging. It is typically defined for each input and output data block by the Adapter device manufacturer.
- IO Messaging: IO Messaging (also called "Implicit Messaging") is a method of reading and writing blocks of data without defining the Connection Point and size for each block transfer. The Connection Point, size and transfer rate (RPI) are defined at the beginning and then the data blocks are transferred at the specified intervals.
- Explicit Messaging: This method of reading or writing data requires that each message defines the type of data and size of data needed for each request.

#### **Object Modeling Example:**

- Class ------ Definition of Automobile
- Attributes -- Make, Model, etc...
- Object ----- A Ford Mustang
- Instance ----Sally's Ford Mustang

# Network Layer Chart



The diagram above illustrates the OSI seven layer model and how EtherNet/IP fits into this model. In general, there are three basic layers for sending and receiving data in the EtherNet/IP protocol:

- EtherNet/IP layer (Register Session, etc...)
- CIP layer (CIP Forward Open, etc...)
- The uppermost layer, which contains several different types of messaging.

The ODVA specification defines many different types of messaging that reside on the CIP layer. Two types of messaging supported in the phase 1 release of the Productivity3000® EtherNet/IP protocol are IO Messaging and Explicit Messaging. IO Messaging is accomplished through a Class 1 Connection and Explicit Messaging can be accomplished through a Class 3 Connection or an Unconnected Message.

Tag Based Messaging (used for reading and writing values to Allen Bradley Control and ComCPUtLogix PLCs) and PCCC (used for reading and writing values to Allen Bradley MicroLogix and SLC PLCs) are planned for subsequent phases of this protocol.

# EtherNet/IP Data

When doing IO Messaging, the data that is transported is defined as "Input" data and "Output" data. Don't confuse this type of data with what most PLCs define as Input data and Output data. In most PLCs, Inputs are typically associated with an Input module that reads point from real word devices. Outputs are typically associated with an Output module that turns off and on real word devices.

In IO Messaging, Input data is data that is sent from the target device back to the Originator or to multiple devices that are listening (multicast messages). Output data is data that is sent from the Target device. This data may or may not be connected to real word devices. That is completely dependent upon the Adapter device. For example: When the Productivity3000 is configured as an EtherNet/IP Adapter device, the Input data and Output data is defined in internal data arrays and does not directly tie to any Input and Output point to the real world. If it is desired to tie these array elements to real word devices, that must be accomplished in code by Copy commands (or other instructions).



**NOTE:** The Scanner (originator) in the P3000 will only accept messages from an Adapter (target) device that the Scanner has established a connection to.

**NOTE**: The Adapter (target) in the P3000 will respond back to a Scanner (originator) in the method (Multicast or Unicast) that is sent in the forward open message from the Scanner (originator).

## **Class 1 and Class 3 Connections**

What are they and how are they best used?

Class 1 Connection is the transport mechanism that IO Messaging uses to send data. The basic concept is that data is sent in one direction: the Originator sends Output data in a Unicast UDP message to the Target and the Target sends Input data in either a Unicast message back to the Originator or Multicast UDP messages to multiple devices. The Input data and Output data messages have no relationship to each other. This method works well for Remote I/O type data and is very efficient due to little overhead and reduced handshaking messages on the wire. Class 3 Connection is one of the mechanisms that Explicit messaging uses. Class 3 messaging uses TCP messages unlike Class 1. Each Class 3 request has a header that defines the type of data requested as well as the size requested. It allows for more flexibility in messaging but does create additional overhead.



**NOTE:** Explicit messaging can be accomplished with unconnected messages as well for more infrequent requests. Explicit messaging is a slower performing method of communications but it typically allows for more flexibility and control when the situation requires it.

When can the P3000 CPU use Class 1 or Class 3 Connections?

 Class 1 and Class 3 Connections can be accomplished with the Productivity3000<sup>®</sup> CPU as an Adapter or as a Scanner or both simultaneously.

How many connections can the P3000 support for Ethernet IP?

- 4 TCP
- 4 Ethernet IP
- 4 CIP (Up to 4 CIP connections are allowed per Ethernet IP connection. Therefore, if one device can support 4 CIP connections then you can have up to a total of 16 CIP connections using 4 devices)

#### Example Setup: Productivity3000 as EtherNet/IP Adapter

The Adapter setup is accomplished through the EtherNet/IP Adapter setup under the Comm Adapter Config section of the Setup menu as seen on right.

evaluationer;27	darm.			
anter eftana stelle ()	4 4 1	Device Name #24.5.0F Adapter		
Dese Back 3				
Inged Parameters				
V Invester Should Carl		10 10 10 10 10 10 10 M	rorth 2	tions:
Setution	Unsigned into 36 22 Arrest	Carrierban Point (3/1)	\$10.	10-53
Date Array	Pep. Coldana	• a destaded	4	(84)
Heatings Size Styles()	100			
Norther of Elements	16	246418 (B(A))	- 84	(948)
		Attribute (Explore)	1	4840
Cutod Parameters				
V INNE DAMAGE			reth 2	diam'r.
Denshore	Longond int 36 22 Arrest	Carrienter Print \$115	1.80	10-64
Dela Array	C.quDutatio	• •	_	
1.000		Garbold	1.4	18+13
particle you ((April)		Sec. Ball	-	inner
Number of Elements	16	20000000000		
		and in Francis	1.40	40.00



When the EtherNet/IP Adapter is selected from the menu the window shown here will open.

Productivity 3000 Hardware User Manual, 4th Edition, Rev.

### **Chapter 6: Communications**

Fill in the required parameters and once configured these parameters will be used to configure the Scanner side as shown in the examples below. The first example shows how to setup a Class 1 IO Message connection from a 3rd party EtherNet/IP Scanner device (an Allen Bradley PLC).

DE LandsEAM Control/Company only Constants Exhaust Device Set

	General (	onnection   Mod	ule Info				
	Type: Vendor	ETHERNET- Allen Bradley	MODULE Generic Eth	erret Module			
	Parent F	Locatio					•
	Name:	P3000_1		Connec	ion Parameter		
	Descriptor	x [		1	inte	ice Size	*
				Input.	101	50	\$ (16
		-		Output	102	50	311
	Conm Fee	Net Data Pit		1 Contra	1	A 0	-
hertiet/D Adapter	-			cono			191
12102000000							
Z Duble EtherhertD	P Adapter					1.00	
Number of Data Blocks	(1-4)	1 () 2	nike Name P3K E/IP Add	oter		E.	
						1.10	
Insuit Parlameters	-				-	4.0	Help
Enable Input Da				Assembly 2	and a		-
Datatype	e: Unsigned	Ht 15 1D Array	Connection Point	101 101	(0.65)		
Data Ara	y south	allock +		-			
Nessage Size Protes	100		Class (I	Splot 4	(0x4)		
theology of Farmer		80	Instance (2	iekot) 301	(0x65)		
The second second	· L						
			Altiouse g	9000	(00)		
Output/Favameters							
Enable Output D	leta	and the second		Assembly 3	status.		
Cetatip	e: Unsgred	Int 35 ID Array	Connection Point	4 (0/0) 302	(3x65)	2	
Data Ara	iy OvpvDa	• kollad	Care D	welet 4	(0+4)		
Heisage Size Dryfes	1: 100		1000				
Number of Element	4	50	Sistance (I	ixplicit) 102	(0x66)		
	1 A		444.44	and and	(mail		
			ALC: U.S. 10	NUMBER OF THE OWNER	1.108.2.1		

The following example shows how a Class 3 Explicit Message might be accomplished from a 3rd party device (Allen Bradley PLC). As you can see the Input Data must be retrieved in one connection or message and the output data in another. Remember that Class 3 messaging is not as efficient in protocol messaging as Class 1 but it does allow for granular control.



**NOTE:** In this example, size configuration is not shown on the Scanner side. The tag created for the Destination must be large enough to contain the data requested (shown with dashed boxes).

Configuration   Tag	
Message Type OP Generic	
Service Get Ambute Single	heatings 3 mere
Service e Pieu) Class 4 Pieu Souhance 101 Ambute 3 Pieu	eri Destrution P3rcuDd4 V
lessage Configuration - MSGtoP3	8
Configuration Communication Tag	
Message Type: CIP Generic	9
Service Set Ambute Single	Sea Denert PDupilosa
Service 10 Pley Case 4 Ph	er Bonne reußer 100 C (Sheet)
Instance 102 Athibate 3 St	Earney 25
	New Tag.
n/9 Adapter	
n,17 Adapter	
nde Etherhel/P Adapter	
nt/P Adapter India Etherhiet/P Adapter er of Data Blocks (1 - 4) 1 (1)	N Device Name P3K E/IP Adapter
nt)P Adapter Indele Ethertiet/IP Adapter er of Data Bodis (1 - 4) 1 (1)	X Device Name P3K E/IP Adapter
nt (P Adapter Index EtherNet (P Adapter er of Data Blocks (1 - 4) 1 (+)	X Device Name (P3K E/IP Adapter
et (P Adapter Indele Etherheit (P Adapter er of Data Blocks (1 - 4) 1 (2) Inta Block 1 (Praneters) Sector (1 - 4)	Device Name P3K E/IP Adapter
et (P Adapter Indele Etherheit (P Adapter er of Data Blocks (1 - 4) 1 (1) Sata Block 1 1 Parameters (Enable Erpst Data Catatrone : Linescend Int 16, 10, America	Device Name P3K E/IP Adapter
et (P Adapter Insbie Etherhet (P Adapter er of Data Blocks (1 - 4) 1 + 1 Data Block 1 (Practices Enable Erput Data Datatope: Unsigned Int 16 ID Array Data Jose Ins (Inschedung)	Device Name P3K E/IP Adapter Assembly Instance Connection Point (3/0) 301 (0x65)
et (P Adapter Inde Etherhet (P Adapter er of Data Blocks (1 - 4) 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Device Name P3K E/IP Adapter Assembly Instance Connection Point (()(0) 101 (0x65) Cases (Explorit) 4 (0x4)
et (P Adapter Indele EtherHet (P Adapter er of Data Blocks (1 - 4) 1 () Data Block 1 (Parameters (Indele Input Data Data Array DeutDataBlock ssage Sire (Internet) 100	Device Name P3K E/IP Adapter Assembly Instance. Connection Point (3/0) 301 (0x65) Coses (Explore) 4 (0x4)
nuble Etherheit/IP Adapter er of Data Blocks (1 -4) 1 + 1 Stata Block 1 (Parameters Snable Input Data Datatope: Unsigned Int 35 3D Array Data Array InputDataBlock ssage Sim (hytes) 100 Junter of Elements 10	Device Name P3K E/IP Adapter Assemble Instance Connection Point (3/0) 301 (0x65) • • • • • • • • • • • • • • • • • • •
nuble Etherheit/P Adapter er of Data Books (1 - 4) 1 + 1 Stata Block 1 (Parameters (Snable Exput Data Catatope: Unisgned Int 35 3D Array Data Array (SnoutDataBlock) ssape Size (Frytes)) 200 surder of Elements (1)	Device Name PIK E/D Adapter Assemble Instance. Connection Point (2/0) 301 (0x65) Class (Explicit) 4 (0x4) Distance (Explicit) 311 (0x65) Ambure (Explicit) 3 (0x3)
nuble Etherheit/P Adapter er of Data Books (1 - 4) 1 1 bata Block 1 (Parameters (Insible Input Data Catatope: Unsigned Int 16 3D Array Data Array DroutDataBlock ssage Size (Dytec) 200	Device Name PIK E/D Adapter Assembly Instance. Connection Point (3/0) 301 (0x65) Cases (Explicit) 4 (0x4) Destance (Explicit) 311 (0x65) Attribute (Explicit) 3 (0x3)
nuble Ethenheit/P Adapter er of Data Blocks (1 - 4) 1 1 ata Block 1 (Parameters (Insible Input Data Data Array InputDataBlock seage Size (Inhen) 100 seage Size (Inhen) 100 (Inher of Elements (10))	Device Name PIK E/D Adapter Assembly Instance. Connection Point (J/O) 301 (0x65) Cases (Exploid) 311 (0x65) Attribute (Exploid) 31 (0x5) Attribute (Exploid) 3 (0x3)
nuble Ethenheit/P Adapter er of Data Blocks (1 - 4) 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Device Name PIK E/D Adapter Assembly Instance. Connection Point (3/0) 321 (0x65) Cases (Exploit) 4 (0x4) Destance (Exploit) 31 (0x65) Attribute (Exploit) 3 (0x3) Attribute (Exploit) 3 (0x3)
nuble Etheritet/IP Adapter er of Data Blocks (1 - 4) 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Device Name PIK E/D Adapter Assembly Instance. Connection Point (3/0) 321 (0x65) Class (Explicit) 4 (0x4) Distance (Explicit) 31 (0x65) Attribute (Explicit) 3 (0x3) Attribute (Explicit) 3 (0x3) Attribute (Explicit) 3 (0x3)
et (P Adapter Institle Ethenheit (P Adapter er of Data Blocks (1 - 4) 1 1 1 Institle Enput Data Data Array Data Array Data Array Deput DataBlock Soage Size (Pytec) 100 Author of Elements 100 Author of Elements 100 Author of Elements 100 Data Array Duput DataBlock	Device Name PIX E/D Adapter Assembly Instance Gennection Point (3/0) Gene (Explicit) Futarce (Explicit) Attribute (Explicit) Attribute (Explicit) Generation Point (3/0) Connection Point (3/0) Gene (Explicit) Generation
et (P Adapter Invalie Etheritet (P Adapter er of Data Blocks (1 - 4) 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	Device Name PIX E/D Adapter Assembly Instance Connection Point (3/0) Class (Explicit) Attribute (Explicit) Attribute (Explicit) Connection Point (3/0) Class (Explicit) Class (Explicit) (1044) (1044)
et (P Adapter India Etheritet (P Adapter er of Data Blocks (1 - 4) 1 1 1 India Block 1 Createrers Enable Input Data Data Array Input DataBlock Stage Size (bytes) Enable Output Data Data Array Doubut Data Data Array Dubut DataBlock Statepe: Unsigned Int 16 32 Array Data Array Dubut DataBlock	Device Name PIX E/D Adapter Assembly Instance Connection Point (3/0) Class (Explicit) Pintance (Explicit) Attribute (Explicit) Attribute (Explicit) Connection Point (3/0) Connection Point (3/0) Class (Explicit) Class (Explicit
et (P Adapter Inde Etherheit (P Adapter er of Data Blocks (1 - 4) 1 + 1 Inta Block 1 (Presentions (Indek Provider Data Array Developtablicok Stage Size (Pytec) 200 Author of Elements Data Array DuputDataBlock Data Array DuputDataBlock stage Size (Pytec) 200 Author of Elements Data Array DuputDataBlock stage Size (Pytec) 200 Author of Elements Data Array DuputDataBlock stage Size (Pytec) 200 Author of Elements Data Array DuputDataBlock	Device Name PIK E/D Adapter Assemble Instance. Connection Point (3/0) 301 (0x65)  Team Explicit Destance (Explicit) 101 (0x65) Attribute (Explicit) 3 (0x3)  Connection Point (3/0) 102 (0x66)  Team Explicit Destance (Explicit) 4 (0x4) Destance (Explicit) 4 (0x4) Destance (Explicit) 3 (0x3)

#### Example Setup: Productivity3000® as EtherNet/IP Scanner

This example shows how to connect the Productivity3000 Scanner function to an EtherNet/ IP adapter device using Class1 IO Messaging. First, create an EtherNet/IP device in the Hardware Configuration as seen below:

landware Centification	
A B S	
Convento Erio 310 200 2.3k	Etherfiet/IP Device

Configure the parameters to match the settings of the Adapter device. The image on right shows the setup of the Input data.

The size, in this case, is dynamic to the configuration of the device. For this particular example, we configured the device in a manner that allows it to publish 8 bytes of data for Input. Many devices will have a fixed configuration that should be published in the manufacturer's documentation.

Net/17 Okent	Properties				
Deves Fame	(amount)	98	10P Lanedail	Generalizee	•
thereful	OUTIN	-	Adapter forme	Carro (Maginaria	• •
PAttern	191.108.1.9		wester E	GeorgedD	•
Pathabe			TON Down	Gentle?.tre	
Con inte	d CP Sealor Inter N L	*** [] **			
Duble	Carlo Street	nale 🔿 🔸	iere	e den lan de e tiese lan de	etete + [] etetet + []
-	-	NAME .	· fried	al Sala Tan Di	-exter + [
1-01		r estraut   con	C MAG	alyter (Les Dr	etistes + [
	Pi Tare (suc) Pi Tare (suc) Proclaminati Data Array Pilan Britani Array di Datamin	20 20 20 20 20 20 20 20 20 20 20 20 20 2	Da Da ti Name d Corr Corr Corr Corr	ta size is o he configu evice. In t nfigured t nanner the bytes of t	determined ration of th this case, v he device i at required input data.
Hanta	lex.	Assembly became	Size		
- 1	φđ	1(Burnler) regard)	The naive reliant passanches quit	ery based on the nor this year application	nber af ( <b>DL From Be</b> 6 (see details below)
_		2 (Bernder h	De saler will u	er have for the sec	ther of 120. In Net or
	April 1	(hopind)	plaumitim qui	f for your application	a (see details below).

#### **Chapter 6: Communications**



locat

Output

Conferences

(breinger

(build)

required.)

6 (This take is 10 (This caller is regulard.)

parameters used for your application (see details before).

parameters used for your application (see details, below)

2 (This value is The value will key based on the number of [D], To Net incl.

The following example shows how to connect the Productivity3000<sup>®</sup> Scanner function to an EtherNet/IP adapter device using Class 3 Explicit Messaging. As with IO Messaging, an EtherNet/IP device must be created in the Hardware Configuration as seen below:

	- Drag d	and Drop	EtherNet/IP Device
	-J (		
let/P Client	Properties		
bevice Name	Conveyor3Drive	TOP Connected	ConvitCPConn •
themet Port	OPU-ETH-Ext	Adapter Name	Conv 1AdapName •
	\$92.168.1.56	Verdor ID	ConvitienD +
IP Address	( second	TCD/D Door	ConvETCP_Error +
IP Address NortNumber	44138	LOUDE FILM	
3P Address YortNumber   Close unuse	d CP Session after	secs	
IP Address PortNumber   Close unuse   Snap Byte (	d CP Sesson after 3	) secs	
P Address Part Number Close unuse Swap Byte ( EUP )	d CP Sesson after X Drder	) secs	
P Address Part/Number Close unuse Solap Byte ( Ext 5	4933 d CP Session after 3 Drder 60 1 Inable Conv 20rueEnable	• Corrector	Online ConviDriveOnline +
P Address Vorthlumber Cose unue Soap Byte Exp y Exp y Exp y	erezo d CP Session after 3 order 60 1 nable Conv 20rveEnable maec) 250	) secs	Online ConviDriveOnline +
P Address fortNumber  Cose unuse  Snap Byte (  EUF 5  EFT Time (  FT Time )	4933 d CP Session after 3 Order 66 1 Inable Conv 20rueEnable meet) 250 voting Sot Surburber	correction     correction     correction     correction     correction	Online ConviDriveOnline + [a Slatus ConviDriveGenditat + [a Status ConviDriveExStat + ]a

Explicit Messages can be performed in 2 ways: Unconnected or Connected (Class 3). The advantage of using Unconnected messaging is it allows more discrete control of each request. The disadvantage of Unconnected messaging is that Unconnected messages have a lower priority and will take longer to get serviced on some devices. Connected messages get serviced faster since there is a connection established to the device. If Connected messaging is desired, create an Explicit Message tab as shown in the image above. If Unconnected messaging is desired, do not create an Explicit Message tab. Only fill out the information in the upper portion of the EtherNet/IP Client Properties window.

Once the desired parameters have been entered, the device may now be referenced in the Explicit Message Instruction. If Unconnected messaging has been selected, choose the Unconnected MSG option in the Connection drop down box. If Connected messaging has been selected, choose the Explicit Message that was configured in the EtherNet/ IP Client Properties window in the Connection drop down box. The rest of the settings should be matched to the specifications documented by the manufacturer. An example for requesting the Identity of a device is shown below. The data array configured for this function must be sufficient in size to hold the returned data from the device for this object. Data can also be written to the device if it supports an object for this purpose. If data is being written, enable the Output selection and specify the data array and size required by that device's object.

Device Nam			Service	5			
	e Conveyorit)	eve.	100000	Implement	stind for:		
		10.00	Service Co	de Class	Instance	Service Name	
Connectio	IN EPP MSG 1	_	965	N	35	licat	_
			0.05	36	36	Gr_atebate_5	iodir
Servic	ce Genero	1	0.01	lis.	36	Ger, Rollader,	48
Service 1	D 14	(Dd)		Class Co	de		and a second
Cieso I	0	[0:1]		Readering	d Decima	-	
-		-	Station of the local division in which the local division in which the local division is not the local division of the local division in the local division in the local division in the local division is not the local division in the local div	0.01	1		and a second
Attribute 3	0 3	2 (0(2)		Contraction of the local division of the loc		_	and it
Instance P	D 3	2 (0(2))	Class	Attribute	5		
1-30 (09	07)	1000	N				1.
12 make	Innut		Autor	Ae 10 hopess	Bale Name	Bata Type	Description
Mes age	connected t	to the ada	pter. This	mumber of		er en be mad	
an	Attribute 2.	1.1			component	or can be read	ia Instance 0,
-	Antribute 2	Destrip	605		composen	o can be read	ia Instance 0,
0-3740	Attribute 2	Descrip	diee		componen	o can be read	ia Instance 0,
0-110 0-140	Annibute 2 Instance	Desatig Class Heat	Gee		componen	o can be read	in Instance 0,

**Identity Object** 

# **Troubleshooting Tips:**

- 1. Use the diagnostic tags in the Hardware Configuration and Explicit Message Instruction:
  - As explained previously in the Network Layer Chart section, there are multiple layers of messaging involved with EtherNet/IP. If it appears that the Productivity3000 is not communicating with another EtherNet/IP device, there are diagnostic tags available to narrow down which layer of the protocol is preventing successful communications.

- a. At the TCP layer, there is a TCP Connected field that will expose the status of the TCP/IP connection when a tag is populated in this field.
- b. There is an Adapter Name field for a String tag and a Vendor ID field for an Integer tag. Both of these fields can help to identify whether the Productivity3000 is connected to the correct device or not.
- c. At the CIP layer, there is a Connection Online field for a Boolean tag.
- d. There are three additional fields to help determine why the CIP session might not be successful: General Status for an Integer tag, Extended Status for an Integer Data Array and Status Description for a String tag.
- 2. Use the TCP connected tag:
  - Step 1 is to check the TCP Connected tag. If the connection has been enabled (by turning on the tag configured in the Enable field or triggering an Explicit Message instruction with an Unconnected MSG specified) and the TCP Connected tag is not true, check the following items:
    - a. Cabling. Ensure that all of the cables are connected and in good shape. In most cases, the Ethernet port that the cable is connected to should indicate a Link Good LED. Ensure that any interim Ethernet switches are powered up and functioning and that the end device is powered up and functional.
    - b. IP address and correct subnet. Check that the IP address entered into the IP Address field is the correct address for the device that you are connecting to. Also check that the EtherNet/IP device's IP address and subnet mask is compatible with the IP address and subnet mask of the Productivity3000. If there are any routers in between the two, ensure that a proper default gateway that matches the router's IP address is configured. If you are unfamiliar with proper IP addressing and subnet configuration, consult with the network administrator for guidance.
    - c. TCP Port number. The default listening TCP port number for EtherNet/IP is 44818. Check that the target device is listening on this specific port number. If it is not, change the value in TCP Port Number field to the appropriate value. If there are interim router devices that are using port forwarding, ensure that the router is properly configured for this setup.



**NOTE:** Attempting to do IO Messaging across routers (different subnets) is unlikely to be successful. IO Messaging uses multicast messaging in many cases and the Port number is not necessarily fixed when the IO Messaging is established (the Forward Open message has the ability to 'negotiate' the port number used for the IO Messages).

- d. Adapter Name and Vendor ID. If the network contains many EtherNet/ IP devices and these devices may not necessarily be connected to the Productivity3000, it may be a good safeguard to check the Adapter Name and Vendor ID returned and verify that these devices are the correct devices to connect to.
- 3. Use the Connection Online and Error tags:
  - If the TCP Connected tag is true and the Adapter Name and Vendor ID look correct, the next tags to look at are the Connection Online, the General Status, the Extended Status and the Status Description.
  - If the Enable tag is true and the Connection Online tag is not true, check the General Status value along with the Extended Status value(s) and the Status Description. If the General Status value and the Extended Status value(s) are part of the defined errors from the ODVA specification,

the Status Description should also return a more descriptive String. Once these errors are known, it may possible to very simply make the adjustment in the settings to correct the issue. If it is not obvious from the description, first check the manufacturer's documentation for corrective action in this particular scenario.

• If the manufacturer's documentation doesn't give corrective action, check the EtherNet/IP Error Code List in this chapter for possible solutions.



**NOTE:** This may not always solve the problem as each device manufacturer may publish the error for slightly different reasons.

- If the Connection Online tag is true and the data being received is different than what is expected, verify that the correct Connection Point values and/or Class, Instance, Attribute values are configured. There may be multiple areas of available data in that device. Verify that the correct data types are being used for both sides. If the data types are mismatched, this may make the data 'appear' to be incorrect.
- Another great tool that can be used is Wireshark. Wireshark is a free network analyzer tool that can be downloaded from www.wireshark.net .



**NOTE:** Using this tool implies some knowledge of how networking protocols function. Using Wireshark will also require that you have a true Ethernet hub (not an unmanaged switch) or a managed switch with Port mirroring capability.

You may also use the following basic steps to check your Ethernet IP Setup.

# Ethernet IP I/O Message Troubleshooting:

- 1. Does the IP Address set up in the Scanner match the Adapter IP Address?
- 2. Is the enable tag entered into the Scanner turned ON?
- 3. Does the connection point entered into the I/O Message Data Block match the connection point of the Adapter?
- 4. Does the number of elements match the Adapter?
- 5. Does the data type match the Adapter?
- 6. Steps 4 & 5 are important because the number of bytes being read from or written to the Adapter have to match the Adapter bytes allocated.

# Ethernet IP Explicit Message Troubleshooting:

- 1. Does the IP Address set up in the Scanner match the Adapter IP Address?
- 2. Is the enable tag entered into the Scanner turned ON when not using the Unconnected MSG connection type?
- 3. Make sure the logic for the EtherNet/IP Explicit Message (EMSG) is TRUE so the instruction is enabled.
- 4. When using Get or Set single attributes in the Service field make sure the Instance ID matches the Instance ID of the Adapter.
- 5. When using Generic in the Service field make sure the Service ID, Class ID, Attribute ID and Instance ID match the Adapter settings.
- 6. Does the number of elements match the Adapter?
- 7. Does the data type match the Adapter?
  - Steps 6 & 7 are important because the number of bytes being read from or written to the Adapter have to match the Adapter bytes allocated.

### ProNET

Productivity Network (ProNET) provides the ability to share data with other P-Series CPU's, This can easily be accomplished using the Productivity Network (PNET) setup in the Hardware Configuration window used to join a data sharing network consisting of other P-Series controllers.

Each member of the data sharing network receives data from all of the other P-Series controllers on that data sharing network. Each node can optionally send data to the other nodes of the data sharing network by electing to "publish" data.

The ProNET configuration uses UDP broadcast packets to publish the blocks of data to the network. One caveat with the use of broadcast packets is that it limits the scope of the shared data network to the local broadcast domain.

ProNET uses the verbs 'publishing' and 'subscribing' to describe how the controller data is exchanged with other P-Series controllers on the data sharing network.

Publishing is analogous to sending data, and is done only if ProNET is configured to 'publish' one or more of its assigned tags. If so configured, the P-Series controller will broadcast a packet that contains the data from the selected tags.

Subscribing is analogous to receiving data, and is accomplished by 'subscribing to' a publisher's global ID of any P-Series CPU on the data sharing network set up to publish its data.



The ProNET configuration works with a 1D array tag(s) that can contain up to 65535 elements, however you are limited to 32 total 32-bit elements, 64 total 16-bit elements, or 128 total 8-bit or Boolean elements of data per publisher array data type. These tags provide the local storage for the data sent and received over the data-sharing network.



**NOTE:** The message size for each data type is limited to 128 bytes regardless of the defined array size.

Data Type	Number of Elements
Boolean	128
Integer 8-Bit	128
Integer 16-Bit	64
Integer 32-Bit	32
Integer 64-Bit	32

When the input logic to the ProNET configuration is Enabled, it operates at a fixed rate of 10 times per second (100ms). The instruction will publish all of the elements of the array that it is configured to publish, and will process any ProNET nodes that it receives. When the input logic is OFF, (the device is disabled), it DOES NOT publish any of its tags and DOES NOT process any ProNET nodes that it receives.

#### **Custom Protocol over Ethernet Functionality**

Besides Modbus RTU, EtherNet/IP, and ProNET the Productivity1000 system has the ability to communicate via Ethernet with other devices using the Custom Protocol over Ethernet (CPoE).

Custom Protocol over Ethernet

The Custom Protocol is a HEX based protocol used to communicate with devices that do not support one of the other protocols on Productivity1000. There are two steps to initiate communications via the Custom Protocol over Ethernet:

- First you must set up a device in the hardware configuration under the CPoE tab.
- Then you must use the Custom Protocol Ethernet (CPE) instruction to initiate messages.

# Hardware Configuration

First you must set up a device to talk to in the CPoE tab of the hardware configuration. This will Require you to:

- Inter a Device Name
- (2) Enter the IP Address of the device you wish to communicate with.
- (3) Enter the port number of the device.
- (4) Enter an Enable tag to enable the device if using TCP.

				CPot De
Custom Protocol over Ethemet Device Proper	tes			*
Devos tarre -Culture bence	(7) If the Bruchers	buou,1		
2 P Address 10.10.10.10	TOP Connected	10%metail	٠	
W Use TOP - OPU as the Matter	TCP/IP Dress	Labora.	٠	C1
10P Hart Number 250 3	Messages Seri	Housestern	*	G.
	* 💼 Messages Received	Heimgelbitrist		
() Use TOF - ON at a Sieve (5)	Feeding Sound Masserpers	Monapolitoliting	*	9
O'U for Junker 1	Paral Queue Overfine	converter	٠	(2)
Train	• []]			
C Une LOF 6				
and inset Scienter 8				
1751/Nat Surviver 3				
175. For Survive 8 Use IP Aldress and USP Published or Tee	normal USP pathot			

- Choose whether you wish to Use the PLC as the master or the slave device via TCP connection
- (6) Choose whether you wish to use a UDP connection.
- Enter tags for status of this device for troubleshooting (Example below shows the Structure method used).

### **Custom Protocol Ethernet Instruction**

Next you must use the Custom Protocol Ethernet instruction in ladder.

- 1. The instruction can be chosen Receive or Send messages to the Custom Device.
- 2. The user can choose to use:
  - A table with tags that allow the user to send a specific data.
  - An array tag that is numerical can be used to Send/Receive from.
  - A string tag that contains an ASCII string to be sent or string location to receive characters to.

# **Communications: Remote I/O and GS-Drives**

# Things To Consider for the design of Remote I/O and GS-Drives

It is important to understand that only one Remote I/O network can be on an unmanaged switch. If two or more Remote I/O networks are mixed into the same physical LAN (local area network), duplicate IP addressing will occur and the system will not function properly. Multiple Remote I/O networks can be used on a managed switch using the VLAN feature to create a virtual separation of the different networks, but multicasting messages are necessary for the network to function properly. Care must be taken when designing a system this way (using a managed switch).

Even if only one Remote I/O network is being used in a facility, it is strongly recommended to keep it on a dedicated network, physically isolated from other networks. As mentioned above, the Productivity3000 Remote I/O network makes use of multi-casting messages and many devices will not function properly in this situation.

The GS Drive configuration does not use multicasting in its setup but there are some initial UDP broadcast messages that occur upon discovery when initiated from the software and at power up. This should be considered if installing the GS Drive network with other devices.



6-56 Productivity Marchan Hardware User Manual, 4th Edition, Rev. V

# **Configuration of Remote Slaves**



NOTE: The P3-RS module is discontinued as of 6/20. Please use P3-RX as a replacement.

The Productivity3000<sup>®</sup> Remote I/O is very easy to configure. Each P3-RS or P3-RX Remote Slave module's address is set by rotary switches on the front of the module. The X1 switch is used to set the least significant digit and the X10 switch is used to set the most significant digit. So if the X10 switch were set to 2 and the X1 switch were set to 4, the Slave Address of that module would be 24. Valid addresses are 01-99; 00 is not valid. Each slave module must have a unique address and up to 16 slave units are allowed on a single system.



The address rotary switches are only read by the P3-RS/RX at power up. Power must be cycled after an address change for it to take effect. Connect a straight through (patch) Ethernet cable from the front of the P3-RS/RX module to an Ethernet switch. Connect a straight through cable from the P3-550(E) Local Ethernet (Remote I/O) port (lower Ethernet port) to the same switch. Open up the Productivity Suite Programming software and connect to the P3-550(E). Once the software is connected, open Hardware Configuration. Select the "Read Configuration" button in the upper left hand corner of this dialog and the P3-550(E) will automatically discover the slave modules connected to the switch and return all found P3-RS/RX modules and their configurations (bases and I/O modules).



6-57

Optor	6 Cthemet Ports Remote Aco	sa Serial Ports		
	External Etherset Part			
1	Part Name OPU-ETH-Ext			
	Port Security Option 🕐 Rei 🔒 Rei	ed Drily ed/Write		
	TOP/DP Settings	000000		
	Use current settings     Use DHCP     Use DHCP     D Acchess     Subvert Mask     255.2     Default Gateway     (200-30,000 mee)     Modeus TCP Part (1.45828)	0 05 255.0 0 nd response	95. 5 102	x100 mg
	Committeent Value (2-1,00	0 eec)		sec.
	Local Ethernet Port			
	Timeout between data ouers a (30-20,000 msec)	nd response	100	x30 msec
	Commitment Salue (200.5)	(1000 mmm <sup>-1</sup> )	20	x 300 mee

There are two fields that can be configured in regards to connectivity to the slave modules (see the Local Ethernet Port Settings section of this chapter for a more detailed explanation of these settings). The above diagram shows the CPU hardware configuration popup where these settings can be found.

1. Timeout between data query and response: This is the time allowed (in 10 millisecond units) between when the CPU sends a message to the P3-RS/RX and when a response is required. If the CPU does not receive the response within the time specified, the outcome will depend on how the P3-RS/RX and its I/O modules are configured:



CAUTION: IF A TIMEOUT OCCURS AND A MODULE WITHIN A P3-RS/RX BASE OR EXPANSION BASE CONNECTED TO THE P3-RS/RX HAS THE "AUTOMATIC MODULE VERIFICATION" SELECTION ENABLED, THE CPU WILL GO OUT OF RUN MODE AND A CRITICAL ERROR WILL BE GENERATED.

1.00	and the second	Inter Factories		
		004171		
	1.6	004122		
	1.1	004121		
	1.0	00-0.1.2.4		
		004125		
	1	00-01.26		
	2	0041.17		
-		0.5.8.9-00		
	12	20-8.1.2.9		
	R	0043.2.W		
		00-03.218		
	No.	20083.2.12	-	
1				_
0	olors (seal) a Asterato D	tarta mode Base Group Decto 1 If the Kenetic Sale Gr	clas	4
	okre Senair E Astenatolio Ocratiliete Chiane RS-	nets enote Base Group Derte 1 f the Kenete Sale Gr	rtian a.g.s.Decorrer te	4

 If a timeout occurs but all of the modules within the P3-RS/RX base or expansion bases connected to the P3-RS/RX have the "No Verification and Enable Hot Swap" selection enabled and the P3-RS/RX module has the "Do not Detect if the Remote Base Group is Disconnected" selection enabled (see above), the CPU will remain in Run and a non-critical error will be generated.



CAUTION: IF A TIMEOUT OCCURS AND THE P3-RS/RX MODULE HAS THE "AUTOMATIC REMOTE BASE GROUP DETECTION" SELECTION ENABLED, THE CPU WILL GO OUT OF RUN MODE AND A CRITICAL ERROR WILL BE GENERATED.

2. Comm Heartbeat Value: (previous page graphic) This value is used to help the P3-RS/RX determine that the P3-550(E) is no longer communicating to it. If the P3-RS/RX module does not receive a message from the P3-550(E) within the time frame specified in the "Comm Heartbeat Value" field in the P3-550(E) configuration window, the P3-RS/RX module will turn off all of its outputs.

# **Configuration of GS-Drive Connections**

GS Drive connections are set up in a similar manner as the Remote Slaves. Set a unique address for each GS-EDRV100 using its DIP switches. Or set the DIP switches to 0 and select the address using NetEdit (free download at

AutomationDirect.com). 01–64 are valid addresses for a GS-EDRV100 in a Productivity3000<sup>®</sup> system. Since the DIP switch settings can only represent 00-63, setting a GS-EDRV100 to address 64 must be done using NetEdit.



After the GS-EDRV100 modules' addresses have been set, be sure to connect the serial cable that comes with the GS-EDRV100 to the GS-Drive serial port. The GS-EDRV100 will automatically configure the GS-Drive serial port to the correct settings. Once the GS-EDRV100 is properly addressed and connected to the GS-Drive, connect a straight through (patch) Ethernet cable from the Ethernet port of the GS-EDRV100 to an Ethernet switch. Connect a straight through cable from the P3-550(E) Local Ethernet Port (Remote I/O) to the same switch.

Open the Productivity Suite Programming software and go online with the P3-550(E). Select Setup and then Hardware Configuration. Select the "Read Configuration" button in the upper left hand corner of this dialog and the P3-550(E) will automatically discover all of the GS-EDRV100s connected to the switch and display all found GS-Drives.



Once the drives have been discovered, the configuration of each drive can be read and written from the programming software.



To allow the P3-550(E) to automatically write the drive parameters on each CPU project transfer and when the CPU is powered up, a setting must be configured in the P3-550(E) project. Go to Tools and Options and select the "Project Transfer" tab. Select the "Transfer GS drive configuration" as shown below. Drive parameters are ONLY transferred to the GS Drive at project transfer or at boot up of the CPU.

tions	
Protect Save Protect Transfer	Ladder Connection
Transfer Project From PAC Opt	urs.
Dpload current retentive v	alues and copy to initial values
Dipload current CPU R5-25	2 settings and copy to project
Upload current CPU RS-48	5 settings and copy to project
Transfer Project to FAC Option Transfer documentation () Transfer GS drive configur	
Copy current retentive tag	values to initial values
1	OK Cancel Help

To monitor the status of the connection between the P3-550(E) and the GS-EDRV100 modules, use the status bits of the GS Read and GS Write instructions as shown below. If a Timeout occurs or an error is received, this can be monitored in the ladder code and appropriate action can be taken.

In Progress	·
Complete	¥
Success	<b>v</b>
Error	w
Tiseout.	¥ [
Exception Response Dring	× [

The Communications Heartbeat function is configured differently for the GS Drives than the Remote Slaves. Primarily because, as mentioned previously, there are two possible communication paths that could be lost:

- P3-550(E) to GS-EDRV100.
- GS-EDRV100 to GS drive.

To configure the GS Drives to detect and react to loss of communications, there a set of parameters that should be configured in the drive. The example below shows the parameters for a GS1, 2, or 3 series drive.

- Parameter P9.03 determines what the drive will do when it detects loss of communications.
- Parameter P9.04 enables the transmission loss detection feature.
- Parameter P9.05 determines the amount of time the drive will wait for a transmission before assuming that the link is lost and react according to how parameter P9.03 is configured.

CS2 Farameter	Description	Range	Detaut
19.00	Communication Address	0f #1254	64
P9.01	Turuminister Speed	00: 4001 baud 01: 600 baud 02: 12300 baud 03: 35400 baud	
P9.62	Communication Protocol	60 Maddea ACE wold 7 das teuro parte 2 wap teu 7 das 1 europarte 2 wolfs 7 das 1 europarte 2 months 7 das 1 europarte 2 months 7 das 1 europarte 2 months 7 das 1 europarte 2 months 8 das 1 europarte 2 months 9 das 1 europarte 2 months 8 das 1 europarte 2 months	
P9.03	Transmission Rault Transmiss	00: Diploy task and coverue opening 01: Display task and RANP to exp 00: Display task and CONT vo wap 07: No task displayed and coversue executing	00
P9.04	Time Our Delexism	ot: Disable of: Exuble	00
P9.05	Time Oue Durakce	0.1 ei 46.5 secondi	8.5
P9.07	Parameter Local	se and seat	00

#### The GS-EDRV100 reads these

configured parameters and if they are configured for detecting communications loss, it will also monitor for loss of communications on the Ethernet side. If communications are lost on the Ethernet side, the GS-EDRV100 will shut down the GS Drive.

It is very important to note that if the communications loss feature is enabled; either a GS Drive Read or GS Drive Write instruction needs to be configured to communicate to the GS-EDRV100 and GS Drive at a poll rate that will prevent the GS-EDRV100 and GS Drive from detecting a loss of communication.

Control of the local of	1 45 Crive Type: 451	In Progress	·
Auto Vella		Country 1	-
Pol Duary	300 milect	Compete	<u> </u>
Pul Offset	0 #145	Success	×
Run Common	d	Dev.	
Prequency	(ap pas Run Freq Nodel		
Jos Commany	09.00	Timeoux	×
Frequency	Falsence Inc. Proc. Back 1 and 1	Ecoston	
	(P5.00) 100 - 100	Kexponse soring	
Motor 0	exp   #Hz   Digital   Analog   Protection	ID ComiSeton Iren	91
Faran, #	Zen	Tagnere / Content	
P9.00	Communication Address		
and the second sec	Transmission Speed		
P9.03			
NG NG	Contaction Perhaps		
8.0 MC MC	Communication Protocol Communication Fault Operation	Set Convertions Behavior	
5.0 5.0 7.0	Connunction Political Communication Pault Operation Time Out Detection	Set_Conve_Loss_Behavior Set_Conve_Loss_Detector	
20 20 20 20 20 20 20 20 20 20 20 20 20 2	Communication Protocol Communication Fault Operation Time Out Detection Time Out Duration	Set_Conv. Loss Behavor Set_Conv. Loss Detector Set_Conv. Loss Telecol.	Value

There is also a parameter (P22.01) that can be monitored to check the health of the serial connection between the GS-EDRV100 and the GS Drive. This parameter can be monitored in the ladder code and appropriate action taken if serial communications loss is detected.

	kind (5593)		
1 Dates haud	a 👔 🙀 vit brow Type: GS	an Perspect	
		Consister	
Acotes		(Ca)	
Palterry	:00 #999	Sater	
Paliona	1 0 met	Ener	2
Atudifie	extrem inctual mac lacest	Tineout	
		Exceptor Interest 2 Jac	
Planual Res	1 · · · · · · · · · · · · · · · · · · ·		
Paran #	Des	Tagrare	Samedo
P21.00	Stores ever cade		
P01.01	Ston careful ray, ship, director, etc.		
P21.52	Ward and a construction with the set		
	A sufficient of the second sec		
P21.00	Actual preset frequency to drive		
P21.00 P23.04	Actual preset Pregency to drive Output current of drive		
P23.00 P23.04 P23.05	Actual present frequency to chrise Codput current of dense Rua notage at chrise		
P21.00 P23.04 P21.05 P21.05	Actual preser Trequency to drive Actual preser Trequency to drive Culput current of drive Bus voltage of drive Actual output voltage of drive		
P21.00 P21.04 P21.05 P21.05 P21.05	Programy contract to date Acculates the Program of the Codput current of dates Bus reflage of drive Acculi output voltage (if drive RTH of accor connected to dates		
P21.33 P21.34 P21.35 P21.35 P21.35 P21.37 P21.37	Program y contract in control Actual present in Angunery to drive Oxford current of drive Bus voltage of drive Actual output voltage of drive RHM of association consect and low Program y after control on drive Program y after control output (to even)		
P21.33 P21.34 P21.35 P21.35 P21.35 P21.35 P21.35 P21.36	Program y contract in other Actual present in Angunety to chose Output current of deve Bus voltage of chose Actual output voltage of deve RMM of works conventional to deve Mengunety after consectable form (the work) Programsy after consectable control (the work)		
F11.33 F33.34 F33.35 F33.35 F33.35 F33.35 F33.35 F33.35 F33.35 F33.15	Program y contract in other Actual present Negatory to drive Colput current of drive Bas voltage of drive Actual output voltage (if drive RPT) of accor convert act to drive Program y after current of the drive Program y after current of colputing (see sort) Program y after current of colputing (see sort) Program y after current of colputing (see sort) Program y after current of colputing (see sort)		
F11.33 F13.34 F13.35 F13.35 F13.37 F13.37 F13.30 F13.30 F13.10 F13.10	Program y contract in carbon Actual present in Anguatory to drive Output current of drive Bas voltage all drive Attual evaluat voltage of drive Program y after current cabilitation (bas work) Program y after current cabilitation (bas work)		

# Chapter 6: Communications

# **Communications:** Port Configuration

The Communications Port Configuration for any module containing comm ports is accessed from the Hardware Configuration window. For example, to access the P3-550(E) communications port configuration, first select the Local Base





Group from the Hardware Configuration window by double left-clicking the Local Base Group or by right-clicking the Local Base Group and selecting Open from the drop down menu as seen above.

Then select the P3-550(E) by double left-clicking the CPU or by right-clicking the CPU and selecting Open from the drop down list as seen above. This will display the P3-550(E) configuration window seen here.



Although the following descriptions will focus on the P3-550(E) communications ports, the settings also apply to any other module containing these ports (P3-530, P3-RS, P3-RX).

# **Communications: Port Configuration**

# Ethernet Configuration

Ethernet Ports: There are two 10/100Base-T Ethernet ports on the P3-550(E) CPU.

- External Ethernet: The upper Ethernet port is referred to as the "External Ethernet Port". This port can connect to Modbus TCP Client devices, Modbus TCP Server devices and PCs running the Productivity3000 programming software.
- The External Ethernet Port is configured with an IP Address, Subnet Mask and Default Gateway, allowing it to function seamlessly on a typical LAN network.
- Local Ethernet: The lower Ethernet (Remote I/O)port is referred to as the "Local Ethernet Port". This port functions as a Productivity3000 Remote I/O Client. The Local Ethernet Port is not configurable and each CPU Remote I/O network should be located on its own physical or logical network.



NOTE: Two CPU Remote I/O networks cannot co-exist on the same LAN.

# **External Ethernet Port Settings**

- (a) Port Name: Allows the entry of a unique Name for the External Ethernet Port. This Name is referenced in the Communications instructions (MRX, MWX, RX, WX) to select the Port to send the request from.
- Port Security Option: This Option can be used as a simple Security measure to prevent Modbus TCP write requests from being accepted by the CPU. To allow Reads and Writes, select Read/Write.
- CP/IP Settings: The IP Setting of this Port may be changed in several ways:
  - The Settings may be entered manually in the Choose CPU tool in the Productivity Suite programming software. This allows the user to make changes to the IP to allow connection by the computer running the Productivity Suite programming software. Changes are sent using Multicast Messages.
  - The Settings can be saved as part of the project. This must be Enabled in the P3-550(E) Hardware Configuration Settings by selecting Use the Following (discussed on Item f below). If handled this way, the Settings stored in the project will take effect at Project Transfer and at boot up only. The Settings may be changed after boot up.
- Use Current Settings: When selected, Project Transfer or boot up will not make changes to the TCP/IP Settings of the CPU.
- Use DHCP: This specifies that the CPU should request its IP Settings from a DHCP Server on the network.



**NOTE:** If the CPU is set to use DHCP for it's IP Settings it cannot, in all likelihood, be used as a Modbus TCP Server.

# **Communications: Port Configuration**

- Use The Following: If this Option is selected, the CPU will set itself to the specified project Settings upon Project Transfer or at boot up.
- IP Address: This field is where the IP Address is specified in Four Octets.

For Example: 192.168.1.5

Subnet Mask: This field is where the Subnet Mask is specified in Four Octets (i.e., 255.255.255.0). The Subnet Mask is used in conjunction with the IP Address to configure a Logical Network.

Default Gateway: This field is where the Default Gateway Address is specified in Four Octets (i.e., 192.168.1.1). This is typically the IP Address of the router on

the network. If a target IP Address is specified in an outgoing message from the CPU that is not in the Local Subnet, the Default Gateway Address is where this message will be sent.

Timeout Between Data Query and Response: The Time period specified in this field is the Time between the queries sent from the CPU (via a Communication instruction, such as a MRX, MWX, RX or WX) and the Time a response from that device is received. If the Response takes longer to receive (or is not received) than the specified Time period, a Timeout Error will occur for the given instruction. Each instruction has a Timeout Status bit that can be assigned to it. See the diagram shown here.



Modbus TCP Port: This is the listening TCP Port Number for Modbus TCP connections. If necessary, this value can be adjusted for advanced router access. In most situations, this Number should be left at 502.

Comm Heartbeat Value: This feature allows the ladder logic in the CPU to know if a device has stopped communicating to the CPU. If a value is placed in this field, the CPU will start a timer between each communication packet coming in to the CPU. If a communication packet fails to be received by the CPU within the specified time period, the System Bit Ethernet Heartbeat Timeout Bit will become true.

# **Remote Access Configuration**

### Local Ethernet Port Settings

- Timeout Between Data Query and Response: The Time period specified in this field is the Time between the queries sent from the CPU (for Remote I/O Nodes, PS-AMC modules and GS Drive Nodes) and the Time a Response from that device is Received. If the Response takes longer to receive (or is not received) than the specified Time period, a Timeout Error will occur for the given device and an Error will be generated in the Error Log. For P3-RS/RX Timeouts, the Error will be critical or non-critical, dependent on the Hot-Swap settings for that unit, its I/O Modules and P3-EX Bases. See Modbus Server diagram shown on previous page.
- Comm Heartbeat Value: This value specifies how long the Remote I/O Slaves and PS-AMC modules should wait for a communication packet from the CPU. If a communication packet is not received from the CPU within the specified time period, all outputs on the Remote Slave will be turned OFF.

# **Remote Access Configuration**

	Options   Ethernet Forts   Remote Access   Serial Parts		
	Viets Server Function Aut (1-55555)     Sessen Timesut 10 mm (1-70)     Sessen Timesut	81	
	Password Option Account		
121	Confirm Parament		

- Web Server Function: Allows the ability to make a non secure web connection to the P3-550(E) in order to access the USB pen drive and view read-only system tags. When enabled, a port number selection is required.
  - Port: (Default 80) Allows user to set a port number ranging from 1-65535.
- Session Timeout: Allows the user to set a specific time limit (1-20 mins.) on inactivity that will close the Web Server connection. If there is no activity between the PC and the Web Server for the specified time limit, the connection will close.
- Mobile Function: Enables Remote Access which allows the CPU Data Remote Monitor App to monitor the selected tags.
- Password Option: Allows the user to set a password for access to the Web Server.
  - Enter an account name and password of up to a combination of 16 numbers and characters (can include special characters).

Productivity<sub>3000</sub>, Hardware User Manual, 4th Edition, Rev. V

# Serial Configuration

ALCON .		No. of Concession, Name	a same the same	et.
2424	Partners (D)	100.20	05-485	
1771	ment particular (h.).	dead from the	Read For the	
	Protoni (C)	main a 171	Halas 571	
	Saultate (1)	10.20	18.36	
	turk Athens (a)			
	Party (D)	OM	OH	
	Deta filts O.b.			
	StarDia (h)	a com	1	
-	Duples Place	+aPDutes	1000	
	RTS Hode	Assert During Transmit		
	RTS Off Delay Time (5 5,000 manc)	1 m	ec:	
	RTS On Delay Time ID 5,000 masch	2.00	ec.	
	Timesuit between query and response (300-30,000 mer)	1.001m	e :	5 c):00 roots
	Phrilium Character Terminit (3-35,000 mmer)			
	Resource, Results 1 Delay (3-5,000 rules)	0		1 mm
	Carmilles/Deet Jave C-1.003 and	D		

When the Serial Ports Tab is selected, the Serial Ports settings are displayed as shown below.

There are two Serial Ports on the P3-550(E) CPU. There is an RS-232 Port with an RJ-12 connector and a 2-wire RS-485 Port with a removable three point terminal block. Both Ports are capable of Modbus RTU Client (device that initiates communications requests) and Server (device that responds to communications requests) communications. They are also capable of ASCII outgoing strings and incoming strings.

# RS-232 and RS-485 Port Settings

- Port Name: Allows the entry of a unique Name for the RS-232 and RS-485 Ports. This name is referenced inside of the Communications instructions (MRX, MWX, RX, WX) and ASCII instructions (AIN, AOUT, CPO, CPI) to select the Port to send or receive the request.
- Port Security: This Option can be used as a simple Security measure to prevent Modbus TCP write requests from being accepted by the CPU. To allow Reads and Writes, select Read/Write.
- Protocol: This field determines whether the Port is used for Modbus RTU communications, sending or receiving ASCII Strings or performing the Custom Protocol function.
- Baud Rate: Choose the Baud Rate that your device and the CPU should communicate in this field. The appropriate choice will vary greatly with device, application and environment. The important point is that all devices communicating on the network need to be set to the same Baud Rate. The available Baud Rates are 1200, 2400, 9600, 19200, 33600, 38400, 57600 and 115200 bps.

### **RS-232 and RS-485 Port Settings**

- Node Address: This field is used only when the CPU is a Modbus RTU Server device. This field is used to uniquely identify the CPU on the network. This setting is also sometimes referred to as a Station Address. This field can be set from 1 to 247.
- Parity: The Parity Bit is used as a simple, low-level form of Error Detection. All devices on the network need to be at the same Parity setting. The appropriate choice will vary with devices. Valid selections are None, Even and Odd.
- Data Bits: This field determines whether the communications packet uses Seven Data Bits or Eight Data Bits. Eight Data Bits is the only valid selection for Modbus RTU. Either Seven or Eight Data Bits can be selected when using ASCII communications. Set this field to match the device that is connected to the CPU.
- Stop Bits: This field determines whether the communications packet uses One or Two Stop Bits. Set this field to match the device that is connected to the CPU.
- Duplex Mode: In ASCII/Custom Protocol mode Half Duplex of Full Duplex can be chosen.
  - Half Duplex: When selected, the serial port can either transmit or receive, but not both at the same time.
  - Full Duplex: When selected, allows the serial port to transmit and receive simultaneously. (Only available in ASCII/Custom Protocol).
- It RTS Mode: Set the RTS mode to control the Request to Send signal out of the Serial Port.
- In the analysis of the second seco



# **RS-232 and RS-485 Port Settings**

(I) RTS On Delay Time (RS-232 Only): This Time period is the amount of Time between when the RTS Signal is turned ON and the data transmission begins. The diagram illustrates this. This setting may be needed when using media converters (RS-232 to RS-485 converters) and/or radio modems. A delay may be needed after the assertion of the RTS Signal and when the data transmission begins for processing time in the device.



Timeout Between Query and Response: The Time period specified in this field is the Time between the queries sent from the CPU (via a Communication instruction, such as an MRX, MWX, RX, or WX) and the Time a Response from that device is Received. If the Response takes longer to receive (or is not received) than the specified Time period, a Timeout Error will occur for the given instruction. Each instruction has a Timeout Status bit that can be assigned to it.



Modbus Character Timeout: The Modbus Character Delay Time is specified as the Time between two bytes (or characters) within a given Modbus Message. The Modbus RTU specification states that this time must be no more than 1.5 Character Times (real time based on Baud Rate). Sometimes delays do occur between bytes when using radio modems, media converters, etc. This setting allows some tolerance in these situations for the incoming Modbus Messages in the CPU. The CPU will wait for the amount of time specified in this field before

discarding the incomplete packet. If the CPU does not receive the remainder of the Message within the specified Time Frame, it will discard the first portion of the Message and wait for a new Message. The diagram illustrates this. This



setting may be needed when using media converters (RS-232 to RS-422/485 converters) and/or radio modems. A delay may be needed at the end of the data transmission for processing time in the devices.

### RS-232 and RS-485 Port Settings

0

Response/Request Delay Response/Request Delay (RS-485 Only): This setting is used when the CPU is a Modbus RTU Server or Client on the RS-485 Port.

The total Response Time can be up to the Total CPU Scan Time + the Value specified in this field. When using 2-wire RS-485 communications, sometimes Echoes can occur since both devices use the same differential signal pair to send and receive.

- If acting as a Server (on left below), upon receiving a Modbus Request, the CPU will wait for the time period specified in this field before sending a Response. This can be used with slow clients that need extra time to change from sending to receiving.
- If acting as a Client (on right below), after receiving a Modbus Response, the CPU will wait for the time period specified in this field before sending another Request. This can be used to delay request messages in order to give extra time for slow server devices.



Comm Heartbeat Value: This feature allows the ladder logic in the CPU to know if a device has stopped communicating to the CPU. If a value is placed in this field, the CPU will start a timer between each communication packet coming in to the CPU. If a communication packet fails to be received by the CPU within the specified Time period, the System Bit RS-232 Heartbeat Timeout Bit or RS-485 Heartbeat Timeout Bit will become true.

### **Chapter 6: Communications**

# **Communications: Error Codes**



**NOTE:** The only time you will see Communications Error Codes is when the CPU is the Master of a Communications Network.

To simplify the process of identifying a possible Error, the Productivity3000<sup>®</sup> CPU will automatically report to a specific memory location an Error Code that helps identify the existing issue. The Error Codes are reported in the Exception Response String Tag specified in the instruction as shown below.

odbus Weita (MMO)			-
• EbenetPart (Pullie)	int .	in Rogram	• 🖬
Padom		Cargota	•
10 Permitte	10	Second	•
Same Rode Number	J15 Default	<285) (FW	• 🗐
Stelates Charts		TimpA	• 🗐
Sane Made Sandre	Drisk-0	Regionse String	- 6
and the second		AREA HAVE A	and particular

The Exception Response String field is available on the following instructions:

- GS Drives Read
- GS Drives Write
- Modbus Read

- Modbus Write
- .....

- Network Read
- Network Write

Dataworx Request

The Table shown below provides a list of Productivity3000 Communication Error Codes that may be reported by the Productivity CPU.

Productivity3000 Communication Error Codes				
Error Code	Description	Suggested Fix		
01	Function Code not supported	Check instruction or connected device and cor- rect Function code or address range selected.		
02	Address out of range. This error is typically generated when a Modbus address has been requested that does not exist in the CPU.	Check instruction or connected device and cor- rect Function code or address range selected.		
03	Illegal Data Value. This error is typically generated when the Modbus request sent to the CPU is formed incorrectly.	Check the Modbus request against the Modbus protocol specification (www.modbus.org) to verify that it was formed correctly.		
04	Device Failure	Check connected device		
06	Slave Device is Busy. This error is typically due to excess communications to the EDRV.	Slow down the poll rate in the GS instruction.		
## **P3000 EtherNet/IP Error Codes**





CPU server (will not generate error) Note: Other adapters may generate this error

P3000 EtherNet/IP Error Codes					
General Status Error	Extended Status Error	Name	Description	P3000 Supported	
0x01	0x0100	Connection In Use/ Duplicate Forward Open	A connection is already established from the target device sending a Forward Open request or the target de- vice has sent multiple forward open request. This could be caused by poor network traffic. Check the cabling, switches and connections.	ø	
0x01	0x0103	Transport Class/ Trigger Combination not supported	The Transport class and trigger combination is not supported. The Productivity3000 CPU only supports Class 1 and Class 3 transports and triggers: Change of State and Cyclic.	1	
0x01	0x0106	Owner Conflict	An existing exclusive owner has already configured a connection to this Connection Point. Check to see if other Scanner devices are connected to this adapter or verify that Multicast is supported by adapter device if Multicast is selected for Forward Open. This could be caused by poor network traffic. Check the cabling, switches and connections.	1	
0x01	0x0107	Target Connection Not Found	This occurs if a device sends a Forward Close on a connection and the device can't find this connection. This could occur if one of these devices has powered down or if the connection timed out on a bad connection. This could be caused by poor network traffic. Check the cabling, switches and connections.	1	
0x01	0x0108	Invalid Network Con- nection Parameter	This error occurs when one of the parameters specified in the Forward Open message is not supported such as Connection Point, Connection type, Connection priority, redundant owner or exclusive owner. The Productivi- ty3000 CPU does not return this error and will instead use errors 0x0120, 0x0121, 0x0122, 0x0123, 0x0124, 0x0125 or 0x0132 instead.	¢	
0x01	0x0109	Invalid Connection Size	This error occurs when the target device doesn't support the requested connection size. Check the documentation of the manufacturer's device to verify the correct Connec- tion size required by the device. Note that most devices specify this value in terms of bytes. The Productivity3000 CPU does not return this error and will instead use errors 0x0126, 0x0127 and 0x0128.	×	
0x01	0x0110	Target for Connection Not Configured	This error occurs when a message is received with a connection number that does not exist in the target device. This could occur if the target device has powered down or if the connection timed out. This could be caused by poor network traffic. Check the cabling, switches and connections.	×	
0x01	0x0111	RPI Not Supported	This error occurs if the Originator is specifying an RPI that is not supported. The Productivity3000 CPU will accept a minimum value of 10ms on a CIP Forward Open request. However, the CPU will produce at the specified rate up to the scan time of the installed project. The CPU cannot product any faster than the scan time of the running project.	ø	

P3000 EtherNet/IP Error Codes					
General Status Error	Extended Status Error	Name	Description	P3000 Supported	
0x01	0x0112	RPI Value not ac- ceptable	<ul> <li>This error can be returned if the Originator is specifying an RPI value that is not acceptable. There may be six additional values following the extended error code with the acceptable values. An array can be defined for this field in order to view the extended error code attributes. If the Target device supports extended status, the format of the values will be as shown below:</li> <li>Unsigned Integer 16, Value = 0x0112, Explanation: Extended Status code</li> <li>[Unsigned Integer 8, Value = variable, Explanation: Acceptable Originator to Target RPI type, values: 0 = The RPI specified in the forward open was acceptable (O -&gt; T value is ignored), 1 = unspecified (use a different RPI), 2 = minimum acceptable RPI (too fast), 3 = maximum acceptable RPI (too slow), 4 = required RPI to corrected mismatch (data is already being consumed at a different RPI), 5 to 255 = reserved.</li> <li>Unsigned Integer 32, Value = variable, Explanation: Value of 0 -&gt; T RPI that is within the acceptable range for the application.</li> </ul>	×	
0x01	0x0113	Out of Connections	The Productivity3000 EtherNet/IP Adapter connection limit of 4 when doing Class 3 connections has been reached. An existing connection must be dropped in order for a new one to be generated.	\$	
0x01	0x0114	Vendor ID or Product Code Mismatch	The compatibility bit was set in the Forward Open message but the Vendor ID or Product Code did not match.	1	
0x01	0x0115	Device Type Mis- match	The compatibility bit was set in the Forward Open message but the Device Type did not match.	>	
0x01	0x0116	Revision Mismatch	The compatibility bit was set in the Forward Open message but the major and minor revision numbers were not a valid revision.	<b>\$</b>	
0x01	0x0117	Invalid Produced or Consumed Application Path	This error is returned from the Target device when the Con- nection Point parameters specified for the O -> T (Output) or T -> O (Input) connection is incorrect or not supported. The Productivity3000 CPU does not return this error and uses the following error codes instead: 0x012A, 0x012B or 0x012F.	×	
0x01	0x0118	Invalid or Inconsistent Configuration Applica- tion Path	This error is returned from the Target device when the Connection Point parameter specified for the Configuration data is incorrect or not supported. The Productivity3000 CPU does not return this error and uses the following error codes instead: 0x0129 or 0x012F.	×	
0x01	0x0119	Non-listen Only Con- nection Not Opened	This error code is returned when an Originator device attempts to establish a listen only connection and there is no non-listen only connection established. The Productiv- ity3000 CPU does not support listen only connections as Scanner or Adapter.	*	

P3000 E	EtherNet/IP	<b>Error Codes</b>		
General Status Error	Extended Status Error	Name	Description	P3000 Supported
0x01	0x011A	Target Object Out of Connections	The maximum number of connections supported by this instance of the object has been exceeded.	×
0x01	0x011B	RPI is smaller than the Production Inhibit Time	The Target to Originator RPI is smaller than the Target to Originator Production Inhibit Time. Consult the manufactur- er's documentation as to the minimum rate that data can be produced and adjust the RPI to greater than this value.	×
0x01	0x011C	Transport Class Not Supported	The Transport Class requested in the Forward Open is not supported. Only Class 1 and Class 3 classes are supported in the Productivity3000 CPU.	×
0x01	0x011D	Production Trigger Not Supported	The Production Trigger requested in the Forward Open is not supported. In Class 1, only Cyclic and Change of state are supported in the Productivity3000 CPU. In Class 3, Application object is supported.	×
0x01	0x011E	Direction Not Sup- ported	The Direction requested in the Forward Open is not supported.	×
0x01	0x011F	Invalid Originator to Target Network Connection Fixed/ Variable Flag	The Originator to Target fixed/variable flag specified in the Forward Open is not supported . Only Fixed is supported in the Productivity3000 CPU.	×
0x01	0x0120	Invalid Target to Originator Network Connection Fixed/ Variable Flag	The Target to Originator fixed/variable flag specified in the Forward Open is not supported. Only Fixed is supported in the Productivity3000 CPU.	×
0x01	0x0121	Invalid Originator to Target Network Con- nection Priority	The Originator to Target Network Connection Priority specified in the Forward Open is not supported. Low, High, Scheduled and Urgent are supported in the Productivi- ty3000 CPU.	×
0x01	0x0122	Invalid Target to Originator Network Connection Priority	The Target to Originator Network Connection Priority specified in the Forward Open is not supported. Low, High, Scheduled and Urgent are supported in the Productivi- ty3000 CPU.	×
0x01	0x0123	Invalid Originator to Target Network Connection Type	The Originator to Target Network Connection Type specified in the Forward Open is not supported. Only Unicast is sup- ported for O -> T (Output) data in the Productivity3000 CPU.	1
0x01	0x0124	Invalid Target to Originator Network Connection Type	The Target to Originator Network Connection Type specified in the Forward Open is not supported. Multicast and Unicast is supported in the Productivity3000 CPU. Some devices may not support one or the other so if this error is encountered try the other method.	1
0x01	0x0125	Invalid Originator to Target Network Connection Redun- dant_Owner	The Originator to Target Network Connection Redundant_ Owner flag specified in the Forward Open is not supported. Only Exclusive owner connections are supported in the Productivity3000 CPU.	1
0x01	0x0126	Invalid Configuration Size	This error is returned when the Configuration data sent in the Forward Open does not match the size specified or is not supported by the Adapter. The Target device may return an additional Unsigned Integer 16 value that specifies the maximum size allowed for this data. An array can be defined for this field in order to view the extended error code attributes.	×

P3000 EtherNet/IP Error Codes						
General Status Error	Extended Status Error	Name	Description	P3000 Supported		
0x01	0x0127	Invalid Originator to Target Size	This error is returned when the Originator to Target (Output data) size specified in the Forward Open does not match what is in the Target. Consult the documentation of the Adapter device to verify the required size. Note that if the Run/Idle header is requested, it will add 4 additional bytes and must be accounted for in the Forward Open calculation. The Productivity3000 CPU always requires the Run/Idle header so if the option doesn't exist in the Scanner device, you must add an additional 4 bytes to the O -> T (Output) setup. Some devices may publish the size that they are looking for as an additional attribute (Unsigned Integer 16 value) of the Extended Error Code. An array can be defined for this field in order to view the extended error code attributes. NOTE: This error may also be generated when a Connection Point value that is invalid for IO Messaging (but valid for other cases such as Explicit Messaging) is specified, such as 0. Please verify if the Connection Point value is valid for IO Messaging in the target device.	۵		
0x01	0x0128	Invalid Target to Originator Size	This error is returned when the Target to Originator (Input data) size specified in the Forward Open does not match what is in Target. Consult the documentation of the Adapter device to verify the required size. Note that if the Run/Idle header is requested, it will add 4 additional bytes and must be accounted for in the Forward Open calculation. The Productivity3000 CPU does not support a Run/Idle header for the T -> 0 (Input) data. Some devices may publish the size that they are looking for as an additional attribute (Unsigned Integer 16 value) of the Extended Error Code. An array can be defined for this field in order to view the extended error code attributes. NOTE: This error may also be generated when a Connection Point value that is invalid for IO Messaging (but valid for other cases such as Explicit Messaging) is specified, such as 0. Please verify if the Connection Point value is valid for IO Messaging in the target device.	*		
0x01	0x0129	Invalid Configuration Application Path	This error will be returned by the Productivity3000 CPU if a Config- uration Connection with a size other than 0 is sent to the CPU. The Configuration Connection size must always be zero if it this path is present in the Forward Open message coming from the Scanner device.	1		
0x01	0x012A	Invalid Consuming Application Path	This error will be returned by the Productivity3000 CPU if the Consuming (O -> T) Application Path is not present in the Forward Open message coming from the Scanner device or if the specified Connection Point is incorrect.	1		
0x01	0x012B	Invalid Producing Application Path	This error will be returned by the Productivity3000 CPU if the Producing (T -> O) Application Path is not present in the Forward Open message coming from the Scanner device or if the specified Connection Point is incorrect.	1		
0x01	0x012C	Config. Symbol Does not Exist	The Originator attempted to connect to a configuration tag name that is not supported in the Target.	×		
0x01	0x012D	Consuming Symbol Does not Exist	The Originator attempted to connect to a consuming tag name that is not supported in the Target.	×		
0x01	0x012E	Producing Symbol Does not Exist	The Originator attempted to connect to a producing tag name that is not supported in the Target.	×		
0x01	0x012F	Inconsistent Application Path Combination	The combination of Configuration, Consuming and Producing appli- cation paths specified are inconsistent.	×		

P3000 B	EtherNet/IP	Error Codes		
General Status Error	Extended Status Error	Name	Description	P3000 Supported
0x01	0x0130	Inconsistent Consume data format	Information in the data segment not consistent with the format of the data in the consumed data.	×
0x01	0x0131	Inconsistent Product data format	Information in the data segment not consistent with the format of the data in the produced data.	×
0x01	0x0132	Null Forward Open function not supported	The target device does not support the function requested in the NULL Forward Open request. The request could be such items as "Ping device", "Configure device application", etc.	×
0x01	0x0133	Connection Timeout Multiplier not accept- able	The Connection Multiplier specified in the Forward Open request not acceptable by the Target device (once multiplied in conjunction with the specified timeout value). Consult the manufacturer device's documentation on what the acceptable timeout and multiplier are for this device.	×
0x01	0x0203	Connection Timed Out	This error will be returned by the Productivity3000 CPU if a message is sent to the CPU on a connection that has already timed out. Connections time out if no message is sent to the CPU in the time period specified by the RPI rate X Connection multiplier specified in the Forward Open message.	×
0x01	0x0204	Unconnected Request Timed Out	This time out occurs when the device sends an Uncon- nected Request and no response is received within the specified time out period. In the Productivity3000 CPU, this value may be found in the hardware configuration under the Ethernet port settings for the P3-550(E) or P3-530.	ø
0x01	0x0205	Parameter Error in Unconnected Request Service	This error occurs when Connection Tick Time/Connection time-out combination is specified in the Forward Open or Forward Close message this is not supported by the device.	×
0x01	0x0206	Message Too Large for Unconnect- ed_Send Service	Occurs when Unconnected_Send message is too large to be sent to the network.	×
0x01	0x0207	Unconnected Acknowledge without Reply	This error occurs if an Acknowledge was received but no data response occurred. Verify that the message that was sent is supported by the Target device using the device manufacturer's documentation.	×
0x01	0x0301	No Buffer Memory Available	This error occurs if the Connection memory buffer in the target device is full. Correct this by reducing the frequency of the messages being sent to the device and/or reducing the number of connections to the device. Consult the manufacturer's documentation for other means of correcting this.	×
0x01	0x0302	Network Bandwidth not Available for Data	This error occurs if the Producer device cannot support the specified RPI rate when the connection has been configured with schedule priority. Reduce the RPI rate or consult the manufacturer's documentation for other means to correct this.	×
0x01	0x0303	No Consumed Connection ID Filter Available	This error occurs if a Consumer device doesn't have an available consumed_connection_id filter.	×
0x01	0x0304	Not Configured to Send Scheduled Priority Data	This error occurs if a device has been configured for a scheduled priority message and it cannot send the data at the scheduled time slot.	×

P3000 E	EtherNet/IP	Error Codes		
General Status Error	Extended Status Error	Name	Description	P3000 Supported
0x01	0x0305	Schedule Signature Mismatch	This error occurs if the schedule priority information does not match between the Target and the Originator.	×
0x01	0x0306	Schedule Signature Validation not Possible	This error occurs when the schedule priority information sent to the device is not validated.	×
0x01	0x0311	Port Not Available	This error occurs when a port number specified in a port segment is not available. Consult the documentation of the device to verify the correct port number.	×
0x01	0x0312	Link Address Not Valid	The Link address specified in the port segment is not correct. Consult the documentation of the device to verify the correct port number.	×
0x01	0x0315	Invalid Segment in Connection Path	This error occurs when the target device cannot understand the segment type or segment value in the Connection Path. Consult the documentation of the device to verify the correct segment type and value. If a Connection Point greater than 255 is specified this error could occur.	\$
0x01	0x0316	Forward Close Ser- vice Connection Path Mismatch	This error occurs when the Connection path in the Forward Close message does not match the Connection Path configured in the connection. Contact Tech Support if this error persists.	×
0x01	0x0317	Scheduling Not Specified	This error can occur if the Schedule network segment or value is invalid.	×
0x01	0x0318	Link Address to Self Invalid	If the Link address points back to the originator device, this error will occur.	×
0x01	0x0319	Secondary Resource Unavailable	This occurs in a redundant system when the secondary connection request is unable to duplicate the primary connection request.	×
0x01	0x031A	Rack Connection Already established	The connection to a module is refused because part or all of the data requested is already part of an existing rack connection.	×
0x01	0x031B	Module Connection Already established	The connection to a rack is refused because part or all of the data requested is already part of an existing module connection.	×
0x01	0x031C	Miscellaneous	This error is returned when there is no other applicable code for the error condition. Consult the manufacturer's documentation or contact Tech support if this error persist.	×
0x01	0x031D	Redundant Connec- tion Mismatch	This error occurs when these parameters don't match when establishing a redundant owner connection: O -> T RPI, O -> T Connection Parameters, T -> O RPI, T -> O Connec- tion Parameters and Transport Type and Trigger.	×
0x01	0x031E	No more User Config- urable Link Resources Available in the Producing Module	This error is returned from the Target device when no more available Consumer connections available for a Producer.	×

## P3000 EtherNet/IP Error Codes

General Status Error	Extended Status Error	Name	Description	P3000 Supported
0x01	0x031F	No User Configurable Link Consumer Re- sources Configured in the Producing Module	This error is returned from the Target device when no Consumer connections have been configured for a Producer connection.	×
0x01	0x0800	Network Link Offline	The Link path is invalid or not available.	×
0x01	0x0810	No Target Application Data Available	This error is returned from the Target device when the appli- cation has no valid data to produce.	×
0x01	0x0811	No Originator Applica- tion Data Available	This error is returned from the Originator device when the application has no valid data to produce.	×
0x01	0x0812	Node Address has changed since the Network was sched- uled	This specifies that the router has changed node addresses since the value configured in the original connection.	×
0x01	0x0813	Not Configured for Off-subnet Multicast	The producer has been requested to support a Multicast connection for a consumer on a different subnet and does not support this functionality.	×
0x01	0x0814	Invalid Produce/Con- sume Data format	Information in the data segment not consistent with the format of the data in the consumed or produced data. Errors 0x0130 and 0x0131 are typically used for this situation in most devices now.	×
0x02	N/A	Resource Unavailable for Unconnected Send	The Target device does not have the resources to process the Unconnected Send request.	×
0x04	N/A	Path Segment Error in Unconnected Send	The Class, Instance or Attribute value specified in the Unconnected Explicit Message request is incorrect or not supported in the Target device. Check the manufacturer's documentation for the correct codes to use.	×
0×09	Index to error	Error in Data Segment	This error code is returned when an error is encountered in the Data segment portion of a Forward Open message. The Extended Status value is the offset in the Data segment where the error was encountered.	×
0x0C	Optional	Object State Error	This error is returned from the Target device when the current state of the Object requested does not allow it to be returned. The current state can be specified in the Optional Extended Error status field.	×
0x10	Optional	Device State Error	This error is returned from the Target device when the current state of the Device requested does not allow it to be returned. The current state can be specified in the Optional Extended Error status field.	×
0x13	N/A	Not Enough Data	Not enough data was supplied in the service request specified.	×
0x15	N/A	Too Much Data	Too much data was supplied in the service request specified.	×