Dual Monitor Workstation Part# 172518 **Assembly Procedure**



Copyright 2025, Automationdirect.com Incorporated/ All Rights Reserved Worldwide

Hardware Included

- 8 Button Head Screws M4-0.7 x 10mm, with lock washers
- 5 Socket Head Cap Screws M6-1.0 x 10mm
- 4 Socket Head Cap Screws M6-1.0 x 12mm
- 1 Socket Head Cap Screw M8-1.25 x 20mm 2 Socket Head Cap Screws M8-1.25 x 45mm
- 2 Roll-in T-Nuts, Slot size 8, 15/40 series M8-1.25 thread
- 2 Flanged Head Screws M3-0.5 x 8mm

0000

Socket Head

Cap Screw

M6-1.0x10mm

0000

0000

0000

0000

, o o o o

- 2 Roll-in T-Nuts, Slot size 10, 45 Series, M8-1.25 thread
- Washer M8
- Washer M8, Plastic
- 2 Serrated Washers, M8

Secure Articulating Member

M6-1.0x10mm Socket Head

to Pillar by installing 2X

Cap Screws with provided 5mm

top screw in step 2-1.

Allen Wrench. Then tighten the

- 2 Plastic Cover Caps
- Velcro Strips, adhesive backed, 1" x 8"
- 1 Allen Wrench 5mm Allen Wrench 6mm
- Socket, 8mm
- 1 Wrench, 10mm







