


# Software

SuperDrive G2 15.1.0.4776

## User's Manual





# **User's Manual**

Series: SuperDrive G2

Language: English

Document: 10001140879 / 22

Publication Date: 04/2019

# Contents

<b>1</b>	<b>SuperDrive G2</b>	<b>6</b>
1	Welcome .....	6
2	Contact .....	7
<b>2</b>	<b>Introduction</b>	<b>8</b>
1	System Requirements .....	8
2	Supported Drives .....	8
3	User's Manual .....	18
<b>3</b>	<b>Getting to Know the Environment</b>	<b>19</b>
1	Main Window .....	19
2	Project Tree .....	20
<b>4</b>	<b>Safety</b>	<b>22</b>
1	Safety Notice .....	22
2	Copyright Notice .....	22
<b>5</b>	<b>What's New</b>	<b>23</b>
1	What's New in this Version .....	23
2	What's New in Previous Versions .....	23
<b>6</b>	<b>Installation/Uninstalation</b>	<b>34</b>
1	Before Installing .....	34
2	Installing .....	34
3	Uninstalling .....	41
4	USB Driver .....	46
<b>7</b>	<b>Menus</b>	<b>47</b>
1	Project .....	47
	New .....	48
	Open .....	48
	Close .....	49
	Save .....	49
	Save As .....	50
	Remove .....	50
	Import .....	51
	Export .....	52
	Change Voltage .....	52
	Print .....	53
	Project Information .....	53
	Exit .....	54
2	Drive .....	54
	Identify Drive .....	55
	Communication Setup .....	57
	Security System .....	63

	Security System (Session) .....	64
	New Parameters File .....	64
	Edit Parameters File .....	65
	Remove Parameters File .....	68
	Export Parameters File .....	69
	Read Parameters from Drive .....	70
	Write Parameters to Drive .....	71
	Monitor Parameters .....	75
	Monitor using Keypad .....	77
	Monitor Status .....	78
	Monitor Speed Reference .....	83
	Trend .....	84
	Remove Trend File .....	92
	Export Trend File .....	92
	Trace .....	93
	Remove Trace File .....	96
	Export Trace File .....	96
<b>3</b>	<b>Tools .....</b>	<b>97</b>
	Options .....	97
	Import Database .....	101
	Convert Project .....	101
	Simplified Conversion Log .....	106
	Remove Simplified Conversion Log .....	108
	Full Conversion Log .....	108
	Remove Full Conversion Log .....	110
<b>4</b>	<b>Help .....</b>	<b>110</b>
	Contents .....	110
	About .....	111
<b>8</b>	<b>Communication .....</b>	<b>113</b>
1	Drive Parametrization .....	113
2	USB Connection .....	116
3	USB Connection - Virtual COM Port .....	118
4	RS232 Connection .....	130
5	RS485 Connection .....	133
6	Bluetooth Connection .....	148
7	Ethernet Connection .....	173
8	RS232 Cable .....	207
9	USB Cable .....	207
10	Ethernet Cable .....	210
11	USB to Serial Adapter .....	210
12	Bluetooth USB Adapter .....	211
13	Ethernet Network Adapter .....	212
14	Before Trying to Establish Communication .....	214
15	Exception During Monitoring .....	214
<b>9</b>	<b>Context menus .....</b>	<b>215</b>
1	Project .....	215
	Rename .....	215
	Save As .....	216
	Close .....	217
<b>10</b>	<b>Libraries .....</b>	<b>218</b>

<b>1</b>	<b>JFreeChart .....</b>	<b>218</b>
<b>2</b>	<b>jSSC .....</b>	<b>218</b>

# 1 SuperDrive G2

Contents of this chapter:

[Welcome](#)

[Contact](#)

---

## Start

Click the Welcome button to start.

Welcome

## 1.1 Welcome

### Welcome to SuperDrive G2 15.1.0.4776 !

Thank you for using SuperDrive G2, a windows based graph tool for parameter setting, command and monitoring of drives.

SuperDrive G2 is a computer tool for making the use of drives as easy and convenient as possible.

SuperDrive G2 provides user-friendly tools for viewing, manipulating, and exchanging data with the drive. Data can be retrieved, changed and stored.

### Main Features

- Online identification of connected drive;
- Offline configuration of drive;
- Parameter transfer from computer to the drive;
- Parameter transfer from drive to the computer;
- Offline editing of the parameters stored on the computer;
- Online editing of the parameters in drive;
- Monitoring of the drive status;
- Command operations (motor stop/run, jog, forward/reverse, local/remote, etc);
- Supports multiple databases for standard and special firmware version;
- RS232, RS485, USB and Ethernet point-to-point serial communication;
- Graphical monitoring of parameters;
- Configuration, import and visualization of variables stored in Trace function of the drive (CFW-11, CFW-11M G2, SCA-06 and CTW900)
- Project importation and exportation;
- Project conversion;
- Online help.

**NOTE!**

Some features are not available in all drives.

## 1.2 Contact



SuperDrive G2 15.1.0.4776

Technical Support: Contact a local branch or representative.

Contact Us: <http://www.weg.net/>

Publication Date: 04/2019

## 2 Introduction

Contents of this chapter:

[System Requirements](#)

[Supported Drives](#)

[User's Manual](#)

### 2.1 System Requirements

Item	Description
Processor	1 GHz or faster processor
Operating System	Windows 7 / 8 / 8.1 / 10 (x86, x64) with latest service pack available or upgrade
	You must have administrator privileges to install the software
Memory	Windows (x86) - 1 GB or more recommended
	Windows (x64) - 2 GB or more recommended
Display Color	High color resolution (16 bits) or more
Display Resolution	1024x768 pixels
	1280x1024 pixels or higher-resolution screen recommended
Disk Space	2 GB of free disk space
Pointing Device	Mouse or compatible pointing device
Java Runtime Environment	It is not necessary to install java; SuperDrive G2 already includes a suitable JRE 8.
Internet Browser	Mozilla Firefox 66 or greater
	Opera 58 or greater
	Internet Explorer 9/10/11 (Windows 7)
	Internet Explorer 10/11 (Windows 8, 8.1)
	Internet Explorer 11 (Windows 10)
	JavaScript enabled
	Browser should support Cascading Style Sheets (CSS1) and JavaScript
Printer	Inkjet or laser compatible with the OS; required only if need printing data.

(x86) = 32-bit Edition.

(x64) = 64-bit Edition.

### 2.2 Supported Drives

The following table shows drives and firmware versions that each database supplied with SuperDrive G2 supports.

Drive	SuperDrive G2
-------	---------------

		15.1.0.4776
CFW-11	1.0X	X
	1.1X	X
	1.3X	X
	1.6X	X
	2.0X	X
	2.46	X
	2.50	X
	2.51	X
	3.0X	X
	3.11	X
	3.12	X
	3.1X	X
	3.30	X
	3.31	X
	3.32	X
	3.33	X
	3.5X	X
	3.90	X
	4.01	X
	4.10	X
	4.20	X
	4.21	X
	5.1X	X
	5.2X	X
	5.30	X
	5.31	X
	5.33	X
	5.35	X
	5.36	X
	5.4X	X
	5.7X	X
	5.8X	X
	15.16	X
	15.30	X
	15.78	X
	15.84	X
	15.90	X
	15.91	X
	15.97	X
	45.11	X
45.12	X	
45.80	X	
55.20	X	
55.82	X	
65.1X	X	
65.83	X	
85.32	X	
85.82	X	
85.84	X	
85.90	X	
CFW-11RB	2.0X	X
	2.1X	X
CFW-11M G2	1.1X	X
CFW701	1.2X	X

	2.0X	X
	2.1X	X
	12.07	X
CFW700	1.0X	X
	1.2X	X
	2.00	X
	2.0X	X
	2.2X	X
CFW500	1.1X	X
	1.5X	X
	1.8X	X
	2.0X	X
CFW501	1.3X	X
	1.5X	X
	1.8X	X
CFW100	1.1X	X
	2.0X	X
	2.1X	X
	2.2X	X
	2.3X	X
	2.4X	X
MW500	1.5X	X
	1.60	X
	2.0X	X
ECW500	1.0X	X
	1.1X	X
	1.3X	X
PLC11-01	1.0X	X
	1.2X	X
	1.4X	X
	1.7X	X
PLC11-02	1.0X	X
	1.2X	X
	1.4X	X
	1.7X	X
CTW900	1.0X	X
	1.1X	X
SCA-06	1.1X	X
	1.2X	X
	1.4X	X
	1.5X	X
	1.7X	X
SSW-06	1.3X	X
	1.4X	X
	1.6X	X
	1.7X	X
	1.8X	X
SSW-07	1.2X	X
	1.3X	X
	1.4X	X
	1.5X	X
SSW-08	1.3X	X
	1.4X	X
	1.5X	X
SSW7000	1.1X	X

	1.3X	X
	1.4X	X
	1.5X	X
	1.6X	X
CFW-09 PM	10.0X	X
	11.3X	X
	12.0X	X

**NOTE!**

- <sup>(1)</sup> SSW-06 1.3X - From version 1.31 and on  
 <sup>(2)</sup> SSW-07 1.2X - From version 1.21 and on  
 <sup>(3)</sup> CFW700 1.0X - From version 1.02 and on

As new firmware versions are created, additional databases are added to SuperDrive G2.

The additional databases can be found on the Internet at the manufacturer's web site (see [Contact](#)).

If your drive uses a special firmware version (customized version), SuperDrive G2 needs an additional database. Request this additional database for the manufacturer.

The software allows communication only with the drive types listed in the above table.

Firmware is the software which controls the drive. To find out which is the firmware version, read parameter P0023.

## Older Versions

The following tables show drives and firmware versions that each database supplied with SuperDrive G2 supports.

Drive		SuperDrive G2				
		12.0.0	12.1.0	13.0.0.3103	14.0.0.3677	15.0.0.4707
CFW-11	1.0X	X	X	X	X	X
	1.1X	X	X	X	X	X
	1.3X	X	X	X	X	X
	1.6X	X	X	X	X	X
	2.0X	X	X	X	X	X
	2.46	X	X	X	X	X
	2.50	X	X	X	X	X
	2.51	X	X	X	X	X
	3.0X	X	X	X	X	X
	3.11	X	X	X	X	X
	3.12	X	X	X	X	X
	3.1X	X	X	X	X	X
	3.30	X	X	X	X	X
	3.31	X	X	X	X	X
	3.32	X	X	X	X	X
	3.33	X	X	X	X	X
	3.5X	X	X	X	X	X
3.90	X	X	X	X	X	

	4.01	X	X	X	X	X
	4.10	X	X	X	X	X
	4.20	X	X	X	X	X
	4.21	X	X	X	X	X
	5.1X	X	X	X	X	X
	5.2X		X	X	X	X
	5.30	X	X	X	X	X
	5.31	X	X	X	X	X
	5.33			X	X	X
	5.4X	X	X	X	X	X
	5.7X			X	X	X
	5.8X		X	X	X	X
	15.16	X	X	X	X	X
	15.30					X
	15.78				X	X
	15.84	X	X	X	X	X
	15.90	X	X	X	X	X
	15.91	X	X	X	X	X
	15.97	X	X	X	X	X
	45.11	X	X	X	X	X
	45.12	X	X	X	X	X
	45.80					X
	55.82					X
	65.1X	X	X	X	X	X
	85.32		X	X	X	X
	85.82				X	X
	85.84					X
	85.90					X
CFW-11RB	2.0X		X	X	X	X
	2.1X					X
CFW-11M G2	1.1X					X
CFW701	1.2X	X	X	X	X	X
	2.0X	X	X	X	X	X
	2.1X					X
	12.07				X	X
CFW700	1.0X	X	X	X	X	X
	1.2X	X	X	X	X	X
	2.00	X	X	X	X	X
	2.0X	X	X	X	X	X
	2.2X					X
CFW500	1.1X	X	X	X	X	X
	1.5X	X	X	X	X	X
	1.8X	X	X	X	X	X
	2.0X		X	X	X	X
CFW501	1.3X	X	X	X	X	X
	1.5X	X	X	X	X	X
	1.8X	X	X	X	X	X

CFW100	1.1X	X	X	X	X	X
	2.0X	X	X	X	X	X
	2.1X	X	X	X	X	X
	2.2X	X	X	X	X	X
	2.3X	X	X	X	X	X
	2.4X	X	X	X	X	X
MW500	1.5X	X	X	X	X	X
	1.60				X	X
	2.0X					X
ECW500	1.0X	X	X	X	X	X
	1.1X		X	X	X	X
	1.3X					X
PLC11-01	1.0X	X	X	X	X	X
	1.2X	X	X	X	X	X
	1.4X	X	X	X	X	X
	1.7X	X	X	X	X	X
PLC11-02	1.0X	X	X	X	X	X
	1.2X	X	X	X	X	X
	1.4X	X	X	X	X	X
	1.7X	X	X	X	X	X
CTW900	1.0X	X	X	X	X	X
	1.1X	X	X	X	X	X
SCA-06	1.1X	X	X	X	X	X
	1.2X	X	X	X	X	X
	1.4X	X	X	X	X	X
	1.5X	X	X	X	X	X
	1.7X				X	X
SSW-06	1.3X	X	X	X	X	X
	1.4X	X	X	X	X	X
	1.6X	X	X	X	X	X
	1.7X	X	X	X	X	X
	1.8X	X	X	X	X	X
SSW-07	1.2X	X	X	X	X	X
	1.3X	X	X	X	X	X
	1.4X	X	X	X	X	X
	1.5X	X	X	X	X	X
SSW-08	1.3X	X	X	X	X	X
	1.4X	X	X	X	X	X
	1.5X	X	X	X	X	X
SSW7000	1.1X	X	X	X	X	X
	1.3X	X	X	X	X	X
	1.4X	X	X	X	X	X
	1.5X			X	X	X
	1.6X				X	X
CFW-09 PM	10.0X	X	X	X	X	X
	11.3X	X	X	X	X	X
	12.0X	X	X	X	X	X

Drive		SuperDrive G2			
		11.0.0	11.1.0	11.2.0	11.3.0
CFW-11	1.0X	X	X	X	X
	1.1X	X	X	X	X
	1.3X	X	X	X	X
	1.6X	X	X	X	X
	2.0X	X	X	X	X
	2.46	X	X	X	X
	2.50	X	X	X	X
	2.51	X	X	X	X
	3.0X	X	X	X	X
	3.11	X	X	X	X
	3.12	X	X	X	X
	3.1X	X	X	X	X
	3.30			X	X
	3.31			X	X
	3.32			X	X
	3.33			X	X
	3.5X	X	X	X	X
	3.90	X	X	X	X
	4.01	X	X	X	X
	4.10	X	X	X	X
	4.20			X	X
	5.1X	X	X	X	X
	5.30			X	X
5.31				X	
5.4X			X	X	
65.1X				X	
CFW701	1.2X	X	X	X	X
	2.0X	X	X	X	X
CFW700	1.0X	X	X	X	X
	1.2X	X	X	X	X
	2.00			X	X
	2.0X	X	X	X	X
CFW500	1.1X	X	X	X	X
	1.5X	X	X	X	X
CFW501	1.3X				X
	1.5X				X
CFW100	1.1X	X	X	X	X
	2.0X	X	X	X	X
	2.1X		X	X	X
	2.2X			X	X
	2.3X				X
MW500	1.5X			X	X
ECW500	1.0X	X	X	X	X
PLC11-01	1.0X	X	X	X	X
	1.2X	X	X	X	X
	1.4X	X	X	X	X
PLC11-02	1.0X	X	X	X	X
	1.2X	X	X	X	X

	1.4X	X	X	X	X
CTW900	1.0X	X	X	X	X
SCA-06	1.1X	X	X	X	X
	1.2X	X	X	X	X
	1.4X			X	X
SSW-06	1.3X	X	X	X	X
	1.4X	X	X	X	X
	1.6X	X	X	X	X
	1.7X	X	X	X	X
SSW-07	1.2X	X	X	X	X
	1.3X	X	X	X	X
	1.4X	X	X	X	X
SSW-08	1.3X	X	X	X	X
	1.4X	X	X	X	X
SSW7000	1.1X	X	X	X	X
CFW-09 PM	10.0X	X	X	X	X
	11.3X	X	X	X	X
	12.0X	X	X	X	X

Drive		SuperDrive G2												
		8.80	8.90	9.00	9.10	9.20	9.30	9.40	9.50	9.60	9.70	9.80	9.90	10.00
CFW-11	1.0X	X	X	X	X	X	X	X	X	X	X	X	X	X
	1.1X	X	X	X	X	X	X	X	X	X	X	X	X	X
	1.3X	X	X	X	X	X	X	X	X	X	X	X	X	X
	1.6X	X	X	X	X	X	X	X	X	X	X	X	X	X
	2.0X	X	X	X	X	X	X	X	X	X	X	X	X	X
	2.46				X	X	X	X	X	X	X	X	X	X
	2.50				X	X	X	X	X	X	X	X	X	X
	2.51				X	X	X	X	X	X	X	X	X	X
	3.0X		X	X	X	X	X	X	X	X	X	X	X	X
	3.11					X	X	X	X	X	X	X	X	X
	3.12					X	X	X	X	X	X	X	X	X
	3.1X							X	X	X	X	X	X	X
	3.30													
	3.31													
	3.32													
	3.33													
	3.5X										X	X	X	X
	3.90				X	X	X	X	X	X	X	X	X	X
	4.01									X	X	X	X	X
	4.10									X	X	X	X	X
	4.20													
	5.1X													X
	5.30													
5.31														
5.4X														
65.1X														
CFW701	1.2X					X	X	X	X	X	X	X	X	
	2.0X											X	X	
CFW700	1.0X	X	X	X	X	X	X	X	X	X	X	X	X	

	1.2X							X	X	X	X	X	X	X
	2.0X											X	X	X
CFW500	1.1X					X	X	X	X	X	X	X	X	X
	1.5X											X	X	X
CFW501	1.3X													
	1.5X													
CFW100	1.1X								X	X	X	X	X	X
	2.0X												X	X
	2.1X													
	2.3X													
MW500	1.5X													
ECW500	1.0X									X	X	X	X	X
PLC11-01	1.0X	X	X	X	X	X	X	X	X	X	X	X	X	X
	1.2X	X	X	X	X	X	X	X	X	X	X	X	X	X
	1.4X	X	X	X	X	X	X	X	X	X	X	X	X	X
PLC11-02	1.0X	X	X	X	X	X	X	X	X	X	X	X	X	X
	1.2X	X	X	X	X	X	X	X	X	X	X	X	X	X
	1.4X	X	X	X	X	X	X	X	X	X	X	X	X	X
CTW900	1.0X						X	X	X	X	X	X	X	X
SCA-06	1.1X	X	X	X	X	X	X	X	X	X	X	X	X	X
	1.2X						X	X	X	X	X	X	X	X
	1.4X													
SSW-06	1.3X	X	X	X	X	X	X	X	X	X	X	X	X	X
	1.4X	X	X	X	X	X	X	X	X	X	X	X	X	X
	1.6X	X	X	X	X	X	X	X	X	X	X	X	X	X
	1.7X	X	X	X	X	X	X	X	X	X	X	X	X	X
SSW-07	1.2X	X	X	X	X	X	X	X	X	X	X	X	X	X
	1.3X	X	X	X	X	X	X	X	X	X	X	X	X	X
	1.4X	X	X	X	X	X	X	X	X	X	X	X	X	X
SSW-08	1.3X	X	X	X	X	X	X	X	X	X	X	X	X	X
	1.4X	X	X	X	X	X	X	X	X	X	X	X	X	X
SSW7000	1.1X	X	X	X	X	X	X	X	X	X	X	X	X	X
CFW-09 PM	10.0X	X	X	X	X	X	X	X	X	X	X	X	X	X
	11.3X	X	X	X	X	X	X	X	X	X	X	X	X	X
	12.0X	X	X	X	X	X	X	X	X	X	X	X	X	X

Drive	SuperDrive G2													
	8.00	8.10	8.11	8.20	8.21	8.30	8.31	8.32	8.33	8.40	8.50	8.60	8.70	
CFW-11	1.0X		X	X	X	X	X	X	X	X	X	X	X	X
	1.1X					X	X	X	X	X	X	X	X	X
	1.3X							X	X	X	X	X	X	X
	1.6X								X	X	X	X	X	X
	2.0X												X	X
	2.46													
	2.50													
	2.51													
	3.0X													
	3.11													
	3.12													

	3.1X														
	3.30														
	3.31														
	3.32														
	3.33														
	3.5X														
	3.90														
	4.01														
	4.10														
	4.20														
	5.1X														
	5.30														
	5.31														
	5.4X														
	65.1X														
CFW701	1.2X														
	2.0X														
CFW700	1.0X											X	X		
	1.2X														
	2.0X														
CFW500	1.1X														
	1.5X														
CFW501	1.3X														
	1.5X														
CFW100	1.1X														
	2.0X														
	2.1X														
	2.3X														
MW500	1.5X														
ECW500	1.0X														
PLC11-01	1.0X							X	X	X	X	X	X	X	
	1.2X									X	X	X	X	X	
	1.4X										X	X	X	X	
PLC11-02	1.0X								X	X	X	X	X	X	
	1.2X									X	X	X	X	X	
	1.4X										X	X	X	X	
CTW900	1.0X													X	
SCA-06	1.1X													X	
	1.2X														
	1.4X														
SSW-06	1.3X	X	X	X	X	X	X	X	X	X	X	X	X	X	
	1.4X					X	X	X	X	X	X	X	X	X	
	1.6X										X	X	X	X	
	1.7X													X	
SSW-07	1.2X				X	X	X	X	X	X	X	X	X	X	
	1.3X						X	X	X	X	X	X	X	X	
	1.4X														

SSW-08	1.3X						X	X	X	X	X	X	X	X
	1.4X													
SSW7000	1.1X													
	1.2X													
CFW-09 PM	10.0X				X	X	X	X	X	X	X	X	X	X
	11.3X						X	X	X	X	X	X	X	X
	12.0X								X	X	X	X	X	X

**NOTE!**

- <sup>(1)</sup> SSW-06 1.3X - From version 1.31 and on  
 <sup>(2)</sup> SSW-07 1.2X - From version 1.21 and on  
 <sup>(3)</sup> CFW700 1.0X - From version 1.02 and on

## 2.3 User's Manual

The user's manual, in several formats, can be found in the folders indicated below, where the SuperDrive G2 is installed.

### PDF

Folder: \help\en\_US\PDF

Example: C:\WEG\SuperDrive G2 15.1.0.4776\help\en\_US\PDF

### HTML

Folder: \help\en\_US\HTML

Example: C:\WEG\SuperDrive G2 15.1.0.4776\help\en\_US\HTML

### CHM

Folder: \help\en\_US\CHM

Example: C:\WEG\SuperDrive G2 15.1.0.4776\help\en\_US\CHM

## 3 Getting to Know the Environment

Contents of this chapter:

[Main Window](#)

[Project Tree](#)


### 3.1 Main Window

The main window allows accessing and navigating specific areas of the application.

On the main window, the user can create and open drive (equipments) projects with several functionalities, depending on the availability of each drive.

The main window contains the following elements:


- 01** - Menu Bar: allows access to the software commands; the commands are accessible under certain conditions.
- 02** - Toolbar: displays buttons that quickly access an application command.
- 03** - Panel with Checkboxes: displays or hides other panels.
- 04** - WEG Web Site: click to open the WEG website in the browser.
- 05** - Help Panel: displays help in 3 languages English, Spanish, Portuguese, in html, chm and pdf formats.
- 06** - Project panel: shows the project name and its path.
- 07** - Communication panel: shows the selected connection type and settings.
- 08** - Project tree: shows the project with the drive information and file list.
- 09** - Appearance panel: shows position, language and look & feel buttons.
- 10** - Status Bar: located at the bottom of the screen. The status bar provides a description of the command or button on which the cursor is placed.



## 3.2 Project Tree

The project tree contains the following elements:

- 01** - Project Name: the name of the project given by the user when saving the file for the first time.
- 02** - Drive Identification: the drive model that displays the device name, firmware version, and rated voltage and current. Some drives may not contain the rated voltage and/or rated current.
- 03** - par extension file: parameter file.
- 04** - trend extension file: file with the trend graphic.
- 05** - trace extension file: file with the trace graphic.



## 4 Safety

Contents of this chapter:

[Safety Notice](#)

[Copyright Notice](#)

### 4.1 Safety Notice

The use of this software can change the operation or the performance of the drive. The user is responsible for the adoption of all necessary precautions to ensure the safety of the equipment and involved personnel. Before this Software is used, read carefully all Instruction of the Online Help. The non observation of these instructions can cause serious damages to the equipment and result in serious personnel injuries.

### 4.2 Copyright Notice

This computer program is protected by copyright law and international treaties. Unauthorized reproduction or distribution of this program, or any portion of it, may result in severe civil and criminal penalties, and will be prosecuted to the maximum extent possible under law.

## 5 What's New

Contents of this chapter:

[What's New - This Version](#)

[What's New - Previous Versions](#)

### 5.1 What's New in this Version

#### **SuperDrive G2 15.1.0.4776**

04/02/2019

New Features:

- Communication with CFW-11 V5.35 was included,
- Communication with CFW-11 V5.36 was included,
- Communication with CFW-11 V55.20 was included,
- Communication with CFW-11 V65.83 was included.

Improvements:

- Database was improved for CFW500 V2.0X,
- Database was improved for MW500 V2.0X,
- Java - JRE update from V1.8.0\_192 to V1.8.0\_202.

Bugfixes:

- Correction of the Trace function whose graph presented incorrect values,
- Serial communication where communication did not work for modbus addresses larger than 1.

### 5.2 What's New in Previous Versions

#### **SuperDrive G2 15.0.0.4707**

11/09/2018

New Features:

- Communication on Ethernet network: CFW-11, CFW500, MW500, SCA-06 and ECW500,
- Communication with the new product CFW-11M G2 V1.1X,
- Communication with CFW-11 V85.90 was included,
- Communication with CFW-11 V85.84 was included,
- Communication with CFW-11 V55.82 was included,
- Communication with CFW-11 V45.80 was included,
- Communication with CFW-11 V15.30 was included,
- Communication with CFW-11RB V2.1X was included,
- Communication with CFW700 V2.2X was included,
- Communication with CFW701 V2.1X was included,
- Communication with MW500 V2.0X was included,
- Communication with ECW500 V1.3X was included.

Improvements:

- New information added to the main window: project, project path, communication, centering button, centering and expanding button, languages, selection of look&feel, buttons for help in various formats and languages,
- About window - new information on the Java in use, operating system and user was added,
- WEG USB Driver - update from V10.00 to V11.00 (automatic installation),
- FTDI USB Driver - update from V2.12.16 to V2.12.28 (automatic installation),
- Java - JRE update from V1.8.0\_144 to V1.8.0\_192.

### Bugfixes:

- Correction on the database for CFW100 V2.3X.

## **SuperDrive G2 14.0.0.3677**

09/26/2017

### New Features:

- Project Conversion;
- Added communication with CFW11 V15.78;
- Added communication with CFW11 V85.82;
- Added communication with CFW701 V12.07;
- Added communication with MW500 V1.60;
- Added communication with SCA-06 V1.7X;
- Added communication with SSW7000 V1.6X.

### Improvements:

- Trend function - improved performance when browsing the chart;
- Java - update JRE from V1.8.0\_102 to V1.8.0\_144;
- Some icons were updated;
- Database update for CFW700 V1.2X;
- Database update for CFW501 V1.8X;
- Minor visual update - about, project information, writing parameters to drive , offline parameters editor and monitoring parameters window.

### Bugfixes:

- Database correction for CFW700 V2.0X;
- Database correction for CFW500 V2.0X.

## **SuperDrive G2 13.0.0.3103**

09/26/2016

### New Functions:

- Compatible with Windows 10;
- Added communication with CFW11 V5.7X;
- Added communication with CFW11 V5.33;
- Added communication with SSW7000 V1.5x.

### Enhancements:

- Trend function - improved performance when browsing the chart;
- WEG USB Driver V10.00 - new version with automatic installation;
- FTDI USB Driver V2.12.16 - new version with automatic installation;
- Java - update JRE from V1.8.0\_74 to V1.8.0\_102.

### Corrections:

- ECW500 - Status Window, modifications: from "Start" to "On", from "Stop" to "Off";
- Database correction for CFW700 V2.0X;
- Database correction for CFW500 V2.0X;
- Database correction for CFW500 V1.8X;
- Database correction for ECW500 V1.1X;
- CFW700 - Manual correction about USB connection availability.

## **SuperDrive G2 12.1.0**

03/14/2016

### New Functions:

- Communication with CFW-11RB V2.0X;
- Communication with ECW500 V1.1X;
- Communication with CFW500 V2.0X;
- Communication with CFW-11 V85.32;
- Communication with CFW-11 V5.2X;
- Communication with CFW-11 V5.8X;
- Function to import databases;
- Function search available both parameter and monitor editor.

### Enhancements:

- Improvements in Trend: Graph showing with better performance and new options to pause, save, calculate instant reading time interval and new graphic display time ranges.

### Corrections:

- Correction in function to Import Projects;
- Communication with CFW500 V1.8X;
- Communication with CFW501 V1.8X;
- Communication with MW500 V1.5X;
- Communication with CFW700 V2.0X.

## **SuperDrive G2 12.0.0**

09/30/2015

### New Functions:

- Windows 8.1 (x86, x64) is supported;
- German language is supported;
- Function to change voltage in project (CFW11 only);
- Communication with CFW11 V4.21;
- Communication with CFW11 V15.16;
- Communication with CFW11 V15.84;
- Communication with CFW11 V15.90;
- Communication with CFW11 V15.91;
- Communication with CFW11 V15.97;
- Communication with CFW11 V45.11;
- Communication with CFW11 V45.12;
- Communication with CFW100 V2.4X;
- Communication with CFW500 V1.8X;
- Communication with CFW501 V1.8X;
- Communication with SCA-06 V1.5X;
- Communication with SSW7000 V1.3X;

- Communication with SSW7000 V1.4X;
- Communication with PLC11-01 V1.7X;
- Communication with PLC11-02 V1.7X;
- Communication with CTW900 V1.1X;
- Communication with SSW06 V1.8X;
- Communication with SSW07 V1.5X;
- Communication with SSW08 V1.5X.

### Enhancements:

- Reduced the response time when connected with CFW11;
- Visual improvements (new icons);
- Improvement in presentation of option Projects (in Options > Projects);
- USB driver update;
- Communication with CFW11 V3.5X, added database in german language;
- Communication with CFW11 V5.4X, added database in german language;
- Communication with CFW11 V65.1X, added database in german language;
- Communication with CFW500 V1.5X, added database in german language;
- Communication with CFW700 V2.0X, added database in german language;
- Communication with MW500 V1.5X, added database in german language.

### Corrections:

- Communication with CFW11 V5.4X;
- Communication with ECW500 V1.0X.

## **SuperDrive G2 11.3.0**

09/24/2014

### New Functions:

- Function Save As project;
- Function Rename project;
- New options for printing parameters;
- Function Remove project;
- Export graphics and parameters to CSV format files;
- Function Security System for CFW11 V65.1X;
- Function Trace for CTW900;
- Communication with CFW501 V1.3X;
- Communication with CFW501 V1.5X;
- Communication with CFW11 V65.1X;
- Communication with CFW11 V5.31;
- Communication with CFW700 V2.0X line 600V;
- Communication with CFW701 V2.0X line 600V;
- Communication with CFW100 V2.3X.

### Enhancements:

- Added operation mode in the status window of ECW500;
- Allow change the default folder where projects are stored.

### Corrections:

- Database correction of ECW500 V1.0X;
- Database correction of CFW100 V2.2X (english);
- Correction in printing parameters where overlapping characters could occur.

## **SuperDrive G2 11.2.0**

05/21/2014

The following features were added:

- Communication with MW500 V1.5X;
- Communication with CFW100 via Bluetooth;
- Communication with CFW100 V2.2X;
- Communication with SCA-06 V1.4X;
- Communication with CFW11 V5.4X;
- Communication with CFW11 V5.30;
- Communication with CFW11 V4.20;
- Communication with CFW11 V3.30;
- Communication with CFW11 V3.31;
- Communication with CFW11 V3.32;
- Communication with CFW11 V3.33.

Minor changes:

- Correction of instability during printing parameters;
- Database correction of CFW500 V1.1X;
- Database correction of CFW500 V1.5X;
- Database correction of CFW700 V2.0X;
- Database correction of CFW701 V2.0X.

## **SuperDrive G2 11.1.0**

02/06/2014

The following features were added:

- Communication with CFW100 V2.1X.

Minor changes:

- Correction in Trace function where there was error in the read/write configuration,
- Fix reading of parameters that were not saved correctly when the reading was taken before saving the project.

## **SuperDrive G2 11.0.0**

12/03/2013

The following features were added:

- Compatible with Windows 8 x86, Windows 8 x64

Minor changes:

- Indication on the parameter list of what has changed (different from standard);
- Fixed the window of Speed Reference to CFW100, CFW500, CFW700/701, CFW11, CTW900, which presented incorrect values;
- Fixed the New File Parameters function (offline generation of files parameters with default values), where the parameters firmware version, rated current of the drive and rated voltage of the drive had incorrect values;
- Fixed the Trend function which stored incorrectly content 0 when reading error occurred;
- Communication with CFW701 V2.0x, database correction.

## **SuperDrive G2 10.00**

10/07/2013

The following features were added:

- Communication with CFW11 V5.1X.

## **SuperDrive G2 9.90**

09/13/2013

The following features were added:

- Communication with CFW100 V2.0X.

## **SuperDrive G2 9.80**

08/22/2013

The following features were added:

- Communication with CFW500 V1.5X;
- Communication with CFW700 V2.0X;
- Communication with CFW701 V2.0X;
- Communication with SSW7000 V1.2X.

## **SuperDrive G2 9.70**

07/12/2013

The following features were added:

- Communication with CFW-11 V3.5X.

## **SuperDrive G2 9.60**

07/05/2013

The following features were added:

- Communication with ECW500 V1.0X;
- Communication with CFW-11 V4.01;
- Communication with CFW-11 V4.10;
- Improved communication with drives (RS232 and RS485);
- Language change no longer requires program restart;
- Automatic loading of database on alternative language.

Minor changes:

- Communication with CFW-11 V3.1x, database correction;
- Communication with CFW100 V1.1x, database correction;
- Communication with CTW900 V1.0x, database correction;
- Several improvements in Identify Drive and Communication Setup windows.

## **SuperDrive G2 9.50**

10/05/2012

The following features were added:

- Communication with CFW100 V1.1X;
- Size and position of windows are saved;
- Project importation and exportation.

Minor changes:

- Communication with CFW701 V1.2X, database correction.

### **SuperDrive G2 9.40**

05/03/2012

The following features were added:

- Communication with CFW11 V3.1X;
- Communication with CFW700 V1.2X.

Minor changes:

- Communication with CFW700 V1.0X, database correction.

### **SuperDrive G2 9.30**

03/16/2012

The following features were added:

- Communication with CTW900 V1.0X;
- Communication with SCA-06 V1.2X.

### **SuperDrive G2 9.20**

12/05/2011

The following features were added:

- Communication with CFW500 V1.1X;
- Communication with CFW701 V1.2X;
- Communication with CFW-11 V3.11;
- Communication with CFW-11 V3.12.

### **SuperDrive G2 9.10**

09/27/2011

The following features were added:

- Trend in the function and Trace, minimum, maximum and legend are now saved when the graph is closed;
- Communication with CFW-11 V2.46;
- Communication with CFW-11 V2.50;
- Communication with CFW-11 V2.51;
- Communication with CFW-11 V3.90.

Minor changes:

- Communication with CFW-11 V3.0x, database correction;
- Communication with CFW700 V1.0x, database correction.

### **SuperDrive G2 9.00**

05/27/2011

The following features were added:

- Offline programming.

### **SuperDrive G2 8.90**

04/05/2010

The following features were added:

- Communication with CFW-11 V3.0x.

### **SuperDrive G2 8.80**

02/22/2010

The following features were added:

- Communication with SSW7000 V1.1x;
- Communication with SSW-07 V1.4x;
- Communication with SSW-08 V1.4x;
- Compatible with Windows 7 x86, Windows 7 x64;
- Compatible with Windows Vista x86, Windows Vista x64;
- Compatible with Windows XP x86, Windows XP x64.

### **SuperDrive G2 8.70**

10/20/2010

The following features were added:

- Communication with SCA-06 V1.1x;
- Communication with SSW-06 V1.7x.

### **SuperDrive G2 8.60**

08/10/2010

The following features were added:

- Communication with CFW700 V1.0x.

### **SuperDrive G2 8.50**

03/05/2010

The following features were added:

- Communication with CFW-11 V2.0x;
- Communication with CFW-11 + PLC11-01 V1.4x;

- Communication with CFW-11 + PLC11-02 V1.4x.

### **SuperDrive G2 8.40**

09/08/2009

The following features were added:

- [Identify Drive](#) address selection,
- [Write Parameters to Drive](#) destination address selection;
- Communication with CFW-11 + PLC11-01 V1.2x;
- Communication with CFW-11 + PLC11-02 V1.2x;
- Communication with SSW-06 V1.6x.

### **SuperDrive G2 8.33**

05/15/2009

The following features were added:

- Communication with CFW-11 + PLC11-02 V1.0x.

### **SuperDrive G2 8.32**

12/18/2008

The following features were added:

- Communication with CFW-09 PM V12.0x;
- Communication with CFW-11 V1.6x.

### **SuperDrive G2 8.31**

05/20/2008

The following features were added:

- Communication with CFW-11 V1.3x;
- Communication with CFW-11 + PLC11-01 V1.0x.

### **SuperDrive G2 8.30**

04/16/2008

The following features were added:

- Trend function,
- Communication with CFW-09 PM V11.3x;
- Communication with SSW-07 V1.3x;
- Communication with SSW-08 V1.3x.

### **SuperDrive G2 8.21**

08/31/2007

The following features were added:

- Communication with CFW-11 V1.1x;

- Communication with SSW-06 V1.4x.

## **SuperDrive G2 8.20**

08/01/2007

The following features were added:

- Communication with SSW-07 V1.2x;
- Communication with CFW-09 PM V10.0x;
- New baud rate for RS232: 4800 bps.

Minor changes:

- Option "Always on Top" was removed from several windows;
- New layout in monitoring windows;
- It is no more necessary to reopen the project after changing [Communication Setup](#).

## **SuperDrive G2 8.11**

04/24/2007

Minor changes:

- Updated CFW-11 data base;
- New baud rate for RS232: 57600 bps.

## **SuperDrive G2 8.10**

03/29/2007

The following features were added:

- Communication with CFW-11 V1.0x;
- USB point-to-point serial communication;
- Reference speed monitoring of CFW-11;
- Trace function;
- Language selection: English, Portuguese and Spanish.

Minor changes:

- Monitor Parameters: a divider offers user-controlled resizing of two components: parameters and messages;
- Monitor Parameters: if the user press the right button of the mouse in the messages container, a small popup menu appears with the option to clean the messages;
- Monitor Parameters and Edit Parameters File: OK and Cancel buttons were replaced with Close button;
- Monitor Keypad: validation of parameter value;
- Monitor Keypad: the user may now type a value directly into the parameter field;
- Always on top functionality is not selected any more when a window is opened;
- Parameters conversion for hexadecimal and binary now supported.

## **SuperDrive G2 8.00**

12/20/2006

Initial Version:

- Automatic identification of connected drives;
- Parameter transfer from computer to the drive;
- Parameter transfer from drive to the computer;
- Offline editing of the parameters stored in files on the computer;
- Monitoring (visualization and change) of drive parameters;
- Monitoring of the drive status and command operations (motor stop/run, jog, forward/reverse, local/remote, etc);
- Supports multiple databases for special firmware version;
- RS232 point-to-point serial communication;
- Online help.

## 6 Installation/Uninstalation

Contents of this chapter:

[Before Installing](#)

[Installing](#)

[Uninstalling](#)

[USB Driver](#)

### 6.1 Before Installing

Check the following items before installing SuperDrive G2:

- If the microcomputer meets the [System Requirements](#);
- Your antivirus software must allow you to install software;
- If the SuperDrive G2 version is compatible with your drive, see [Supported Drives](#).

### 6.2 Installing

When installing a newer version of SuperDrive G2 it is recommended that you first [uninstall](#) the previous version and re-boot your system to make sure the installation executes correctly.

Close all open programs currently running to prevent interference with the installation process.


To install SuperDrive G2, please follow the steps below.

#### Installation


**01** - You must be logged in as an administrator to install the program; if you're using a standard account, the application will fail to run;

**02** - If User Account Control (UAC) is enabled (Control Panel > User Accounts > Change User Account Control Settings), you will be notified before the installer starts the installation and try to make a change in the Windows configuration; click Yes to confirm that you allow the program to make changes to your computer, otherwise you can not install the program;


**03** - You should also run the installer with elevated privileges; to do so, right-click installer displays a menu; click Run as administrator;




**04** - Select the language and click OK.




**05** - In the install wizard, respond to the License Agreement, then click Next.




**06** - Click Next.




**07** - Specify an empty folder within which to install SuperDrive G2. Verify that the installation location is correct and that you have available disk space for the installation.




**08** - Confirm to create the empty folder.




**09** - Click Next.




**10** - Select the program group to create program's shortcuts and click Next.




**11** - Select the program's shortcuts you want as additional icons: create a desktop icon and create a quick launch icon. Click Next.




**12** - Please review or change any settings. Click Install to begin the installation.





**13** - Click Finish to complete the setup.



## 6.3 Uninstalling

If necessary, you can uninstall SuperDrive G2 using the following procedures.

### Uninstall

**NOTE!**

As indicated below, use the Programs and Features utility to remove SuperDrive G2. Do not manually delete files and folders.

### Windows 10

The following example is executed on Windows 10. For other systems, the procedures are similar. Some data are intentionally invisible, as they vary according to the version.

**01** - You must be logged in as an administrator to remove the program; if you're using a standard account (non-administrator), then you can not remove the software;

**02** - If User Account Control (UAC) is enabled (Control Panel > User Accounts > Change User Account Control Settings), you will be notified before starting the removal and try to make a change in the Windows configuration; click Yes to confirm that you allow the program to make changes to your computer, otherwise you can not remove the program;

**03** - Right mouse click on Start button, and then select Programs and Features option.




**04** - Select SuperDrive G2 from the list and click Uninstall.

The screenshot shows the Windows Settings application, specifically the 'Apps & features' section. The left sidebar contains navigation options: Home, Find a setting, Apps, Apps & features (selected), Default apps, Offline maps, Apps for websites, Video playback, and Startup. The main area displays a list of installed applications with their respective icons, names, sizes, and installation dates.


App Name	Size	Installation Date
SuperDrive G2 15.0.0.4672 WEG	1,39 GB	17/10/2018
Tips Microsoft Corporation	334 KB	12/08/2018
TortoiseSVN 1.7.15.25753 (64 bit) TortoiseSVN	38,8 MB	17/01/2018
Voice Recorder Microsoft Corporation	16,0 KB	12/08/2018
Vulkan Run Time Libraries 1.0.... LunarG, Inc.	1,66 MB	21/06/2018
Weather Microsoft Corporation	16,0 KB	12/08/2018
Web Media Extensions Microsoft Corporation	16,0 KB	12/08/2018
WEG Programming Suite 2.40 WEG	670 MB	15/06/2018
WEG USBIO Driver v11.00 WEG Equipamentos Eletricos...		21/06/2018



The screenshot shows the Windows Settings application, specifically the 'Apps & features' section. The left sidebar contains navigation options: Home, Find a setting, Apps, Apps & features (selected), Default apps, Offline maps, Apps for websites, Video playback, and Startup. The main content area displays a list of installed applications with their names, publishers, sizes, and installation dates. The 'SuperDrive G2' application is highlighted at the top, showing its version (15.0.0.4672) and size (1,39 GB). Below it are other applications like 'Tips', 'TortoiseSVN', 'Voice Recorder', 'Vulkan Run Time Libraries', 'Weather', 'Web Media Extensions', and 'WEG Programming Suite'.

App Name	Publisher	Size	Installation Date
SuperDrive G2 15.0.0.4672	WEG	1,39 GB	17/10/2018
Tips	Microsoft Corporation	334 KB	12/08/2018
TortoiseSVN 1.7.15.25753 (64 bit)	TortoiseSVN	38,8 MB	17/01/2018
Voice Recorder	Microsoft Corporation	16,0 KB	12/08/2018
Vulkan Run Time Libraries 1.0....	LunarG, Inc.	1,66 MB	21/06/2018
Weather	Microsoft Corporation	16,0 KB	12/08/2018
Web Media Extensions	Microsoft Corporation	16,0 KB	12/08/2018
WPS	WEG	670 MB	



**05** - Follow the instructions to remove the software.





## 6.4 USB Driver

The WEG USB driver and the FTDI USB driver (Virtual COM Port) are automatically installed during the installation of SuperDrive G2.

### WEG USB Driver

The WEG USB driver can be found in the USB\_Driver folder where SuperDrive G2 is installed.

Example: C:\WEG\SuperDrive G2 15.1.0.4776\USB\_Driver\USBIO

### FTDI USB Driver

The FTDI USB driver can be found in the USB\_Driver folder where SuperDrive G2 is installed.

Example: C:\WEG\SuperDrive G2 15.1.0.4776\USB\_Driver\FTDI

## 7 Menus

Contents of this chapter:

<a href="#">Project</a>	<a href="#">Drive</a>	<a href="#">Tools</a>	<a href="#">Help</a>
<a href="#">New</a>	<a href="#">Identify Drive</a>	<a href="#">Options</a>	<a href="#">Contents</a>
<a href="#">Open</a>	<a href="#">Communication Setup</a>	<a href="#">Import Database</a>	<a href="#">About</a>
<a href="#">Close</a>	<a href="#">Security System</a>	<a href="#">Convert Project</a>	
<a href="#">Save</a>	<a href="#">Security System (Session)</a>	<a href="#">Simplified Conversion Log</a>	
<a href="#">Save As</a>	<a href="#">New Parameters File</a>	<a href="#">Remove Simplified Conversion Log</a>	
<a href="#">Remove</a>	<a href="#">Edit Parameters File</a>	<a href="#">Full Conversion Log</a>	
<a href="#">Import</a>	<a href="#">Remove Parameters File</a>	<a href="#">Remove Simplified Conversion Log</a>	
<a href="#">Export</a>	<a href="#">Export Parameters File</a>		
<a href="#">Change Voltage</a>	<a href="#">Read Parameters from Drive</a>		
<a href="#">Print</a>	<a href="#">Write Parameters to Drive</a>		
<a href="#">Project Information</a>	<a href="#">Monitor Parameters</a>		
<a href="#">Exit</a>	<a href="#">Monitor using Keypad</a>		
	<a href="#">Monitor Status</a>		
	<a href="#">Monitor Speed Reference</a>		
	<a href="#">Trend</a>		
	<a href="#">Remove Trend File</a>		
	<a href="#">Export Trend File</a>		
	<a href="#">Trace Function</a>		
	<a href="#">Remove Trace File</a>		
	<a href="#">Export Trace File</a>		

### 7.1 Project

[New](#)  
[Open](#)  
[Close](#)  
[Save](#)  
[Save As](#)  
[Remove](#)  
[Import](#)  
[Export](#)  
[Change Voltage](#)  
[Print](#)  
[Project Information](#)  
[Exit](#)

### 7.1.1 New

#### ACCESS

Toolbar:   
Menu: Project > New  
Shortcut Key: Ctrl+N

#### FUNCTION

Creates a new project with a standard name.

#### DESCRIPTION

Drive Identification window is presented. See [Identify Drive](#).

### 7.1.2 Open

#### ACCESS

Toolbar:   
Menu: Project > Open  
Shortcut Key: Ctrl+O


#### FUNCTION

Opens a previously saved project.

#### DESCRIPTION

User must select a project folder and open the project.

The project name and the drive information are shown in the Project Window.



### 7.1.3 Close

#### ACCESS

Toolbar:   
 Menu: Project > Close  
 Shortcut Key: none

#### FUNCTION

Closes the project.

#### DESCRIPTION

If the project contains unsaved data, a save request dialog will be shown.

### 7.1.4 Save

#### ACCESS

Toolbar:   
 Menu: Project > Save  
 Shortcut Key: Ctrl+S

## FUNCTION

Saves the project.

## DESCRIPTION

Enabled if the project has unsaved changes.

When the project is first time saved, a dialog is shown with the following information:

- Name - type a name for the new project. If the specified name is invalid or already exists, a warning message will be prompted.
- Location - a default location is shown, but can be changed.
- Folder - view only.
- Description - type the project description. It can be changed later in the [Project Information](#).

### 7.1.5 Save As

## ACCESS

Toolbar:   
Menu: Project > Save As  
Shortcut Key: Ctrl+D

## FUNCTION

Saves a project with different name.

## DESCRIPTION

Enabled when a project is created or opened.

When Save As function runs, a dialog is shown with the following information:

- Name - type a name for the new project. If the specified name is invalid or already exists, a warning message will be prompted.
- Location - a default location is shown, but can be changed.
- Folder - view only.
- Description - type the project description. It can be changed later in the [Project Information](#).

### 7.1.6 Remove

## ACCESS

Toolbar:   
Menu: Project > Remove  
Shortcut Key: none

## FUNCTION

Erases the current project.

## DESCRIPTION


Enabled when a project is open.

When Remove function runs, a confirmation dialog is shown with the following information:

- Name - name of the project which is going to be deleted.
- Location - a default location is shown.
- Folder - project's location is shown.
- Description - the project description is shown.

Buttons

- OK Button: confirms the exclusion of current project.
- Cancel Button: keeps the current project.



### 7.1.7 Import

## ACCESS

Toolbar:   
 Menu: Project > Import  
 Shortcut Key: none

## FUNCTION

Imports a previously exported project.

## DESCRIPTION

User must select a project file with extension sdg2z and click the Import button.

This project will be imported into the default folder for projects.

If the project or any of the files already exist, the user will receive a confirmation box to overwrite the project.

If the user chooses to overwrite the conflicting files will be overwritten, otherwise, no files will be overwritten and the project will not be imported.

If, during import of the project, another project is open, then it will be closed. If data is not saved, a confirmation window appears allowing the user to save changes, discard them, or cancel the operation.

When completed the import process, the project will be imported automatically open.

### 7.1.8 Export

#### ACCESS

Toolbar:   
Menu: Project > Export  
Shortcut Key: none

#### FUNCTION

Exports the current project to a file.

#### DESCRIPTION

The project must be open.

Click the Export button. Initially the default filename is the name of the project, which can be changed.

Clicking the save button, the file is created with the extension sdg2z which can be imported using the Import function.

### 7.1.9 Change Voltage

#### ACCESS

Toolbar:   
Menu: Project > Change Voltage  
Shortcut Key: none

#### FUNCTION

Allow to migrate the currently opened project to a new one, with another model of CFW11

drive.

## DESCRIPTION

User must have a project opened.

This option loads an wizard to help changing the model of drive and checking its parameters.

If there are no compatible drives to the current model, no options will be presented to choice.

### 7.1.10 Print

## ACCESS

Toolbar: 

Menu: Project > Print

Shortcut Key: Ctrl+P

## FUNCTION

Prints the parameters file selected in the Project Window.

## DESCRIPTION

Prints all parameters stored in the parameters file:

- Parameter number.
- User's settings.
- Unit.

### 7.1.11 Project Information

## ACCESS

Toolbar: 

Menu: Project > Project Information

Shortcut Key: Ctrl+I

## FUNCTION

Adds or modifies project information.

## DESCRIPTION

Shows the following information:

- Name - the name of the project. View only.
- Location - the location of the project. View only.
- Folder - the folder where the project is. View only.
- Description - type the project description.

Name, Location and folder can not be changed after it is first time saved. See [Save](#).

Description can be changed at any time.

## 7.1.12 Exit

### ACCESS

Toolbar: 

Menu: Project > Exit

Shortcut Key: Ctrl+Q

### FUNCTION

Exits SuperDrive G2.

### DESCRIPTION

SuperDrive G2 asks the user if he wishes to exit.

If the project contains unsaved data, a save request dialog will be shown.

## 7.2 Drive

[Identify Drive](#)

[Communication Setup](#)

[Security System](#)

[Security System \(Session\)](#)

[New Parameters File](#)

[Edit Parameters File](#)

[Remove Parameters File](#)

[Export Parameters File](#)

[Read Parameters from Drive](#)

[Write Parameters to Drive](#)

[Monitor Parameters](#)

[Monitor Using Keypad](#)

[Monitor Status](#)

[Monitor Speed Reference](#)

[Trend](#)

[Remove Trend File](#)

[Export Trend File](#)

[Trace Function](#)

[Remove Trace File](#)

[Export Trace File](#)

## 7.2.1 Identify Drive

### ACCESS

Toolbar: 


Menu: Drive > Identify Drive

Shortcut Key: none

### FUNCTION

Automatic identification of the drive (drive must be connected to computer) or user select the drive manually.

### APPEARANCE



### DESCRIPTION

#### Drive Type


If no drive is configured, it shows the address and "No Drive Configured" message.

If any drive is configured, the following information is displayed:

- Address.
- Type.
- Firmware version.
- Nominal voltage.
- Nominal current.

Remove button: clears the Drive Type field (remove the drive configuration).

#### Automatic Identification




- Connection Type: USB => When USB is selected in Communication Setup window,
- Connection Type: Serial => When Serial is selected in Communication Setup window,
- Connection Type: Bluetooth => When Bluetooth is selected in Communication Setup window,
- Connection Type: Ethernet => When Ethernet is selected in Communication Setup window.

Scan button: scans for drives connected to the computer. If any drive is connected, configuration is presented. The scan is finished when a drive is identified.

Start from Address button: to select the initial address of the scan when the connection type is serial; for USB connection, this button is disabled.

### Manual Identification



Drive Type Button: select the drive model, firmware version and nominal voltage / current.

Accessory Button: selects the accessory when it exists; select accessory name and firmware version.

**General Buttons**


OK button: applies changes and closes the window.

Cancel button: discard all changes and closes the window.

**Selection - Drive Type**

The drive need not to be connected to the computer.

Example:



**7.2.2 Communication Setup**

**ACCESS**

Toolbar: 


Menu: Drive > Communication Setup

Shortcut Key: none

**FUNCTION**

This dialog box allows you to configure the PC communication port to match the setting on the drive for proper communication.


**APPEARANCE**



## DESCRIPTION

Select the connection type: USB, Serial, Bluetooth or Ethernet.

## USB



For USB no adjustment is necessary.

Get Version Button: Click this button to read the version of USB driver installed on the microcomputer.

Installed Version Field: displays the version of USB driver installed on the microcomputer.

Recommended Version Field: displays the correct version of USB driver should be installed on the computer.

Note Field: displays a message indicating whether the USB driver installed is OK or not.

Message on Note Field	User Action
USB driver Ok!	Nothing to do, USB driver correctly installed.
Reasons - No drive (equipment) is connected to the PC - Old USB driver - No USB driver installed See online help.	Install the USB driver available in USB_Driver\USBIO folder where SuperDrive G2 is installed. To install: run setup.exe and follow the installation wizard.

The following timing settings are available for USB:

Timing	Range	Default
--------	-------	---------

Transmission Delay (ms)	0 ... 20000	0
Response Delay (ms)	0 ... 20000	0
Time-out (ms)	100 ... 20000	500

For more details see [Drive Parametrization](#).

## Serial

Communication Setup

Connection Type:

USB  Serial  Bluetooth  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	0	ms	0	[0 ... 20000]
Time-out	100	ms	100	[100 ... 20000]

Serial:

Equipment: User Setting

Serial Port: COM4

Data Bits: 8

Stop Bits: 2

Parity: No Parity

Baud Rate: 9600

OK Cancel

For RS232 you need to adjust some values. The communication protocol is Modbus-RTU.

Connection Type	Serial Port Settings	Range	Default
RS232	Baud rate (bps)	4800, 9600, 19200, 38400 or 57600	9600
	Data bits	8	8
	Stop bits	1 or 2	2
	Parity	No Parity, Even or Odd	No Parity

In addition to the possibility of manual configuration of the fields, it is also possible to load factory default values of each drive.

The model is selected in the Equipment checkbox.

After the drive is selected, the fields are automatically defined.

The following timing settings are available for Serial:

Timing	Range	Default
Transmission Delay (ms)	0 ... 20000	0
Response Delay (ms)	0 ... 20000	0
Time-out (ms)	100 ... 20000	500

For more details see [Drive Parametrization](#).

### Bluetooth

Communication Setup

Connection Type:

USB  Serial  Bluetooth  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	50	ms	50	[50 ... 20000]
Time-out	1000	ms	1000	[1000 ... 20000]

Bluetooth:

Equipment: CFW100

Serial Port: COM4

Data Bits: 8

Stop Bits: 1

Parity: Even

Baud Rate: 19200

Note: For the proper operation of the CFW100 inverter with the CFW100-CBLT module, parameters P310, P311 and P312 must be set with the factory default values.

For further details refer to the CFW 100 programming manual version V2.0X or above.

OK Cancel

The following timing settings are available for Bluetooth:

Timing	Range	Default
Transmission Delay (ms)	0 ... 20000	0
Response Delay (ms)	0 ... 20000	50
Time-out (ms)	100 ... 20000	500

It may be necessary to increase the response delay to avoid communication errors.

### Ethernet

Communication Setup

Connection Type:

USB  Serial  Bluetooth  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	0	ms	0	[0 ... 20000]
Time-out	5000	ms	5000	[5000 ... 20000]

Ethernet:

Field	Value	Default	Range
IP Address	192.168.0.10	192.168.0.10	XXXX.XXXX.XXXX.XXXX
Port	502	502	1 ... 65535
Unit ID	255	255	1 ... 255

OK Cancel

Set the fields as indicated below.

Campo	Padrão
Endereço IP	192.168.0.10
Porta	502
Unidade Id	255

Use these values for communication with WEG drives.

### Buttons

OK: applies changes and closes the window.

Cancel: discard all changes and closes the window.

### 7.2.3 Security System

#### ACCESS

Toolbar:   
 Menu: Drive > Security System  
 Shortcut Key: none

#### FUNCTION

The Security System allows you to configure a password to lock online parameters edition during a communication between PC and the drive.  
 The offline activities and/or the execution of commands are not locked by Security System.

#### DESCRIPTION

The Security System - when available - allows to enable, disable or change current drive's password. These operations are done in online mode.

SuperDrive G2 shows a message alerting the user if current drive does not have Security System capabilities.


**WARNING!**

Define a strong password to the Security System. Use uppercase and lowercase letters and numbers intercalated.



Minimal requirement for password in SuperDrive G2 is one digit, but is strongly recommended to define a password with at least eight characters.

Keep your password in a safe place.



**[1]** Presents the current Security System state. It could be: Enabled, Disabled or Communication Failure;

- [2] This button Disables the Security System (when the current state is Enabled) or Enables the Security System (when the current state is Disabled);  
[3] This button changes the current Security System password;  
[4] This button closes the Security System window.

## 7.2.4 Security System (Session)

### ACCESS

Toolbar: 

Menu: Drive > Security System (Session)

Shortcut Key: none

### FUNCTION

The Security System (Session) allows you to temporarily unlock online parameters edition during a communication between PC and the drive. By this option, it is not necessary to disable permanently the Security System. So, when the current project is closed the Security System is automatically enabled, locking the online parameters edition.

### DESCRIPTION

The Security System (Session) - when available - allows to online parameters editing. This operation is done in online mode.

SuperDrive G2 shows a message alerting the user if current drive does not have Security System capabilities.

To allow the temporary online parameters edition it is mandatory you inform the password which is stored in drive.

This option is only available if the drive (which is connected to PC) already have a password to the Security System.

To access any functionality with access to edit a parameter, SuperDrive G2 asks if the user wants to allow the temporary online edition of parameters. The answer to this question keeps in SuperDrive G2 until the current project is closed.

To lock the temporary online edition of parameters just close the current project, or click over the icon  - it corresponds to the Security System (Session) - and confirm the locking of online parameters edition in the confirmation message.

## 7.2.5 New Parameters File

### ACCESS

Toolbar: 

Menu: Drive > New Parameters File

Shortcut Key: none

## FUNCTION

Creates a new parameters file with factory setting.

## DESCRIPTION

If the project does not exist, a project name is requested to save.  
 If the project already exists, a parameters file name is requested.

### Buttons


Save: saves the parameters file and closes window.

Cancel: discard all changes and closes the window.

The filename must be specified by user and it it created with factory setting.

The file created is shown in Project Window (list of drive files).

This new file can be changed using [Edit Parameters File](#).



## 7.2.6 Edit Parameters File

### ACCESS

Toolbar:

Menu: Drive > Edit Parameters File

Shortcut Key: none

## FUNCTION

It opens a parameters file previously saved. It allows viewing and changing the parameters in the offline editor.

## PRESENTATION

The screenshot shows a window titled "Offline Parameters Editor: Address 1 - ParametersFile.par". It features a search bar with "Find What:" and "Find Next" buttons, and a checkbox for "Match entire cell contents". The main area contains a table with the following data:

Number	Function	Minimum	Maximum	Factory Setting	User Setting	Unit	Comparison
0	Access to Parameters	0	9999	0	0		
1	Speed Reference	0	18000	0	0	rpm	
2	Motor Speed	0	18000	0	0	rpm	
3	Motor Current	0	4500	0	0	A	
4	DC Link Voltage (Ud)	0	2000	0	0	V	
5	Motor Frequency	0	300	0	0	Hz	
6	VFD Status	0	7	0: Ready	0: Ready		
7	Motor Voltage	0	2000	0	0	V	
9	Motor Torque	-1000	1000	0	0	%	
10	Output Power	0	6553,5	0	0	kW	
12	DI8 to DI1 Status	00h	FFh	00h	00h		
13	DO5 to DO1 Status	00h	1Fh	00h	00h		
14	AO1 Value	0	100	0	0	%	
15	AO2 Value	0	100	0	0	%	
16	AO3 Value	-100	100	0	0	%	
17	AO4 Value	-100	100	0	0	%	
18	AI1 Value	-100	100	0	0	%	
19	AI2 Value	-100	100	0	0	%	
20	AI3 Value	-100	100	0	0	%	
21	AI4 Value	-100	100	0	0	%	
23	Software Version	0	655,35	1,1	1,1		
27	Accessories Config. 1	00h	FFFFh	00h	00h		
28	Accessories Config. 2	00h	FFFFh	00h	00h		
29	Power Hardware Config	00h	FFFFh	00h	00h		
30	IGBTs Temperature U	-20	150	0	0	°C	
31	IGBTs Temperature V	-20	150	0	0	°C	
32	IGBTs Temperature W	-20	150	0	0	°C	
33	Rectifier Temperature	-20	150	0	0	°C	
34	Internal Air Temp.	-20	150	0	0	°C	
36	Fan Heatsink Speed	0	15000	0	0	rpm	
37	Motor Overload Status	0	100	0	0	%	

The window also includes a status bar at the bottom right with the text "Offline".

## DESCRIPTION

The user must select a file name in the Project Window and double-click on the file name or press Edit Parameters File.

The program will display a general view of all available parameters in a separate window. To edit a parameter, double-click on the user setting of the parameter that you wish to edit.

The following fields are available:

- Parameter number.
- Function.
- Minimum value.
- Maximum value.
- Factory setting.
- User's setting.

- Unit.

When the parameter is read-only, the user's setting field is disabled (it cannot be edited).

The user types the parameter value and presses Enter. Only values between minimum and maximum are allowed.

Some parameters present a simple list of values in a single column. The user can select entries from the list with the mouse. Only an item at a time can be selected.

The user can search information in the parameter table by informing the text or value to be searched and clicking on **Find Next**. When checking the option **Match entire cell contents**, the system searches for events where the entire cell content is equal to the searched term.


### Buttons

Close: applies the changes if the user selects Yes and closes the window.

### Log Panel

01

When the parameter file was generated by the project converter (see [Convert Project](#)), a message informs that the user must review the parameters as follows.



02

In this case, there is a simplified log file and a full log file available associated to the parameter file.

In the window, a panel (Project Conversion Log) appears with 2 buttons.

- Button  : shows the simplified conversion log.
- Button  : shows the full conversion log.

Offline Parameters Editor: Address 1 - p1.par

Find What:  Find Next  Match entire cell contents


Project Conversion Log: Shows simplified conversion log. Shows full conversion log.

Number	Function	Minimum	Maximum	Factory Setting	User Setting	Unit	Comparison
0	Access to Parameters	0	9999	0	0		
1	Speed Reference	0	18000	0	0	rpm	
2	Motor Speed	0	18000	0	0	rpm	
3	Motor Current	0	4500	0	0	A	
4	DC Link Voltage (Ud)	0	2000	0	0	V	
5	Motor Frequency	0	300	0	0	Hz	
6	VFD Status	0	7	0: Ready	0: Ready		
7	Motor Voltage	0	2000	0	0	V	
9	Motor Torque	-1000	1000	0	0	%	
10	Output Power	0	6553,5	0	0	kW	
12	DI8 to DI1 Status	00h	FFh	00h	00h		
13	DO5 to DO1 Status	00h	1Fh	00h	00h		
14	AO1 Value	0	100	0	0	%	
15	AO2 Value	0	100	0	0	%	
16	AO3 Value	-100	100	0	0	%	
17	AO4 Value	-100	100	0	0	%	
18	AI1 Value	-100	100	0	0	%	
19	AI2 Value	-100	100	0	0	%	
20	AI3 Value	-100	100	0	0	%	
21	AI4 Value	-100	100	0	0	%	
23	Software Version	0	655,35	1, 1	1, 1		
27	Accessories Config. 1	00h	FFFFh	00h	00h		
28	Accessories Config. 2	00h	FFFFh	00h	00h		
29	Power Hardware Config	00h	FFFFh	00h	00h		
30	IGBTs Temperature U	-20	150	0	0	°C	
31	IGBTs Temperature V	-20	150	0	0	°C	
32	IGBTs Temperature W	-20	150	0	0	°C	
33	Rectifier Temperature	-20	150	0	0	°C	
34	Internal Air Temp.	-20	150	0	0	°C	
36	Fan Heatsink Speed	0	15000	0	0	rpm	
37	Motor Overload Status	0	100	0	0	%	

Offline

03

When exiting the window, the system asks the user if the parameters review has been completed.



- Yes: the system does not inform or ask about the parameter review anymore.
- No: the system keeps informing or asking about the parameter review.

7.2.7 Remove Parameters File

ACCESS

Toolbar:


Menu: Drive > Remove Parameters File

Shortcut Key: none

## FUNCTION

Removes the parameters file.

## APPEARANCE



## DESCRIPTION

User must select a filename in the Project Window.

SuperDrive G2 will ask the user to confirm deleting the file.

### 7.2.8 Export Parameters File

## ACCESS

Toolbar: 

Menu: Drive > Export Parameters File

Shortcut Key: none


## FUNCTION

Exports the content of a parameters file to another file in CSV format.

## DESCRIPTION

User must select a parameters file name in Project Window.

SuperDrive G2 requests user to confirm the file export. In affirmative case, a window is shown with the following options:



- Field delimiter. Options: semicolon or comma.
- Field separator. Options: single quotes, double quotes or without quotes.
- The name of the new file, in CSV format.
- Buttons to export and to cancel the export.

## 7.2.9 Read Parameters from Drive

### ACCESS

Toolbar: 


Menu: Drive > Read Parameters from Drive

Shortcut Key: none

### FUNCTION

It reads all the parameters from the drive to the computer.

### APPEARANCE



**DESCRIPTION**

All the parameters are saved in a computer file.


The user specifies the file name.

Then the user can view or edit the parameters.

**Parameters File Generated By the Project Converter**

If the parameters file was generated by the project converter, it is not possible to overwrite the file by reading the parameters from the drive.

An error message appears.



It is only possible to overwrite this file after the parameters review ([Edit Parameters File](#) function).

**7.2.10 Write Parameters to Drive**

**ACCESS**

Toolbar:   
 Menu: Drive > Write Parameters to Drive  
 Shortcut Key: none

**FUNCTION**

It sends all the parameters from the computer to the drive.


## DESCRIPTION

The user must select a file name in the Project Window.

Some parameters can only be changed when the drive is disabled (motor stopped).

### Serial


Select the drive address to which you want to send the parameters.



Press the OK button to start.

### USB / Bluetooth / Ethernet


To start writing all parameters, the user must answer Yes to confirm the action.



### Parameters File Generated By the Project Converter

If the parameters file was generated by the project converter, it is not possible to write the parameters to the drive.


An error message appears.




It is only possible to send the parameters to the drive after the parameters review ([Edit Parameters File](#) function).

**Parameter Writing Sequence (All Drives Except for CFW500 / CFW501 / MW500)**


The parameters are sequentially written from the first to the last parameter (from the lowest to the highest number).




At the end, a message pops up.



An error log may pop up in case some writing error occurs.







**Parameter Writing Sequence (CFW500 / CFW501 / MW500)**

The parameters are sequentially written from the first to the last parameter (from the lowest to the highest number) except for P312.


Parameter P312 (Serial Protocol) is only written at the end of the writing process.





Thus, in case of a writing error in a parameter, P312 is not written at the end of the writing process, and the user can send the parameters to the drive again.



On the other hand, if the parameters were all successfully written, then P312 is also sent to the drive.



An error log may pop up in case some writing error occurs.



## 7.2.11 Monitor Parameters

### ACCESS

Toolbar:

Menu: Drive > Monitor Parameters

Shortcut Key: none

## FUNCTION

Monitors all parameters in a grid. Allows to view and change the parameters in the online editor.

## APPEARANCE

Number	Function	Minimum	Maximum	Factory Setting	User Setting	Unit	Comparison
0	Access to Parameters	0	9999	0	0		
1	Speed Reference	0	18000	0	89	rpm	
2	Motor Speed	0	18000	0	0	rpm	
3	Motor Current	0	4500	0	0	A	
4	DC Link Voltage (Ud)	0	2000	0	300	V	
5	Motor Frequency	0	1020	0	0	Hz	
6	VFD Status	0	7	0: Ready	0: Ready		
7	Motor Voltage	0	2000	0	0	V	
9	Motor Torque	-1000	1000	0	0	%	
10	Output Power	0	6553,5	0	0	kW	
11	Output cosPhi	0	1	0	0		
12	DI8 to DI1 Status	00000000b	11111111b	00000000b	00000000b		
13	DO5 to DO1 Status	00000000b	00011111b	00000000b	0000001b		
14	AO1 Value	0	100	0	0	%	
15	AO2 Value	0	100	0	0	%	
16	AO3 Value	-100	100	0	0	%	
17	AO4 Value	-100	100	0	0	%	
18	AI1 Value	-100	100	0	5,05	%	
19	AI2 Value	-100	100	0	5	%	
20	AI3 Value	-100	100	0	5	%	
21	AI4 Value	-100	100	0	-100	%	
23	Software Version	0	655,35	0	55,82		
25	DI16 to DI9 Status	00000000b	11111111b	00000000b	00000000b		
26	DO13 to DO6 Status	00000000b	11111111b	00000000b	00000000b		
27	Accessories Config. 1	00h	FFFFh	00h	00h		
28	Accessories Config. 2	00h	FFFFh	00h	50h		

## DESCRIPTION

The program will show an overview of all the available parameters in a separate window. When SuperDrive G2 is online with a drive, it will show information from the drive being monitored. To edit a parameter double click on the parameter's user setting you would like to edit.

The following fields are available:

- Parameter number;
- Function;
- Minimum value;
- Maximum value;
- Factory setting;
- User's setting;
- Unit;
- Comparison.

When the parameter is read-only, the user's setting field is disabled (it can't be edited).

The user types the parameter value and press Enter. Only values between minimum and maximum are allowed.

In the online mode, to save the parameters in a file it is necessary confirming the action when the window is closed.

Some parameters shows a simple list of values in a single column. The user can select list entries with the mouse. Only one item can be selected at a time. When the user selects an item, any previously selected item is deselected first.

The user also can search for information in the parameter table typing the text or value to search and clicking on **Find Next**. By checking the **Match entire cell contents** option, the system searches for instances where the contents of the entire cell are equal to the search term.

### 7.2.12 Monitor using Keypad

#### ACCESS

Toolbar: 


Menu: Drive > Monitor using Keypad

Shortcut Key: none

#### FUNCTION

Monitors one parameter and sends commands to the drive.

#### APPEARANCE



#### DESCRIPTION

The following information related to the parameter are shown:

- Parameter number.
- Function.
- User's setting.
- Unit.

The user can view/change one parameter at a time.

Besides the parameters number there is a pair of tiny arrow buttons that let the user select the parameter number from an ordered sequence.

When the parameter is read-only, the user can't change the parameter value.

When the parameter can be changed, a button is available for changing the parameter's user setting.

Clicking on this button opens a new window where the user can change the parameter's user setting and press the Send button. Only values between minimum and maximum are allowed.

Some parameters shows a simple list of values in a single column. The user can select list entries with the mouse. Only one item can be selected at a time.

The drive commands window has buttons as described below.

### Command Buttons

- Jog.
- Direction of rotation (forward/reverse).
- Local/Remote.
- Start.
- Stop.
- General Enable.
- General Disable.
- Reset.

To use these command buttons in SuperDrive G2, some parameters must be programmed to the serial/USB option:

- CFW-11 / CFW700 / CFW701 / CFW500 / CFW501 / MW500 - P0220...P0228;
- CFW100 - P220, P222, P226...P228;
- SSW-06 / SSW-07 / SSW-08 / SSW7000 - P220, P229, P230.

## 7.2.13 Monitor Status

### ACCESS

Toolbar: 

Menu: Drive > Monitor Status

Shortcut Key: none

### FUNCTION


Shows the status of the drive.

## DESCRIPTION

The drive status window has indicators as described below.

### CFW-11 / CFW-11M G2 Status

- Drive Status;
- Direction of Rotation: Forward/Reverse;
- Local/Remote;
- General Enable;
- Ramp Enable;
- Jog.




### CFW-11RB Status

- Drive Status;
- General Enable;
- Ramp Enable.

### CFW700 / CFW701 Status

- Drive Status;
- Direction of Rotation: Forward/Reverse;
- Local/Remote;
- General Enable;
- Ramp Enable;
- Jog.



### CFW500 / CFW501 / MW500 Status

- Drive Status;
- Direction of Rotation: Forward/Reverse;
- Local/Remote;
- General Enabled;
- Motor running;
- Jog;
- Configuration Mode;
- Alarm;
- Fault.

### CFW100 Status

- Drive Status;
- Direction of Rotation: Forward/Reverse;
- Local/Remote;
- General Enabled;
- Motor running;
- Jog;
- Configuration Mode;
- Alarm;
- Fault.

### ECW500 Status

- Drive Status;
- State of Limiters;
- State of Digital Inputs;
- Events.

Monitor Status
✕

Status

ECW500 Disabled

Running startup ramp

Limiters

LUF Enabled	LEOC Enabled
LEUC Enabled	LTOC Enabled

Digital Inputs

On	Off
Increment	Decrement
MTVC	MECC
Enable Online	Disable Online
Enable Parallel	Disable Parallel
Pre Position	Reset Alarms
Backup	

Operation Mode

MTVC	MECC
MPFC	Droop
Open Loop	MRPC
Backup	Auto-Tuning


Event	Date
EV003: Alarm Reset	07/31/2018 15:03:09
EV008: LUF stopped	07/27/2018 16:02:39
EV000: ECW off	07/27/2018 16:02:39
WR008: Pwr PhaseFault	07/27/2018 16:02:37
EV007: LUF acting	07/27/2018 16:02:34

23 ms

### Status do CTW900

- Drive Status;
- Accelerating;
- Decelerating;
- Jog;
- Blocked;
- Configuration Mode;
- Auto-Ajuste;
- Segunda Rampa;
- Local/Remoto;
- Horário/Anti-horário;
- Invertendo;
- Subtensão;
- Alarme;

- Falha;
- DIs;
- DOs.



### SSW-06 / SSW-07 / SSW-08 Status

- Drive Status;
- Direction of Rotation: Forward/Reverse;
- Local/Remote;
- General Enable;
- Motor Running;
- Jog;
- Accelerating;
- Current Limit;
- Full Voltage;
- Decelerating;
- Braking;
- Reverting;
- Main Power On;
- Bypass.

## SSW7000 Status

- Drive Status;
- Direction of Rotation: Forward/Reverse;
- Local/Remote;
- General Enable;
- Motor Running;
- Jog;
- Accelerating;
- Full Voltage;
- Bypass;
- Decelerating;
- Braking;
- Reverting;
- Delay P0831;
- Main Power On;
- Configuration Mode;
- Alarm;
- Fault.

## 7.2.14 Monitor Speed Reference


### ACCESS

Toolbar:   
 Menu: Drive > Monitor Speed Reference  
 Shortcut Key: none

### FUNCTION

Shows the speed reference of the drive.

### APPEARANCE



### DESCRIPTION

There are 6 fields which show data related to speed reference:

- Speed Reference - RPM or 13 bits
- Parameter

- User Setting
- Minimum
- Maximum
- New User Setting

The user can type a new value in New User Setting field and press Send button. Only values between minimum and maximum value are allowed.

The new value will appear in User Setting field after the drive has changed the value.

## 7.2.15 Trend

### ACCESS

Toolbar: 

Menu: Drive > Trend

Shortcut Key: none


### FUNCTION

Captures signal values from drives and displays it as a graph. Data can also be saved, printed and exported.

Up to ten drive signals can be monitored.

The Trend is for low to medium sampling rates.

### APPEARANCE



## DESCRIPTION


The following items are presented below:

- Configuring Trend,
- Acquiring Trend Data,
- Viewing Trends,
- Export Trends,
- Print Trends,
- Disk Usage.


## Configuring Trend

### Adding Channels

To add a channel, choose Add Channel.



In the Add Channel dialog box, enter the channel information. Use the drop down list to select the channel variable.



Once the channel is added to the trend, the range (upper and lower limits of Y-axis) and other properties related can be set.

To set the channel range and other properties:

1. Select the desired channel,
2. Set the maximum and minimum limits of the Y-axis labels and change the color of the line used to draw the signal.

To hide channels in the trend:


1. Select the desired channel,
2. Uncheck the visibility property.

 **NOTE!** To redisplay hidden channels, check the visibility property again.

### Removing Channels

To remove a channel from the trend


1. Select the desired channel,
2. Choose Remove Channel.



### Configuring the Time Axis

The range of the time (horizontal axis) visible on the graph can be changed by using the Trend Time Axis drop down list.

The time axis requires a range in seconds.




### Selecting the Sampling Rate

Adjust the sampling period when needed.

The sampling period requires a value in milliseconds, between 200 ms (0.2 s) and 86,400,000 ms (24h).


This is the period of time until next channels be acquired.



Check the box to calculate continuously the faster sampling rate.

This sampling rate may vary according to communication type between drive and PC and the amount of channels being acquired simultaneously.

When this option is enabled, data are read as fast as possible:



**NOTE!**

Enable **Continuous** option to read data from channels as fast as possible. The minimum sampling period can vary according to the number of channels, communications' baud rate, etc.



While capturing, the Trend displays the values of the channels.

In an ideal condition, these are the minimal sampling rate for each communication type:

- USB: at least 150 ms. Add 50 ms for each channel being observed.
- Serial: at least 150 ms. Add 50 ms for each channel being observed.
- Bluetooth: at least 350 ms. Add 300 ms for each channel being observed.

To monitor for a long period of time, use a high sampling interval.

Otherwise, the amount of points being constantly processed should cause slowdowns and instability during the graphic presentation.


Use the equation below to estimate the amount of points in the graphic.

$$\text{Amount of Points} = \frac{\text{Channels Quantity} \times \text{Time of Acquisition (s)}}{\text{Sampling Rate (ms)} / 1000}$$


Results over than 20,000 points may cause slowdowns and instability:

### Opening Graph

A dialog box prompts you to view the graph:



Message while updating chart on screen:



## Acquiring Trend Data

### Capturing and Saving Trends

After channels were added to Trend, you must start capturing to view the trend on the graph.

There are four options available: **Start**, **Pause**, **Stop** and **Save**.

The options **Start**, **Pause** and **Stop** requires communication with drive.

- Start Button: Press **Start** button to start trending.
- Pause Button: Click **Pause** when is necessary analysing data during the acquisition.

While it is enabled, the acquisition still running but the last data read are not shown in the graph.

To scroll Trend, choose **Pause**. Clicking over the graphic will show up the scroll bar (only if there is part of the graphic not shown in the visible area).


When **Pause** is deselected, the graphic shows last data being acquired.

- Stop Button: Press **Stop** to stop trending of the selected signals. The acquired data are not save yet.
- Save Button: Press **Save** to store the acquired data.

SuperDrive G2 offers an option to save a trend for later analysis without a drive connected.

The files have the extension **.trend**.

A dialog box is shown. Type the filename and click **Save**:

**NOTE!**

While data is being acquired, Trend shows last channels's data in graphic.

When the graphic is scrolled during the data acquisition, it stops showing the last data read.

To revert it, is necessary to **Restore Width** (it is placed above the graphic).

## Viewing Trends

To open a previously saved trend, select the file with the **.trend** extension in the Project Window and then choose menu **Drive > Trend**.

It is not necessary to have the drive connected while viewing previously saved trends.


You can move through the samples using the scroll bar to examine data in detail.

## Using the Cursor

To activate this marker press the **left mouse button** over the graph area.

The marker can be moved by clicking the mouse over the trend screen.

The selected sample time and value of each channel are indicated.



## Zoom

You can zoom in and zoom out of the trend.

To zoom in on the trend, choose **+** or **Zoom** and place the mouse pointer at the top left corner of the area you want to zoom in.

Click and hold the left mouse button then drag the pointer to draw a rectangle and release the mouse button.

The view of the trend zooms in.

To zoom out of the trend, choose **-**. The view of the trend zooms out. Horizontal Zoom Out stops when the width reaches its original value.

## Scroll (Pan)

You can scroll the trend using the mouse.

To scroll Trend, choose **Pan**.


Click and hold the left mouse button at the graph area then drag the pointer to move graph in direction the mouse is moved.

## Export Trends

The currently displayed trend can be exported to a PNG file.

To export a trend:

1. Open the trend you want to export,
2. Choose **Export**,
3. Enter a filename for the PNG file.




 **NOTE!** To export the data acquired, go on [Export Trend File](#).

## Print Trends

The currently displayed trend can be printed.

To print a trend:

1. Open the trend you want to print,
2. Choose **Print**.



 **NOTE!** When printing or exporting, it is recommended to set the legend visible.

## Disk Usage

Trend creates temporary files during data acquiring. These information are needed to estimate how much disk space will be required for trend files:

- Number of channels,
- Time interval (total in s),
- Sampling rate (in ms).

Use the equation below to estimate necessary amount of free disk space:

$$\text{Disk Space} = \frac{\text{Number of Channels} \times \text{Time Interval (s)} \times 25}{\text{Sampling Rate (ms)} / 1000}$$

### Examples

Case 1

Monitor 5 channels during 100 s (1:40:00) at 200 ms sampling rate:

$$\text{Disk Space} = \frac{5 \times 100 \times 25}{200 / 1000} = 62 \text{ Kb}$$

Case 2

Monitor 10 channels during 14400 s (4:00:00) at 500 ms sampling rate:

$$\text{Disk Space} = \frac{10 \times 14400 \times 25}{500 / 1000} = 7 \text{ Mb}$$

Case 3

Monitor 4 channels during 2592000 s (30 days) at 500 ms sampling rate:

$$\text{Disk Space} = \frac{4 \times 2592000 \times 25}{500 / 1000} = 518 \text{ Mb}$$

Case 4

Monitor 2 channels during 864000 s (10 days) at 2000 ms sampling rate:

$$\text{Disk Space} = \frac{2 \times 864000 \times 25}{2000 / 1000} = 21 \text{ Mb}$$

## 7.2.16 Remove Trend File

### ACCESS

Toolbar: 

Menu: Drive > Remove Trend File

Shortcut Key: none

### FUNCTION

Remove all trend files.

### DESCRIPTION

User must select a filename in the Project Window.

SuperDrive G2 will ask the user to confirm deleting all trend files.

## 7.2.17 Export Trend File

### ACCESS

Toolbar: 

Menu: Drive > Export Trend File

Shortcut Key: none

### FUNCTION


Exports the content of a trend file to another file in CSV format.

### DESCRIPTION

User must select a trend file name in the project tree.

SuperDrive G2 requests user to confirm the file export.

In affirmative case, a window is shown with the following options:



- Field delimiter. Options: semicolon or comma.
- Field separator. Options: single quotes, double quotes or without quotes.
- The name of the new file, in CSV format.
- Buttons to export and to cancel the export.

## 7.2.18 Trace

### ACCESS

Toolbar: 


Menu: Drive > Trace

Shortcut Key: none

### FUNCTION

It presents a graph of acquired trace function's data.

### APPEARANCE



## DESCRIPTION

The window presents a graph of trace channel's data for the selected file. If no file is selected, a blank graph is presented.

Press the button Config Trace to configure the trace function.

### Trace Function Configuration

A window with trace configuration parameters is presented.

Use the editable fields to change parameters contents.

The editable fields have the factory default value (if no file was selected), or the values from the previously saved file.

- Read configuration - to read the trace configuration parameters from the drive. The parameters settings will be read from the drive and presented in the window.
- Write configuration - to send the trace configuration to the drive. The configuration parameters are sent to the drive.
- Start Trace - used to start the trace function on the drive. The start trace command is sent to the drive.
- Close - to close the configuration window.
- Acquire data - to acquire trace function data.


### Trace Function Acquisition

If the trace function status is not complete, the trace function status monitor window is presented.

While the status is not complete, the button OK is disabled and the acquisition can not be performed.

When the status is complete, all programmed trace channel's data is acquired.

When the acquisition is complete please type the file name where all trace information and channel's data is to be stored.



## Graph Visualization

Trace channel's data is presented in a graph.

The channel information table is presented below the graph.

- # - trace channel's index.
- Visible - shows/changes channel's visibility in the graph.
- Color - shows/changes the color which represents channel's data in the graph.
- Description - trace channel's acquired variable description.
- Sample time - time of the selected sample in the chart.
- Sample value - value of the selected sample in the chart.
- Unit - trace channel's data unit.
- Minimum - shows/changes the lower bound for the axis of this channel in the graph.
- Maximum - shows/changes the upper bound for the axis of this channel in the graph.

A black vertical line is shown at the trigger position. At the top of the graph is the trigger description.

## Graph Manipulation

It is possible to change the sample cursor position by clicking at the graph.

A toolbar with the following options can be found above the graph:

- Export: exports the graph area as a PNG image.
- Print: prints the graph area.
- Pan: changes to Pan Mode.
- Zoom: changes to Zoom Mode.
- Zoom +: magnifies the graph area.
- Zoom -: zoom out the graph area.
- Restore width: restores the initial width of the horizontal axis.
- Restore height: restores the initial height of the vertical axis.
- Auto height: automatic height depending on the maximum or minimum values of the samples.
- Legend: shows/hide the graph legend.

## Pan Mode

In Pan Mode press the mouse button over the graph area and drag to move the graph in the desired direction.

## Zoom Mode

In Zoom Mode press the mouse button over the graph area and drag to draw a zoom box. Release the mouse button to magnify the selected graph area.

## 7.2.19 Remove Trace File

### ACCESS

Toolbar:   
Menu: Drive > Remove Trace File  
Shortcut Key: none

### FUNCTION

Remove all trace files.

### DESCRIPTION

User must select a filename in the Project Window.

SuperDrive G2 will ask the user to confirm deleting all trace files.

## 7.2.20 Export Trace File

### ACCESS

Toolbar:   
Menu: Drive > Export Trace File  
Shortcut Key: none

### FUNCTION


Exports the content of a trace file to another file in CSV format.

### DESCRIPTION

User must select a trace file name in the project tree.

SuperDrive G2 requests user to confirm the file export.

In affirmative case, a window is shown with the following options:



- Field delimiter. Options: semicolon or comma.
- Field separator. Options: single quotes, double quotes or without quotes.
- The name of the new file, in CSV format.
- Buttons to export and to cancel the export.

## 7.3 Tools

[Options](#)

[Import Database](#)

[Convert Project](#)

[Simplified Conversion Log](#)

[Remove Simplified Conversion Log](#)

[Full Conversion Log](#)

[Remove Simplified Conversion Log](#)

### 7.3.1 Options

## ACCESS

Toolbar: 


Menu: Tools > Options

Shortcut Key: none

## FUNCTION

Allows the user to select options for SuperDrive G2.

## PRESENTATION



## DESCRIPTION

The options are available via tabbed menu. To access them, click over the tab name:

- Language
- Print
- Projects

### Language


Allows the user to select a language.

Three languages are available:

- English,
- Spanish,
- German,
- Portuguese.

Besides the language selection of the software, the user can change the priority language selection of alternative database, which occurs when the selected drive does not have support for the selected language.

When successfully applies a language change, system presents a confirmation message.




### Print

Allows the user to select the parameters printing options.

Four options are available:



- Print all parameters;
- Print all parameters, highlight changes in bold font (when compared to standard values);
- Print all parameters, highlight changes in red font (when compared to standard values);
- Print changed parameters only (when compared to standard values).



### Projects

Allows the user to select the main projects folder, when SuperDrive G2 projects are stored.

This option presents the current main projects folder, where is possible to change this path: You must close the project before accessing this function. Otherwise, while a project is open SuperDrive G2 disables this option.



- [1] Current path and folder where projects are stored.
- [2] New path where projects will be stored. This field only updates after you choose a new path through items [3] or [4].
- [3] When selecting this option, the system restores the standard path and folder where projects will be stored.
- [4] This button selects a new path where projects will be stored.
- [5] This button apply the changes. It will be available only if there were changes.

## 7.3.2 Import Database

### ACCESS

Toolbar: 

Menu: Tools > Import Database

Shortcut Key: none

### FUNCTION

Allows the user to import or update databases for SuperDrive G2.

### DESCRIPTION

User must select a Database Package file.

The information of the selected Database Package is displayed in the Import Database window.

**NOTE!**

Ensure there is no project open before access this function.

## 7.3.3 Convert Project

### ACCESS

Toolbar: 


Menu: Tools > Convert Project

Shortcut Key: none

### FUNCTION

This function allows converting a project from one firmware version to another firmware version.

### PRESENTATION



The project conversion window, shown above, has 10 panels, which are presented in a simplified way below:

Description	Steps
Original Project	Target Project
Original Drive	Target Drive
Original Accessory	Target Accessory
Convert Project	Result after the Conversion

Each panel has the following information:

- Description: brief description of the convert project function.
- Steps: indicate the fields to be changed/selected, and the button to start the project conversion.
- Original Project: source project name, as well as its path.
- Target Project: target project name, as well as its path.
- Original Drive: model, firmware version and voltage/rated current.
- Target Drive: model, firmware version and voltage/rated current.
- Original Accessory: source accessory name and firmware version, when available.
- Target Accessory: target accessory name and firmware version, when available.
- Convert Project: button to start the project conversion; this button is enabled under certain conditions.
- Result after the Conversion: presents a progress bar during the project conversion, showing a success or error status at the end of the conversion; 2 buttons are available: simplified conversion log and full conversion log.

## DESCRIPTION

It is possible to select the firmware version, rated voltage and current in the target project.

Accessory, when available, can also be selected.

A new project will be created.


Source project will not be modified.

### Checkbox - Show the fields to fill in/select and button to start conversion

The user can click on the checkbox to highlight the fields (orange) which must be modified before starting the project conversion.


### How to Convert the Projects

- 01** - Fill in the name of the target project.
- 02** - Select the firmware version, rated voltage and rated current of the target drive.
- 03** - Select the accessory and firmware version, when available.
- 04** - Click on the button to start the project conversion.
- 05** - Click Yes to start the project conversion.



**06** - Wait for the process to finish.

**07** - Select one of the presented options.



- Simplified Conversion Log: opens the simplified conversion log viewer.
- Full Conversion Log: opens the full conversion log viewer.
- No: return to the project conversion window.

**08** - It returns to the project conversion window after closing the log viewer.


It is possible to view the conversion log.

2 buttons are available:

- Simplified Conversion Log: opens the simplified conversion log viewer.
- Full Conversion Log: opens the full conversion log viewer.

## 09 - Exit the Project Conversion Window.

When exiting the window, after the successful project conversion, the system asks if the user wants to open the new project that has been generated.



- Yes: closes the original project and opens the new created project.
- No: returns to the main window of the SuperDrive G2, keeping the source project open.

## Review of the Parameters Generated in the Target Project

In the Convert Project panel, a **warning message** tells the user to check all the parameters after conversion.

Therefore, the user must open the target project and review the content of the parameters in the [offline parameter editor](#), changing the content if necessary.

In the parameter editor, after the edition, the system asks the user if the review is complete (yes or no).

It is necessary to review the parameters in order to be able to send the converted parameters to the drive or to read the parameters and overwrite the converted parameters.

If the parameters are not reviewed, the system will allow neither reading nor writing the converted parameters.

## Conversion Log

The (simplified or full) conversion log can then be viewed. See the chapters:

- [Simplified Conversion Log](#).
- [Full Conversion Log](#).

## Rules Used in the Project Conversion

01

- Reason: Parameter in the source project does not exist in the target project
- Action: Non-existent parameter in the target project

02

- Reason: Target parameter is read-only
- Action: Factory setting of the target parameter assumed

03

- Reason: Content of the source parameter is equal to the factory setting
- Action: Factory setting of the target parameter assumed

04

- Reason: Source parameter content is between the maximum and minimum of the target parameter
- Action: Source parameter content is copied to the target parameter content

05

- Reason: Source parameter content is out of the limits of the target parameter
- Action: Factory setting of the target parameter assumed

06

- Reason: Target parameter is new (it does not exist in the source project)
- Action: Factory setting of the target parameter assumed

### 7.3.4 Simplified Conversion Log

## ACCESS

Toolbar: 

Menu: Tools > Simplified Conversion Log


Shortcut Key: none

## FUNCTION

It displays the simplified conversion log, generated by the convert project function.

This log includes the parameter conversions, but only new parameters or parameters whose content has been changed in the target project.

## PRESENTATION



## DESCRIPTION

The log viewer shows the log where it is possible to view from the beginning to the end, with a horizontal and vertical scroll bar.

- Print Button: sends the log to the current printer.
- Close Button: closes the window.

### Simplified Conversion Log Content

The log has the following information:

- Date.
- Time.
- Original project name, including the drive model, firmware version, rated voltage/current, firmware version/accessory.
- Target project name, including the drive model, firmware version, rated voltage/current, firmware version/accessory.
- Parameters file name.
- List of new/changed parameters, where each parameter presents: number, description, content, and applied action (only new parameters or the ones whose content has been changed by the project converter).

### 7.3.5 Remove Simplified Conversion Log

#### ACCESS

Toolbar: 


Menu: Tools > Remove Simplified Conversion Log

Shortcut Key: none

#### FUNCTION

It removes the simplified conversion log.

#### PRESENTATION



#### DESCRIPTION

When clicking on the button or menu item **Remove Simplified Conversion Log**, a message prompts the confirmation to remove the file.

- Yes: removes the file.
- No: aborts the operation.

### 7.3.6 Full Conversion Log

#### ACCESS

Toolbar: 

Menu: Tools > Full Conversion Log


Shortcut Key: none

#### FUNCTION

It displays the full conversion log, generated by the **Convert Project** function.

This log includes the conversions of all the parameters.

#### PRESENTATION



## DESCRIPTION

The log viewer shows the log where it is possible to view from the beginning to the end, with a horizontal and vertical scroll bar.

- Print Button: sends the log to the current printer.
- Close Button: closes the window.

## Full Conversion Log Content

The log has the following information:

- Date.
- Time.
- Original project name, including the drive model, firmware version, rated voltage/current, firmware version/accessory.
- Target project name, including the drive model, firmware version, rated voltage/current, firmware version/accessory.
- Parameters file name.
- List of all the parameters of the target project, where each parameter presents: number/description of the original project, number/description of the target project, original and target parameter content, reason and applied action.

### 7.3.7 Remove Full Conversion Log

#### ACCESS

Toolbar: 


Menu: Tools > Remove Full Conversion Log

Shortcut Key: none

#### FUNCTION

It removes the full conversion log.

#### PRESENTATION



#### DESCRIPTION

When clicking on the button or menu item **Remove Full Conversion Log**, a message prompts the confirmation to remove the file.

- Yes: removes the file.
- No: aborts the operation.

## 7.4 Help

[Contents](#)

[About](#)

### 7.4.1 Contents

#### ACCESS

Toolbar: 

Menu: Help > Contents

Shortcut Key: none

#### FUNCTION

Opens the online help.

---

## DESCRIPTION

A comprehensive online documentation is available. The documentation can be printed.

### 7.4.2 About

## ACCESS

Toolbar:   
Menu: Help > About  
Shortcut Key: none


## FUNCTION

Displays information about SuperDrive G2 version, build, etc.

## DESCRIPTION

Displays the following information:

- Software name.
- Version.
- Build.
- Launch date.
- Copyright.
- Simplified software description.
- Operational systems where the software can run.
- Java informations.



## 8 Communication

Contents of this chapter:

[Drive Parametrization](#)

[USB Connection](#)

[USB Connection - Virtual COM Port](#)

[RS232 Connection](#)

[RS485 Connection](#)

[Bluetooth Connection](#)

[Ethernet Connection](#)

[RS232 Cable](#)

[USB Cable](#)

[Ethernet Cable](#)

[USB to Serial Adapter](#)

[Bluetooth USB Adapter](#)

[Ethernet Network Adapter](#)

[Before Trying to Establish Communication](#)

[Exception During Monitoring](#)

### 8.1 Drive Parametrization

The following parameters must be set as below:

Drive	Connection Type	Parameter	Description	Recommended
<b>CFW-11</b>	<a href="#">Ethernet</a>	0723	Anybus Identification	19 = EtherNet/IP or 21 = Modbus-TCP or 23 = PROFINET IO
		0841	Communication Rate	0 = Auto
		0842	Time-out Modbus TCP	0
		0843	IP Address Configuration	0 = Parameters
		0844	IP1 Address	192
		0845	IP2 Address	168
		0846	IP3 Address	0
		0847	IP4 Address	10

Drive	Connection Type	Parameter	Description	Recommended
<b>CFW-11</b> <b>CFW-11RB</b> <b>CFW-11M G2</b>	<a href="#">USB</a> (WEG)	-----	-----	-----
<b>CFW700</b> <b>CFW701</b>	<a href="#">RS485</a>	0308	Serial Address	1
		0310	Serial Baud Rate	1 = 19200 bits/s
		0311	Serial Bytes Config.	1 = 8 bits, even parity, 1sb
<b>CFW500</b> <b>CFW501</b>	<a href="#">RS485</a>	0308	Serial Address	1
		0310	Serial Baud Rate	1 = 19200 bits/s
		0311	Serial Bytes Config.	1 = 8 bits, even parity, 1sb
		0312	Serial Protocol	2 = Modbus RTU [with plug-in module CFW500-IOS] 6 = HMIR (1) + Modbus RTU (2) [with plug-in module CFW500-CUSB, CFW500-CRS232 or CFW500-CRS485] 7 = Modbus RTU (2) [with plug-in module CFW500-CUSB, CFW500-CRS232 or CFW500-CRS485]
	<a href="#">USB (Virtual COM Port)</a> (FTDI)	0312	Serial Protocol	6 = HMIR (1) + Modbus RTU (2) [with plug-in module CFW500-CUSB] 7 = Modbus RTU (2) [with plug-in module CFW500-CUSB]
<b>CFW500</b> <b>MW500</b>	<a href="#">Ethernet</a>	0800	Ethernet Module Identification	1 = Modbus TCP or 2 = EtherNet/IP or 3 = PROFINET IO
		0803	Ethernet Communication Rate	0 = Auto
		0806	Watchdog Modbus TCP	0.0 ... 65.5 s
		0810	IP Address Configuration	0 = Parameters
		0811	IP1 Address	192
		0812	IP2 Address	168
		0813	IP3 Address	0
		0814	IP4 Address	10
<b>MW500</b>	<a href="#">RS232</a>	0308	Serial Address	1
		0310	Serial Baud Rate	1 = 19200 bits/s
		0311	Serial Bytes Config.	1 = 8 bits, even parity, 1sb
		0312	Serial Protocol	2 = Modbus RTU
	<a href="#">RS485</a>	0308	Serial Address	1
		0310	Serial Baud Rate	1 = 19200 bits/s
		0311	Serial Bytes Config.	1 = 8 bits, even parity, 1sb
		0312	Serial Protocol	2 = Modbus RTU [with plug-in

Drive	Connection Type	Parameter	Description	Recommended
				module CFW500-IOS]
				6 = HMIR (1) + Modbus RTU (2) [with plug-in module CFW500-CUSB, CFW500-CRS232 or CFW500-CRS485]
				7 = Modbus RTU (2) [with plug-in module CFW500-CUSB, CFW500-CRS232 or CFW500-CRS485]
	<a href="#">USB (Virtual COM Port)</a>	0312	Serial Protocol	2 = Modbus RTU (1) [with plug-in module CFW500-CUSB] 6 = HMIR (1) + Modbus RTU (2) [with plug-in module CFW500-CUSB]
<b>CFW100</b>	<a href="#">RS485</a>	0308	Serial Address	1
		0310	Serial Baud Rate	1 = 19200 bits/s
		0311	Serial Bytes Config.	1 = 8 bits, even parity, 1sb
		0312	Serial Protocol	2 = Modbus RTU
	<a href="#">USB (Virtual COM Port)</a> (FTDI)	0308	Serial Address	1
		0310	Serial Baud Rate	1 = 19200 bits/s
		0311	Serial Bytes Config.	1 = 8 bits, even parity, 1sb
		0312	Serial Protocol	2 = Modbus RTU
	<a href="#">Bluetooth</a>	0770	Bluetooth Device Name	Random number
		0771	Bluetooth PIN	1234
<b>CTW900</b>	<a href="#">USB</a> (WEG)	-----	-----	-----
<b>ECW500</b>	<a href="#">RS485</a>	30006	Serial Baud Rate	2 = 38400 bits/s
		30008	Serial Parity	0 = None
		30010	Serial Stop Bits	1
<b>SCA-06</b>	<a href="#">USB</a> (WEG)	-----	-----	-----
		<a href="#">Ethernet</a>	0800	Ethernet Module Identification
	0803		Ethernet Communication Rate	0 = Auto
	0806		Watchdog Modbus TCP	0.0
	0810		IP Address Configuration	0 = Parameters
	0811		IP1 Address	192
	0812		IP2 Address	168
	0813		IP3 Address	0

Drive	Connection Type	Parameter	Description	Recommended
		0814	IP4 Address	10
<b>SSW-06</b>	<a href="#">RS232</a>	308	SSW Address	1
		312	Serial Protocol	1: MB 9600 N (Modbus-RTU 9600 bps, no parity), 8 bits, 2sb
	<a href="#">USB (Virtual COM Port)</a> (FTDI)	-----	-----	USB Communication Kit (K-USB) should be used, which is supplied with the product
<b>SSW-07</b> <b>SSW-08</b>	<a href="#">RS232</a>	308	SSW Address	1
		312	Serial Protocol	1: MB 9600 N (Modbus-RTU 9600 bps, no parity), 8 bits, 2sb
<b>SSW7000</b>	<a href="#">USB</a> (WEG)	-----	-----	-----
<b>CFW-09 PM</b>	<a href="#">RS232</a>	308	Serial:Address	1
		310	Serial:Bit Rate	1: 9600 bps
		311	Serial:Data Con.	3: 8b, no parity, 2sb
		312	Serial:Protocol	2: Modbus-RTU



**NOTE!**

Drive and SuperDrive G2 must use the same settings.  
 For CFW-09 PM, P308, P310 and P311 can be changed, see Frequency Inverter Manual - CFW-09 PM.  
 For CFW700, P0308, P0310 and P0311 can be changed, see Programming and Maintenance Manual - CFW700.  
 For SSW, P308 and P312 can be changed, see Serial Communication Manual.  
 (1) CFW500 - Port 1 - terminals 12, 14, 16.  
 (2) CFW500 - Port 2 - USB, DB9 or RS485 connector (terminals 20, 22, 24).

## 8.2 USB Connection

The drive should be located at a distance shorter than 3 m from the computer.

This connection is made with [USB Cable](#), supplied with drive user's guide.

USB Driver: user must install the USB driver available at USB\_Driver\USBIO folder.

### CFW-11 / CFW-11RB / CFW-11M G2

Figure below shows how to connect a computer to the drive (USB).



**WARNING!**  
 Switch off the drive before making the connections.

1. The USB connector is in the front cover of the drive.
2. Connect the type B connector of usb cable to the usb connector of the drive.
3. Connect the type A connector of usb cable to the computer usb port.
4. Check if in the SuperDrive G2 [Communication Setup](#) the selected connection type is USB.

## CTW900

**WARNING!**  
 Switch off the drive before making the connections.

1. The USB connector is in the front cover of the drive.
2. Connect the type B connector of usb cable to the usb connector of the drive.
3. Connect the type A connector of usb cable to the computer usb port.
4. Check if in the SuperDrive G2 [Communication Setup](#) the selected connection type is USB.

## SCA-06

**WARNING!**  
 Switch off the drive before making the connections.

1. The USB connector is in the front cover of the drive.
2. Connect the type B connector of usb cable to the usb connector of the drive.
3. Connect the type A connector of usb cable to the computer usb port.
4. Check if in the SuperDrive G2 [Communication Setup](#) the selected connection type is USB.

## SSW7000

**WARNING!**  
 Switch off the drive before making the connections.

1. The USB connector is in the front cover of the drive.
2. Connect the type B connector of usb cable to the usb connector of the drive.

3. Connect the type A connector of usb cable to the computer usb port.
4. Check if in the SuperDrive G2 [Communication Setup](#) the selected connection type is USB.

## CFW700 / CFW701

Figure below shows how to connect a computer to the drive (USB).



### WARNING!



Switch off the drive before making the connections.  
 This connection is available in CFW700's HMI since S/N 1024003697.  
 This connection is available in CFW701's HMI since S/N 1023801859.

1. The USB connector is in the drive's HMI.
2. Connect the type mini-B connector of [usb cable](#) to the usb connector of the drive.
3. Connect the type A connector of usb cable to the computer usb port.
4. Check if in the SuperDrive G2 [Communication Setup](#) the selected connection type is USB.

## 8.3 USB Connection - Virtual COM Port


The drive should be located at a distance shorter than 3 m from the computer.

This connection is made with [USB Cable](#), supplied with drive user's guide.

USB Driver: user must install the USB driver available at USB\_Driver\FTDI folder.


## SSW-06

Figure below shows how to connect a computer to the drive (USB).



Device manager in Windows indicates which serial port is connected to the drive.

The computer name in device manager is purposely unreadable.



In SuperDrive G2, select the serial port correctly in Communication Setup window as follows.

Communication Setup

Connection Type:

USB  Serial  Bluetooth  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	0	ms	0	[0 ... 20000]
Time-out	100	ms	100	[100 ... 20000]

Serial:

Equipment	SSW-06
Serial Port	COM6
Data Bits	8
Stop Bits	2
Parity	No Parity
Baud Rate	9600

OK Cancel


**WARNING!**

Switch off the drive before making the connections.


1. Connect the mini-B connector of usb cable to the usb connector of the drive.
2. Connect the type A connector of usb cable to the computer usb port.
3. In device manager check which serial port is connected.
4. Check if in the SuperDrive G2 [Communication Setup](#) the selected connection type is serial.
5. The serial port in the window of communication setup window should be the same serial port that appears in the device manager, where the USB cable is connected.

**CFW500 / CFW501**

Figure below shows how to connect a computer to the drive (USB).



Device manager in Windows indicates which serial port is connected to the drive. The computer name in device manager is purposely unreadable.



In SuperDrive G2, select the serial port correctly in Communication Setup window as follows.

Communication Setup

Connection Type:

USB  Serial  Bluetooth  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	0	ms	0	[0 ... 20000]
Time-out	100	ms	100	[100 ... 20000]

Serial:

Equipment: CFW500

Serial Port: COM6

Data Bits: 8

Stop Bits: 1

Parity: Even

Baud Rate: 19200

OK Cancel


**WARNING!**

Switch off the drive before making the connections.


1. Connect the mini-B connector of usb cable to the usb connector of the drive.
2. Connect the type A connector of usb cable to the computer usb port.
3. In device manager check which serial port is connected.
4. Check if in the SuperDrive G2 [Communication Setup](#) the selected connection type is serial.
5. The serial port in the window of communication setup window should be the same serial port that appears in the device manager, where the USB cable is connected.

**CFW100**

Figure below shows how to connect a computer to the drive (USB).



Device manager in Windows indicates which serial port is connected to the drive. The computer name in device manager is purposely unreadable.



In SuperDrive G2, select the serial port correctly in Communication Setup window as follows.

Communication Setup

Connection Type:

USB  Serial  Bluetooth  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	0	ms	0	[0 ... 20000]
Time-out	100	ms	100	[100 ... 20000]

Serial:

Equipment: CFW100

Serial Port: COM6

Data Bits: 8

Stop Bits: 1

Parity: Even

Baud Rate: 19200

OK Cancel

**WARNING!**

Switch off the drive before making the connections.



1. Connect the mini-B connector of usb cable to the usb connector of the drive.
2. Connect the type A connector of usb cable to the computer usb port.
3. In device manager check which serial port is connected.
4. Check if in the SuperDrive G2 [Communication Setup](#) the selected connection type is serial.
5. The serial port in the window of communication setup window should be the same serial port that appears in the device manager, where the USB cable is connected.
6. Never change values in **P308**, **P310** and **P312** during a connection. Changing these parameters instantly causes connection lost between PC and drive.

**MW500**


Figure below shows how to connect a computer to the drive (USB).

**WARNING!**

With the drive turned off, be sure that position 1 of DipSwitch S10 is OFF, as shown below:



Device manager in Windows indicates which serial port is connected to the drive. The computer name in device manager is purposely unreadable.



In SuperDrive G2, select the serial port correctly in Communication Setup window as follows.

Communication Setup

Connection Type:

USB  Serial  Bluetooth  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	0	ms	0	[0 ... 20000]
Time-out	100	ms	100	[100 ... 20000]

Serial:

Equipment: MW500

Serial Port: COM6

Data Bits: 8

Stop Bits: 1

Parity: Even

Baud Rate: 19200

OK Cancel

**WARNING!**

Switch off the drive before making the connections.

1. Connect the mini-B connector of usb cable to the usb connector of the drive.
2. Connect the type A connector of usb cable to the computer usb port.
3. In device manager check which serial port is connected.
4. Check if in the SuperDrive G2 [Communication Setup](#) the selected connection type is serial.
5. The serial port in the window of communication setup window should be the same serial port that appears in the device manager, where the USB cable is connected.

## 8.4 RS232 Connection

The RS-232 standard (Recommended Standard 232) is only used in peer-to-peer communication, that is, it accepts two devices for communication: one master and one slave.

The drive, which is the slave, must be located less than 10 meters away from the computer (master).

### SSW-06

Figure below shows how to connect a computer to the drive (RS232 point-to-point).



**WARNING!** Switch off the drive before making the connections.

1. Opens the front cover of the drive.
2. Connect the [RS232 PC/Drive Serial Cable](#) to the X2 serial connector.
3. Plug DB9 connector directly into any one of the computer serial COM port. Use one of the available serial ports, since this information will be necessary later on SuperDrive G2 [Communication Setup](#) during operation.
4. Configure the communication parameters on the drive. The communication parameters are described in [Drive Parametrization](#).

## SSW-07

Figure below shows how to connect a computer to the drive (RS232 point-to-point).



**WARNING!** Switch off the drive before making the connections.

1. Take out the optional plug-in cover.
2. Replace the cover with the optional plug-in module. Make sure that the module is connected.
3. Insert the DB9 connector of the [RS232 Connection Cable](#) to the optional module (XC41 connector) and tighten the screws to fix the connector.
4. Plug DB9 connector directly into any one of the computer serial COM port. Use one of the

available serial ports, since this information will be necessary later on the SuperDrive G2 [Communication Setup](#) during operation.

5. Configure the communication parameters on the drive. The communication parameters are described in [Drive Parametrization](#).

## SSW-08



### WARNING!

Switch off the drive before making the connections.

1. Take out the optional plug-in cover.
2. Replace the cover with the optional plug-in module. Make sure that the module is connected.
3. Insert the DB9 connector of the [RS232 Connection Cable](#) to the optional module (XC41 connector) and tighten the screws to fix the connector.
4. Plug DB9 connector directly into any one of the computer serial COM port. Use one of the available serial ports, since this information will be necessary later on the SuperDrive G2 [Communication Setup](#) during operation.
5. Configure the communication parameters on the drive. The communication parameters are described in [Drive Parametrization](#).

## MW500



### WARNING!

Switch off the drive before making the connections.

1. Be sure that accessory RS232 Serial Interface Module is present and correctly connected to the drive.
2. Connect the DB9 connector from [RS232 Connection Cable](#) to the DB9 serial connector of RS232 Serial Interface Module.
3. Plug the another DB9 connector of cable directly into any one of the computer serial COM port. Use one of the available serial ports, since this information will be necessary later on the SuperDrive G2 [Communication Setup](#) during operation.
4. Configure the communication parameters on the drive. The communication parameters are described in [Drive Parametrization](#).

## CFW-09 PM



### WARNING!

Switch off the drive before making the connections.

1. Remove the keypad (HMI) from the inverter.
2. Install RS232 Serial Interface Module in place of the keypad.
3. Connect the [RS232 PC/Drive Serial Cable](#) to the XC7 serial connector.
4. Plug DB9 connector directly into any one of the computer serial COM port. Use one of the available serial ports, since this information will be necessary later on the SuperDrive G2 [Communication Setup](#) during operation.
5. Configure the communication parameters on the drive. The communication parameters are described in [Drive Parametrization](#).

## 8.5 RS485 Connection

The RS-485 standard (Recommended Standard 485) is a serial communication standard.

Based on differential signaling over a twisted pair, it is ideal for transmission at high speeds, over long distances and in environments prone to electromagnetic interference.


It allows communication between several elements (multipoint) on the same data network.

RS-485 is not a protocol, but simply an electrical interface.

The drive, which is the slave, must be located less than 1000 meters away from the computer (master).


### **CFW700 / CFW701**

Figure below shows how to connect a computer to the drive (RS485 point-to-point).



Device manager in Windows indicates which serial port is connected to the USB RS485 converter.

The computer name in device manager is purposely unreadable.



In SuperDrive G2, select the serial port correctly in Communication Setup window as follows.

Communication Setup

Connection Type:

USB  Serial  Bluetooth  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	0	ms	0	[0 ... 20000]
Time-out	100	ms	100	[100 ... 20000]

Serial:

Equipment: CFW700

Serial Port: COM6

Data Bits: 8

Stop Bits: 1

Parity: Even

Baud Rate: 19200

OK Cancel


**WARNING!**

Switch off the drive before making the connections.

1. Connect the type B connector of USB cable to the USB connector of the USB RS485 converter.
2. Connect the type A connector of USB cable to the computer usb port.
3. In device manager check which serial port is connected.
4. Check if in the SuperDrive G2 [Communication Setup](#) the selected connection type is serial.
5. The serial port in the window of communication setup window should be the same serial port that appears in the device manager, where the USB cable is connected.


**CFW500 / CFW501**

Figure below shows how to connect a computer to the drive (RS485 point-to-point).



Device manager in Windows indicates which serial port is connected to the USB RS485 converter.

The computer name in device manager is purposely unreadable.



In SuperDrive G2, select the serial port correctly in Communication Setup window as follows.

Communication Setup

Connection Type:

USB  Serial  Bluetooth  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	0	ms	0	[0 ... 20000]
Time-out	100	ms	100	[100 ... 20000]

Serial:

Equipment: CFW500

Serial Port: COM6

Data Bits: 8

Stop Bits: 1

Parity: Even

Baud Rate: 19200

OK Cancel


**WARNING!**

Switch off the drive before making the connections.


1. Connect the type B connector of USB cable to the USB connector of the USB RS485 converter.
2. Connect the type A connector of USB cable to the computer USB port.
3. In device manager check which serial port is connected.
4. Check if in the SuperDrive G2 [Communication Setup](#) the selected connection type is serial.
5. The serial port in the window of communication setup window should be the same serial port that appears in the device manager, where the USB cable is connected.

**CFW100**

Figure below shows how to connect a computer to the drive (RS485 point-to-point).



Device manager in Windows indicates which serial port is connected to the USB RS485 converter.  
 The computer name in device manager is purposely unreadable.



In SuperDrive G2, select the serial port correctly in Communication Setup window as follows.

Communication Setup

Connection Type:

USB  Serial  Bluetooth  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	0	ms	0	[0 ... 20000]
Time-out	100	ms	100	[100 ... 20000]

Serial:

Equipment: CFW100

Serial Port: COM6

Data Bits: 8

Stop Bits: 1

Parity: Even

Baud Rate: 19200

OK Cancel


**WARNING!**

Switch off the drive before making the connections.

1. Connect the type B connector of USB cable to the USB connector of the USB RS485 converter.
2. Connect the type A connector of USB cable to the computer USB port.
3. In device manager check which serial port is connected.
4. Check if in the SuperDrive G2 [Communication Setup](#) the selected connection type is serial.
5. The serial port in the window of communication setup window should be the same serial port that appears in the device manager, where the USB cable is connected.

**MW500**


Figure below shows how to connect a computer to the drive (RS485 point-to-point).



Device manager in Windows indicates which serial port is connected to the USB RS485

converter.

The computer name in device manager is purposely unreadable.



In SuperDrive G2, select the serial port correctly in Communication Setup window as follows.

Communication Setup

Connection Type:

USB  Serial  Bluetooth  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	0	ms	0	[0 ... 20000]
Time-out	100	ms	100	[100 ... 20000]

Serial:

Equipment: MW500

Serial Port: COM6

Data Bits: 8

Stop Bits: 1

Parity: Even

Baud Rate: 19200

OK Cancel


**WARNING!**

Switch off the drive before making the connections.

1. Connect the type B connector of USB cable to the USB connector of the USB RS485 converter.
2. Connect the type A connector of USB cable to the computer USB port.
3. In device manager check which serial port is connected.
4. Check if in the SuperDrive G2 [Communication Setup](#) the selected connection type is serial.
5. The serial port in the window of communication setup window should be the same serial port that appears in the device manager, where the USB cable is connected.


**ECW500**

Figure below shows how to connect a computer to the drive (RS485 point-to-point).



Device manager in Windows indicates which serial port is connected to the USB RS485 converter.

The computer name in device manager is purposely unreadable.



In SuperDrive G2, select the serial port correctly in Communication Setup window as follows.

Communication Setup

Connection Type:

USB  Serial  Bluetooth  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	0	ms	0	[0 ... 20000]
Time-out	100	ms	100	[100 ... 20000]

Serial:

Equipment: ECW500

Serial Port: COM6

Data Bits: 8

Stop Bits: 1

Parity: No Parity

Baud Rate: 38400

OK Cancel

**WARNING!**

Switch off the drive before making the connections.

1. Connect the type B connector of USB cable to the USB connector of the USB RS485 converter.
2. Connect the type A connector of USB cable to the computer USB port.
3. In device manager check which serial port is connected.
4. Check if in the SuperDrive G2 [Communication Setup](#) the selected connection type is serial.
5. The serial port in the window of communication setup window should be the same serial port that appears in the device manager, where the USB cable is connected.

## 8.6 Bluetooth Connection

Bluetooth is a global wireless and low-power-consumption communication standard that allows data exchange between devices over short distances.

The data exchange is done by means of radiofrequency, allowing a device to detect the other, regardless of their positions, as long as they are within a certain distance range.

The drive must be less than 1 m, 10 m or 100 m from the computer, depending on the Bluetooth technology available on your PC.

Class	Range
Class 1	Up to 100 m (330 ft)
Class 2	Up to 10 m (33 ft)
Class 3	Up to 1 m (3 ft)

However, the use of Bluetooth devices requires pairing for communication.

To pair devices is to establish a connection between two Bluetooth devices (in this case, between a computer and the driver).

## CFW100

The topics below present details on the use of the Bluetooth technology.

The steps presented in this chapter are valid for Windows 10.

For other operating systems (Windows 7 / 8 / 8.1), the steps are similar; see Windows help.

### Drive with CFW100-CBLT Accessory

Make sure the drive has the Bluetooth communication module called CFW100-CBLT.

Make sure the drive has parameters P310, P311 and P312 set to the factory default values.

If the computer does not have Bluetooth technology, use a [adaptador USB Bluetooth](#).

#### NOTA!

Once the Bluetooth is enabled on the computer, do not remove or replace the Bluetooth USB adapter during use.



For the proper operation of the CFW100 inverter with the CFW100-CBLT module, parameters P310, P311 and P312 must be set to the factory default values. During communication, the values of parameters P308, P310, P311 and P312 must not be changed. Otherwise, communication between the drive and the SuperDrive G2 will be lost.



## Módulo de Comunicação Bluetooth

Make sure the LED of the drive Bluetooth communication module is on (ACTIVE). That indicates the CFW100-CBLT module is active.

The CFW100-CBLT communication module has two LEDs that indicate the communication status:

**01** - Red LED (ACTIVE): indicates the CFW100-CBLT module is active.



**02** - Green LED (STATUS): indicates the serial communication service of the CFW100-CBLT module is active.

That means that, after the successful pairing, when the SuperDrive G2 starts communication with the CFW100 - for example, reading a drive parameter - the green LED turns on and will remain on even if no communication occurs between the drive and the SuperDrive G2. The LED will only turn off when the drive is turned off. When the drive is turned back on, the green LED remains off.



## PC with Active Bluetooth

Make sure the Bluetooth interface on the computer is turned on or the Bluetooth USB adapter is connected to the PC and working. The Bluetooth logo will appear on Windows taskbar.




The Bluetooth status on the PC can also be checked on Windows Settings window.


**01** - One of the ways to view the settings is described below.

1. Press the key WIN + R,
2. Type ms-settings:bluetooth
3. Press OK
4. The Bluetooth settings window will open and you can check if the Bluetooth is active.

The window below illustrates the operation.



The blue button below indicates the Bluetooth is active on the computer.



**02** - A second way to view the settings is described below.

Windows Start Menu > Settings > Devices > Bluetooth & other devices = check if the Bluetooth status is active.

### CONNECT THE COMPUTER TO THE DRIVE VIA BLUETOOTH

Only two steps are necessary to prepare the environment to use the Bluetooth:

**01** - First, it is necessary to pair Windows with the drive (see item **Pairing Windows with the Drive**),

**02** - Then you should configure the SuperDrive G2 for Bluetooth communication (see item **Configuring the Bluetooth Communication on the SuperDrive G2**).


After those two steps, the SuperDrive G2 will be ready to communicate with the drive via Bluetooth.

#### Pairing Window with the Drive


At the first use, Windows requests the execution of some additional steps as follows.

**01** - Turn on the CFW100 (with Bluetooth) and make it discoverable.

**02** - Click Windows Start Menu button on the left corner of the screen. After that, select the Settings icon.




**03** - On the Settings window, clique on Devices.




**04** - The Devices window pops up. On the left menu of such window, select Bluetooth & other devices.

Make sure the Bluetooth technology is activated in Windows (Bluetooth button ON).




**05** - Click on the Add Bluetooth or other device button.




**06** - The Add a device window pops up.



**07** - Click on the Bluetooth button.




**08** - At this moment, Windows starts looking for Bluetooth devices.



**09** - Windows shows the device found on the screen. In this case, a CFW100 was found. The code shown is the content of parameter 770 (P770 = 7367).

Click on the device found.

**NOTA!**


Always use a unique code (content of P770) for each drive.

**10** - Some Bluetooth devices require authentication before pairing.


The CFW100 is a device that requires authentication. A message will be displayed on the window with a code generated by Windows.

Always accept that code (it may be a different number from the one shown below).


Click the Connect button to continue.




**11** - At this moment, Windows executes the pairing and shows a message saying that the device is ready to go.



**12** - A Windows notification usually pops up saying the device is ready. That notification disappears automatically.




**13** - Also on the Devices window, with the Bluetooth & other devices selected (menu on the left of the window), the paired device (CFW100) appears on the paired device list as shown below.




### Configuring the Bluetooth Communication on the SuperDrive G2

On the SuperDrive G2, it is necessary to configure the same output serial COM port that Windows reserved for Bluetooth. See the steps below.

- 01** - Open the Windows Bluetooth settings window (**Bluetooth & other devices**).




**02** - Move the scroll bar to find the link **More Bluetooth options**. Click on that link.



**03** - Windows **Bluetooth Settings** window pops up. Select the **COM Ports** tab.


For each Bluetooth device, 2 COM ports are used. Check which is the output COM port (Output Direction).

In this example, the output COM4 port will be used in the configuration of the SuperDrive G2.



**04** - In the Windows device manager, you can also see the serial ports used by the Bluetooth interface.

In this example, the ports are COM4 and COM5.



**05** - On the SuperDrive G2, Communication Setup window, select the connection type (Bluetooth).

Communication Setup

Connection Type:

USB  Serial  Bluetooth  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	50	ms	50	[50 ... 20000]
Time-out	1000	ms	1000	[1000 ... 20000]

Bluetooth:

Equipment	User Setting
Serial Port	COM6
Data Bits	8
Stop Bits	1
Parity	Even
Baud Rate	19200

Note: For the proper operation of the CFW100 inverter with the CFW100-CBLT module, parameters P310, P311 and P312 must be set with the factory default values.

For further details refer to the CFW100 programming manual version V2.0X or above.

OK Cancel

**06** - On this window, you can see the fields:

- Transmission delay,
- Response delay,
- Time out and
- Data on the serial port (read only) used by the Bluetooth.

You must set the device, serial port, data bits, stop bits, parity and baud rate of the serial port selected for Bluetooth.

In order to do that, click on the field of the current equipment (in this example **User Setting**) or the **Serial** radio button.

**07** - On the RS232 serial communication window, set the equipment and the serial port as previously observed in the Bluetooth settings.

The other fields should also be set (data bits, stop bits, parity and baud rate).

In this example, the output port is COM4.

Communication Setup ✕

Connection Type:

USB
  Serial
  Bluetooth
  Ethernet


Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	0	ms	0	[0 ... 20000]
Time-out	100	ms	100	[100 ... 20000]

Serial:

Equipment	CFW 100	▼
Serial Port	COM4	▼
Data Bits	8	▼
Stop Bits	1	▼
Parity	Even	▼
Baud Rate	19200	▼

**08** - Return to the Bluetooth interface on this window. Check if the port used by the Bluetooth is the same as the one previously selected in the RS232 serial interface.




**09** - Now the SuperDrive G2 is ready to communicate with the CFW100 via Bluetooth.


### Removing a Bluetooth Device from Windows (Unpair)

Below are the steps to remove a Bluetooth device from Windows.

**01** - Click on the Windows Start Menu button on the left corner of the screen. After that, select the Settings icon.




**02** - On the Settings window, click on Devices.




**03** - The Devices window pops up. On the left menu of such window, select Bluetooth & other devices.

The list of paired devices is displayed on the right side of the window.




**04** - Select and click the paired device. A Remove button is enabled.


Click on the Remove device button.



**05** - A message prompts the confirmation to remove it. Click on Yes.



**06** - At this moment, Windows removes the device, and it is erased from the window.



## ERRORS

**01** - If a pairing error between Windows and the drive occurred, check the following items:

- Check if there are obstacles between the drive and the computer;
- Check if the drive is not too far away from the PC;
- Check if there is another PC with Bluetooth enabled which is trying to connect to the same drive.

## 8.7 Ethernet Connection

Ethernet is an interconnection technology for local networks - Local Area Network (LAN) - based on the transmission of packages. It defines the electric signals for the physical layer, in addition to the package format and protocols for the Media Access Control (MAC) of the OSI model.

Ethernet, however, mainly defines the media and package format. Based on Ethernet, several higher level protocols and services were specified and developed so as to allow the execution of the desired tasks via network, such as package routing, establishment of connection, file transmission and reception, etc. Several of those protocols were also widely spread and used, such as IP, TCP, UDP, FTP and HTTP.

Widely used to interconnect computers in offices, the Ethernet technology also started to be employed in industrial environments to interconnect field equipment. For the industrial

environment, different communication protocols were created based on Ethernet, for instance, Modbus TCP, EtherNet/IP and PROFINET.

Click on the link to go directly to the products: [CFW-11](#) [CFW500 / MW500](#) [SCA-06](#)

### CFW-11

The CFW-11 frequency inverter offers the Anybus-CC communication modules as accessory items.

In order to use the SuperDrive G2 with the CFW-11 on Ethernet, an Anybus-CC accessory must be connected to the drive according to the protocol used:

Protocol	Accessory	Image	Description
EtherNet/IP	ETHERNETIP-05		1 Ethernet port
EtherNet/IP	ETHERNET-2P-05		2 Ethernet ports with built-in switch
Modbus TCP	MODBUSTCP-05		1 Ethernet port
PROFINET IO	PROFINETIO-05		2 Ethernet ports with built-in switch

For further details on the specific characteristics and functionalities of the protocols, refer to the Anybus-CC user's manual of the CFW-11.

#### Example 01 Configuration Using Peer-to-Peer Modbus TCP Protocol - CFW-11

- 01** - Install the MODBUSTCP-05 accessory on the CFW-11.



For further information, refer to the Anybus-CC installation guide of the CFW-11.

**02** - View the parameter below (read only), which allows identifying the Ethernet module type connected to the equipment.

Parameter	Description	Adjustable Range	Value
P0723	Anybus ID	0 = Inactive ... 21 = Modbus TCP ... 25 = Reserved	21 = Modbus TCP

**03** - View/set the parameters below.

Parameter	Description	Adjustable Range	Value
P0841	Baud Rate	0 = Auto 1 = 10 Mbps, half duplex 2 = 10 Mbps, full duplex 3 = 100 Mbps, half duplex 4 = 100 Mbps, full duplex	0 = Auto
P0842	Time-out Modbus TCP	0 ... 655	0
P0843	IP Address Configuration	0 = Parameters 1 = DHCP 2 = DCP 3 = IPconfig	0 = Parameters
P0844	IP1 Address	0 ... 255	192
P0845	IP2 Address	0 ... 255	168
P0846	IP3 Address	0 ... 255	0
P0847	IP4 Address	0 ... 255	10

**04** - Once the parameters are set, it is necessary to restart the equipment.


It informs the communication module status:

Parameter	Description	Adjustable Range	Value
P0724	Anybus Communicatin Status	0 = Disable 1 = Not Supported 2 = Access Error 3 = Offline 4 = Online	4 = Online


**05** - Configure the Ethernet network in Windows operating system; follow the directions of items 05.01 ... 05.08.

**NOTA!**  
 If the computer does not have an Ethernet port, it is necessary to use an Ethernet network adapter. For further details, see the topic [Ethernet Network Adapter](#).


**05.01** - Open the control panel.




**05.02** - Select Network and Sharing Center.




**05.03** - Select the Unidentified network (Public network) by clicking according to the figure. In this case, the link is Ethernet 4.



**05.04** - The network status is displayed. Click on the Properties button.



**05.05** - The Properties window pops up. Select Internet Protocol Version 4 (TCP/IPv4) and click on the Properties button.



**05.06** - The IPV4 Properties window is shown without any addresses configured.


The image shows a screenshot of the "Internet Protocol Version 4 (TCP/IPv4) Properties" dialog box. The "Alternate Configuration" tab is selected. The dialog contains the following elements:

- General tab (selected)
- Alternate Configuration tab
- Text: "You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings."
- Radio button:  Obtain an IP address automatically:
- Radio button:  Use the following IP address:
- Form fields for "Use the following IP address":
  - IP address: [ . . . ]
  - Subnet mask: [ . . . ]
  - Default gateway: [ . . . ]
- Radio button:  Obtain DNS server address automatically
- Radio button:  Use the following DNS server addresses:
- Form fields for "Use the following DNS server addresses":
  - Preferred DNS server: [ . . . ]
  - Alternate DNS server: [ . . . ]
- Checkbox:  Validate settings upon exit
- Button: Advanced...
- Buttons: OK, Cancel

**05.07** - Select the Use the following IP address option.

Fill out the fields with the addresses as follows.

Click on the OK button to end the task.



**05.08** - At this moment, the Ethernet network is properly configured in Windows operating system.

**06** - In SuperDrive G2, configure the Ethernet connection in the Communication Setup window.

A time-out above 5000 ms is recommended. Lower values may produce faults during communication.

Set the IP Address, Port and Unit ID fields as follows.

Communication Setup

Connection Type:

USB
  Serial
  Bluetooth
  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	0	ms	0	[0 ... 20000]
Time-out	5000	ms	5000	[5000 ... 20000]

Ethernet:

Field	Value	Default	Range
IP Address	192.168.0.10	192.168.0.10	XXXX.XXXX.XXXX.XXXX
Port	502	502	1 ... 65535
Unit ID	255	255	1 ... 255

OK Cancel

**07** - Now, communication between the drive and computer is possible.

**Example 02 Configuration Using Peer-to-Peer EtherNet/IP Protocol - CFW-11**

**01** - Install the ETHERNETIP-05 accessory on the CFW-11.



For further information, refer to the Anybus-CC installation guide of the CFW-11.

**02** - View the parameter below (read only), which allows identifying the Ethernet module type connected to the equipment.

Parameter	Description	Adjustable Range	Value
P0723	Anybus ID	0 = Inactive ... 19 = EtherNet/IP ... 25 = Reserved	19 = EtherNet/IP

**03** - Visualize/ajuste os parâmetros abaixo.

Parameter	Description	Adjustable Range	Value
P0841	Baud Rate	0 = Auto 1 = 10 Mbps, half duplex 2 = 10 Mbps, full duplex 3 = 100 Mbps, half duplex 4 = 100 Mbps, full duplex	0 = Auto
P0842	Time-out Modbus TCP	0 ... 655	No Used
P0843	IP Address Configuration	0 = Parameters 1 = DHCP 2 = DCP 3 = IPconfig	0 = Parameters
P0844	IP1 Address	0 ... 255	192
P0845	IP2 Address	0 ... 255	168
P0846	IP3 Address	0 ... 255	0
P0847	IP4 Address	0 ... 255	10

**04** - Once the parameters are set, it is necessary to restart the equipment.

It informs the communication module status:

Parameter	Description	Adjustable Range	Value
P0724	Anybus Communicatin Status	0 = Disable 1 = Not Supported 2 = Access Error 3 = Offline 4 = Online	4 = Online

**05** - The following steps are the same as those used in **Example 01** of the CFW-11.

**Example 03 Configuration Using Peer-to-Peer PROFINET Protocol - CFW-11**

**01** - Install the PROFINETIO-05 accessory on the CFW-11.



For further information, refer to the Anybus-CC installation guide of the CFW-11.

**02** - View the parameter below (read only), which allows identifying the Ethernet module type connected to the equipment.

Parameter	Description	Adjustable Range	Value
P0723	Anybus ID	0 = Inactive ... 23 = PROFINET IO ... 25 = Reserved	23 = PROFINET IO

**03** - View/set the parameters below.

Parameter	Description	Adjustable Range	Value
P0841	Baud Rate	0 = Auto 1 = 10 Mbps, half duplex 2 = 10 Mbps, full duplex 3 = 100 Mbps, half duplex 4 = 100 Mbps, full duplex	0 = Auto
P0842	Time-out Modbus TCP	0 ... 655	Not Used
P0843	IP Address Configuration	0 = Parameters 1 = DHCP 2 = DCP 3 = IPconfig	0 = Parameters
P0844	IP1 Address	0 ... 255	192
P0845	IP2 Address	0 ... 255	168
P0846	IP3 Address	0 ... 255	0
P0847	IP4 Address	0 ... 255	10

**04** - Once the parameters are set, it is necessary to restart the equipment.

It informs the communication module status:

Parameter	Description	Adjustable Range	Value
P0724	Anybus Communicatin Status	0 = Disable 1 = Not Supported 2 = Access Error 3 = Offline 4 = Online	4 = Online

**05** - The following steps are the same as those used in **Example 01** of the CFW-11.

## CFW500 / MW500

In order to use the Ethernet network, it is necessary to install the proper accessory.


There are three different plug-in modules, according to the specified communication protocol:

Protocolo	Accessory	Image	Description
Modbus TCP	CFW500-CEMB-TCP		1 Ethernet port
EtherNet/IP	CFW500-CETH-IP		1 Ethernet port
PROFINET IO	CFW500-CEPN-IO		1 Ethernet port

For further details on the specific characteristics and functionalities of the protocols, refer to the Ethernet user's manual of the CFW500.

### Example 01 Configuration Using Peer-to-Peer Modbus TCP Protocol - CFW500

**01** - Install the CFW500-CEMB-TCP accessory on the CFW500.



For further information, refer to the installation guide of the corresponding accessory.

**02** - View the parameter below (read only), which allows identifying the Ethernet module type connected to the equipment.

Parameter	Description	Adjustable Range	Value
P0800	Ethernet module identification	0 = Unidentified 1 = Modbus TCP 2 = EtherNet/IP 3 = PROFINET IO	1 = Modbus TCP

**03** - View/set the parameters below.

Parameter	Description	Adjustable Range	Value
P0803	Ethernet Baud Rate	0 = Auto 1 = 10Mbit/s, half duplex 2 = 10Mbit/s, full duplex 3 = 100Mbit/s, half duplex 4 = 100Mbit/s, full duplex	0 = Auto
P0806	Watchdog Modbus TCP	0,0 ... 65,5 s	0,0
P0810	IP Address Configuration	0 = Parameters 1 = DHCP	0 = Parameters
P0811	IP1 Address	0 ... 255	192
P0812	IP2 Address	0 ... 255	168
P0813	IP3 Address	0 ... 255	0
P0814	IP4 Address	0 ... 255	10


**04** - Once the parameters are set, it is necessary to restart the equipment.

**05** - Configure the Ethernet network in Windows operating system; follow the directions of items 05.01 ... 05.08.


**NOTA!**

 If the computer does not have an Ethernet port, it is necessary to use an Ethernet network adapter. For further details, see the topic [Ethernet Network Adapter](#).


**05.01** - Open the control panel.




**05.02** - Select Network and Sharing Center.




**05.03** - Select the Unidentified network (Public network) by clicking according to the figure. In this case the link is Ethernet 4.



**05.04** - The network status is displayed. Click on the Properties button.



**05.05** - The Properties window pops up. Select Internet Protocol Version 4 (TCP/IPv4) and click on the Properties button.



**05.06** - The IPV4 Properties window is shown without any addresses configured.


The image shows a screenshot of the "Internet Protocol Version 4 (TCP/IPv4) Properties" dialog box. The "Alternate Configuration" tab is selected. The dialog contains the following elements:

- General tab (selected)
- Alternate Configuration tab
- Text: "You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings."
- Radio button:  Obtain an IP address automatically:
- Radio button:  Use the following IP address:
  - IP address: [ . . . ]
  - Subnet mask: [ . . . ]
  - Default gateway: [ . . . ]
- Radio button:  Obtain DNS server address automatically
- Radio button:  Use the following DNS server addresses:
  - Preferred DNS server: [ . . . ]
  - Alternate DNS server: [ . . . ]
- Checkbox:  Validate settings upon exit
- Button: Advanced...
- Buttons: OK, Cancel

**05.07** - Select the Use the following IP address option.

Fill out the fields with the addresses indicated below.

Click the OK button to end the task.



**05.08** - At this moment, the Ethernet network is properly configured in Windows operating system.

**06** - In SuperDrive G2, configure the Ethernet connection in the Communication Setup window.

A time-out above 5000 ms is recommended. Lower values may produce faults during communication.

Set the IP Address, Port and Unit ID fields as follows.

Communication Setup

Connection Type:

USB
  Serial
  Bluetooth
  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	0	ms	0	[0 ... 20000]
Time-out	5000	ms	5000	[5000 ... 20000]

Ethernet:


Field	Value	Default	Range
IP Address	192.168.0.10	192.168.0.10	XXXX.XXXX.XXXX.XXXX
Port	502	502	1 ... 65535
Unit ID	255	255	1 ... 255

OK Cancel

**07** - Now, communication between the drive and computer is possible.

**Example 02 Configuration Using Peer-to-Peer EtherNet/IP Protocol - CFW500**

**01** - Install the CFW500-CETH-IP accessory on the CFW500.



For further information, refer to the installation guide of the corresponding accessory.

**02** - View the parameter below (read only), which allows identifying the Ethernet module type connected to the equipment.

Parameter	Description	Adjustable Range	Value
P0800	Ethernet module identification	0 = Unidentified 1 = Modbus TCP 2 = EtherNet/IP 3 = PROFINET IO	2 = EtherNet/IP

**03** - View/set the parameters below.

Parameter	Description	Adjustable Range	Value
P0803	Baud Rate Ethernet	0 = Auto 1 = 10Mbit/s, half duplex 2 = 10Mbit/s, full duplex 3 = 100Mbit/s, half duplex 4 = 100Mbit/s, full duplex	0 = Auto
P0806	Watchdog Modbus TCP	0,0 ... 65,5 s	0,0
P0810	IP Address Configuration	0 = Parameters 1 = DHCP	0 = Parameters
P0811	IP1 Address	0 ... 255	192
P0812	IP2 Address	0 ... 255	168
P0813	IP3 Address	0 ... 255	0
P0814	IP4 Address	0 ... 255	10


**04** - Once the parameters are set, it is necessary to restart the equipment.

**05** - The following steps are the same as those used in **Example 01** of the CFW500.

---

**Example 03 Configuration Using Peer-to-Peer PROFINET IO Protocol - CFW500**

**01** - Install the CFW500-CEPN-IO accessory on the CFW500.



For further information, refer to the installation guide of the corresponding accessory.

**02** - View the parameter below (read only), which allows identifying the Ethernet module type connected to the equipment.

Parameter	Description	Adjustable Range	Value
P0800	Ethernet module identification	0 = Unidentified 1 = Modbus TCP 2 = EtherNet/IP 3 = PROFINET IO	3 = PROFINET IO

**03** - View/set the parameters below.

Parameter	Description	Adjustable Range	Value
P0803	Ethernet Baud Rate	0 = Auto 1 = 10Mbit/s, half duplex 2 = 10Mbit/s, full duplex 3 = 100Mbit/s, half duplex 4 = 100Mbit/s, full duplex	0 = Auto
P0806	Watchdog Modbus TCP	0,0 ... 65,5 s	0,0
P0810	IP Address Configuration	0 = Parameters 1 = DHCP	0 = Parameters
P0811	IP1 Address	0 ... 255	192
P0812	IP2 Address	0 ... 255	168
P0813	IP3 Address	0 ... 255	0
P0814	IP4 Address	0 ... 255	10

**04** - Once the parameters are set, it is necessary to restart the equipment.

**05** - The following steps are the same as those used in [Example 01](#) of the CFW500.

## SCA-06

The SCA-06 servo drive has the ECO5, ECO6 and ECO7 communication modules as accessory items.

In order to use the SuperDrive G2 with SCA-06 on Ethernet, an accessory must be connected to the drive according to the protocol used:

Protocol	Accessory	Image	Description
EtherNet/IP	ECO5		2 Ethernet ports
Modbus TCP	ECO6		2 Ethernet ports
PROFINET IO	ECO7		2 Ethernet ports

For further details on the specific characteristics and functionalities of the protocols, refer to the Ethernet communication manual of the SCA-06.

### Example 01 Configuration Using Peer-to-Peer Modbus TCP Protocol - SCA-06

**01** - Install the ECO06 accessory on the SCA-06.



For further information, refer to the Installation, Configuration and Operation Guide of the ECO6 accessory of the SCA-06.

**02** - View the parameter below (read only), which allows identifying the Ethernet module type connected to the equipment.

Parameter	Description	Adjustable Range	Value
P0800	Ethernet Module Identification	0 = Unidentified 1 = Modbus TCP 2 = EtherNet/IP 3 = PROFINET IO	1 = Modbus TCP

**03** - View/set the parameters below.


Parameter	Description	Adjustable Range	Value
P0803	Ethernet Baud Rate	0 = Auto 1 = 10Mbit/s, half duplex 2 = 10Mbit/s, full duplex 3 = 100Mbit/s, half duplex 4 = 100Mbit/s, full duplex	0 = Auto
P0806	Watchdog Modbus TCP	0,0 ... 65,5 s	0,0
P0810	IP Address Configuration	0 = Parameters 1 = DHCP	0 = Parameters
P0811	IP1 Address	0 ... 255	192
P0812	IP2 Address	0 ... 255	168
P0813	IP3 Address	0 ... 255	0
P0814	IP4 Address	0 ... 255	10

**04** - Once the parameters are set, it is necessary to restart the equipment.


**05** - Configure the Ethernet network in Windows operating system; follow the directions of items 05.01 ... 05.08.

**NOTA!**  If the computer does not have an Ethernet port, it is necessary to use an Ethernet network adapter. For further details, see the topic [Ethernet Network Adapter](#).


**05.01** - Open the control panel.




**05.02** - Select Network and Sharing Center.




**05.03** - Select the Unidentified network (Public network) by clicking according to the figure. In this case the link is Ethernet 4.




**05.04** - The network status is displayed. Click on the Property button.



**05.05** - The Properties window pops up. Select Internet Protocol Version 4 (TCP/IPv4) and click on the Properties button.



**05.06** - The IPV4 Properties window is shown without any addresses configured.




The image shows a screenshot of the "Internet Protocol Version 4 (TCP/IPv4) Properties" dialog box. The "Alternate Configuration" tab is selected. The dialog contains the following elements:

- General tab (selected)
- Alternate Configuration tab
- Text: "You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings."
- Radio button:  Obtain an IP address automatically:
- Radio button:  Use the following IP address:
- Form fields for "Use the following IP address":
  - IP address: [ . . . ]
  - Subnet mask: [ . . . ]
  - Default gateway: [ . . . ]
- Radio button:  Obtain DNS server address automatically
- Radio button:  Use the following DNS server addresses:
- Form fields for "Use the following DNS server addresses":
  - Preferred DNS server: [ . . . ]
  - Alternate DNS server: [ . . . ]
- Checkbox:  Validate settings upon exit
- Button: Advanced...
- Buttons: OK, Cancel

**05.07** - Select the **Use the following IP address** option.

Fill out the fields with the addresses indicated below.

Click the **OK** button to end the task.



**05.08** - At this moment, the Ethernet network is properly configured in Windows operating system.

**06** - In SuperDrive G2, configure the Ethernet connection in the Communication Setup window.

A time-out above 5000 ms is recommended. Lower values may produce faults during communication.

Set the IP Address, Port and Unit ID fields as follows.

Communication Setup

Connection Type:

USB
  Serial
  Bluetooth
  Ethernet

Timing:

Field	Value	Unit	Default	Range
Transmission Delay	0	ms	0	[0 ... 20000]
Response Delay	0	ms	0	[0 ... 20000]
Time-out	5000	ms	5000	[5000 ... 20000]

Ethernet:

Field	Value	Default	Range
IP Address	192.168.0.10	192.168.0.10	XXXX.XXXX.XXXX.XXXX
Port	502	502	1 ... 65535
Unit ID	255	255	1 ... 255

OK Cancel

**07** - Now, communication between the drive and computer is possible.

**Example 02 Configuration Using Peer-to-Peer EtherNet/IP Protocol - SCA-06**

**01** - Install the ECO05 accessory on the SCA-06.



For further information, refer to the Installation, Configuration and Operation Guide of the ECO5

accessory of the SCA-06.

**02** - View the parameter below (read only), which allows identifying the Ethernet module type connected to the equipment.

Parameter	Description	Adjustable Range	Value
P0800	Ethernet Module Identification	0 = Unidentified 1 = Modbus TCP 2 = EtherNet/IP 3 = PROFINET IO	2 = EtherNet/IP

**03** - View/set the parameters below.

Parameter	Description	Adjustable Range	Value
P0803	Ethernet Baud Rate	0 = Auto 1 = 10Mbit/s, half duplex 2 = 10Mbit/s, full duplex 3 = 100Mbit/s, half duplex 4 = 100Mbit/s, full duplex	0 = Auto
P0806	Watchdog Modbus TCP	0,0 ... 65,5 s	0,0
P0810	IP Address Configuration	0 = Parameters 1 = DHCP	0 = Parameters
P0811	IP1 Address	0 ... 255	192
P0812	IP2 Address	0 ... 255	168
P0813	IP3 Address	0 ... 255	0
P0814	IP4 Address	0 ... 255	10

**04** - Once the parameters are set, it is necessary to restart the equipment.

**05** - The following steps are the same as those used in **Example 01** of the SCA-06.

**Example 03 Configuration Using Peer-to-Peer PROFINET IO Protocol - SCA-06**

**01** - Install the ECO07 accessory on the SCA-06.



For further information, refer to the Installation, Configuration and Operation Guide of the ECO7 accessory of the SCA-06.

**02** - View the parameter below (read only), which allows identifying the Ethernet module type connected to the equipment.

Parameter	Description	Adjustable Range	Value
P0800	Ethernet Module Identification	0 = Unidentified 1 = Modbus TCP 2 = EtherNet/IP 3 = PROFINET IO	3 = PROFINET IO

**03** - View/set the parameters below.

Parameter	Description	Adjustable Range	Value
P0803	Ethernet Baud Rate	0 = Auto 1 = 10Mbit/s, half duplex 2 = 10Mbit/s, full duplex 3 = 100Mbit/s, half duplex 4 = 100Mbit/s, full duplex	0 = Auto
P0806	Watchdog Modbus TCP	0,0 ... 65,5 s	0,0
P0810	IP Address Configuration	0 = Parameters 1 = DHCP	0 = Parameters
P0811	IP1 Address	0 ... 255	192
P0812	IP2 Address	0 ... 255	168
P0813	IP3 Address	0 ... 255	0
P0814	IP4 Address	0 ... 255	10

**04** - Once the parameters are set, it is necessary to restart the equipment.


**05** - The following steps are the same as those used in **Example 01** of the SCA-06.

## 8.8 RS232 Cable

### RS232 PC/DRIVE SERIAL CABLE

Drive: CFW-09 PM, SSW-06

Figure below shows the cable parts for point-to-point RS232 connection. Only pins 2, 3 and 5 of the DB9 female connector are used.




Maximum cable length: 10 meters.

### RS232 CONNECTION CABLE

Drive: SSW-07, SSW-08

Figure below shows the cable parts for point-to-point RS232 connection. Only pins 2, 3 and 5 of the DB9 female connector are used.



Maximum cable length: 10 meters.

## 8.9 USB Cable

### USB CABLE

Drive: CFW-11, SCA-06, SSW7000, CTW900

Figure below shows the cable parts for point-to-point USB connection.





Figure below shows the connectors.



A = Type A connector  
 B = Type B connector

Maximum cable length: 3 meters.

Always use a standard host/device shielded USB cable. Unshielded cables may lead to communication errors.

The USB connection is galvanically isolated from the mains power supply and from other high voltages internal to the inverter. However, the USB connection is not isolated from the Protective Ground (PE). Use an isolated computer for the USB connection or a desktop connected to the same Protective Ground (PE) of the inverter.

**Purchase Suggestions**

Manufacturer:

- Samtec, Inc: <http://www.samtec.com/>

If you want to buy USB cable directly from Samtec, please see below.

Description	Item
USB shielded High Speed Cable, 1 m, Samtec	USBC-AM-MB-B-B-S-1
USB shielded High Speed Cable, 2 m, Samtec	USBC-AM-MB-B-B-S-2
USB shielded High Speed Cable, 3 m, Samtec	USBC-AM-MB-B-B-S-3

At the time this help was being written, the specification was found at <http://www.samtec.com/ftppub/cpdf/USBC-AM-BM-B-B-S-X-MKT.pdf>

**USB CABLE (mini-B)**

Drive: CFW100, CFW700, CFW701

Figure below shows the cable parts for point-to-point USB connection.




Figure below shows the connectors.



A = Type A connector  
 B = Type mini-B connector

Maximum cable length: 3 meters.

Always use a standard host/device shielded USB cable. Unshielded cables may lead to communication errors.

The USB connection is galvanically isolated from the mains power supply and from other high voltages internal to the inverter. However, the USB connection is not isolated from the Protective Ground (PE). Use an isolated computer for the USB connection or a desktop connected to the same Protective Ground (PE) of the inverter.

**Purchase Suggestions**

Manufacturer:

- Samtec, Inc: <http://www.samtec.com/>

If you want to buy USB cable directly from Samtec, please see below.

Description	Item
USB shielded High Speed Cable, 1 m, Samtec	USBC-AM-BM-B-B-S-1
USB shielded High Speed Cable, 2 m, Samtec	USBC-AM-BM-B-B-S-2
USB shielded High Speed Cable, 3 m, Samtec	USBC-AM-BM-B-B-S-3

At the time this help was being written, the specification was found at <http://www.samtec.com/ftppub/cpdf/USBC-AM-MB-B-B-S-X-X-MKT.pdf>

## 8.10 Ethernet Cable

This cable is used to connect the SuperDrive G2 to the Ethernet drive.

This cable has RJ45 connectors at both ends.

The figure below shows an example of this cable.



## 8.11 USB to Serial Adapter

The USB to serial adapter is the best solution for the connection of serial equipment (RS232) to USB ports, i. e., for connecting computer USB output to a RS232 serial equipment.

This is a low cost solution and meets the install requirements of new computer serial ports that have busy bus bars or equipments that are not fitted with RS232 ports.

The USB to serial adapter allows the plug & play connection with your computer, thus maintaining free the existing serial port.

Figures below show a sample of this adapter.

### PURCHASE SUGGESTIONS

**Manufacturer: Comm5 Tecnologia**

Product	Conversor de USB para 1 saída serial RS232
Model	1S-USB - conversor USB para 1 serial
Web Site	<a href="https://www.comm5.com.br/produtos/conversor-usb/1s-usb/">https://www.comm5.com.br/produtos/conversor-usb/1s-usb/</a>

For further information about product installation, please refer to user's manual.



**Manufacturer: Tripp Lite**

Product	High-Speed USB-to-Serial Adapter
Model	USA-19HS
Web Site	<a href="http://www.tripplite.com/keyspan-high-speed-usb-to-serial-adapter~USA19HS/">http://www.tripplite.com/keyspan-high-speed-usb-to-serial-adapter~USA19HS/</a>

For further information about product installation, please refer to user's manual.



### 8.12 Bluetooth USB Adapter

Drive: CFW100

The image below shows an USB Bluetooth adapter (a.k.a. dongle) which should be connected to the USB port of computer. There are several models with different features.



### 8.13 Ethernet Network Adapter

The Ethernet network adapter is an adapter that allows connecting a computer with a USB port to a device using the Ethernet.

This adapter is usually light, easy to use and very practical.

The adapter features a USB port type A at one end and a RJ-45 port at the other, being a standard fitting for a variety of compatible devices.

This adapter eliminates the use of other cables or adapters.

Also, no external power supplies are necessary.

The figure below shows an example of an Ethernet network adapter.




#### Example of Connection Using an Ethernet Network Adapter

**01** - Connect the Ethernet network adapter (USB connector to RJ45 connector) to the computer.

The adapter USB port (type A connector) is connected to the computer USB port.

Then, connect the drive (equipment) Ethernet cable to the network adapter.


The simplified figure below shows the connection of the drive to the computer using an Ethernet cable and Ethernet network adapter.



**02** - Check the Windows device manager.

Notice that Windows operating system recognized the hardware.

In this example, the adapter is shown as Realtek USB FE Family Controller



**03** - Device Not Recognized.

In case Windows operating system does not recognize the device (Ethernet network adapter), the adapter drive, supplied by the manufacturer, must be installed.

After the driver installation, Windows recognizes the device.

## 8.14 Before Trying to Establish Communication

Before trying to establish communication make sure the following has been done:

- Communication cable connected to the drive;
- Communication cable connected to computer;
- Drive is powered up;
- Communication parameters on the drive correspond to SuperDrive G2 communication settings.

## 8.15 Exception During Monitoring

### **SOFT-STARTER**

#### **SSW-06 V1.3X**

- P014 to P017 = 13107 => this means there is no fault.

#### **SSW-07 and SSW-08**

- P219 defines parametrization mode for the following parameters: P101, P102, P104, P110, P202, P206, P401, P520, P521, P611, P613, P617, P620 and P640;
- On Trimpot and Dip Switch Mode, the parametrization of the above parameters is done through the Trimpots and Dip Switches. These parameters act like read only parameters, showing the Trimpots and Dip Switches programmed values. The values which were programmed through RS232 serial communication are not used;
- On Keypad Mode, the parametrization of parameters previously cited is made with RS232 serial communication or Keypad. The value adjusted with Trimpots and Dip Switch are not used.

## 9 Context menus

Contents of this chapter:

[Rename](#)

[Save As](#)

[Close](#)

### 9.1 Project

#### ACCESS


Toolbar: none  
Context Menu  
Shortcut Key: none

#### FUNCTION

Allows the user to select options related to current project.

#### DESCRIPTION

The options are available through a context menu. To access them, select the current project name and then right mouse click over it:



SuperDrive G2 offers three options via context menu:

- [Rename](#)
- [Save As](#)
- [Close](#)

#### 9.1.1 Rename

#### ACCESS


Toolbar: none  
Context Menu > Rename project  
Shortcut Key: none

## FUNCTION

Allows the user to rename current project.

## DESCRIPTION

This option is available through a context menu. To access it, right mouse click over the current project name:



A dialog box is shown, asking for a new project name.

Case the new name already exists, system adds automatically an unique code to the end of name was typed.

### 9.1.2 Save As

## ACCESS

Toolbar: 

Context Menu > Save As

Shortcut Key: Ctrl+D

## FUNCTION

Saves a project with different name.

## DESCRIPTION

Enabled when a project is created or opened.

When Save As function runs, a dialog is shown with the following information:

- Name - type a name for the new project. If the specified name is invalid or already exists, a warning message will be prompted.
- Location - a default location is shown, but can be changed.
- Folder - view only.
- Description - type the project description. It can be changed later in the [Project Information](#).

### 9.1.3 Close

#### ACCESS

Toolbar:   
Context Menu > Close  
Shortcut Key: none

#### FUNCTION

Closes the project.

#### DESCRIPTION

If the project contains unsaved data, a save request dialog will be shown.

## 10 Libraries

Contents of this chapter:

[JFreeChart](#)

[jSSC](#)

### 10.1 JFreeChart

This software incorporates JFreeChart, © 2005-2012 Object Refinery Limited.

The JFreeChart home page can be found at: <http://www.jfree.org/jfreechart/>.

To read GNU Lesser General Public Licence, Version 3, access <http://www.gnu.org/licenses/lgpl.html>.

To get the complete source code of JFreeChart for the version of the library that it is used in this software please contact the manufacturer (see [Contact](#)).

### 10.2 jSSC

This software incorporates jSSC, © 2010-2012 Sokolov Alexey.

The jSSC home page can be found at: <http://code.google.com/p/java-simple-serial-connector/>.

To read GNU Lesser General Public Licence, Version 3, access <http://www.gnu.org/licenses/lgpl.html>.

To get the complete source code of jSSC for the version of the library that it is used in this software please contact the manufacturer (see [Contact](#)).

# Index

## - A -

About 111

## - B -

Before Installing 34  
 Before Trying To Establish Communication 214  
 Bluetooth Connection 148  
 Bluetooth USB Adapter 211

## - C -

Close 49  
 Communication 113  
 Communication Setup 57  
 Contact 7  
 Contents 110  
 Convert Project 101  
 Copyright Notice 22

## - D -

Drive 54  
 Drive Parametrization 113

## - E -

Edit Parameters File 65  
 Ethernet Cable 210  
 Ethernet Connection 173  
 Ethernet Network Adapter 212  
 Exception During Monitoring 214  
 Exit 54  
 Export 52  
 Export Parameters File 69  
 Export Trace File 96  
 Export Trend File 92

## - F -

Full Conversion Log 108

## - G -

Getting to Know the Environment 19

## - H -

Help 110

## - I -

Identify Drive 55  
 Import 51  
 Import Database 101  
 Installation/Uninstalation 34  
 Installing 34  
 Introduction 8

## - J -

JFreeChart 218  
 jSSC 218

## - L -

Libraries 218

## - M -

Main Window 19  
 Menus 47  
 Monitor Parameters 75  
 Monitor Speed Reference 83  
 Monitor Status 78  
 Monitor using Keypad 77

## - N -

New 48  
 New Parameters File 64

## - O -

Open 48  
 Options 97

## - P -

Print 53  
 Project 47  
 Project Information 53  
 Project Tree 20

---

## - R -

Read Parameters from Drive 70  
Remove 50  
Remove Full Conversion Log 110  
Remove Parameters File 68  
Remove Simplified Conversion Log 108  
Remove Trace File 96  
Remove Trend File 92  
RS232 Cable 207  
RS232 Connection 130  
RS485 Connection 133

## - S -

Safety 22  
Safety Notice 22  
Save 49  
Save As 50  
Security System 63  
Security System (Session) 64  
Simplified Conversion Log 106  
SuperDrive G2 6  
Supported Drives 8  
System Requirements 8

## - T -

Tools 97  
Trace 93  
Trend 84

## - U -

Uninstalling 41  
USB Cable 207  
USB Connection 116  
USB Connection - Virtual COM Port 118  
USB Driver 46  
USB to Serial Adapter 210  
User's Manual 18

## - W -

Welcome 6  
What's New 23  
What's New in Previous Versions 23  
What's New in this Version 23  
Write Parameters to Drive 71