

SureSERVO[™]
QUICK START GUIDE



In This Appendix ...

Quick Start for <i>SureServo</i> [™] Drives	A-2
Spin the Motor	A-2
Position Mode Quick Start (Pt & Pr)	A-4
Velocity Mode Quick Start (V & Vz)	A-8
Torque Mode Quick Start (T & Tz)	A-10
Tuning Quick Start for <i>SureServo</i> [™] Drives	A-12
Tuning Overview	A-12
PDF Adaptive Auto-Tune Mode Adjustments	A-12

Quick Start for *SureServo*™ Drives

This guide allows you to get your *SureServo* motor and drive up and running as quickly as possible. This is not a substitute for reviewing the entire manual. You will need to familiarize yourself with the complete feature set of the drive. This quick start guide will serve as initial setup only.



WARNING: To prevent serious injury or damage to equipment, always start any new servo setup with the motor shaft disconnected from the load. The quick start will bypass mechanical overtravels and overrides. DISCONNECT THE LOAD. Always wire an E-Stop circuit into the power feed for the drive. Always drop the main incoming power for E-Stop conditions; control power can remain ON.

The Quick Start Guide is divided into four sections:

- Spin the Motor
- Position Mode Quick Start
- Velocity Mode Quick Start
- Torque Mode Quick Start

Spin the Motor

The first thing you want to do with the *SureServo* is spin the motor. This section will verify that all the components and cabling are working properly by allowing you to JOG the motor. These simple steps will get your *SureServo* system up and moving:

1. **Disconnect the motor from any load.** Connect the motor cables to the motor and drive. Make sure to connect the motor ground. Do not connect CN1, the I/O connector.
2. **Wire the appropriate fusing and an E-stop contactor to the drive.** See Chapter 2 for wiring information. Make sure to connect an external ground to the drive (large, multi-strand conductors are recommended). Verify that the E-Stop contactor functions properly before plugging the power connector into the drive.
3. **Power up the drive.** There will be errors. ALE 14 and ALE 15 are Alarm Errors for the Overtravel Limit switches (see Chapter 7 for explanation; they are NC by default).
4. **Set Parameter P2-08 to 10.** This will reset the drive to factory defaults. Press **MODE**, then press **NEXT** until **P2-00** appears. Press **ARROW-UP** until **P2-08** appears. Press **ENTER**. Press **ARROW-UP** until you enter a value of 10. Press **ENTER** to accept. See Chapter 3 for additional keypad help. If using *SureServo* Pro software (recommended), the drive communication defaults to 19.2k, 8, 0, 1, MODBUS RTU, Node 1 (this is the software default, too).

Note: For each parameter change in the software, you must download all settings to the drive.

P2-08	Password (and Factory Default)
10	Reset Drive to Factory Defaults

5. **Set the appropriate motor code in P1-31.**

Refer to the “Servo Drive Parameters” chapter for details.

P1-31 Motor Code	
10 = 100 W	21 = 1 kW (low inertia)
11 = 200 W	22 = 1 kW (medium inertia)
12 = 400 W	30 = 2 kW
20 = 750 W	31 = 3 kW

** For SureServo drives with firmware version 2.103, execute Step 6. For previous firmware versions, skip Step 6 and proceed to Step 7.

6. (for **firmware v2.103 only**)

Disable Digital Input 8 (DI8) by changing the value in **P2-17** to zero. Refer to “Servo Drive Parameters” chapter for details.

7. **Cycle Power to the Drive.**

8. **Set Parameter P2-30 to 1.** This temporarily overrides Servo Enable, CW Limit, and CCW Limit. Make sure the motor is disconnected from the load.

P2-30 Auxiliary Function	
1	Force Servo to be Enable (regardless of input status)

9. **Jog the motor.** For Keypad operation: Go to **P4-05**, JOG Operation. Press **ENTER**. This is the JOG speed setpoint. Adjust this to the desired jogging speed. (**NEXT** will move the cursor to the left.) Press **ENTER**. The LED display will show “JOG”. Press the **UP-ARROW** or **DOWN-ARROW** to Jog the motor forward or reverse. Press **MODE** to exit the JOG operation.

P4-05 JOG Operation	
100	Jog the motor at 100 rpm when the JOG signal is active

If the motor run, stop, and direction behavior is not as expected, then recheck the motor power wiring at the drive U, V, W, and ground terminals. (Refer to Chapter 2 for wire color and terminal connection information.)

10. **Cycle Control Power to the drive.** This will reset **P2-30**, re-enabling the Servo Enable, CW Limit, and CCW Limit inputs.

Position Mode Quick Start (Pt & Pr)

This section explains the basic procedures necessary to control the *SureServo* drive in Position Mode; both pulse input (Pt) and internal positioning (Pr). In Pt mode, positioning commands come from high-speed pulse trains from the terminals. In Pr mode, positioning commands are held in internal registers.

Pt Mode - High-Speed Pulse Input (Position - terminals)

1. **Spin the Motor.** Follow the instructions in the previous section to verify that the motor and drive are functioning properly. Cycle power to the drive. At this point, power, fusing, and an E-stop contactor should all be wired appropriately (see Chapter 2 for wiring information). The motor code in **P1-31** should be set to the correct motor type.
2. **Set the Pulse Type and Control Mode.** **P1-00** selects the type of pulse stream that will come into the drive. **P1-01** selects the actual control mode: 0000 will result in Pt mode with the motor spinning CCW as forward. The second MSB selects direction. Note: 0101 will result in Pt mode with motor spinning CW as forward.

P1-00	External Input Pulse Type (See Chapter 2 and Appendix C for encoder wiring details.)
000	Quadrature Input - A, /A, B, /B (typical encoder input signals)
001	CW + CCW pulse input
002	Pulse + Direction
See the "Servo Drive Parameters" chapter for more information regarding Positive vs. Negative signals, forward/reverse, etc.	

P1-01	Control Mode and Output Direction
0000	Drive accepts Position Control via external pulse inputs with CW direction.
0100	Drive accepts Position Control via external pulse inputs with CCW direction.
See the "Servo Drive Parameters" chapter for more information regarding changing directions, dual modes, etc.	

3. **Configure the Digital Inputs.** Select which DI (digital inputs) your system will require. See **P2-10** through **P2-17** to select the correct configuration (these parameters set NO/NC and the functionality of each input). A minimum configuration should contain at least Servo Enable, Alarm Reset, Fault Stop, and CW/CCW limits (if your system has overtravels). Once these settings are configured, cycle power to the drive for them to take effect. The motor should now follow the incoming pulses when the servo is enabled, so when you turn the encoder shaft the servo motor will follow the movement.

P2-10 Through P2-17		Digital Input Definition	
P2-10	101	DI1 = Servo Enable	Normally Open
P2-14	102	DI5 = Alarm Reset	Normally Open
P2-15	022	DI6 = Reverse Overtravel (set to 000 to disable this input)	Normally Closed
P2-16	023	DI7 = Forward Overtravel (set to 000 to disable this input)	Normally Closed
P2-17	121	DI8 = Fault Stop	Normally Open
See the "Servo Drive Parameters" chapter for more information regarding normally open vs. normally closed, additional functions, etc.			

4. **Gearing.** Electronic Gearing can be set in **P1-44** (Numerator) and **P1-45** (Denominator). Default setting is 1/1 (1 incoming pulse = motor movement of 1 count). Note: One revolution of a 2500ppr quadrature encoder (A, /A, B, /B) will actually cause the motor to rotate one entire revolution since the SureServo treats each transitional edge as an input (2500ppr x 4 = 10,000 = 1 motor rev).

Pr Mode - Internal Indexing (Position - registers)

1. **Spin the Motor.** Follow the instructions in the previous section to verify that the motor and drive are functioning properly. Cycle power to the drive. At this point, power, fusing, and an E-stop contactor should all be wired appropriately according to Chapter 2. The motor code in **P1-31** should be set to the correct motor type.
2. **Set the Control Mode.** **P1-01** selects the actual control mode: 0001 will result in Pr mode with the motor spinning CCW as forward. The second MSB selects direction. Note: 0101 will result in Pr mode with motor spinning CW as forward.

P1-01 Control Mode and Output Direction	
0001	Drive is in Internal Indexing Mode. Setpoints are internal registers selected via Digital Inputs with CCW direction.
0101	Drive is in Internal Indexing Mode. Setpoints are internal registers selected via Digital Inputs with CW direction.
See the "Servo Drive Parameters" chapter for more information regarding changing directions, dual modes, etc.	

3. **Configure the Basic Digital Inputs.** Select which digital inputs your system will require. See **P2-10** through **P2-17** to select the correct configuration (these parameters set NO/NC and the functionality of each input). A minimum configuration should contain at least Servo Enable, Alarm Reset, and CW/CCW limits (if your system has overtravel limits).

P2-10 Through P2-17		Digital Input Definition	
P2-10	101	DI1 = Servos On	Normally Open
P2-14	102	DI5 = Alarm Reset	Normally Open
P2-15	022	DI6 = Reverse Overtravel (set to 000 to disable this input)	Normally Closed
P2-16	023	DI7 = Forward Overtravel (set to 000 to disable this input)	Normally Closed
P2-17	121	DI8 = Fault Stop	Normally Open
See the "Servo Drive Parameters" chapter for more information regarding normally open vs. normally closed, additional functions, etc.			

4. **Configure the position selection.** The drive can be configured to select the internal Position setpoint by 3 digital inputs; POS0, POS1, and POS2. Any of the digital inputs can be set as POS0 (code 11), POS1 (code 12), or POS2 (code 13) in **P2-10** through **P2-17**. By configuring all 3 inputs, all of the 8 internal presets can be selected via external signals.

To save digital inputs for other uses, not all POSx's have to be configured. If only two setpoints are needed (for example: the motor needs to move and then return), then only one POSx needs to be configured. Configuring only input POS2 (POS0 and POS1 not assigned) would allow the selection of Position 1 and Position 5.

Or, if you will be writing to the Modbus address of Position 0 to change the setpoint after each index, no digital inputs have to be used at all. Disabling the inputs causes them to act as if they were inactive, so when all POSx inputs are disabled = Position 1. One input, however, should be selected as the Command Trigger (code 08). When pulsed, this input will cause the drive to move to the selected setpoint position.

P2-10 Through P2-17		Digital Input Definition	
P2-11	111	DI2 = POS0 (bit 0 of the binary code to select internal setpoints)	Normally Open
P2-12	112	DI3 = POS1 (bit 1 of the binary code to select internal setpoints)	Normally Open
P2-13	108	DI4 = Command Trigger	Normally Open
Defining POS0 and POS1 will allow selection of Positions 1-4. See the "Servo Drive Parameters" chapter for more information regarding normally open vs. normally closed, additional functions, etc.			

5. **Configure the Position Setpoints.** Parameter **P1-33** selects Incremental or Absolute mode. Enter a value of "0" for Absolute Mode or enter "1" for Incremental mode. Parameters (**P1-15** through **P1-30**) determine the setpoints of Positions 1 through 8. Each setpoint has 2 parts; motor revolutions and pulses. One motor revolution consists of 10,000 counts. So, to move the motor Incrementally 3-½ turns (or to Absolute position 3-½ revs from home), place a 3 in the first position parameter and a 5000 into the second.

P1-33		Position Control Mode
0		Absolute Mode - Each index will cause the motor to move to (or stay at) an absolute position.
1		Incremental Mode - Each index will cause the motor to advance by the commanded amount.
See the "Servo Drive Parameters" chapter for more information regarding different modes, resolution, etc.		

P1-15 Through P1-30		Position Setpoints
P1-15	3	Index #1 - Motor Revolutions
P1-16	5000	Index #1 - Motor Counts (out of 10,000 counts per 1 revolution).
The above settings will cause the motor to move 3-1/2 revolutions when POSx inputs are OFF and the Command Trigger is pulsed. See the "Servo Drive Parameters" chapter for more information regarding different modes, resolution, etc.		

6. **Configure Accel, Decel, and Speeds.** P1-34 and P1-35 are the Acceleration and Deceleration parameters (accel time in ms from 0 rpm to P1-55 max velocity limit, and decel time from max velocity limit to 0 rpm). P1-36, Accel/Decel S-Curve Time (ms), must be set to a non-zero number for accel and decel to take effect. *Without adjusting the 3 acc/dec parameters, the drive may fault when first moved.* Parameters P2-36 through P2-43 are the 8 speed settings that correspond to the 8 position setpoints. Their default is 1000 rpm. Once all of the above parameters are configured, cycle power to the drive. The drive should now respond to the Command Trigger Input.

P1-34 Through P1-36 Acceleration, Deceleration, and S-Curve		
P1-34	200	Acceleration Time (in ms)
P1-35	200	Deceleration Time (in ms)
P1-36	50	S-Curve Time (in ms) - This setting must be non-zero for Acceleration/Deceleration to take effect.
See the "Servo Drive Parameters" chapter for more information regarding ranges, etc.		

P2-36 Through P2-43 Index Speeds		
P2-36	1000	Speed for Index #1 (in rpm). All speed settings are 1000 rpm default.
See the "Servo Drive Parameters" chapter for more information regarding ranges, etc.		

POS2	POS1	POS0	Position Setpoint	Velocity
0	0	0	Position 1 = P1-15, P1-16	Velocity 1 = P2-36
0	0	1	Position 2 = P1-17, P1-18	Velocity 2 = P2-37
0	1	0	Position 3 = P1-19, P1-20	Velocity 3 = P2-38
0	1	1	Position 4 = P1-21, P1-22	Velocity 4 = P2-39
1	0	0	Position 5 = P1-23, P1-24	Velocity 5 = P2-40
1	0	1	Position 6 = P1-25, P1-26	Velocity 6 = P2-41
1	1	0	Position 7 = P1-27, P1-28	Velocity 7 = P2-42
1	1	1	Position 8 = P1-29, P1-30	Velocity 8 = P2-43
NOTE: If a POSx selector is not defined, it has a value of 0 (off).				

Velocity Mode Quick Start (V & Vz)

1. **Spin the Motor.** Follow the instructions in the previous section to verify that the motor and drive are functioning properly. Cycle power to the drive. At this point, power, fusing, and fault stop should all be wired appropriately; see Chapter 2 for wiring information. The **P1-31** motor code should be set to the correct motor type.
2. **Set the Control Mode.** **P1-01** selects the actual control mode; 0002 will result in analog/preset Velocity mode with the motor spinning CCW as forward. (The second MSB selects direction.) Vz Mode (internal velocity presets only) can be selected by entering 0004.

P1-01	Control Mode and Output Direction	
xx02	Drive is in Velocity Mode V.	Drive Speed is determined via analog signal or by internal presets.
xx04	Drive is in Velocity Mode Vz. Speed is determined by internal presets only.	
See the "Servo Drive Parameters" chapter for more information regarding changing directions, dual modes, etc.		

3. **Configure the Digital Inputs.** Select which DI (digital inputs) your system will require. See **P2-10** through **P2-17** to select the correct configuration (these parameters set NO/NC and the functionality of each input). A minimum configuration should contain at least Servo Enable, Alarm Reset, Fault Stop, and CW/CCW limits (if your system has overtravels). If you want to be able to select Preset Speeds, you must also configure inputs for SPD0 and SPD1 (to be able to select the speed setpoints through binary code). Once these settings are configured, cycle power to the drive for them to take effect.

P2-10 Through P2-17		Digital Input Definition	
P2-10	101	DI1 = Servo Enable	Normally Open
P2-11	114	DI2 = SPD0 (bit 0 of the binary code to select the desired speed)	Normally Open
P2-12	115	DI3 = SPD1 (bit 1 of the binary code to select the desired speed)	Normally Open
P2-14	102	DI5 = Alarm Reset	Normally Open
P2-15	022	DI6 = Reverse Overtravel (set to 000 to disable this input)	Normally Closed
P2-16	023	DI7 = Forward Overtravel (set to 000 to disable this input)	Normally Closed
P2-17	121	DI8 = Fault Stop	Normally Open
See the "Servo Drive Parameters" chapter for more information regarding normally open vs. normally closed, additional functions, etc.			

4. **Configure the Velocity Setpoints (if using Preset Velocities).** P1-09, P1-10, and P1-11 are the three Velocity Setpoints that can be selected via the digital inputs. When the digital inputs are both inactive, the speed command will be the +/-10V analog input command if in V mode. If the drive is in Vz mode, the command speed will be absolute zero (to allow for a "no drift" command).

P1-09 Through P1-11 Internal Speed Setpoints		
P1-09	100	1st Velocity Command (SPD1 = OFF; SPD0 = ON)
P1-10	200	2nd Velocity Command (SPD1 = ON; SPD0 = OFF)
P1-11	300	3rd Velocity Command (SPD1 = ON; SPD0 = ON)
If both SPD0 and SPD1 are OFF, the drive will follow the analog input. See the "Servo Drive Parameters" chapter for more information regarding normally open vs. normally closed, additional functions, etc.		

5. **Configure Accel, Decel, and Speeds.** P1-34 and P1-35 are the Acceleration and Deceleration parameters (accel time in ms from 0 rpm to P1-55 max velocity limit, and decel time from max velocity limit to 0 rpm). P1-36, Accel/Decel S-Curve Time (ms), must be set to a non-zero number for accel and decel to take effect. *Without adjusting the 3 acc/dec parameters, the drive may fault when first moved.*

P1-34 Through P1-36 Acceleration, Deceleration, and S-Curve		
P1-34	200	Acceleration Time (in ms)
P1-35	200	Deceleration Time (in ms)
P1-36	50	S-Curve Time (in ms) - This setting must be non-zero for Acceleration/Deceleration to take effect.
See the "Servo Drive Parameters" chapter for more information regarding ranges, etc.		

6. **Enable the Drive and Apply the Velocity Command.** If no errors exist, the drive should now follow the commanded velocity when enabled. With the Digital Inputs for Velocity Command Select Inputs SPD0 and SPD1 both inactive (or undefined), the drive should respond to an analog input signal if configured for V mode (if configured for Vz mode, both inputs inactive = zero speed). For both V and Vz modes, the drive should move at the preset speeds when Velocity Command Select Inputs SPD0 and SPD1 are set appropriately.

SPD1	SPD0	Velocity Setpoint
0	0	Vz Mode = 0 (zero) V Mode = Analog signal
0	1	1st Velocity Command = P1-09
1	0	2nd Velocity Command = P1-10
1	1	3rd Velocity Command = P1-11
NOTE: If SPD1 or SPD0 are not defined, their value is 0 (off).		

Torque Mode Quick Start (T & Tz)

1. **Spin the Motor.** Follow the instructions in the previous section to verify that the motor and drive are functioning properly. Cycle power to the drive. At this point, power, fusing, and E-stop should all be wired appropriately. The motor code in **P1-31** should be set to the correct motor type.
2. **Set the Control Mode.** **P1-01** selects the actual control mode; 0003 will result in analog/preset Torque mode with the motor spinning CCW as forward. (The second MSB selects direction.) Tz Mode (internal torque presets only) can be selected by entering 0005.

P1-01	Control Mode and Output Direction	
xx03	Drive is in Torque Mode T. Drive torque is determined via analog signal or by internal presets.	
xx05	Drive is in Torque Mode Tz. Drive torque is determined by internal presets only.	
See the "Servo Drive Parameters" chapter for more information regarding changing directions, dual modes, etc.		

3. **Configure the Digital Inputs.** Select which DI (digital inputs) your system will require. See **P2-10** through **P2-17** to select the correct configuration (these parameters set NO/NC and the functionality of each input). A minimum configuration should contain at least Servo Enable, Alarm Reset, Fault Stop, and CW/CCW limits (if your system has overtravels). If you want to be able to select Preset Torques, you must also configure inputs for Torque Command Inputs TCM0 and TCM1 (to be able to select the Torque setpoints through binary code). Once these settings are configured, cycle power to the drive for them to take effect.

P2-10 Through P2-17		Digital Input Definition	
P2-10	101	DI1 = Servo Enable	Normally Open
P2-11	116	DI2 = TCM0 (bit 0 of the binary code to select the desired torque)	Normally Open
P2-12	117	DI3 = TCM1 (bit 1 of the binary code to select the desired torque)	Normally Open
P2-14	102	DI5 = Alarm Reset	Normally Open
P2-15	022	DI6 = Reverse Overtravel (set to 000 to disable this input)	Normally Closed
P2-16	023	DI7 = Forward Overtravel (set to 000 to disable this input)	Normally Closed
P2-17	121	DI8 = Fault Stop	Normally Open
See the "Servo Drive Parameters" chapter for more information regarding normally open vs. normally closed, additional functions, etc.			

4. **Configure the Torque Setpoints and Speed Limits.** P1-12, P1-13, and P1-14 are the three Torque Setpoints that can be selected via the digital inputs. When the digital inputs are both inactive, the Torque command will be the +/-10V analog input command if in T mode. If the drive is in Tz mode, the command torque will be an absolute zero. P1-02, P1-09, P1-10, and P1-11 set the speed limits that will be used in Torque mode. P1-02 enables an analog Velocity limit when using the analog Torques signal. The other three parameters are velocity limits that correspond to Torque Presets 1, 2, and 3.

P1-12 Through P1-14		Internal Torque Setpoints
P1-12	30	1st Torque Command (TCM1 = OFF; TCM0 = ON)
P1-13	40	2nd Torque Command (TCM1 = ON; TCM0 = OFF)
P1-14	50	3rd Torque Command (TCM1 = ON; TCM0 = ON)
If both TCM0 and TCM1 are OFF, the drive will follow the analog input. See the "Servo Drive Parameters" chapter for more information regarding normally open vs. normally closed, additional functions, etc.		

5. **Configure Accel, Decel, and Speeds.** P1-34 and P1-35 are the Acceleration and Deceleration parameters (accel time in ms from 0 rpm to P1-55 max velocity limit, and decel time from max velocity limit to 0 rpm). P1-36, Accel/Decel S-Curve Time (ms), must be set to a non-zero number for accel and decel to take affect. *Without adjusting the 3 acc/dec parameters, the drive may fault when first moved.*

P1-34 Through P1-36		Acceleration, Deceleration, and S-Curve
P1-34	200	Acceleration Time (in ms)
P1-35	200	Deceleration Time (in ms)
P1-36	50	S-Curve Time (in ms) - This setting must be non-zero to Acceleration/Deceleration to take effect.
See the "Servo Drive Parameters" chapter for more information regarding ranges, etc.		

6. **Enable the Drive and Apply the Torque Command.** If no errors exist, the drive should now follow the commanded Torque when enabled. With the Digital Inputs for Torque Command Select Inputs TCM0 and TCM1 both inactive (or undefined), the drive should respond to an analog input signal if configured for T mode (if configured for Tz mode, both inputs inactive = zero Torque). For both T and Tz modes, the drive should move to the preset speeds when Torque Command Select Inputs TCM0 and TCM1 are set appropriately.

TCM1	TCM0	Torque Level
0	0	Tz Mode = 0 (zero) T Mode = Analog signal
0	1	1st Torque Command = P1-12
1	0	2nd Torque Command = P1-13
1	1	3rd Torque Command = P1-14
NOTE: If TCM1 or TCM0 are not defined, their value is 0 (off).		

Tuning Quick Start for SureServo™ Drives

Tuning Overview

After installing the SureServo system and testing its functionality (wiring, communication, motion, etc.), you may decide that the default tuning selection is either too responsive or not responsive enough for your application. This Quick Start Guide section will walk you through the very basic steps to adjust the drive tuning using the “PDFF Adaptive Auto-Tune Mode”. Other tuning modes are explained in the “Control Modes of Operation and Tuning” Chapter of this manual.

The SureServo drive has three available modes of tuning: Manual, Easy, and Auto. (The Auto tuning mode includes two sub-modes: Adaptive Auto and Fixed Auto.)

Manual Tuning Mode requires an in-depth knowledge of tuning parameters and the physical characteristics of the system, and it will not be covered in this Quick Start Guide. **Easy-Tune Mode** presets many of the tuning parameters and is useful when the system load (and inertia) changes significantly. Easy-Tune is helpful if the inertia mismatch ratio is not known. After Easy-Tuning, it may still be necessary to switch to a fixed mismatch ratio tuning method to fine-tune the system. **Auto-Tune Mode** is available in Adaptive and Fixed sub-modes. In Adaptive Auto-Tune Mode, the drive constantly monitors the load and adjusts the tuning parameters. In Fixed Auto-Tune Mode, the inertia and mismatch are known and entered by the user.



Refer to the “Control Modes of Operation and Tuning” chapter of this manual for more details and explanation of tuning the servo in all of the different modes, and how to select which mode is best for your application.

PDFF Adaptive Auto-Tune Mode Adjustments

The PDFF Adaptive Auto-Tune Mode (P2-32 = 4) constantly monitors the system load and inertia, and continually updates the tuning parameters. Besides P2-32, the only additional parameter that needs to be set by the user is P2-31, which determines the overall responsiveness of the servo system.



The actual load being controlled must be connected to the motor before performing tuning.

For Keypad Tuning

- 1) Set P2-32 to “4” (PDFF Adaptive Auto-Tune Mode).
The drive must not be enabled for this change to occur.
- 2) Enable the drive.
- 3) Write down the current value of P2-31 (response level). The value will be a two-digit number. Each digit is independent of the other, and each has a range of 0 to F (hex).
- 4) Adjust the left (leading) digit to change the responsiveness of the servo system. Increase this number to make the system more responsive, or decrease the number to make the system less responsive (more “sluggish”). If you increase the number too much, the system will become unstable and begin to vibrate. If you decrease the number too much, the system will not respond quickly enough to command signals.

If you cannot stabilize the drive using this method, try switching to a tuning mode with a fixed mismatch ratio such as P2-32 = 3 or 5. Adjust the parameters for that mode per Table 6-1 of the “Control Modes of Operation and Tuning” chapter. In the fixed mode, set P2-31 to the value the drive had previously calculated in the PDFF Adaptive Auto-Tune Mode.

BLANK
PAGE