



BONDED WINDOWS

1. ROUTE COVER FACE DOWN AND REMOVE THE TWO MOUNTING BOSS WHEN REQUIRED.

SPECIAL REQUIREMENTS

2. ROUTE BOTH SURFACES BEFORE BONDING MINIMUM OVERLAP BETWEEN THE WINDOW AND THE COVER FACE. MINIMUM OVERLAP SHALL BE 1/4\"/>