

**INSTRUCTIONS: CLEAN SURFACE  
WITH THE PROVIDED ALCOHOL  
PAD BEFORE ATTACHING PRINT  
POCKET. REMOVE BACKING TAPE  
POSITION PRINT POCKET, AND  
PRESS FIRMLY TO ADHERE.**