

DEEP HINGED HMI COVERS

BUL87926



REV. A

ASSEMBLY INSTRUCTIONS FOR DEEP HINGED HMI COVERS (1481SDH / 1481SSDH)

INSTRUCTIONS :

- A) Locate HMI cover in desired location.
- B) Use HMI cover as template for marking mounting hole location.
(Use chart to confirm maximum cutout size)
- C) Mark all holes in body.
- D) Drill (9/32" / 7.1mm) holes.
- E) File sharp edges of cutout.
- F) Install cover into place using supplied hardware.
- G) Tighten hardware until the gasket is fully compressed against the mating surface.

ITEM #	DESCRIPTION
1	HMI COVER
2	SCREW 1/4-20X3/4 HEX ZP
3	NUT - 1/4-20 UNC, KEPS, ZP



PART NUMBER	MAXIMUM CUTOUT SIZE (IN)		NUMBER OF SCREWS
	H	W	
1481SDH1418	9.19	11.56	8
1481SDH1612	11.19	5.14	8
1481SDH2016	15.19	9.14	8
1481SDH2416	19.19	9.14	10
1481SDH2420	19.19	13.14	12
1481SDH3024	25.19	17.14	14
1481SDH2430	19.19	23.14	14
1481SDH3624	31.19	17.14	16

PART SHOWN -

NOTE: ALL PARTS ALSO OFFERED IN STAINLESS STEEL.

