





1. Screw probe to the mounting aid.
2. Insert mounting aid with probe into coaxial tube until centering piece engages.
3. Remove pre-installed metal retaining clip.
4. Uninstall centering piece.
5. Place a centering piece in upper position.
6. Install metal retaining clip to hold centering piece in place.
7. Install lower centering piece and metal retaining clip.
8. Remove rod and uninstall mounting aid.