

Table of Contents

Chapter 1.0 System Requirements	1
Chapter 2.0 DataNet OPC Overview	2
2.1 DataNet OPC Software Products	5
Chapter 3.0 Installation	7
Chapter 4.0 Registration	16
Chapter 5.0 Configuration	20
5.1 Main Configuration	20
5.2 Column Configuration	25
5.3 Row Configuration	27
5.4 Row-Logging Configuration	32
Chapter 6.0 Historical Text Files	38
Chapter 7.0 DataNet OPC Server	40
7.1 Installing Service	40
7.2 Running Service	42
7.3 Pausing	43
7.4 Stopping	45
7.5 Uninstalling	46
Chapter 8.0 Troubleshooting	47