

AUXILIARY FAN ATTACHMENTS


FOR 45MM & 55MM WIDE

STELLAR SR22 COMPACT SOFT STARTERS *

* SR22 soft starters automatically detect fan connections, and adjust their operation accordingly.

- Cooling fans are temperature controlled, and do not run continuously.
- Fans turn on when starter reaches 45°C [113°F] or higher.

Please Note: Customers should reference the SR22 Soft Starter Quick-Start Guide (SR22_DS) at AutomationDirect.com.



Unit Width	Fan Kit Part No.	Fan Size	Fan Voltage
45mm	SR22-FAN-45	25mm x 25mm	12V
55mm	SR22-FAN-55	40mm x 40mm	24V