

# TERMINATOR INSTALLATION AND I/O MANUAL

---



Please include the Manual Number and the Manual Issue, both shown below, when communicating with Technical Support regarding this publication.

**Manual Number:** T1K-INST-M  
**Issue:** 3rd Edition, Rev. C  
**Issue Date:** 08/20

<b>Edition/Rev</b>	<b>Date</b>	<b>Publication History</b>
First Edition	11/00	Original issue
Rev. A	02/01	Added new module and minor corrections
Rev. B	07/01	Added new modules
Rev. C	04/02	Added new modules and minor corrections
Rev. D	12/02	Added new module and general updates
Rev. E	04/03	Added new module and added Class 1, Division 2, Zone 2 Approval
2nd Edition	09/03	Added new module and minor corrections
Rev. A	09/04	Added new modules and minor corrections
3rd Edition	05/13	Converted manual from Interleaf to QuarkXpress and made minor corrections
Rev. A	10/16	Added T1F-16TMST thermistor input module
Rev. B	01/18	Added Module Control Byte examples (4-21 to 4-24). General updates.
Rev. C	08/20	T1H-PBC discontinued, added notes to Chapter 3 accordingly.