



TABLE OF CONTENTS

Chapter 1 - Getting Started

Introduction.....	1-2
Conventions Used.....	1-3
Before you begin.....	1-4
Step 1: Install Software.....	1-5
Step 2: Launch Programming Software	1-7
Step 3: Set Up User Account.....	1-9
Step 4: Create a Project.....	1-10
Step 5: Compile and Save Project.....	1-16
Step 6: Apply Power	1-17
Step 7: Establish PC to PLC Communications.....	1-18
Step 8: Write Project into PLC.....	1-30
Step 9: Place PLC in RUN Mode	1-31
Step 10: Test Project using Data View Monitor	1-32
Step 11: Y001 Output On?.....	1-33
Step 12: Test Project Using Remote PLC App.....	1-34
Additional Training Resources	1-38

Chapter 2 - Specifications

Overview of PLC System	2-2
Regulatory and Standards Compliance.....	2-3
CLICK PLUS PLC Units	2-4
Option Slot I/O Modules	2-6
Option Slot Intelligent Modules	2-8

Stackable I/O Modules	2-9
Power Budgeting	2-13
PLC Unit Specifications	2-16
Option Slot I/O Module Specifications	2-31
Option Slot Intelligent Module Specifications	2-86
Stackable I/O Module Specifications	2-93
Power Supply Specifications	2-130
Programming Software	2-133
Data Types, Memory, and Numbering System	2-134
PLC Operation	2-138
Accessories	2-142
 Chapter 3 - Installation and Wiring	
Safety Guidelines	3-2
Introduction to the CLICK PLUS PLC Mechanical Design	3-5
Mounting Guidelines	3-10
Installing the CLICK PLUS PLC	3-20
Wiring Guidelines	3-22
I/O Wiring Checklist	3-30
System Wiring Strategies	3-31
LAN Provisioning over Bluetooth	3-42
Option Slot Analog I/O Configuration	3-46
High-Speed Input/Output Configuration	3-53
Setting Up and Using an SD Card	3-58
 Chapter 4 - PLC Communications	
Introduction	4-2
PLC Communication Ports Specifications	4-3
LED Status Indicators	4-4
Remote PLC App Configuration and Use	4-6

C2-DCM Intelligent Module Communication Ports Specifications.....	4-7
3 Steps to Using the CLICK PLC Communications	4-8
Typical Communication Applications	4-9
W-1: USB Port Wiring	4-13
W-2: Com Port 2 (RS-232) Wiring	4-14
W-3: Com Port 1 (Ethernet) Wiring.....	4-18
W-4: Com Port 3 Wiring	4-20
W-5: C2-DCM Com Port RS-232 Wiring	4-21
W-6: C2-DCM Com Port RS-485 Wiring	4-22
C-1: USB Port Setup.....	4-23
C-2: Com Port 1 (Ethernet) Setup	4-24
C-3: Wireless LAN (WLAN) Setup.....	4-25
C-4: Bluetooth Setup	4-26
C-5: Com Port 2 Setup (Modbus RTU).....	4-27
C-6: Com Port 2 Setup (ASCII)	4-28
C-7: Com Port 3 Setup (Modbus RTU).....	4-29
C-8: Com Port 3 Setup (ASCII)	4-30
C-9: C2-DCM Com Port 1 or 2 Setup (ASCII)	4-31
C-10: C2-DCM Com Port 1 or 2 Setup (Modbus RTU)	4-32
P-1: Modbus Slave (Server) Programming.....	4-33
P-2: Modbus Master Programming (Modbus RTU).....	4-37
P-3: Modbus Client (Modbus TCP) Programming	4-42
P-4: ASCII Receive Programming	4-48
P-5: ASCII Send Programming	4-51

Chapter 5 - Intelligent Modules

CLICK PLUS Intelligent Modules	5-2
C2-DCM Communication Module.....	5-2
C2-NRED Node-RED Module	5-3
C2-OPCUA OPC UA Server Module.....	5-29

Chapter 6 - Maintenance

PLC Maintenance	6-2
-----------------------	-----

Chapter 7 - Troubleshooting

Troubleshooting Direction	7-2
PLC unit Troubleshooting	7-3
Bluetooth Troubleshooting	7-5
Wireless LAN Troubleshooting	7-6
USB Troubleshooting	7-7
SD Card Troubleshooting	7-8
Power Supply Troubleshooting.....	7-9
I/O Module Troubleshooting	7-10
Resetting to Factory Defaults	7-14
Troubleshooting Electrical Noise Problems.....	7-15
Error Codes.....	7-16

Appendix A - Security Considerations for Control Systems Networks

Security Considerations for Control Systems Networks.....	A-2
---	-----