# DL405 Family of Products

This page provides an overview of the variety of products found in the DL405 family.

### **CPUs**

- <u>D4-454</u> 110/220 VAC P/S
- <u>D4-454DC-1</u> 24VDC P/S 30.8K total memory 16 PID loops with auto-tune

### Memory cartridges

• UVPROM - 15.5K (<u>D4-UV-2</u>)

### Programming

 DirectSOFT Programming for Windows (PC-DSOFT6) Handheld programmer (D4-HPP-1)

#### Bases

- 4-slot base (<u>D4-04B-1</u>)
- 6-slot base (<u>D4-06B-1</u>)
- 8-slot base (<u>D4-08B-1</u>)

## Local expansion base power supplies

- 110/220 VAC P/S (D4-EX)
- 24VDC P/S (D4-EXDC)

### Discrete input modules

- DC input
- 16-point 12-24 VDC (D4-16ND2)
- 16-point 12–24 VDC (1ms response) (D4-16ND2F)
- 32-point 24VDC (<u>D4-32ND3-1</u>)
- 64-point 20–28 VDC (<u>D4-64ND2</u>) AC input modules
- 8-point 110/220 VAC (<u>D4-08NA</u>)
- 16-point 110VAC (<u>D4-16NA</u>)
- AC/DC input modules
- 16-pt 12–24 VAC/DC (<u>D4-16NE3</u>)

## Discrete output modules

- DC output modules
- 16-point 5-24 VDC (D4-16TD1)
- 16-point 12-24 VDC (D4-16TD2)
- 32-point 5–26 VDC (<u>D4-32TD1</u>)
- 32-point 12-24 VDC (D4-32TD2)
- 64-point 5-26 VDC (D4-64TD1)
- AC output modules
- 8-point 18–220 VAC (<u>D4-08TA</u>)
- 16-point 18–220 VAC (<u>D4-16TA</u>)
- Relay output modules
- 8-point 2A (<u>D4-08TR</u>)
- 8-point 5A/pt (isolated) (<u>F4-08TRS-2</u>)
- 8-point 10A/pt (isolated) (<u>F4-08TRS-1</u>)
- 16-point 1A/pt (<u>D4-16TR</u>)

### Analog modules(12-bit)

- Analog input
- 4-channel in, current/voltage (F4-04AD)
- 4-channel in, current/voltage (isolated) (F4-04ADS)
- 8-channel in, current/voltage (F4-08AD)
- 16-channel in, current (F4-16AD-1)
- 16-channel in, voltage (F4-16AD-2)
- Analog output
- 4-channel out, current (F4-04DA-1)
- 4-channel out, voltage (F4-04DA-2)
- 8-channel out, current (F4-08DA-1)
- 8-channel out, voltage (F4-08DA-2)
- 16-channel out, current (F4-16DA-1)
- 16-channel out, voltage (F4-16DA-2)
- Temperature Input
- 8-channel in, type J thermocouple (F4-08THM-J)

### Analog modules(16-bit)

- Temperature Input
- 8-channel in, RTD (<u>F4-08RTD</u>)
- 8-channel in, thermocouple (F4-08THM)
- Analog output
- 4-channel out, current (isolated) (F4-04DAS-1)
- Communications/ networking modules
- Ethernet communications [H4-ECOM100]
- Data communications (D4-DCM)
- Modbus Client (F4-MAS-MB)

### Specialty modules

- High-speed counter I/O (<u>H4-CTRIO</u>)
- 8/16 channel input simulator (<u>D4-16SIM</u>)
- 4-loop temperature controller (<u>F4-4LTC</u>)
- BASIC CoProcessor Module
- 128K triple port (<u>F4-CP128-1</u>)

## CPU-Slot Server controllers

• Ethernet base controller (H4-EBC)

### Remote I/O modules

- Ethernet
- Ethernet remote Client Module (<u>H4-ERM100</u>)
- Ethernet base Controller (Server) (<u>H4-EBC</u>)
- Remote I/O protocol (serial)
- Remote I/O Client Module (<u>D4-RM</u>)
- Remote I/O Server 110/220 VAC (D4-RS)

## DL405 CPUs

#### System capacity

System capacity is the ability of the CPU to accommodate a variety of applications. Here are a few key considerations when determining system capacity:

How much memory do you need? Consider both ladder memory and data registers (V-memory). For ladder memory, most boolean instructions require one word. Some other instructions, such as timers, counters, etc., require two or more words. Our V-memory locations are

#### Performance

If you have a time-critical application where every millisecond is important, then the <u>D4-454</u> CPU, with the fastest overall scan time, is the right choice. The <u>D4-454</u> is very fast at performing even the most basic of math or data instructions and will provide a faster overall scan time. 16-bit words and are useful for data storage, etc.

What type of memory do you need? The <u>D4-454</u> has 15.5K of built in M-RAM ladder memory and no memory cartridge is needed.

How many I/O points are required? You will need to know how many field devices are required. Compare the <u>D4-454</u> specifications tables on the next page with

D4-4	D4-454 Parameters						
Features	<u>D4-454</u>						
Total Memory	46.8K						
Ladder Memory	31.5K						
DirectSOFT	Yes, version 6.1 or later						
Memory Cartridge	No, (same amount of memory as the largest memory cartridge)						
Battery	<u>D2-BAT-1</u> (CR2354)						
Mode Switch	Toggle Switch (Same position/ function)						
Port 1 and 3 Baud Rate	2400, 4800, 9600, 19200, 38400						
Port 1 and 3 Settings	8 data bits, 1 start bit, 1 stop bit, Odd, Even or No parity						
Port 2 Protocol	DirectNet (Client/Server), K-sequence, Non-procedure, Modbus RTU (Client/ Server)						
Firmware Update	Supported from all ports						

NOTE: Any hardware with a date code less than 09X0 or with a first digit that is not 0, 1, or 2 may not work with the <u>D4-454</u>. We suggest that any hardware older than ten years and not currently sold on the AutomationDirect.com website be upgraded to a newer version. your application requirements.

Are there any remote I/O points? In many applications, the cost of bringing the individual control wiring back to the PLC control panel can be reduced by the use of remote I/O. The <u>D4-454</u> CPU has built-in serial remote I/O connections on the lower 25-pin port; or use Ethernet Remote I/O for fast and easy set-up and communications.

D4-454 Unsupported Modules Table						
Bases	Retired					
D4-04B, D4-04BNX	Yes					
D4-06B, D4-06BNX	Yes					
D4-08B, D4-08BNX	Yes					
Input Modules						
D4-32ND3-2	Yes					
D4-16NA-1	Yes					
Output Modules						
D4-08TD1	Yes					
Comm Modules						
H4-ECOM	Yes					
Remote I/O Modules						
D4-ERM	Yes					
D4-ERM-F	Yes					
Specialty Modules						
D4-PULS	Yes					
D4-HSC	Yes					
F4-CP128-R	Yes					
F4-CP512-1	Yes					

## **DL405 CPU Specifications**

	DL405 CPU Specifications						
	<u>D4-454</u>						
System Capacity							
Total memory available (words)	46.8K						
Ladder memory (words)							
built-in memory	31.5K						
with memory cartridge	N/A						
V-memory (words)	15.3K						
Battery backup	Yes, MRAM*						
Total CPU memory I/O pts. available							
(actual							
Ì/O points depend on I/O configuration selected)	2/4/8/16/32/64						
I/O module point density	4/6/8						
I/O module slots per base	1024 in/1024 out						
Local/local expansion	4224 max.						
Serial Remote I/O (including local &	3						
exp. I/O	512, 2048						
Remote I/O Channels	Yes,						
I/O pts. per remote module	8192 max.						
channel	(Including local and exp.						
Ethernet Remote I/O (including	1/0)						
local/exp. I/O)	Map into V-memory						
discrete I/O pts.	Limited by power budget						
	16,384 (16 fully expanded						
Analog I/O channels	H4-EBC Servers using						
Remote I/O channels	V-memory and bit-of-word						
I/O per remote channel	instructions)						
·	instructions)						
Destauran							
Performance	0.00						
Contact execution (boolean)	0.96 µs 4–5 ms						
Typical scan (1K boolean)	4–51115						
Programming and Diagnostics							
RLL ladder style	Yes						
RLL PLUS/flowchart style (Stages)	Yes/1024						
Run time editing	Yes						
Supports Overrides	Yes						
Variable/fixed scan	Fixed or variable						
Instructions	210						
Control relays	2048						
Timers	256						
Counters	256						
Immediate I/O	Yes						
Subroutines	Yes						
For/next loops	Yes						
Timed interrupt	Yes						
Integer math	Yes						
Floating-point math	Yes						
	Yes						
Trigonometric functions							
Trigonometric functions	Yes						
Table instructions	Yes						
Table instructions PID	Yes						
Table instructions PID Drum sequencers	Yes Yes						
Table instructions PID Drum sequencers Bit of word	Yes Yes Yes						
Table instructions PID Drum sequencers Bit of word Real-time clock/calendar	Yes Yes Yes Yes						
Table instructions PID Drum sequencers Bit of word Real-time clock/calendar Internal diagnostics	Yes Yes Yes Yes Yes						
Table instructions PID Drum sequencers Bit of word Real-time clock/calendar Internal diagnostics Password security	Yes Yes Yes Yes Multi-level						
Table instructions PID Drum sequencers Bit of word Real-time clock/calendar Internal diagnostics Password security System and User error log	Yes Yes Yes Yes Multi-level Yes						
Table instructions PID Drum sequencers Bit of word Real-time clock/calendar Internal diagnostics Password security System and User error log IBox instructions	Yes Yes Yes Yes Multi-level						
Table instructions PID Drum sequencers Bit of word Real-time clock/calendar Internal diagnostics Password security System and User error log IBox instructions CPU Ports Communications	Yes Yes Yes Yes Multi-level Yes Yes						
Table instructions PID Drum sequencers Bit of word Real-time clock/calendar Internal diagnostics Password security System and User error log IBox instructions CPU Ports Communications Built-in ports	Yes Yes Yes Yes Multi-level Yes Yes 4 ports						
Table instructions PID Drum sequencers Bit of word Real-time clock/calendar Internal diagnostics Password security System and User error log IBox instructions CPU Ports Communications Built-in ports K-sequence (proprietary protocol)	Yes Yes Yes Yes Multi-level Yes Yes 4 ports Yes						
Table instructions PID Drum sequencers Bit of word Real-time clock/calendar Internal diagnostics Password security System and User error log IBox instructions <b>CPU Ports Communications</b> Built-in ports K-sequence (proprietary protocol) DirectNET	Yes Yes Yes Yes Multi-level Yes Yes Yes 4 ports Yes Yes						
Table instructions PID Drum sequencers Bit of word Real-time clock/calendar Internal diagnostics Password security System and User error log IBox instructions <b>CPU Ports Communications</b> Built-in ports K-sequence (proprietary protocol) DirectNET Modbus Client/Server	Yes Yes Yes Yes Multi-level Yes Yes Yes Yes Yes Yes Yes						
Table instructions PID Drum sequencers Bit of word Real-time clock/calendar Internal diagnostics Password security System and User error log IBox instructions <b>CPU Ports Communications</b> Built-in ports K-sequence (proprietary protocol) DirectNET Modbus Client/Server ASCII out (Print)	Yes Yes Yes Yes Multi-level Yes Yes Yes Yes Yes Yes Yes						
Table instructions PID Drum sequencers Bit of word Real-time clock/calendar Internal diagnostics Password security System and User error log IBox instructions <b>CPU Ports Communications</b> Built-in ports K-sequence (proprietary protocol) DirectNET Modbus Client/Server	Yes Yes Yes Yes Multi-level Yes Yes Yes Yes Yes Yes Yes						

## **D4-454 Key Features**



#### D4-454 CPU\*

The D4-454 CPUs provides tremendous capability using updated microprocessor technology allowing the D4-454 to be the CPU of choice for the DL405 family.

#### Built-in CPU Communications Ports

The D4-454 offers four built-in ports for extra convenience. The 15-pin port offers our proprietary K-sequence protocol and is primarily used for programming connections to a PC running DirectSOFT6 programming software (version 6.1 or later) or to a D4-HPP-1 handheld programmer. It can also be used to connect to a *C-more* panel or other operator interfaces. The 6-pin phone jack supports K-sequence; DirectNET Client/ Server, ASCII output and Modbus RTU Client/Server protocols. The bottom 25pin port contains two logical ports with different pins for each port. It is primarily a networking port that supports DirectNET Client/Server or Modbus Client/Server protocols. The bottom port can be used as an ASCII output port for connections to devices that can accept ASCII input. It can also be used as a remote I/O Client. The Communications Ports table on the next page has a complete description of each port.

\* The D4-454 CPU is a direct replacement for the retired D4-450 CPU.

#### 16 PID Loops

The D4-454 CPU can process up to 16 PID loops directly in the CPU. You can select from various control modes including automatic control, manual control, and cascade control. There are a wide variety of alarms including Process Variable, Rate of Change, and Deviation. The various loop operation parameters are stored in V-memory, which allows easy access from operator interfaces. Setup is accomplished with our DirectSOFT6 Programming Software. An overview of the various loop specifications and features is on page tDL4-7.


### **Floating-point Math**

The D4-454 CPU supports IEEE format floating-point math calculations. This feature means the D4-454 includes full trigonometric functions and various forms of integer/floating point number conversions.

#### **Power Supplies**

We offer a choice of two built-in power supplies for the D4-454 CPUs. Available choices are an AC source or DC source:

- 110/220 VAC version D4-454
- 24VDC version D4-454DC-1




NOTE: Any hardware older than tens years old may not work with the <u>D4-454</u>. We suggest that any hardware older than ten years and not currently sold on the AutomationDirect.com website be upgraded to a newer version.

## **D4-454 Features**

The diagram on this page shows the various hardware features found on the D4-454 CPU.

RUN       Forces CPU to RUN mode. Locks Comm port- will not receive incoming data.         TERM       Allows peripherals (HPP, DCM, DirectSOFT, etc.) to select operating mode         STOP       Forces CPU out of RUN         CPU Status Indicators         PWR       ON       CPU power good OFF         ON       CPU power failure         RUN       ON       CPU is in STOP mode         CPU       ON       CPU self-diagnostics error         OFF       CPU battery is low       OFF         CPU battery is good or disabled       DIAG         DIAG       ON       CPU diagnostics or local bus error         OFF       CPU diagnostics or local bus error         OFF       CPU diagnostics or local bus good         I/O       ON       CPU diagnostics or local bus good         I/O       ON       DET is being transmitted         DAT       ON       Data is being transmitted         RXD       ON       Data is being transmitted         OFF       No data is being transmitted         OFF       No data is being transmitted         RXD       ON       Data is being transmitted         OFF       No data is being transmitted       DirectSOFT programming software, C-more panels, network, etc.         Phone </th <th></th> <th>CP</th> <th>U Keyswitch</th>		CP	U Keyswitch						
IteRW       etc.) to select operating mode         STOP       Forces CPU out of RUN         CPU Status Indicators         PWR       ON       CPU power good         OFF       CPU power failure         RUN       ON       CPU is in RUN mode         OFF       CPU is in STOP mode         CPU       ON       CPU self-diagnostics error         OFF       CPU self-diagnostics good         BATT       ON       CPU battery is good or disabled         DIAG       ON       CPU diagnostics or local bus error         OFF       CPU diagnostics or local bus good         I/O       ON       CPU diagnostics or local bus good         I/O       ON       Data is being transmitted         OFF       No data is being transmitted         RXD       ON       Data is being transmitted         RXD       ON       Data is being transmitted         Phone       DirectSOFT programming software, C-more         Jack       panels, network, etc. Supports K-sequence         Port 2       protocol, network, etc. Supports K-sequence         Port 3       Programming port, RS232, 9600 baud, connects to         DirectSOFT, DV-1000, C-more panels, network, etc       Supports K-sequence I/O Cilent available on Port 3 only.)	RUN								
CPU Status Indicators         PWR       ON       CPU power good         OFF       CPU power failure         RUN       ON       CPU is in RUN mode         OFF       CPU is in STOP mode         CPU       ON       CPU self-diagnostics error         OFF       CPU battery is low         OFF       CPU battery is good or disabled         DIAG       ON       CPU diagnostics or local bus error         OFF       CPU diagnostics or local bus good         I/O       ON       DOFF       CPU diagnostics or local bus good         I/O       ON       Data is being transmitted         OFF       No data is being transmitted         OFF       No data is being transmitted         OFF       No data is being transmitted         RXD       ON       Data is being transmitted         No FF       No data is being transmitted       No data is being transmitted         Phone       DirectSOFT programming software, C-more       panels, network, etc. Supports K-sequence panels, network, etc. Supports K-sequence protocol, DirectNET (Client or Server) protocol, Non-squence (ASCII out), and Modbus RTU (Client or Server) protocol.         Port 0       Etc.       K-sequence protocol (fixed station address=1)         Baud rate selectable via software up to 38.4K baud.	TERM								
PWR       ON       CPU power good CPU power failure         RUN       ON       CPU is in RUN mode OFF       CPU is in STOP mode         CPU       ON       CPU self-diagnostics error OFF       CPU self-diagnostics good         BATT       ON       CPU battery is low OFF       CPU battery is good or disabled         DIAG       ON       CPU battery is good or disabled         DIAG       ON       CPU diagnostics or local bus error CPU diagnostics or local bus good         I/O       ON       L/O self-diagnostics error U/O self-diagnostics good         I/O       ON       Data is being transmitted         OFF       No data is being transmitted         RXD       ON       Data is being transmitted         OFF       No data is being transmitted       Orrer         RXD       ON       Data is being transmitted         Phone       DirectSOFT programming software, C-more panels, network, etc. Supports K-sequence protocol, DirectNET (Client or Server) protocol, Non-squence (ASCII out), and Modbus RTU (Client or Server) protocol.         Port 2       Programming port, RS232, 9600 baud, connects to HPP, DirectSOFT, DV-1000, C-more panels, etc.         K-sequence protocol (fixed station address=1)       General purpose port for RS232 and RS422 (RS485 Remote I/O Client available on Port 3 only.)       Baud rate selectable via software up to 38.4K baud.	STOP	Forces (	, , , , , , , , , , , , , , , , , , , ,						
PWR       OFF       CPU power failure         RUN       ON       CPU is in RUN mode CPU is in STOP mode         CPU       ON       CPU self-diagnostics error OFF       CPU self-diagnostics good         BATT       ON       CPU battery is low OFF       CPU battery is good or disabled         DIAG       ON       CPU diagnostics or local bus error OFF       CPU diagnostics or local bus good         I/O       ON       L/D self-diagnostics good       I/O         I/O       ON       Data is being transmitted         OFF       No data is being transmitted       I/O         ON       Data is being transmitted       No data is being transmitted         RXD       ON       Data is being transmitted         OFF       No data is being transmitted       No data is being transmitted         Phone       DirectSOFT programming software, C-more panels, network, etc. Supports K-sequence protocol, DirectNET (Client or Server) protocol, Non-squence (ASCII out), and Modbus RTU (Client or Server) protocol.         15-pin       Programming port, RS232, 9600 baud, connects to HPP, DirectSOFT, C-more panels, etc.         K-sequence protocol (fixed station address=1)       General purpose port for RS232 and RS422 (RS485 Remote I/O Client available on Port 3 only.) Baud rate selectable via software up to 38.4K baud.         25-pin       General purpose port for RS232 and RS422 (RS485 Remot									
RUN       OFF       CPU is in STOP mode         CPU       ON       CPU self-diagnostics error         OFF       CPU battery is low       OFF       CPU battery is good or disabled         DIAG       ON       CPU battery is good or disabled         DIAG       ON       CPU battery is good or disabled         DIAG       ON       CPU diagnostics or local bus error         OFF       CPU diagnostics or local bus good         I/O       ON       I/O self-diagnostics error         OFF       I/O self-diagnostics good         TXD       ON       Data is being transmitted         OFF       No data is being transmitted         DirectSOFT programming software, C-more panels, network, etc.       Sequence         Port 2       protocol, DirectNET (Client or Server) protocol, Non-squence (ASCII out), and Modbus RTU (Client or Server) protocol.         15-pin       Port 0       K-sequence protocol (fixed station address=1)       General purpose port for RS232 and RS422 (RS485 Remote I/O Client available on Port 3 only.)       Baud rate se	PWR	-							
CPU       OFF       CPU self-diagnostics good         BATT       OFF       CPU battery is low         OFF       CPU battery is good or disabled         DIAG       ON       CPU diagnostics or local bus error         OFF       CPU diagnostics or local bus error         OFF       CPU diagnostics or local bus good         I/O       ON       I/O self-diagnostics error         OFF       I/O self-diagnostics good         TXD       ON       Data is being transmitted         OFF       No data is being transmitted         DirectSOFT programming software, C-more         panels, network, etc.       Sequence         Port 2       protocol, DirectNET (Client or Server) protocol,         Non-squence (ASCII out), and Modbus RTU       (Client or Server) protocol.         15-pin       Port 0       K-sequence protocol (fixe	RUN	-							
BATT       OFF       CPU battery is good or disabled         DIAG       OF       CPU battery is good or disabled         DIAG       OFF       CPU diagnostics or local bus error CPU diagnostics or local bus good         I/O       OFF       I/O self-diagnostics error OFF         OFF       No self-diagnostics good         TXD       ON       Data is being transmitted OFF         No data is being transmitted       OFF         OFF       No data is being transmitted         OFF       DirectSOFT programming software, C-more         panels, network, etc.       Sequence         Port 0       K-sequence protocol (fixed station address=1)         General purpose port for RS232 and RS422	CPU								
DIAG       OFF       CPU diagnostics or local bus good         I/O       ON       I/O self-diagnostics error         OFF       I/O self-diagnostics good         TXD       ON       Data is being transmitted         OFF       No data is being transmitted         OFF       No data is being transmitted         RXD       OFF       No data is being transmitted         OFF       No data is being transmitted         OFF       No data is being transmitted         Communications Ports       General purpose port for RS232. Baud rate is selectable up to 38.4Kb. Connects to         DirectSOFT programming software, C-more panels, network, etc.       Supports K-sequence protocol, DirectNET (Client or Server) protocol, Non-squence (ASCII out), and Modbus RTU (Client or Server) protocol.         15-pin       Programming port, RS232, 9600 baud, connects to HPP, DirectSOFT, DV-1000, C-more panels etc.         K-sequence protocol (fixed station address=1)       General purpose port for RS232 and RS422 (RS485 Remote I/O Client available on Port 3 only.)         Baud rate selectable via software up to 38.4K baud.       Connects to DirectSOFT, C-more panels, network, etc         Port 1       Two logical ports (separate pins on connector). Software selectable protocol includes: Protocol Port 1 Port 3 K-sequence 3 3         DirectNETCEIent/Server 3 3       Modbus Client/Server 3 3         Modbus Client/Server 3 3	BATT								
IVO       OFF       I/O self-diagnostics good         TXD       ON       Data is being transmitted         OFF       No data is being transmitted         Communications Ports       General purpose port for RS232. Baud rate is selectable up to 38.4Kb. Connects to DirectSOFT programming software, C-more panels, network, etc. Supports K-sequence protocol, DirectNET (Client or Server) protocol, Non-squence (ASCII out), and Modbus RTU (Client or Server) protocol.         15-pin       Programming port, RS232, 9600 baud, connects to HPP, DirectSOFT, DV-1000, C-more panels etc.         K-sequence protocol (fixed station address=1)       General purpose port for RS232 and RS422 (RS485 Remote I/O Client available on Port 3 only.)         Baud rate selectable via software up to 38.4K baud.       Connects to DirectSOFT, C-more panels, network, etc         Two logical ports (separate pins on connector). Software selectable protocol includes: Protocol       Prot 1 Port 3         Port 3       DirectNETClient/Server 3 3       A         Modbus Client/Server 3 3       Semore 3       A	DIAG								
IXD       OFF       No data is being transmitted         RXD       ON       Data is being transmitted         OFF       No data is being transmitted         OFF       No data is being transmitted         Communications Ports         General purpose port for RS232. Baud rate is selectable up to 38.4Kb. Connects to DirectSOFT programming software, C-more panels, network, etc. Supports K-sequence protocol, DirectNET (Client or Server) protocol, Non-squence (ASCII out), and Modbus RTU (Client or Server) protocol.         15-pin       Programming port, RS232, 9600 baud, connects to HPP, DirectSOFT, DV-1000, C-more panels etc.         K-sequence protocol (fixed station address=1)       General purpose port for RS232 and RS422 (RS485 Remote I/O Client available on Port 3 only.)         Baud rate selectable via software up to 38.4K baud.       Connects to DirectSOFT, C-more panels, network, etc         Port 1       Two logical ports (separate pins on connector). Software selectable protocol includes: Protocol Port 1 Port 3         Port 3       DirectNETClient/Server 3 3       Modbus Client/Server 3 3	1/0								
RXD       OFF       No data is being transmitted         Communications Ports         General purpose port for RS232. Baud rate is selectable up to 38.4Kb. Connects to DirectSOFT programming software, C-more panels, network, etc. Supports K-sequence protocol, DirectNET (Client or Server) protocol, Non-squence (ASCII out), and Modbus RTU (Client or Server) protocol.         15-pin       Programming port, RS232, 9600 baud, connects to HPP, DirectSOFT, DV-1000, C-more panels etc.         K-sequence protocol (fixed station address=1)       General purpose port for RS232 and RS422 (RS485 Remote I/O Client available on Port 3 only.)         Baud rate selectable via software up to 38.4K baud.       Connects to DirectSOFT, C-more panels, network, etc         Two logical ports (separate pins on connector). Software selectable protocol includes: Protocol       Port 3         Port 3       DirectNETClient/Server 3       3         Modbus Client/Server 3       3         Remote I/O n/a       3	ΤΧΟ	ON Data is being transmitted							
Phone       General purpose port for RS232. Baud rate         is selectable up to 38.4Kb. Connects to       DirectSOFT programming software, C-more         pack       panels, network, etc. Supports K-sequence         Port 2       protocol, DirectNET (Client or Server) protocol,         Non-squence (ASCII out), and Modbus RTU       (Client or Server) protocol.         15-pin       Programming port, RS232, 9600 baud, connects         to HPP, DirectSOFT, DV-1000, C-more panels       etc.         K-sequence protocol (fixed station address=1)       General purpose port for RS232 and RS422         (RS485 Remote I/O Client available on Port 3 only.)       Baud rate selectable via software up to 38.4K baud.         Connects to DirectSOFT, C-more panels, network, etc       Two logical ports (separate pins on connector).         Software selectable protocol includes:       Protocol         Port 3       DirectNETClient/Server 3       3         Modbus Client/Server 3       3	RXD	Data to boing a direction							
Phone Jack       is selectable up to 38.4Kb. Connects to DirectSOFT programming software, C-more panels, network, etc. Supports K-sequence protocol, DirectNET (Client or Server) protocol, Non-squence (ASCII out), and Modbus RTU (Client or Server) protocol.         15-pin Port 0       Programming port, RS232, 9600 baud, connects to HPP, DirectSOFT, DV-1000, C-more panels etc.         K-sequence protocol (fixed station address=1)         General purpose port for RS232 and RS422 (RS485 Remote I/O Client available on Port 3 only.)         Baud rate selectable via software up to 38.4K baud.         Connects to DirectSOFT, C-more panels, network,etc         Two logical ports (separate pins on connector).         Software selectable protocol includes: Protocol         Prot 1 and Port 3         DirectNETClient/Server 3       3 Modbus Client/Server 3		Con	nmunications Ports						
15-pin Port 0       to HPP, DirectSOFT, DV-1000, C-more panels etc.         K-sequence protocol (fixed station address=1)         General purpose port for RS232 and RS422 (RS485 Remote I/O Client available on Port 3 only.)         Baud rate selectable via software up to 38.4K baud.         Connects to DirectSOFT, C-more panels, network,etc         Two logical ports (separate pins on connector).         Software selectable protocol includes: Protocol         Port 3         DirectNETClient/Server 3         A         Modbus Client/Server 3         A	Jack	is select DirectS0 panels, protocol Non-squ	able up to 38.4Kb. Connects to DFT programming software, <b>C-more</b> network, etc. Supports K-sequence , DirectNET (Client or Server) protocol, uence (ASCII out), and Modbus RTU						
<ul> <li>(RS485 Remote I/O Client available on Port 3 only.) Baud rate selectable via software up to 38.4K baud.</li> <li>Connects to DirectSOFT, <i>C-more</i> panels, network,etc Two logical ports (separate pins on connector). Software selectable protocol includes: Protocol Port 1 Port 3 K-sequence 3 3 DirectNETClient/Server 3 3 Modbus Client/Server 3 3 Remote I/O n/a 3</li> </ul>		Program to HPP, etc.	nming port, RS232, 9600 baud, connects DirectSOFT, DV-1000, <i>C-more</i> panels,						
	Port 1 and	(RS485 only.) Baud ra baud. Conneci network Two logi Softward Protocol K-seque DirectNf Modbus Remote	Remote I/O Client available on Port 3 te selectable via software up to 38.4K ts to DirectSOFT, <i>C-more</i> panels, ,etc ical ports (separate pins on connector). e selectable protocol includes: I Port 1 Port 3 ence 3 3 ETClient/Server 3 3 Client/Server 3 3 I/O n/a 3						


#### **D4-454 CPU Hardware Features**



### D4-454 communications ports pin-out


#### Phone jack


#### 15-pin connector




Port 2

#### 25-pin connector







## **D4-454 Features**

#### D4-454 Scan control

The <u>D4-454</u> CPU provides several scan control options, which are useful in some high-speed machine control applications.

Variable — The scan varies as necessary from scan to scan. The actual scan time depends on the instructions being executed.

Limited — This is similar to a variable scan in that the scan varies as necessary. However, if the actual scan time exceeds a specified target scan time, then a scan overrun condition is indicated.

Fixed — If the scan is finished before the time specified, idle time is added to ensure a fixed scan period. If the scan exceeds the time specified, the scan is extended to ensure all instructions are executed. A scan overrun condition is also reported.


Memory — The memory of the D4-454 is fully contained in the CPU and stored in MRAM which is a non-volatile form of memory. No memory card is required. The battery is used for retention of the Real Time Clock.

#### Full array of instructions

Imagine if someone asked you to write a book, but then told you that you could only use 50 different words? That would be a tough job! The same is true for writing a PLC program. The right instruction can greatly simplify your control program.


The D4-454 supports over 200 powerful instructions. These include:

- Four types of drum sequencers, each with 16 steps and up to 16 outputs
- Leading and trailing edge triggered oneshots
- Bit of word manipulation (bit set, reset, etc.)
- Trigonometric functions
- Floating point conversions
- Ibox instructions that simplify tasks such as configuring analog modules or performing complex math equations



DirectSOFT 6.1 or later, is required to program the D4-454.






## D4-454 PID loops

	PID Loop Specifications and Key Features
Number of Loops	Selectable, 16 maximum
CPU V-memory Required	32 V-memory locations per loop selected (An additional 32 V-memory locations per loop required if using Ramp/Soak)
PID Algorithm	Position or velocity form of the PID equation. Optionally specify direct or reverse acting, square root of the error and error squared control.
Auto Tuning	Open loop step response method and closed loop limit cycle method.
Sample Rate	Specify the time interval between PV samples, 0.05 to 99.99 in units of seconds or minutes. If using all 16 loops, the smallest sample rate is limited to either 0.2 seconds or (PLC scan time x number of loops).
Loop Operation Modes	Loop can be in automatic control, manual (operator) control, or cascade control. PV alarm monitoring continues when loops are in manual mode.
Ramp/Soak	Up to 16 steps (8 ramp, 8 soak) per loop, with indication of Ramp/Soak step.
Square Root PV	Specify a square root of the PV for a flow control application.
Limit SP	Specify a maximum and minimum value for allowable setpoint changes.
Limit OUT	Specify a maximum and minimum value for the output range.
Gain	Specify proportional gain of 0.01 to 99.99.
Reset	Specify integral time of 0.1 to 99.98 in units of seconds or minutes.
Rate	Specify the derivative time, 0.00 to 99.99 seconds.
Rate Limiting	Specify a derivative gain limiting coefficient to filter the PV used in calculating the derivative term (0 to 20).
Bumpless Transfer I	Bias and setpoint are initialized automatically when the loop is switched from manual to automatic. This provides for a bumpless transfer, which reduces the chance of sharp changes in the output as a result of entering automatic mode.
Bumpless Transfer II	Bias is set equal to the Output when the module is switched from manual to automatic. This allows switching in and out of automatic mode without having to re-enter the setpoint.
Step Bias	Provides proportional bias adjustment for large setpoint changes. This may stabilize the loop faster and reduce the chance of the output going out of range. Step bias should be used in conjunction with the normal adjusted bias operation.
Anti-windup	If the position form of the PID equation is specified, the reset action is stopped when the PID output reaches 0 or 100%. Select adjusted bias or freeze bias operation.
Error Deadband	Specify an incremental value above and below the setpoint in which no change in output is made.
Error Squared	Squaring the error minimizes the effect a small error has on the Loop output, however, both Error Squared and Error Deadband control may be enabled.
Alarm Specifications	
Deadband	Specify 0.1% to 5% alarm deadband on all alarms except Rate of Change.
PV Alarm Points	Specify PV alarm settings for low-low, low, high, and high-high conditions. You can also specify a deadband to minimize the alarm cycles when the PV approaches alarm limits.
PV Deviation	Specify alarms to indicate two ranges of PV deviation from the setpoint value (yellow and red deviation).
Rate of Change	Specify a rate-of-change limit for the PV.
Need Temperature Control	

Need Temperature Control?

If you're only interested in controlling temperature, then there may be a better solution than the <u>D4-454</u> CPU. Check out the <u>F4-4LTC</u> module. This module has the capabilities of our single loop controllers built into one economical module! Detailed specifications can be found later in this section. This module can directly control up to four loops and it even includes built-in relay outputs for heater or chiller control! If you use the built-in PID capability of the D4-454 CPU, you still have to purchase the analog input modules and the output modules (either discrete or analog) in order to complete the loop.

This can result in a much higher overall cost when compared to the F4-4LTC.



## **DL405 Programming Tools and Cables**

#### Select a programming device

There are two tools for programming the DL405 CPUs: DirectSOFT PC-based programming software and the <u>D4-HPP-1</u> handheld programmer.

#### DirectSOFT programming software

Our powerful Windows-based programming packages make it easy for you to program and monitor your DL405 PLC system. The version of the software that supports the DL405 CPUs is described in the table below. See the DirectLOGIC Overview Section DL in this catalog for detailed information on DirectSOFT.

Direct Soft Part Number	Price	Description				
<u>D4-HPP-1</u>	Retired	Handheld Programmer				
<u>PC-DSOFT6</u>	\$462.00	Programs all PLC families DL05/06/105/205/305/405				
<u>PC-DS100</u>	Free	Free version of DirectSOFT; programs all DirectLOGIC PLC CPUs; limited to 100 word program				

#### DL405 programming cables


Choose the proper cable to connect the DL405 CPU to your PC running DirectSOFT.

CPU	Price	Port	Cable	Price
	- <u>454</u> \$1,026.00	Top port (15 pin)	D4-DSCBL	\$85.00
<u>D4-454</u>		Lower port (25pin)	D3-DSCBL-2	\$77.00
		Phone jack (RJ12)	D2-DSCBL	\$41.50


#### Handheld programmer


The <u>D4-HPP-1</u> handheld programmer connects to the 15-pin port on any of the DL405 CPUs. A memory cartridge is located on the side of the handheld programmer. This slot allows you to copy memory cartridges (including UV PROMs) and transfer data/programs between the CPU and a memory cartridge.

Direct4	5HPP 🗄	IANDHELD	PROGRA	MMER	0					1
Оте	□ RUN □ TEST □ POM ■ 1 I I I I I I I I I I I I I I I I I I									
STR			ŝĜ	ADD			1		BIT ST	
AND	MLS			SUB	PNTR	S(SG)	7	8	9 9	
				P≊∘	Z(SPD)		E(H) 4	F(H) 5	ů	
ОЛТ		SR	BCD	⊢¥[]	C(CR)	ASC	B(H)	C(H) 2	D(H) 3	NXT
Ľ	RST.			ž	GX M	YOUT	A(H)		SHFT	
D4-HF	P-1				Ø					Koyo



#### Pin labeling conforms to IBM DTE and DCE standards





#### 9-pin D–Connector (female)

