


Enclosure Accessories – Adapter Plates for Disconnect Enclosures



Operator Adapter Plates

An operator adapter plate is required to install a disconnect in all Wiegmann WA series enclosures with a universal flange cutout. Operator adapters include an adapter plate and additional parts used to interlock the enclosure door with the disconnect operating mechanism. Panel drilling and installation instructions are furnished with each adapter. Each brand and type of disconnect requires a different operator adapter. It is important to select the proper operator adapter and enclosure for the disconnect that you have selected.



Operator Adapter Plates			
Part Number	Price	Description	Wt. [lb]
<u>WA21CHVA</u>	\$167.00	Wiegmann operator adapter plate, for use with Eaton/Cutler Hammer flange mounted handle mechanisms type C371, Eaton Flex-Shaft F0S03C, F1S03/06C F3S03C, F4S04C, and ABB Controls disconnects	2
<u>WA21FUFA</u>	\$142.00	Wiegmann operator adapter plate, for use with Fuji Electric BW9F series disconnects	3
<u>WA21SDA</u>	\$167.00	Wiegmann operator adapter plate, for use with Socomec 37299002 and 37299003 disconnect handles. Also fits Schneider Square D Class 9422 disconnect handles.	2

Blank Adapter Plates

These adapter plates are used to cover flange cutouts in disconnect enclosures when disconnects are not installed. This greatly increases the versatility of the disconnect enclosures, enabling them to also be used as regular 12 enclosures.

Wiegmann blank adapter plates are made from heavy gauge steel, with oil-resistant gasket to maintain the dust-tight and oil-tight qualities of the enclosure. All blank adapter plates are painted ANSI 61 gray polyester powder. All necessary mounting hardware and instructions are included.



Blank Adapter Plates			
Part Number	Price	Description	Wt. [lb]
<u>WA22BAP</u>	Retired	Wiegmann blank adapter plate. For use with ABN12 disconnect enclosures. Includes mounting hardware.	2
<u>WA3456BAP</u>	\$142.00	Wiegmann blank adapter plate. For use with all Wiegmann wall-mount disconnect enclosures except ABN12 models and all Wiegmann stainless steel floor-mount and freestanding disconnect enclosures. Includes mounting hardware.	2