DURAPULSE GS10 AC Drives – Introduction





| DURAPULSE GS10 AC Drives | | | | | | | | | |
|--------------------------|---------|-----|-----|----------|-----|-----|-----|-----|-----|
| Motor Rating | HP | 1/4 | 1/2 | 1 | 2 | 3 | 5 | 7.5 | 10 |
| Mului Hallily | kW | 0.2 | 0.4 | 0.75 | 1.5 | 2.2 | 3.7 | 5.5 | 7.5 |
| 120V Single-phase | | ✓ | ✓ | ✓ | | | | | |
| 230V Single-phase | | ✓ | ✓ | ✓ | ✓ | ✓ | | | |
| 230V Three-phase | | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | ✓ | |
| 460V Three-phase | | ✓ | ✓ | √ | ✓ | ✓ | ✓ | ✓ | |
| √ = GS10 model av | ailable | | | | | | | | |

Overview

The DURAPulse GS10 new generation of Micro drives with vector control provides many standard and advanced functions—all in a compact size and cost effective price.

The drives include many of the same standard features as our GS family of drives including dynamic braking, PID, and RS-485 Modbus communication.

The GS10 drive includes 230VAC models for 1-phase or 3-phase applications. The drive supports parameter sets for up to two (2) independent induction AC motors (IM) or a single permanent magnet AC motor(PM).

DURApulse GS10 AC drives offers two control modes: standard V/Hz and sensorless vector (SVC) for IM or PM motors..

DURApulse GS10 provides one analog input, one analog output, five digital inputs (including one pulse train input up to 10kHz), one digital output, and one SPDT relay output. All of the analog and digital I/O can be configured for a wide variety of input or output functions.

The drive parameter set also includes function groups to provide multipump control, automatic operation programming, and simple positioning stop.

Features

- Broad offering from 1/4 to 10 hp
- Single-phase 120VAC up to 1hp
- Single-phase 230VAC up to 3hp
- Three-phase 230VAC up to 7.5 hp (also 1-phase capable with derating, see selection tables)
- Three-phase 460VAC up to 10hp
- Dual rating design CT/VT Ratings (Normal & Heavy Duty)
- "Zero Stack" side-by-side zero gap installation
- Compact Design
- Spring clamp terminal blocks
- · Speed control potentiometer built in
- Flexible carrier frequency to 15khz and output frequency to 599Hz
- Free downloadable software for drive configuration
- Field-upgradable drive firmware
- Optional LCD text-based advanced keypad (IP66/NEMA 1) can be remotely mounted
- Local/Remote control mode selection or digital/comm input with Hand/Off/Auto control
- · Display custom values on keypad
- Momentary power loss restarts
- 100kA Short Circuit Current Rating
- DC Bus Connection Terminals (except 120VAC models)
- Conduit Box(s) for NEMA 1
- Analog I/O configurable 1 Input/1 Output
- Multi-Motor Control (2 total)
- PID Controller including sleep and wake
- Built-in functions include multi-pump control, auto sequence, and simple position stop
- Password protection
- RTD and/or PTC input motor protection
- Modular Cooling Fan with quick disconnect for easy replacement
- High speed communication interfaces with MODBUS RTU built in
- Circuit boards have conformal coating for improved environmental tolerance
- Excellent heat-sink design; able to operate at 50°C ambient temperature
- Fire Mode Run fire mode during emergencies to have uninterrupted smoke removal and system pressure
- Two-year warranty
- CE, UL, cUL

Accessories

- · AC line reactors
- EMI filters
- Braking resistors
- Fuses
- · Conduit boxes
- · Mounting Kits
- Replacement cooling fans
- Optional advanced LCD keypad (and remote-mount bezel kit)
- · GSoft2 drive configuration software
- USB-485M USB to Serial Converter (needed for software connection)
- Detailed descriptions and specifications for GS accessories are available in the "GS/ DURApulse Accessories" section.

Typical Applications

- Conveyors
- Compressors
- Material handling
- Extruding
- Grinding
- · Shop tools
- Fans
- Pumps
- HVAC
- Mixing

Selecting the Proper Drive Rating

Selecting the Proper Drive Rating

Determine Motor Voltage and Full-Load Amperage (FLA)

Motor voltage and FLA are located on the nameplate of the motor. NOTE: FLA of motors that have been rewound may be higher than stated.

Determine Motor Overload Requirements

Many applications experience temporary overload conditions due to starting requirements or impact loading. Most AC drives are designed to operate at 150% overload for 60 seconds. If the application requires an overload greater than 150% or longer than 60 seconds, the AC drive must be oversized.

NOTE: Applications that require replacement of existing motor starters with AC drives may require up to 600% overload.

Determine Application Type: Constant Torque or Variable Torque

This torque requirement has a direct effect on which drive to select. Variable Torque applications are generally easier to start; typically fans and pumps. Most other applications outside fans and pumps fall into the Constant Torque category (machine control, conveyors, etc.). If you are unsure of the application, assume Constant Torque. The specification, derating, and selection tables are generally segregated by Constant Torque and Variable Torque.


Installation Altitude

AC drives rely on air flow for cooling. As the altitude increases, the air becomes less dense, and this drop in air density decreases the cooling properties of the air. Therefore, the AC drive must be oversized to compensate for the decrease in cooling. GS10 drives are designed to operate at 100% capacity at altitudes up to 1000 meters.

NOTE: For use above 1000m, the AC drive must be derated as described below.

Derate Output Current Based on Altitude Above 1000 Meters

- If the AC drive is installed at an altitude of 0–1000m, follow normal operation restrictions.
- If installed at an altitude of 1000–2000m, decrease 1% of the rated current or lower 0.5°C of temperature for every 100m increase in altitude.
- · Maximum altitude for Corner Grounded is 2000m. If installation at an altitude higher than 2000m is required, please contact AutomationDirect.



Selecting the Proper Drive Rating, continued


Determine Maximum Enclosure Internal Temperature


AC drives generate a significant amount of heat and can cause the internal temperature of an enclosure to exceed the rating of the GS10 drive, even when the ambient temperature is less than 104°F (40°C). Enclosure ventilation and/or cooling may be required to reduce maximum internal temperature to 104°F (40°C) or less. Ambient temperature measurements/calculations should be made for the maximum expected temperature.

NOTE: For use above 104°F (40°C), the AC drive must be derated as described below.

Derate Output Current Based on Temperature Above 104°F (40°C) or 122°F (50°C)

| | Drive Derating by Temperature and Protection Level | | | | | | |
|-------------------------|---|--|--|--|--|--|--|
| Protection Level | Derating | | | | | | |
| UL Open Type / IP20* | If the GS10 drive operates at the rated current, the ambient temperature needs to be between -20–50°C. If the temperature is above 50°C, decrease 2.5% of the rated current for every 1°C increase in temperature. The maximum allowable temperature is 60°C. | | | | | | |
| NEMA 1 / UL Type 1* | When the GS10 drive is operating at the rated current, the ambient temperature must be between -20–40°C. When the temperature is over 40 °C, for every increase by 1°C, decrease the rated current 2.5%. The maximum allowable temperature is 60°C. | | | | | | |





Selecting the Proper Drive Rating, continued

Derate Output Current Based on Carrier Frequency (if necessary)

Carrier Frequency Effects

AC Drives rectify the incoming 50 or 60Hz line power resulting in DC power at 0Hz. The resulting DC power is then pulse-width modulated and supplied to the motor by the drive's power electronics. IGBTs invert the DC power, simulating a sine wave at the desired frequency (that's what allows variable speed in AC induction motors). The speed at which the IGBTs are turned ON and OFF is called Carrier Frequency. In GS10 drives, the Carrier Frequency can range from 2kHz to 15kHz. Though Carrier Frequency can be adjusted, there are trade-offs between high Carrier Frequencies and low Carrier Frequencies.

Benefits of Higher Carrier Frequencies:

- · Better efficiency (lower harmonic losses) in the motor
- · Lower audible noise

Benefits of Lower Carrier Frequencies:

- · Better efficiency in the drive
- · Lower EMI (electrical noise)
- Reduced reflective wave peak voltage

As a general rule, the Carrier Frequency should be set as low as possible without creating unacceptable audible noise in the motor. Smaller systems can have higher Carrier Frequencies, but larger drives (>20 or 30hp) should not have Carrier Frequencies set higher than 6kHz. Heavy duty applications typically run around 2–4 kHz.

Derating Tables

The tables below show the derating curves for GS10 drives running in two different modes under variable torque and constant torque conditions.

Line 1: Ta = 50°C / Load = 100%

Line 2: Ta = 50°C / Load = 75% or Ta = 40°C / Load = 100%


Line 3: Ta = 50°C / Load = 50% or Ta = 35°C / Load = 100%


Set PWM mode via P11.41.

SVPWM = Space Vector Pulse Width Modulation mode


DPWM = Two Phase Pulse Width Modulation mode


Variable Torque Carrier Frequency Derating





Constant Torque Carrier Frequency Derating





DURAPULSE GS10 AC Drives – Selection SpecificationsGS10 Drive Model Selection Tables

| | GS10 <u>120V^{1,4} 1-Phase Specifications – Frame Sizes A, C</u> | | | | | | | | |
|---------------------------|--|--------------------------------|-----|------------------|--------------------------------------|-------------------|--|--|--|
| Mod | el Nai | | | GS11N-10P2 | <u>GS11N-10P5</u> | <u>GS11N-11P0</u> | | | |
| Price | ; | | | \$127.00 | \$135.00 | \$151.00 | | | |
| Fran | ie Siz | е | | A | A | С | | | |
| Dime | ension | nal Drawing | | <u>PDF</u> | <u>PDF</u> | <u>PDF</u> | | | |
| | May | Motor Output | hp | 1/4 | 1/2 | 1 | | | |
| | IVIAA | motor output | kW | 0.2 | 0.4 | 0.75 | | | |
| ing | | Rated Output Capacity | kVA | 0.6 | 1.0 | 1.8 | | | |
| Output Rating | CT | Rated Output Current | A | 1.6 | 2.5 | 4.8 | | | |
| put | | Carrier Frequency ³ | kHz | 2–15 (default 4) | | | | | |
| mo | Rated Output Capacity | | kVA | 0.7 | 1.0 | 2.1 | | | |
| | VT | Rated Output Current | A | 1.8 | 2.7 | 5.5 | | | |
| | | Carrier Frequency ³ | kHz | | 2–15 (default 4) | | | | |
| 2 | CT | Rated Input Current | Α | 6 | 9.4 | 18 | | | |
| Input Rating ² | VT | Rated Input Current | Α | 6.8 | 10.1 | 20.6 | | | |
| Ra | Rate | d Voltage/Frequency | | One-pl | hase: 100–120 VAC (-15% to +10%), 50 | /60 Hz | | | |
| indu | 0pei | rating Voltage Range (VAC) | | | 85–132 | | | | |
| | Freq | uency Tolerance (Hz) | | | 47–63 | | | | |
| IE2 E | fficie | ncy - Relative Power Loss | | 4.3% | 3.2% | 2.9% | | | |
| Weig | iht (k | g [lb]) | | 0.4 [0.88] | 0.5 [1.10] | 1 [2.20] | | | |
| Cool | ing M | ethod | | Convective Fan | | | | | |
| IP Ra | ating | | | | IP20 | | | | |

^{1 -} For Use With Three-Phase Motors Only.

^{4 -} No DC bus connection terminals (DC+,DC-) are provided on 120V models.

| | | GS10 2 | <u> 230V</u> | ¹ 1-Phase Sp | ecifications – | Frame Sizes | A, B, C | |
|---------------------------|--------|--------------------------------|--------------|-------------------------|----------------|------------------------|--------------|------------|
| Mod | el Nai | | | GS11N-20P2 | GS11N-20P5 | GS11N-21P0 | GS11N-22P0 | GS11N-23P0 |
| Price | , | | | \$119.00 | \$121.00 | \$131.00 | \$167.00 | \$198.00 |
| Frame Size A A B C | | | С | С | | | | |
| Dime | ensio | nal Drawing | | PDF | PDF | PDF | PDF | PDF |
| | May | Motor Output | hp | 1/4 | 1/2 | 1 | 2 | 3 |
| | IVIAX | тогог оиграг | kW | 0.2 | 0.4 | 0.75 | 1.5 | 2.2 |
| ing | | Rated Output Capacity | kVA | 0.6 | 1.1 | 1.8 | 2.9 | 4.2 |
| Output Rating | CT | Rated Output Current | Α | 1.6 | 2.8 | 4.8 | 7.5 | 11 |
| tput | | Carrier Frequency ³ | kHz | | | 2–15 (default 4) | | |
| 00 | | Rated Output Capacity | kVA | 0.7 | 1.2 | 1.9 | 3.2 | 4.8 |
| | VT | Rated Output Current | Α | 1.8 | 3.2 | 5 | 8.5 | 12.5 |
| | | Carrier Frequency ³ | kHz | | | 2-15 (default 4) | | |
| 2 | CT | Rated Input Current | Α | 5.1 | 7.3 | 10.8 | 16.5 | 24.2 |
| ting | VT | Rated Input Current | Α | 5.8 | 8.3 | 11.3 | 18.5 | 27.5 |
| t Ra | Rate | d Voltage/Frequency | | | One-phase 2 | 00-240 VAC (-15% to +1 | 0%) 50/60 Hz | |
| Input Rating ² | 0pe | rating Voltage Range (VAC) | | | | 170–265 | | |
| 7 | Freq | uency Tolerance (Hz) | | | | 47–63 | | |
| IE2 E | fficie | ncy - Relative Power Loss | | 4.7% | 3.1% | 2.7% | 2.5% | 2.4% |
| Weig | jht (k | g [lb]) | | 0.4 [0.88] | 0.5 [1.10] | 0.8 [1.76] | 1 [2.20] | 1 [2.20] |
| Cool | ing M | lethod | | | Conv | ective | | Fan |
| IP R | ating | | | | | IP20 | | |
| | | With Three Dhase Meters Only | | | | | | <u> </u> |

^{1 -} For Use With Three-Phase Motors Only.

^{2 -} If 3-phase power source is non-symmetrical, refer to "Circuit Connections - RFI Jumper" in the GS10 AC Drives User Manual, Chapter 2. Please refer to "GS10 DURApulse Accessories – Fusing" (pg.tGSX-75) for input fusing information.

^{3 -} The carrier frequency value is a factory default. Decrease the current value if you need to increase the carrier frequency. Refer to "Derate Output Current Based on Carrier Frequency".

^{2 -} If 3-phase power source is non-symmetrical, refer to "Circuit Connections - RFI Jumper" in the GS10 AC Drives User Manual, Chapter 2. Please refer to "GS10 DURApulse Accessories - Fusing" (pg.tGSX-75) for input fusing information.

^{3 -} The carrier frequency value is a factory default. Decrease the current value if you need to increase the carrier frequency. Refer to "Derate Output Current Based on Carrier Frequency".

Specifications
GS10 Drive Model Selection Tables, continued

| | | GS10 | 230 | V ¹ 3-Phase Spec | ifications – Fram | e Sizes A, B | | |
|---------------------------|--|--|------------|-----------------------------|------------------------------|------------------------------|-------------------|--|
| Mode | el Nar | ne | | GS13N-20P2 | <u>GS13N-20P5</u> | GS13N-21P0 | <u>GS13N-22P0</u> | |
| Price | Price \$127.00 \$129.00 \$142.00 \$17 | | | | | \$170.00 | | |
| Fran | me Size A A A | | | | | В | | |
| Dime | ension | al Drawing | | <u>PDF</u> | <u>PDF</u> | <u>PDF</u> | <u>PDF</u> | |
| | | Motor Output | hp | 0.25 [0.1] | 0.5 [0.25] | 1 [0.5] | 2 [1] | |
| | (3-pl | hase [1-phase]) ⁴ | kW | 0.2 [0.1] | 0.4 [0.2] | 0.75 [0.375] | 1.5 [0.75] | |
| ing | | Rated Output Capacity (3-phase [1-phase]) | kVA | 0.6 [0.3] | 1.1 [0.55] | 1.8 [0.9] | 2.9 [1.5] | |
| Output Rating | СТ | Rated Output Current (3-phase [1-phase]) | | 1.6 [0.8] | 2.8 [1.4] | 4.8 [2.4] | 7.5 [3.75] | |
| Outp | Carrier Frequency ³ kHz | | | 2–15 (default 4) | | | | |
| | | Rated Output Capacity | | 0.7 | 1.2 | 1.9 | 3.0 | |
| | VT Rated Output Current | | Α | 1.8 3.0 5.0 | | 5.0 | 8.0 | |
| | | Carrier Frequency ³ | kHz | | 2–15 (default 4) | | | |
| 12 | CT | Rated Input Current | Α | 1.9 | 3.4 | 5.8 | 9.0 | |
| Input Rating ² | VT | Rated Input Current | Α | 2.2 | 3.8 | 6.0 | 9.6 | |
| t Ra | Rate | d Voltage/Frequency | | 3 | 3-phase or 1-phase 200-240 \ | /AC (-15% to +10%), 50/60 Hz | Z | |
| ndu | 0per | ating Voltage Range (VAC) | | | 170- | -265 | | |
| 7 | Freq | uency Tolerance (Hz) | | | 47- | -63 | | |
| IE2 E | fficie | ncy - Relative Power Loss | | 4.7% | 3.1% | 2.7% | 2.4% | |
| Weig | ht (kg | j [lb]) | | 0.4 [0.88] | 0.5 [1.10] | 0.6 [1.32] | 0.8 [1.76] | |
| Cool | ing M | ethod | | | Convective | | Fan | |
| IP Ra | nting | | | | IP | 20 | | |
| See ta | ble be | low for notes. | | | | | | |

| GS10 <u>230V</u> ¹ 3-Phase Specifications – Frame Sizes C, D | | | | | | | | | |
|---|--------------------------------|--|-----|------------|------------------------------------|-------------------|-----------|--|--|
| Mode | el Nar | пе | | GS13N-23P0 | <u>GS13N-25P0</u> | <u>GS13N-27P5</u> | | | |
| Price |) | | | \$209.00 | \$209.00 \$222.00 | | | | |
| Fram | ie Sizi | e | | С | С | D | | | |
| Dime | ension | nal Drawing | | <u>PDF</u> | <u>PDF</u> | <u>PDF</u> | | | |
| | Мах | Motor Output | hp | 3 [1.5] | 5 [2.5] | 7.5 [3.5] | | | |
| | (3-pl | hase [1-phase]) ⁴ | kW | 2.2 [1.1] | 3.7 [1.85] | 5.5 [2.75] | | | |
| ing | | Rated Output Capacity (3-phase [1-phase]) | kVA | 4.2 [2.1] | 6.5 [3.25] | 9.5 [4.75] | | | |
| Output Rating | СТ | | | | 11 [5.5] 17 [8.5] | | 25 [12.5] | | |
| Outp | Carrier Frequency ³ | | kHz | | | | | | |
| | | Rated Output Capacity | kVA | 4.8 | 7.4 | 10.3 | | | |
| | VT | | | 12.5 | 19.5 | 27 | | | |
| | | Carrier Frequency ³ | kHz | | 2–15 (default 4) | | | | |
| 2 | CT | Rated Input Current | A | 13.2 | 20.4 | 30 | | | |
| ting | VT | Rated Input Current | A | 15 | 23.4 | 32.4 | | | |
| Input Rating ² | Rate | d Voltage/Frequency | | 3-phase of | 1-phase 200–240 VAC (-15% to +10%) |), 50/60 Hz | | | |
| ndu | Oper | rating Voltage Range (VAC) | | | 170–265 | | | | |
| 1 | Freq | uency Tolerance (Hz) | | | 47-63 | | | | |
| IE2 E | fficie | ncy - Relative Power Loss | | 2.4% | 2.2% | 2.3% | | | |
| Weig | ht (kg | g [lb]) | | 1 [2.20] | 1 [2.20] 1 [2.20] 2 [4.41] | | | | |
| Cool | ing M | ethod | | | Fan | | | | |
| IP Ra | ating | | | | IP20 | | | | |

^{1 -} For Use With Three-Phase Motors Only.

^{2 -} If 3-phase power source is non-symmetrical, refer to "Circuit Connections - RFI Jumper" in the GS10 AC Drives User Manual, Chapter 2. Please refer to "GS10 DURApulse Accessories – Fusing" (pg.tGSX-75) for input fusing information.

^{3 -} The carrier frequency value is a factory default. Decrease the current value if you need to increase the carrier frequency. Refer to "Derate Output Current Based on Carrier Frequency".

^{4 -} Three phase models can be powered with 1-phase or 3-phase input power. If using 1-phase input power, GS11 models up to 3HP provide higher output power than equivalent GS13 models with 1-phase.

DURAPULSE GS10 AC Drives – Selection Specifications

GS10 Drive Model Selection Tables, continued

| | GS10 <u>460V</u> ¹ 3-Phase Specifications – Frame Sizes A, B | | | | | | | | |
|---------------------------|---|--------------------------------|-----|------------|---------------------------------------|-------------------|--|--|--|
| Mode | el Nai | те | | GS13N-40P5 | <u>GS13N-41P0</u> | <u>GS13N-42P0</u> | | | |
| Price | | | | \$156.00 | \$157.00 | \$181.00 | | | |
| Fram | e Siz | е | | A | A | В | | | |
| Dime | nsion | nal Drawing | | PDF | PDF | <u>PDF</u> | | | |
| | May | Motor Output | hp | 1/2 | 1 | 2 | | | |
| | IVIAA | тогог ошриг | kW | 0.4 | 0.75 | 1.5 | | | |
| ing | | Rated Output Capacity | kVA | 1.1 | 2.1 | 3.2 | | | |
| Output Rating | CT | Rated Output Current | A | 1.5 | 2.7 | 4.2 | | | |
| tpat | | Carrier Frequency ³ | kHz | | | | | | |
| 8 | | Rated Output Capacity | kVA | 1.4 | 2.3 | 3.5 | | | |
| | VT | Rated Output Current | Α | 1.8 | 4.6 | | | | |
| | | Carrier Frequency ³ | kHz | | | | | | |
| ~ | CT | Rated Input Current | Α | 2.1 | 3.7 | 5.8 | | | |
| ting | VT | Rated Input Current | Α | 2.5 | 4.2 | 6.4 | | | |
| Ra | Rate | d Voltage/Frequency | | Three- | phase 380-480 VAC (-15% to +10%), 50/ | 60 Hz | | | |
| Input Rating ² | 0pei | rating Voltage Range (VAC) | | | 323–528 | | | | |
| - | Freq | uency Tolerance (Hz) | | | 47–63 | | | | |
| IE2 E | fficie | ncy - Relative Power Loss | | 3.7% | 2.5% | 2.2% | | | |
| Weight (kg [lb]) | | | | 0.6 [1.32] | 0.7 [1.54] | 0.8 [1.76] | | | |
| Cool | ing M | ethod | | Conv | ective | Fan | | | |
| IP Ra | nting | | | | IP20 | | | | |
| See ta | able be | low for notes. | | | | | | | |

| | | GS1 | 0 <u>460</u> | <u>V</u> 1 3-Phase Spe | ecifications – Fr | ame Sizes C, D | | |
|---------------------|--------|--------------------------------|--------------|------------------------|---------------------|--------------------------|-------------------|--|
| Mod | el Na | те | | GS13N-43P0 | <u>GS13N-45P0</u> | GS13N-47P5 | <u>GS13N-4010</u> | |
| Price | Price | | | \$202.00 | \$238.00 | \$327.00 | \$369.00 | |
| Fran | ne Siz | е | | С | С | D | D | |
| Dime | ensio | nal Drawing | | <u>PDF</u> | <u>PDF</u> | <u>PDF</u> | <u>PDF</u> | |
| | Mav | Motor Output | hp | 3 | 5 | 7 1/2 | 10 | |
| | IVIAX | motor output | kW | 2.2 | 3.7 | 5.5 | 7.5 | |
| ing | | Rated Output Capacity | kVA | 4.2 | 6.9 | 9.9 | 13 | |
| Output Rating | CT | Rated Output Current | A | 5.5 | 9 | 13 | 17.5 | |
| put | | Carrier Frequency ³ | kHz | 2–15 (default 4) | | | | |
| mo | | Rated Output Capacity | kVA | 5.0 | 8.0 | 12 | 15.6 | |
| | VT | Rated Output Current | A | 6.5 | 10.5 | 14.5 | 19.8 | |
| | | Carrier Frequency ³ | kHz | 2–15 (default 4) | | | | |
| 2 | CT | Rated Input Current | A | 6.1 | 9.9 | 14.3 | 19.3 | |
| Rating ² | VT | Rated Input Current | A | 7.2 | 11.6 | 16.0 | 21.8 | |
| Ra | Rate | ed Voltage/Frequency | | | Three-phase 380-480 | VAC (-15% to +10%), 50/6 | 60 Hz | |
| Input | 0pe | rating Voltage Range (VAC) | | | | 323–528 | | |
| | Freq | uency Tolerance (Hz) | | | | 47–63 | | |
| IE2 E | fficie | ncy - Relative Power Loss | | 2.3% | 2.0% | 1.9% | 1.9% | |
| Weig | jht (k | g [lb]) | | 1 [2.20] | 1 [2.20] | 2 [4.41] | 2 [4.41] | |
| Cool | ing M | lethod | | | | Fan | | |
| IP Ra | ating | | | | | IP20 | | |

^{1 -} For Use With Three-Phase Motors Only.

^{2 -} If 3-phase power source is non-symmetrical, refer to "Circuit Connections – RFI Jumper" in the GS10 AC Drives User Manual, Chapter 2. Please refer to "GS10 DURApulse AccessoriesFusing" (pg.tGSX-75) for input fusing information.

^{3 -} The carrier frequency value is a factory default. Decrease the current value if you need to increase the carrier frequency. Refer to "Derate Output Current Based on Carrier Frequency".

DURAPULSE **GS10 AC Drives** – **General Specifications**

GS10 Drive Model Selection Tables, continued

| | GS10 General | Specifications (Applicable to | All Models) | | | | |
|----------------------------|--|--|---|--|--|--|--|
| | Control Method | V/F, Sensorless Vector (SVC) | | | | | |
| | Applicable Motor | IM (Induction Motor), Permanent Magnet AC (If | PM and SPM) | | | | |
| | | 150% / 3Hz | (V/F, SVC control for IM, CT) | | | | |
| | Starting Torque ¹ | 100% / (motor rated frequency/20) | (SVC control for PM, CT) | | | | |
| | Speed Control Range ¹ | 1: 50 (V/F, SVC control for IM, CT) 1: 20 (SVC control for PM, CT) | | | | | |
| | Max. Output Frequency | 0.00–599.00 Hz | | | | | |
| | Overload Capacity | VT: rated output current of 120% 60 sec, 150% CT: rated output current of 150% 60 sec, 200% | | | | | |
| | Frequency Setting Signal | 0–10 V / 4(0)–20 mA Pulse input: Single Pulse (10kHz), PWM (1kHz |), | | | | |
| | Digital Inputs | Five (5) - 24VDC NPN or PNP, includes 1 frequ | ency input 10kHz | | | | |
| | Digital Outputs | Two (2) - (1)-48VDC, (1) Relay-250VAC/30VDC | , | | | | |
| | Analog Inputs | One (1) - selectable Voltage or Current | | | | | |
| | Analog Outputs | One (1) - voltage | | | | | |
| Control Characteristics | Main Functions | Multiple motor switching (max 2 motor settine) Fast start-up Deceleration Energy Back (DEB) function Fast deceleration function Master and Auxiliary frequency source select Restart after momentary power loss Speed tracking Over-torque detection 16-step speed (including the master speed) Accel./decel. time switch S-curve accel./decel Three-wire operation control JOG frequency Frequency upper/lower limit settings DC brake at start-up and stop PID control Simple Positioning Function Multi Pump Sequence RS-485 Serial Communications (38.4kps material) | table | | | | |
| | Application Macro | Built-in application parameter groups (selected by industry) and user-defined application parameter groups. | | | | | |
| Protection | Motor Protection | Over-current, over-voltage, over-heating, phase | | | | | |
| Characteristics | Stall Prevention | Stall prevention during acceleration, deceleration | on, and running (independent settings). | | | | |
| Agency Approvals | | UL, cUL, CE, REACH | | | | | |
| 1: Control accuracy n | nay vary depending on the environment, a | oplication conditions, or different motors. For more infor | mation, contact AutomationDirect. | | | | |

DURAPULSE GS10 AC Drives – Environmental Specifications


GS10 Environmental Specifications

| Environmental Conditions for GS10 AC Drives | | | | | | | | |
|---|--|------------------------------|------------------------------|--|--|--|--|--|
| Condition | Operation | Storage | Transportation | | | | | |
| Installation Location | IEC 60364-1/ IEC 60664-1 Pollution degree 2, Indoor use only. | n/a | n/a | | | | | |
| Ambiant Townsystems | IP20/UL Open Type: -20–50°C (-20–60°C w/derating) | -40-85°C | -20-70°C | | | | | |
| Ambient Temperature | Non-condensing, no | n-freezing | | | | | | |
| Relative Humidity | 90%, no water condensation | 95%, no water condensation | | | | | | |
| Air Pressure | 86–106 kPa | 70–106 kPA | | | | | | |
| Pollution Level | Concentrate pro | hibited | | | | | | |
| | Class 3C2; Class 3S2 | Class 2C2; Class 2S2 | Class 1C2; Class 1S2 | | | | | |
| Environmental Air | No corrosive/inflammable | gases permitted | | | | | | |
| Altitude | <1000 m (For altitudes > 1000 | m, derate to use it.) | | | | | | |
| Package Drop | n/a | ISTA procedure 1A (according | ng to weight) IEC 60068-2-31 | | | | | |
| Vibration | 1.0 mm, peak to peak value range from 2–13.2 Hz; 0.7–2.0 G range from 13.2–55 Hz; 2.0 G range from 55–512 Hz. Compliance with IEC 60068-2-6 | | 5 Hz–2 kHz m displacement | | | | | |
| Impact | 15G, 11ms Compliance with IEC/EN60068-2-27 | 30 |)G | | | | | |

DO NOT expose the GS10 AC Drive to harsh environments such as dust, direct sunlight, corrosive/flammable gases, humidity, liquid, or vibrations. The salts in the air must be less than 0.01 mg/cm² every year.

DURAPULSE GS10 AC Drives Specifications – Air Flow and Power (Heat) Dissipation

Minimum Clearances and Air Flow for GS10 Series Drives



| Side by Side Drive | Installation |
|--------------------|--------------------|
| | Side by Side Drive |

| GS10 Minimum Mounting Clearances* | | | | | | | | | |
|--------------------------------------|-----------|-----------|-----------|----------------------------|-------------------|--|--|--|--|
| | | | | Operation Te | mperature (°C) | | | | |
| Installation Method | A (mm) | B (mm) | C (mm) | Max (w/out derating) | Max (Derating) | | | | |
| Single drive installation | 50 | 30 | _ | 50 | 60 | | | | |
| Side-by-side horizontal installation | 50 | 30 | 30 | 50 | 60 | | | | |
| Zero stack installation | 50 | 30 | 0 | 40 | 50 | | | | |

* Failure to follow the minimum mounting clearances may cause the fan to malfunction and cause a heat dissipation problem.

| GS10 Airflow and Power Dissipation | | | | | | | | | | |
|------------------------------------|-------|-----------------|----------------------|------------------------------|----------|-------|--|--|--|--|
| Model | Frame | Airflow Rate | | Power Dissipation (Watts) | | | | | | |
| Number | Size | Flow Rate (cfm) | Flow Rate (m³/hr) | Loss External (Heat sink) | Internal | Total | | | | |
| GS11N-10P2 | Α | 0 | 0 | 8 | 10 | 18 | | | | |
| GS11N-10P5 | A | U | U | 14.2 | 13.1 | 27.3 | | | | |
| GS11N-11P0 | С | 16.0 | 27.2 | 29.1 | 23.9 | 53 | | | | |
| GS11N-20P2 | Α | 0 | 0 | 8.6 | 10 | 18.6 | | | | |
| GS11N-20P5 | A | U | U | 16.3 | 14.5 | 30.8 | | | | |
| GS11N-21P0 | В | 10 | 16.99 | 29.1 | 20.1 | 49.2 | | | | |
| GS11N-22P0 | С | 16.0 | 27.2 | 46.5 | 31 | 77.5 | | | | |
| GS11N-23P0 | C | 10.0 | 21.2 | 70 | 35 | 105 | | | | |
| GS13N-20P2 | | | | 8.6 | 10 | 18.6 | | | | |
| GS13N-20P5 | Α | 0 | 0 | 16.5 | 12.6 | 29.1 | | | | |
| <u>GS13N-21P0</u> | | | | 31 | 13.2 | 44.2 | | | | |
| <u>GS13N-22P0</u> | В | 10 | 16.99 | 50.1 | 24.2 | 74.3 | | | | |
| GS13N-23P0 | С | 16 | 27.2 | 76 | 30.7 | 106.7 | | | | |
| <u>GS13N-25P0</u> | C | 10 | 21.2 | 108.2 | 40.1 | 148.3 | | | | |
| <u>GS13N-27P5</u> | D | 23.4 | 39.7 | 192.8 | 53.3 | 246.1 | | | | |
| <u>GS13N-40P5</u> | Α | 0 | 0 | 17.6 | 11.1 | 28.7 | | | | |
| <u>GS13N-41P0</u> | ^ | | U | 30.5 | 17.8 | 48.3 | | | | |
| <u>GS13N-42P0</u> | В | 10 | 16.99 | 45.9 | 21.7 | 67.6 | | | | |
| <u>GS13N-43P0</u> | С | 16 | 27.2 | 60.6 | 22.8 | 83.4 | | | | |
| <u>GS13N-45P0</u> | | 10 | 21.2 | 93.1 | 42 | 135.1 | | | | |
| <u>GS13N-47P5</u> | D | 23.4 | 39.7 | 132.8 | 39.5 | 172.3 | | | | |
| GS13N-4010 | ט | 23.4 | 39.1 | 164.7 | 55.8 | 220.5 | | | | |

- Published flow rates are the result of active cooling using fans, factory installed in the drive.
- Unpublished flow rates (0.0) are the result of passive cooling in drives without factory installed fans
- · The required airflow shown in the chart is for installing a single GS10 drive in a confined space.
- When installing multiple GS10 drives, the required air volume would be the required air volume for a single GS10 drive multiplied by the number of GS10 drives.
- When calculating power dissipation (Watt Loss), use the <u>Total</u> value. Heat dissipation shown in the chart is for installing a single GS10 drive in a confined space.
- When installing multiple drives, the volume of heat/power dissipation should be the heat/power dissipated by a single GS10 drive multiplied by the number of GS10 drives.
- Heat dissipation for each model is calculated by rated voltage, current and default carrier frequency.

DURAPULSE GS10 AC Drives Specifications – Terminals

Control Circuit Terminal Names and Definitions

| | | Control Circuit Terminals | | | | | |
|-------------------------------------|--|--|--|--|--|--|--|
| Terminal Symbol | Terminal Function | Description | | | | | |
| +24V | Digital control signal common (Source) | +24V ± 10% 100mA | | | | | |
| DCM | Digital control / Frequency signal common (Sink) | Digital control common | | | | | |
| FWD (DI1) REV (DI2) DI3 - DI5 | Digital input 1–5 | Source Mode: ON: activation current 3.3 mA ≥ 11 VDC OFF: cut-off voltage ≤ 5 VDC Sink Mode: ON: activation current 3.3 mA ≤ 13 VDC OFF: cut-off voltage ≥ 19 VDC DI5: Single pulse input, the maximum input frequency=10kHz. PWM pulse input, the maximum input frequency=1kHz. Digital inputs can be configured by the user for many different functions. Refer to P02.00–02.05 to program the digital inputs FWD (DI1), REV (DI2), DI3–DI5. | | | | | |
| | | When P02.00=0, FWD (DI1) and REV (DI2) can be programmed. When P02.00≠0, the functions of FWD (DI1) and REV (DI2) act according to P02.00 setting. When P02.05=0, DI5 is pulse input terminal. When P00.20 = 4, DI5 is the speed command source. Refer to P10.16 for DI5 pulse configuration. | | | | | |
| D01 | Digital Output 1 (photo coupler) | The AC motor drive outputs various monitoring signals through a transistor (open collector). Refer to P2.16 to program the output. | | | | | |
| DOC | Digital Output Common (photo coupler) | R Max 48 Vpc DOC 50 mA | | | | | |
| R10 | Relay Output 1 (N.O.) | The AC motor drive outputs various monitoring signals through a relay output. Refer to P2.13 to program the output. Resistive Load | | | | | |
| R1C | Relay Output 1 (N.C.) | 3.0 Å (NO), 3.0 Å (NC) @250VAC 5.0 Å (NO), 3.0 Å (NC) @30VDC Inductive Load (COS 0.4) 1.2 Å (NO), 1.2 Å (NC) @250VAC 2.0 Å (NO), 1.2 Å (NC) @30VDC | | | | | |
| R1 | Relay Output 1 Common | | | | | | |
| +10V | Potentiometer power supply | Power supply for analog frequency setting: +10.5 ± 0.5 VDC / 20mA | | | | | |
| | Analog voltage frequency command AI-V Mode (Potentiometer) +10V AI (0V~+10V) ACM Internal circuit | The AI default is 0–10 V (AI-V, voltage mode). To switch to current mode, two steps are required: 1. A dip switch must be configured (follow the instructions on the inner side of the front cover or see page 2–xx) 2. Change P03.28 to 1 (0mA) or 2 (4mA) Use P03.00 to program AI functionality for either Voltage or Current mode. AI resolution=12 bits | | | | | |
| AI | AI-V Mode (voltage input) +10V AI (0V-+10V) W Internal circuit | Voltage (AI-V) mode • Impedance: 20 kΩ • Range 0–Max. Output Frequency (P01.00): 0 to 10 V • P03.28 = 0 | | | | | |
| | AI-C Mode AI Al circuit ACM Internal circuit | Current (AI-C) mode • Impedance: 250 Ω • Range 0– Maximum Output Frequency (P01.00): 0–20 mA/4–20 mA • Range switching according to P03.28 = 1 (0mA) or 2 (4mA) | | | | | |

DURAPULSE GS10 AC Drives Specifications – Terminals

Control Circuit Terminal Names and Definitions

| | Control | Circuit Terminals (continued) | | | |
|--------------------|---|---|--|--|--|
| Terminal Symbol | Terminal Function | Description | | | |
| A01 | Multi-function analog voltage output AO1 ACM | AO1 outputs an analog voltage signal based on P03.20. • Range: 0–10 V (P03.21=0) corresponds to the maximum operating range of the control target • Max. output current: 2 mA • Max. Load: $5 \text{ k}\Omega$ • AO1 resolution=12 bits | | | |
| ACM | Analog Signal Common | Analog signal common terminal | | | |
| PE | RS485 | The PE terminal is for shielded cable to ground to decrease interference when you use RS485 communication. | | | |
| | PIN 1, 2, 6: Reserved | | | | |
| | PIN 3, 7: SGND | | | | |
| RJ45 | PIN 4: SG- | The RJ45 port provides a serial communications connection. Max Baud Rate = 38.4kbps | | | |
| 71340 | PIN 5: SG+ | The Note port provided a social communications confidence. Max badd Nate = 50.4kbps | | | |
| | PIN 8: +10V supply GS4-KPD (provides (optional) power supply) | | | | |


DURAPULSE **GS10** AC Drives – Basic Wiring Diagram

Main Circuit Wiring Diagram: GS10 All Models

Note: Users MUST connect wiring according to the circuit diagram shown below. (Refer to GS10 User Manual for additional specific wiring information.)

Note: DC reactors (chokes) are specified but not stocked by AutomationDirect.


Note: DC- and DC+/+1 terminals not provided on 120V models.




Control Circuit Wiring Diagram: Digital Inputs - Internal Power

Note: Users MUST connect wiring according to the circuit diagram shown below. (Refer to GS10 User Manual for additional specific wiring information.)

(1) Sink Mode with internal power (+24 V_{DC})




2 Source Mode with internal power (+24 V_{DC})




Control Circuit Wiring Diagram: Digital Inputs - External Power

Note: Users MUST connect wiring according to the circuit diagram shown below. (Refer to GS10 User Manual for additional specific wiring information.)

③ Sink Mode with external power




4 Source Mode with external power



DURAPULSE **GS10 AC Drives** – Basic Wiring Diagram

System Wiring Diagram:

Note: Users MUST connect wiring according to the circuit diagram shown below. (Refer to user G10 User Manual for additional specific wiring information.)




| Syste | System Wiring Components | | | | | | | |
|---|---|--|--|--|--|--|--|--|
| Component | Function | | | | | | | |
| Power input terminal | Supply power according to the rated power specifications indicated in the manual | | | | | | | |
| NFB or fuse | There may be a large inrush current during power on. Select a suitable NFB (Non Fuse Breaker or Circuit Breaker) or Fuse. | | | | | | | |
| Electromagnetic contactor | Switching the power ON/OFF on the primary side of the electromagnetic contactor can turn the drive ON/OFF, but frequent switching can cause machine failure. Do not switch ON/OFF more than once an hour. Do not use the electromagnetic contactor as the power switch for the drive; doing so shortens the life of the drive. | | | | | | | |
| AC reactor (input terminal) | When the main power supply capacity is greater than 500 kVA, or when it switches into the phase capacitor, the instantaneous peak voltage and current generated may destroy the internal circuit of the drive. It is recommended that you install an input side AC reactor in the drive. This also improves the power factor and reduces power harmonics. The wiring distance should be within 10 m. | | | | | | | |
| Zero phase reactor | Used to reduce radiated interference, especially in environments with audio devices, and reduce input and output side interference. The effective range is AM band to 10 MHz. | | | | | | | |
| EMC filter | Can be used to reduce electromagnetic interference. | | | | | | | |
| Brake module and Brake resistor (BR) | Used to shorten the deceleration time of the motor. | | | | | | | |
| AC reactor (output terminal) | The motor cable length affects the size of the reflected wave on the motor end. | | | | | | | |

DURAPULSE **GS10 AC Drives** – Basic Wiring Diagram

Control Wiring Diagram: Full I/O

Note: Users MUST connect wiring according to the circuit diagram shown below. (Refer to the GS10 user manual for additional specific wiring information.)



www.automationdirect.com

tGSX-15

DURAPULSE GS10 AC Drives – Optional Accessories

Accessories Available for GS10 AC Drives

The table below lists types of accessories available for your GS10 series drive. GS10 uses many of the same accessories as the GS20(X) series drives–GS20 numbered parts that can be used with GS10 are noted in the table below. To see if your specific model can use a particular accessory, please click the reference link to go to the accessory page.

| GS10 | GS10 AC Drives Available Software and Accessories | | | | | | | | | |
|---|---|--------------------------------|---|--|--|--|--|--|--|--|
| Accessory | GS10 Accessory | GS20 Accessory used by GS10 | Reference | | | | | | | |
| GSoft 2 Drive Software | ✓ | | "GSoft2 Drive Configuration Software" on page tGSX-103 | | | | | | | |
| Braking Resistors | ✓ | | "GS10/GS20 Braking Resistors" on page tGSX-64 | | | | | | | |
| Capacitive Filter | | ✓ | "Capacitive Filter" on page tGSX-79 | | | | | | | |
| Conduit Boxes | ✓ | | "GS10 Conduit Boxes" on page tGSX-66 | | | | | | | |
| DIN Rail Mounting (A–C frame only) | | ✓ | "DIN Rail Mounting" on page tGSX-85 | | | | | | | |
| EMC Filter | ✓ | | "GS10 Standard Footprint EMC Filter and Zero Phase Reactor" on page tGSX-69 | | | | | | | |
| EMC Shield Plates | | ✓ | "EMC Shield Plate" on page tGSX-79 | | | | | | | |
| EMI Filters | ✓ | | "GS10/GS20 High Performance EMI Input Filters" on page tGSX-73 | | | | | | | |
| Fuses/Circuit Breakers | ✓ | | "GS10 Fuses/Circuit Breakers" on page tGSX-75 | | | | | | | |
| Line/Load Reactor/Voltage Time Filter | ✓ | | "GS10 Line Reactors/Voltage Time Filters" on page tGSX-82 | | | | | | | |
| Mounting Adapter Plate (A–C frame only) | | ✓ | "Mounting Adapter Plate" on page tGSX-86 | | | | | | | |
| Optional Advanced Keypad | | ✓ | "Advanced Keypad" on page tGSX-105 | | | | | | | |
| Replacement Fan Kit | | ✓ | "Cooling Fans for GSxx Series Drives (Spare/Replacement)" on page tGSX-87 | | | | | | | |
| RF Filter | ✓ | | "RF Filter" on page tGSX-88 | | | | | | | |

GS10 Series Optional Accessories - Braking

GS10 Braking Resistors

Use the table below to find the appropriate braking resistor model for your GS10 series AC drive. For more information and installation instructions, please see the GS10 series User Manual. All listed resistors are available for purchase at www.automationdirect.com.

| | | | G | S10 AC | Drive Braking | j Co | mponent | Selection | | | | | |
|---------------|-----------------------------------|-----------|-----------------------|----------------------|---------------------------------------|--------|---------------------------|----------------------------|------------------------|----------|----------------------------|--|--|
| age | Drive Brake Capacity - Max Torque | | | | 125% Braking Torque @ 10% Duty Cycle* | | | | | | | | |
| 10/ | Drive Model | Power | Min | Max Total | Open | Type B | raking Resist | or | NEMA1 Resistors | with The | ermal Switch | | |
| Drive Voltage | Dilve Model | (hp) | Resistor Value (Ω) | Brake Current (A) | Part # | Qty. | Brake Torque (kg•m) | Total Brake Current (A) | Part # | Qty. | Total Brake Current (A) | | |
| | GS11N-10P2 | 1/4 | 190.0 | 2 | GS-BR-080W750 | 1 | 0.1 | 0.5 | BR-N1-240W200 | 1 | 2.0 | | |
| 207 | GS11N-10P5 | 1/2 | 95.0 | 4 | CC DD 000W200 | 1 | 0.3 | 1.9 | DD N4 240W4E0 | 1 | 2.6 | | |
| 1 | GS11N-11P0 | 1 | 63.3 | 6 | GS-BR-080W200 | 1 | 0.5 | 1.9 | BR-N1-240W150 | 1 | 2.0 | | |
| | GS11N-20P2 | 1/4 | 190.0 | 2 | GS-BR-080W750 | 1 | 0.1 | 0.5 | BR-N1-240W200 | 1 | 2.0 | | |
| | <u>GS11N-20P5</u> | 1/2 | 95.0 | 4 | GS-BR-080W200 | 1 | 0.3 | 1.9 | BR-N1-240W150 | 1 | 2.6 | | |
| | <u>GS11N-21P0</u> | 1 | 63.3 | 6 | <u>us-bn-000W200</u> | 1 | 0.5 | 1.9 | <u>DN-N1-240W130</u> | 1 | 2.0 | | |
| | <u>GS11N-22P0</u> | 2 | 47.5 | 8 | GS-BR-200W091 | 1 | 1 | 4.2 | BR-N1-280W50 | 1 | 7.8 | | |
| | <u>GS11N-23P0</u> | 3 | 38.0 | 10 | GS-BR-300W070 | 1 | 1.5 | 5.4 | | 1 | 7.0 | | |
| 2301 | <u>GS13N-20P2</u> | 1/4 | 190.0 | 2 | GS-BR-080W750 | 1 | 0.1 | 0.5 | BR-N1-240W200 | 1 | 2.0 | | |
| 23 | <u>GS13N-20P5</u> | 1/2 | 95.0 | 4 | GS-BR-080W200 | 1 | 0.3 | 1.9 | BR-N1-240W150 | 1 | 2.6 | | |
| | <u>GS13N-21P0</u> | 1 | 63.3 | 6 | <u>uo-bii-000W200</u> | 1 | 0.5 | 1.5 | BR-N1-240W150 | 1 | 2.0 | | |
| | GS13N-22P0 | 2 | 47.5 | 8 | GS-BR-200W091 | 1 | 1 | 4.2 | BR-N1-280W50 | 1 | 7.8 | | |
| | GS13N-23P0 | 3 | 38.0 | 10 | GS-BR-300W070 | 1 | 1.5 | 5.4 | <u> </u> | 1 | 7.0 | | |
| | <u>GS13N-25P0</u> | 5 | 19.0 | 20 | GS-BR-400W040 | 1 | 2.5 | 9.5 | BR-N1-800W25 | 1 | 15.6 | | |
| | GS13N-27P5 | 7 1/2 | 16.5 | 23 | GS-BR-1K0W020 | 1 | 3.7 | 19 | BR-N1-800W18P0 | 1 | 21.7 | | |
| | <u>GS13N-40P5</u> | 1/2 | 380.0 | 2 | GS-BR-080W750 | 1 | 0.3 | 1 1 | BR-N1-250W400 | 1 | 2.0 | | |
| | <u>GS13N-41P0</u> | 1 | 190.0 | 4 | | 1 | 0.5 | · · | BR-N1-240W200 | 1 | 3.9 | | |
| _ | GS13N-42P0 | 2 | 126.7 | 6 | GS-BR-200W360 | 1 | 1 | 2.1 | BR-N1-240W150 | 1 | 5.2 | | |
| 460V | GS13N-43P0 | 3 | 108.6 | 7 | GS-BR-300W250 | 1 | 1.5 | 3 | BR-N1-500W200 | 1 | 3.9 | | |
| ' | <u>GS13N-45P0</u> | 5 | 84.4 | 9 | GS-BR-400W150 | 1 | 2.5 | 5.1 | BR-N1-500W130 | 1 | 6.0 | | |
| | <u>GS13N-47P5</u> | 7 1/2 | 50.7 | 15 | GS-BR-1K0W075 | 1 | 3.7 | 10.2 | BR-N1-720W85 | 1 | 9.2 | | |
| | <u>GS13N-4010</u> | 10 | 40.0 | 19 | <u> </u> | 1 | 5.1 | 10.2 | <u>BR-N1-1K2W50</u> | 1 | 15.6 | | |
| * 10% L | Duty Cycle with ma | aximum ON | (braking) time | for 10 seconds. | | | | | | | | | |

GS10 Series Optional Accessories – Conduit Boxes

| | GS10 – Conduit Box Selection Table | | | | | | | | | | |
|--|------------------------------------|-------------------|-------------|------------|-----------------------------------|--|--|--|--|--|--|
| Driv | e | Con | Description | | | | | | | | |
| Model | Frame | Part # | Price | Drawing | Description | | | | | | |
| GS11N-10P2 GS11N-20P2 GS13N-20P2 GS13N-20P5 | A1, A2 | <u>GS10A-N1A1</u> | \$25.00 | <u>PDF</u> | | | | | | | |
| GS11N-10P5 GS11N-20P5 GS13N-21P0 GS13N-40P5 GS13N-41P0 | A3-A6 | <u>GS10A-N1A3</u> | \$26.00 | PDF | | | | | | | |
| GS11N-21P0 GS13N-22P0 GS13N-41P0 | В | <u>GS10A-N1B</u> | \$28.00 | <u>PDF</u> | GS10 series conduit box, NEMA1 | | | | | | |
| GS11N-11P0 GS11N-22P0 GS11N-23P0 GS13N-23P0 GS13N-25P0 GS13N-43P0 GS13N-45P0 | С | <u>GS10A-N1C</u> | \$30.00 | PDF | | | | | | | |
| GS13N-25P5 GS13N-47P5 GS13N-4010 | D | GS10A-N1D | \$30.00 | PDF | | | | | | | |

^{*} Conduit Box Kits include mounting hardware; box base, box cover, bushings, and screws.

Conduit box dimensions are shown below and on the following page.

GS10 Conduit Boxes

Optional Conduit Box Kits can be ordered separately. These kits bolt onto the bottom of the applicable GS10 drive to provide a convenient connection point for conduit entry, allowing the GS10 to achieve a NEMA 1/UL type 1 environmental protection rating; especially useful for GS10 drives mounted outside of an electrical control panel.



Example GS10 Conduit Box

GS10 Series Optional Accessories – EMC Filter & Zero Phase Reactor

GS10 Standard Footprint EMC Filter and Zero Phase Reactor


If electromagnetic noise is harmful to your manufacturing environment, we recommend that you select an EMC filter as shown below. For some motor drive models, you need to work with zero phase reactors to be compliant with EMC regulations. Refer to the table and figure below for the recommended model, setting method, and maximum motor cable length of the EMC filter and zero phase reactor. The footprint filter allows mounting of the drive on top of the recommended filter, saving panel space and wiring. For more information and installation instructions, please see your GS10 series User Manual.

| | GS10 EMC Filter and Zero Phase Reactor | | | | | | | | | | | |
|-------|--|------------------|-----------------------------|--------------------|-----------------------------------|---|----------|----------|----------------------------|-------------------|--------------------|----------|
| | | | | | | | | | Emission | Radiated Emission | | |
| Frame | Drive Model | Input Current | Footprint Filter Model # | Price | Recommended Zero Phase Reactor | | motor o | | C2-motor cable length-100m | C2-mo | otor cable 100m | length- |
| | | (A) | ivioaei # | | Zero Pilase Reactor | | Po | sition | to Install a Zero F | Phase Ro | eactor | |
| | | | | | | 1 | 2 | 3 | n/a | 1 | 2 | 3 |
| | <u>GS11N-10P2</u> | 6 | | | | | | | N/A | | | |
| | GS11N-10P5 | 9.4 | EMF11AM21A | \$58.00 | | | | | N/A | | | |
| | GS11N-20P2 | 5.1 | <u>LIVII TIAWZIA</u> | ψ50.00 | | | ✓ | ✓ | N/A | | ✓ | ✓ |
| | GS11N-20P5 | 7.3 | | |] | | ✓ | ✓ | N/A | | ✓ | ✓ |
| Α | GS13N-20P2 | 1.9 | EMF10AM23A \$80.00 | | | | ✓ | ✓ | N/A | | ✓ | ✓ |
| | GS13N-20P5 | 3.4 | | \$80.00 \$73.00 | | | ✓ | ✓ | N/A | | ✓ | ✓ |
| | GS13N-21P0 | 5.8 | | | | | ✓ | ✓ | N/A | | ✓ | ✓ |
| | GS13N-40P5 | 2.1 | EMF6A0M43A | | | | | ✓ | N/A | | | ✓ |
| | GS13N-41P0 | 3.7 | <u>EIVIFOAUIVI43A</u> | | | | | ✓ | N/A* | | | ✓ |
| | <u>GS11N-21P0</u> | 10.8 | EMF11AM21A | \$58.00 | | | ✓ | ✓ | N/A | | ✓ | ✓ |
| В | GS13N-22P0 | 9 | EMF10AM23A | \$80.00 | RF008X00A | | ✓ | ✓ | N/A | | ✓ | ✓ |
| | GS13N-42P0 | 5.8 | EMF6A0M43A | \$73.00 | RFUUOXUUA | | | ✓ | N/A | | | ✓ |
| | GS11N-11P0 | 18 | | | | | | | N/A | | | |
| | GS11N-22P0 | 16.5 | EMF27AM21B | \$102.00 | | | | ✓ | N/A | | | ✓ |
| | GS11N-23P0 | 24.2 | | | | | | ✓ | N/A | | | ✓ |
| С | GS13N-23P0 | 13.2 | EMES/AMOSE | \$125.00 | | | √ | √ | N/A | | ✓ | ✓ |
| | GS13N-25P0 | 20 | EMF24AM23B | φ1∠5.00 | | | √ | √ | N/A | | ✓ | ✓ |
| | GS13N-43P0 | 6.1 | EME40AM40D | #100 00 | | | | | N/A | | | |
| | GS13N-45P0 | 9.9 | EMF12AM43B \$128.00 | | | | √ | √ | N/A | | ✓ | ✓ |
| | GS13N-27P5 | 30 | EMF33AM23B | \$182.00 | | ✓ | √ | | N/A | ✓ | √ | |
| D | GS13N-47P5 | 14.3 | EMF23AM43B | ¢175.00 | | ✓ | ✓ | ✓ | N/A | ✓ | √ | ✓ |
| | GS13N-4010 | 19.3 | EIVIFZ3AIVI43B | \$175.00 | JU | ✓ | ✓ | ✓ | N/A | ✓ | ✓ | √ |

EMF Series Filter Dimensions

EMF11AM21A EMF10AM23A EMF6A0M43A EMF6A0M43A

(Units = mm [in])



www.automationdirect.com

AC Drives 1

GS10/GS20 Series Optional Accessories – EMI Input Filters

GS10/GS20 High Performance EMI Input Filters

High performance EMI filters may improve drive performance for certain applications. Use the table below to select the correct filter for your drive. For additional information and installation instructions, please see your GSx series User Manual.

| | | | EMI Filters Selection | |
|--------------------|--------------------------|------------------------------------|---|---------------------------|
| Model | | Description | EMI Fil | |
| GS10 Drives | GS20(X) Drives | - | Roxburgh Filters Chassis 1ph | Roxburgh Filters C2 Rated |
| <u> 3S11N-10P2</u> | GS21-10P2 | 120V 1ph 0.25 hp | <u>RES90F10</u> | <u>MIF10</u> |
| <u> </u> | GS21-10P5 | 120V 1ph 0.5 hp | <u>RES90F16</u> | <u>MIF16</u> |
| <u> 3S11N-11P0</u> | GS21-11P0 | 120V 1ph 1.0 hp | <u>RES90S30</u> | <u>MIF23</u> |
| <u> GS11N-20P2</u> | GS21-20P2 | 230V 1ph 0.25 hp | <u>RES90F06</u> | <u>MIF06</u> |
| GS11N-20P5 | GS21-20P5 | 230V 1ph 0.5 hp | <u>RES90F10</u> | <u>MIF10</u> |
| GS11N-21P0 | GS21-21P0 | 230V 1ph 1.0 hp | <u>RES90F16</u> | <u>MIF16</u> |
| GS11N-22P0 | GS21-22P0 | 230V 1ph 2.0 hp | <u>RES90S20</u> | <u>MIF23</u> |
| <u> 3S11N-23P0</u> | GS21-23P0 | 230V 1ph 3.0 hp | <u>RES90S30</u> | <u>MIF330B</u> |
| S13N-20P2 | GS23-20P2 | 230V 3ph 0.25 hp | - | <u>KMF306A</u> |
| <u> 3S13N-20P5</u> | GS23-20P5 | 230V 3ph 0.5 hp | - | <u>KMF306A</u> |
| <u> SS13N-21P0</u> | GS23-21P0 | 230V 3ph 1.0 hp | - | <u>KMF306A</u> |
| SS13N-22P0 | GS23-22P0 | 230V 3ph 2.0 hp | - | <u>KMF318A</u> |
| SS13N-23P0 | GS23-23P0 | 230V 3ph 3.0 hp | - | <u>KMF318A</u> |
| SS13N-25P0 | GS23-25P0 | 230V 3ph 5.0 hp | - | <u>KMF325A</u> |
| GS13N-27P5 | GS23-27P5 | 230V 3ph 7.5 hp | - | <u>KMF336A</u> |
| | GS23-2010 | 230V 3ph 10hp | - | <u>KMF350A</u> |
| ı/a | GS23-2015 | 230V 3ph 15hp | - | <u>KMF370A</u> |
| | GS23-2020 | 230V 3ph 20hp | - | KMF3100A |
| GS13N-40P5 | GS23-40P5 | 460V 3ph 0.5 hp | - | <u>KMF306A</u> |
| GS13N-41P0 | GS23-41P0 | 460V 3ph 1.0 hp | - | KMF306A |
| SS13N-42P0 | GS23-42P0 | 460V 3ph 2.0 hp | - | KMF306A |
| GS13N-43P0 | GS23-43P0 | 460V 3ph 3.0 hp | - | KMF310A |
| SS13N-45P0 | GS23-45P0 | 460V 3ph 5.0 hp | - | KMF318A |
| GS13N-47P5 | GS23-47P5 | 460V 3ph 7.5 hp | - | KMF318A |
| GS13N-4010 | GS23-4010 | 460V 3ph 10hp | - | KMF325A |
| | GS23-4015 | 460V 3ph 15hp | - | KMF336A |
| | GS23-4020 | 460V 3ph 20hp | - | KMF350A |
| | GS23-4025 | 460V 3ph 25hp | - | KMF350A |
| | GS23-4030 | 460V 3ph 30hp | - | KMF370A |
| | GS23-51P0 | 575V 3ph 1.0 hp | - | KMF306V |
| | GS23-52P0 | 575V 3ph 2.0 hp | - | KMF306V |
| | GS23-53P0 | 575V 3ph 3.0 hp | - | KMF306V |
| | GS23-55P0 | 575V 3ph 5.0 hp | _ | KMF310V |
| | GS23-57P5 | 575V 3ph 7.5 hp | _ | KMF318V |
| | GS23-5010 | 575V 3ph 10hp | _ | KMF318V |
| | GS21X-20P5 | 230V 1ph 0.5 hp | RES90F10 | MIF10 |
| | GS21X-21P0 | 230V 1ph 1.0 hp | RES90F16 | MIF16 |
| | GS21X-22P0 | 230V 1ph 1.0 hp | RES90S20 | MIF23 |
| ı/a | GS21X-23P0 | 230V 1ph 2.0 hp | RES90S30 | MIF330B |
| ., | GS23X-20P5 | 230V 3ph 0.5 hp | - | <u>KMF306A</u> |
| | GS23X-21P0 | 230V 3ph 1.0 hp | _ | <u>KMF306A</u> |
| | GS23X-22P0 | 230V 3ph 1.0 hp | - | <u>KMF310A</u> |
| | GS23X-23P0 | 230V 3ph 2.0 hp | - | KMF318A |
| | GS23X-25P0 | 230V 3ph 5.0 hp | - | KMF325A |
| | GS23X-27P5 | 230V 3ph 7.5 hp | - | <u>KMF325A</u> KMF336A |
| C | GS23X-27P5 GS23X-40P5 | | - | |
| | GS23X-41P0 | 460V 3ph 0.5 hp 460V 3ph 1.0 hp | - | <u>KMF306A</u> KMF306A |
| | | | - | |
| | GS23X-42P0 | 460V 3ph 2.0 hp | <u>-</u> | <u>KMF306A</u> |
| | GS23X-43P0 | 460V 3ph 3.0 hp | - | <u>KMF310A</u> |
| | GS23X-45P0 | 460V 3ph 5.0 hp | - | KMF318A |
| | GS23X-47P5 | 460V 3ph 7.5 hp | - | KMF318A |
| | GS23X-4010 | 460V 3ph 10hp | - m or by clicking the following links: - <u>KMF Series Filters,</u> - <u>MI</u> | <u>KMF325A</u> |

GS10 Series Optional Accessories – Fuses/Circuit Breakers

GS10 Fuses/Circuit Breakers

Protection devices are essential to prevent damage to your GS10 series drive and application equipment. Please use the fuse specification chart below to select fuses that are applicable to your drive. Only use UL-certified fuses which comply with your local regulations.

| | | | use | Specification | Chart GS | S10 DURAPUL | se Drives | | | | |
|----------------------|-------|---|-------------|-----------------|-----------|------------------------|--------------------|------|-----------------|--|--|
| | | | Input Power | | | Input Fuse | | | Circuit Breaker | | |
| Drive Model | HP | Ø | Volts | GS10 Input Amps | Fuse Amps | Fast Acting Class T | Edison Class J* | Size | Molded Case CB | | |
| GS11N-10P2 | 1/4 | 1 | 120 | 6 | 7.2 | TJN10 | JHL10 | 20 | G3P-020 | | |
| GS11N-10P5 | 1/2 | 1 | 120 | 9.4 | 10.8 | TJN10 | JHL10 | 25 | G3P-025 | | |
| GS11N-11P0 | 1 | 1 | 120 | 18 | 22 | TJN25 | JHL25 | 50 | G3P-050 | | |
| GS11N-20P2 | 1/4 | 1 | 230 | 5.1 | 7.2 | TJN10 | JHL10 | 15 | G3P-015 | | |
| GS11N-20P5 | 1/2 | 1 | 230 | 7.3 | 12.8 | TJN15 | JHL15 | 20 | G3P-020 | | |
| GS11N-21P0 | 1 | 1 | 230 | 10.8 | 20 | TJN20 | JHL20 | 30 | G3P-030 | | |
| GS11N-22P0 | 2 | 1 | 230 | 16.5 | 34 | TJN35 | JHL35 | 45 | G3P-030 | | |
| GS11N-23P0 | 3 | 1 | 230 | 24.2 | 50 | TJN50 | JHL50 | 70 | G3P-070 | | |
| GS13N-20P2 | 1/4 | 3 | 230 | 1.9 | 7.2 | TJN10 | JHL10 | 15 | G3P-015 | | |
| GS13N-20P5 | 1/2 | 3 | 230 | 3.4 | 12.8 | TJN15 | JHL15 | 15 | G3P-015 | | |
| <u>GS13N-21P0</u> | 1 | 3 | 230 | 5.8 | 20 | TJN20 | JHL20 | 15 | G3P-015 | | |
| GS13N-22P0 | 2 | 3 | 230 | 9 | 32 | TJN35 | JHL35 | 25 | G3P-025 | | |
| GS13N-23P0 | 3 | 3 | 230 | 13.2 | 50 | TJN50 | JHL50 | 40 | G3P-040 | | |
| <u>GS13N-25P0</u> | 5 | 3 | 230 | 20 | 78 | <u>TJN80</u> | JHL80 | 60 | G3P-060 | | |
| GS13N-27P5 | 7 1/2 | 3 | 230 | 30 | 59.4 | TJN60 | JHL60 | 63 | G3P-060 | | |
| GS13N-40P5 | 1/2 | 3 | 460 | 2.1 | 7.2 | <u>TJS10</u> | JHL10 | 15 | G3P-015 | | |
| <u>GS13N-41P0</u> | 1 | 3 | 460 | 3.7 | 12 | <u>TJS15</u> | JHL15 | 15 | G3P-015 | | |
| <u>GS13N-42P0</u> | 2 | 3 | 460 | 5.8 | 18.4 | <u>TJS20</u> | JHL20 | 15 | <u>G3P-015</u> | | |
| GS13N-43P0 | 3 | 3 | 460 | 6.1 | 26 | TJS25 | JHL25 | 20 | <u>G3P-020</u> | | |
| <u>GS13N-45P0</u> | 5 | 3 | 460 | 9.9 | 42 | TJS45 | JHL45 | 30 | <u>G3P-030</u> | | |
| <u>GS13N-47P5</u> | 7 1/2 | 3 | 460 | 14.3 | 34.5 | <u>TJS35</u> | JHL35 | 32 | G3P-030 | | |
| GS13N-4010 | 10 | 3 | 460 | 19.3 | 45.1 | TJS45 | JHL45 | 45 | <u>G3P-040</u> | | |
| * High-spood Class I | | | | | | | | | | | |

^{*} High-speed Class J.

Note: JHL fuses can be used with GS and DURAPULSE drives in non-UL applications. Fuse the drive according to NEC guidelines (NEC Article 430). For UL applications, GS, and DURAPULSE drives require Class T fuses (refer to the drive's user manual for details).


DuraPulse Optional Accessories – General

EMC Shield Plate

EMC Shield Plates are available for use with shielded cable and your GS10/GS20/GS30 drive. For GS20X drives, please use Earthing Plates. Each shield plate is compatible with all GS10, GS20, and GS30 drives of that frame size. For more information and installation instructions, see your GSxx series User Manual.

| EMC Shield Plate Selection | | | | | | | | | |
|----------------------------|-------|------------------------|---------|--|--|--|--|--|--|
| Drive Series | Frame | EMC Shield Plate Model | Price | | | | | | |
| GS10/20/30 | Α | GS20A-ESP-A | \$28.00 | | | | | | |
| GS10/20/30 | В | GS20A-ESP-B | \$29.00 | | | | | | |
| GS10/20/30 | С | GS20A-ESP-C | \$29.00 | | | | | | |
| GS10/20/30 | D | GS20A-ESP-D | \$31.00 | | | | | | |
| GS20/30 | Е | GS20A-ESP-E | \$43.00 | | | | | | |
| GS20/30 | F | GS20A-ESP-F | \$43.00 | | | | | | |
| GS30 | G | GS30A-ESP-G | \$47.00 | | | | | | |
| GS30 | Н | GS30A-ESP-H | \$50.00 | | | | | | |
| GS30 | I | GS30A-ESP-I | \$54.00 | | | | | | |

| EMC Shield Plate Dimensions | | | | | | | | | |
|-----------------------------|---------------|---------------|--|--|--|--|--|--|--|
| Model | Dimensions | | | | | | | | |
| Mouel | а | b | | | | | | | |
| GS20A-ESP-A | 69.3 [2.73] | 80.0 [3.15] | | | | | | | |
| GS20A-ESP-B | 67.7 [2.67] | 79.7 [3.14] | | | | | | | |
| GS20A-ESP-C | 78.0 [3.07] | 91.0 [3.58] | | | | | | | |
| GS20A-ESP-D | 103.4 [4.07] | 97.0 [3.82] | | | | | | | |
| GS20A-ESP-E | 124.3 [4.89] | 77.4 [3.05] | | | | | | | |
| GS20A-ESP-F | 168.0 [6.61] | 80.0 [3.15] | | | | | | | |
| GS30A-ESP-G | 243.5 [9.59] | 154.9 [6.10] | | | | | | | |
| GS30A-ESP-H | 262.0 [10.31] | 201.9 [7.95] | | | | | | | |
| GS30A-ESP-I | 304.0 [11.97] | 260.7 [10.26] | | | | | | | |




Capacitive Filter

The GS20A-CAPF capacitive filter supports basic filtering and noise interference reduction for all GS10, GS20(X), and G30 models, 460V and below. For more information and installation instructions, please see your GSxx series User Manual.

The GS20A-CAPF cannot be used with 575V models.

| | Capacitive Filter | | | | | | |
|---------------------------|-------------------|---------|-----------------------|----------------------|----------------------------------|--|--|
| Drive Series | Model | Price | Applicable Voltage | Temperature Range | Capacitance | | |
| GS10/ GS20(X)/ GS30 | GS20A-CAPF | \$24.00 | 110–480 VAC | -40-85°C | Cx: 1uF ± 20% Cy: 0.1uF ± 20% | | |



GS10 Series Optional Accessories – Line Reactors/ VTF Filters

GS10 Line Reactors/Voltage Time Filters

Installing an AC Line Reactor on the input side of an AC motor drive can increase line impedance, improve the power factor, reduce input current, increase system capacity, and reduce interference generated from the motor drive.

Installing a load reactor or voltage time filter on the drive's output side can increase the high-frequency impedance to reduce the dV/dT and terminal voltage to protect the motor. Use output filters if the motor cable length exceeds 100ft.


| | GS10 Li | ine/Load F | Reactor ar | nd AC Output F | ilter Selection | IS | | |
|--------------------------|---|--------------------------|------------|-------------------------|-------------------------|--------------------------|--|--|
| GS10 Model | CT Input Amps (rms) | Saturation Amps (rms) | Motor HP | Line Reactor (LR2)** | Load Reactor (LR2)** | AC Output Filter (VTF)** | | |
| GS11N-10P2 | 1.6 | 3.2 | 0.25 | LR2-10P2-1PH | LR2-20P2 | VTF-46-DE | | |
| GS11N-10P5 | 2.5 | 5 | 0.5 | LR2-10P5-1PH | LR2-20P5 | VTF-246-CFG | | |
| GS11N-11P0 | 4.8 | 9.6 | 1.0 | LR2-11P5-1PH | LR2-21P0 | VTF-24-FH | | |
| GS11N-20P2 | 1.6 | 3.2 | 0.25 | LR2-20P5-1PH | LR2-20P2 | VTF-46-DE | | |
| GS11N-20P5 | 2.8 | 5.6 | 0.5 | LR2-20P5-1PH | LR2-20P5 | VTF-246-CFG | | |
| GS11N-21P0 | 4.8 | 9.6 | 1.0 | LR2-21P5 | LR2-21P0 | VTF-24-FH | | |
| GS11N-22P0 | 7.5 | 15 | 2.0 | LR2-22P0-1PH | LR2-22P0 | VTF-246-HKL | | |
| GS11N-23P0 | 11 | 22 | 3.0 | <u>LR-27P5</u> | <u>LR-25P0</u> | VTF-24-JL | | |
| GS13N-20P2 | 1.6 | 3.2 | 0.25 | LR2-20P2 | LR2-20P2 | VTF-46-DE | | |
| GS13N-20P5 | 2.8 | 5.6 | 0.5 | LR2-20P5 | LR2-20P5 | VTF-246-DGH | | |
| GS13N-21P0 | 4.8 | 9.6 | 1.0 | LR2-20P7 | LR2-20P7 | VTF-24-FH | | |
| <u>GS13N-22P0</u> | 7.5 | 15 | 2.0 | LR2-22P0 | LR2-22P0 | VTF-246-HKL | | |
| <u>GS13N-23P0</u> | 11 | 22 | 3.0 | <u>LR-25P0</u> | <u>LR-23P0</u> | VTF-24-JL | | |
| <u>GS13N-25P0</u> | 17 | 34 | 5.0 | <u>LR-27P5</u> | <u>LR-25P0</u> | VTF-46-LM | | |
| <u>GS13N-27P5</u> | 25 | 50 | 7.5 | LR-2010 | <u>LR-27P5</u> | VTF-46-NP | | |
| <u>GS13N-40P5</u> | 1.5 | 3 | 0.5 | LR2-40P5 | <u>LR2-40P5</u> | VTF-46-DE | | |
| <u>GS13N-41P0</u> | 2.7 | 5.4 | 1.0 | <u>LR2-42P0</u> | <u>LR2-41P0</u> | <u>VTF-246-CFG</u> | | |
| <u>GS13N-42P0</u> | 4.2 | 8.4 | 2.0 | <u>LR2-45P0</u> | <u>LR2-42P0</u> | <u>VTF-24-FH</u> | | |
| GS13N-43P0 | 5.5 | 11 | 3.0 | <u>LR2-45P0</u> | LR2-43P0 | VTF-24-FH | | |
| <u>GS13N-45P0</u> | 9 | 18 | 5.0 | <u>LR2-47P5</u> | LR2-45P0 | VTF-246-HKL | | |
| <u>GS13N-47P5</u> | 13 | 26 | 7.5 | <u>LR-4010</u> | LR2-47P5 | VTF-24-JL | | |
| GS13N-4010 | 17.5 | 34 | 10.0 | <u>LR-4015</u> | <u>LR-4010</u> | VTF-24-JL | | |
| * Not available at Auton | * Not available at AutomationDirect.com | | | | | | | |


^{*} All specs for the LR2 and VTF can be found at www.automationdirect.com

DuraPulse Optional Accessories – Mounting Kits DIN Rail Mounting

Frame A, B, and C GS10, GS20, and GS30 drives can be DIN rail mounted using a DIN rail mounting kit. One kit is used for A and B frame drives, while a second kit is used for C frame drives. Please see the GSxx series User Manual for additional information and installation instructions.

| GSxx DIN Rail Mounting Compatibility | | | | | | | |
|--------------------------------------|-------------|------------------|-------|--------------|--------|--|--|
| | Drive Model | | Frame | DIN Rail Kit | Price | | |
| GS10 Series | GS20 Series | GS30 Series | | | | | |
| GS11N-10P2 | GS21-10P2 | _ | A1 | | | | |
| GS11N-20P2 | GS21-20P2 | _ | A1 | | | | |
| GS13N-20P2 | GS23-20P2 | _ | A1 | | | | |
| GS13N-20P5 | GS23-20P5 | GS31-20P5 | A2 | | | | |
| - | - | GS33-20P5 | A2 | | | | |
| - | _ | GS33-40P5 | A2 | | | | |
| GS11N-10P5 | GS21-10P5 | GS33-21P0 | A3 | | | | |
| GS11N-20P5 | GS21-20P5 | GS33-41P0 | A3 | | | | |
| GS13N-40P5 | GS23-40P5 | _ | A4 | GS20A-DR-AB | \$6.00 | | |
| GS13N-21P0 | GS23-21P0 | _ | A5 | | | | |
| - | GS23-41P0 | _ | A5 | | | | |
| - | GS23-51P0 | - | A5 | | | | |
| GS13N-41P0 | - | _ | A6 | | | | |
| GS13N-22P0 | GS23-22P0 | GS33-22P0 | B1 | | | | |
| GS13N-42P0 | GS23-42P0 | GS33-42P0 | B1 | | | | |
| - | GS23-52P0 | _ | B1 | | | | |
| GS11N-21P0 | GS21-21P0 | GS31-21P0 | B2 | | | | |
| GS11N-22P0 | GS21-11P0 | GS31-22P0 | C1 | | | | |
| GS11N-23P0 | GS21-22P0 | <u>GS33-23P0</u> | C1 | | | | |
| GS13N-23P0 | GS21-23P0 | <u>GS33-25P0</u> | C1 | | | | |
| GS13N-25P0 | GS23-23P0 | GS33-43P0 | C1 | | | | |
| GS11N-11P0 | GS23-25P0 | GS33-45P0 | C1 | GS20A-DR-C | \$6.00 | | |
| GS13N-43P0 | GS23-43P0 | _ | C1 | | | | |
| GS13N-45P0 | GS23-45P0 | - | C1 | | | | |
| _ | GS23-53P0 | - | C1 | | | | |
| - | GS23-55P0 | - | C1 | | | | |







DuraPulse Optional Accessories – Mounting Kits

Mounting Adapter Plate

The mounting adapter plate can be used to change the wiring orientation for the GS10, GS20, and GS30 series and provides flexibility for installation. This accessory changes the wiring method from the "bottom-mains input/ bottom-motor output" to the "top-mains input/bottom-motor output" for GS10/GS20/GS30. Use the table below to select the correct mounting plate for your drive. Please see your GSxx series User Manual for additional information and installation instructions.

| GSxx Mounting Adapter Compatibility | | | | | | |
|-------------------------------------|-------------|-------------|----------------|-------------|---------|--|
| | Drive Model | Frame | Mounting Plate | Price | | |
| GS10 Series | GS20 Series | GS30 Series | | | | |
| GS11N-10P2 | GS21-10P2 | _ | A1 | | | |
| GS11N-20P2 | GS21-20P2 | _ | A1 | | | |
| GS13N-20P2 | GS23-20P2 | _ | A1 | | | |
| <u>GS13N-20P5</u> | GS23-20P5 | GS31-20P5 | A2 | | | |
| _ | _ | GS33-20P5 | A2 | | | |
| - | _ | GS33-40P5 | A2 | | | |
| GS11N-10P5 | GS21-10P5 | GS33-21P0 | A3 | | | |
| GS11N-20P5 | GS21-20P5 | GS33-41P0 | A3 | | | |
| GS13N-40P5 | GS23-40P5 | _ | A4 | GS20A-MP-AB | \$51.00 | |
| GS13N-21P0 | GS23-21P0 | _ | A5 | | | |
| - | GS23-41P0 | _ | A5 | | | |
| - | GS23-51P0 | - | A5 | | | |
| GS13N-41P0 | _ | _ | A6 | | | |
| GS13N-22P0 | GS23-22P0 | GS33-22P0 | B1 | | | |
| GS13N-42P0 | GS23-42P0 | GS33-42P0 | B1 | | | |
| - | GS23-52P0 | _ | B1 | | | |
| GS11N-21P0 | GS21-21P0 | GS31-21P0 | B2 | | | |
| GS11N-22P0 | GS21-11P0 | GS31-22P0 | C1 | | | |
| GS11N-23P0 | GS21-22P0 | GS33-23P0 | C1 | | | |
| GS13N-23P0 | GS21-23P0 | GS33-25P0 | C1 | | | |
| GS13N-25P0 | GS23-23P0 | GS33-43P0 | C1 | | | |
| GS11N-11P0 | GS23-25P0 | GS33-45P0 | C1 | GS20A-MP-C | \$60.00 | |
| GS13N-43P0 | GS23-43P0 | _ | C1 | | | |
| GS13N-45P0 | GS23-45P0 | _ | C1 | | | |
| - | GS23-53P0 | - | C1 | | | |
| | GS23-55P0 | _ | C1 | | | |








GS20A-MP-C

DuraPulse Optional Accessories – Replacement Cooling Fans

Cooling Fans for GSxx Series Drives (Spare/Replacement)

NOTE: The fans described below are included with the applicable GS10, GS20(X), and GS30 AC Drive, and are also available for purchase separately as spare/replacement components.

| | G | 1910, 6920 | (X), GƏJU | - Fan | Selection Table | | |
|--|---|--|--------------|----------|--|---------------|---------|
| | Drive Model | | Fan Mode | / * | Description | Size | Voltage |
| GS10 Series | GS20(X) Series | GS30 Series | Part # | Price | Description | SIZE | voitage |
| GS13N-22P0 GS13N-42P0 | GS23-22P0 GS23-42P0 GS23-52P0 | GS31-21P0 GS33-22P0 GS33-42P0 | GS20A-FAN-B | \$24.00 | GS20 series main cooling fan, replacement. | 40x40x15 mm | |
| - | GS21X-23P0 GS23X-23P0 GS23X-25P0 GS23X-45P0 | _ | GS20XA-FAN-B | \$56.00 | GS20X series main cooling fan, replacement | 60x60x25 mm | |
| GS11N-11P0 GS11N-23P0 GS13N-23P0 GS13N-25P0 GS13N-43P0 GS13N-45P0 | GS21-11P0 GS21-22P0 GS21-23P0 GS23-23P0 GS23-25P0 GS23-43P0 GS23-45P0 GS23-53P0 GS23-55P0 | GS31-22P0 GS31-23P0 GS33-23P0 GS33-25P0 GS33-43P0 GS33-45P0 | GS20A-FAN-C | \$26.00 | GS20 series main cooling fan, replacement. | 50x50x20 mm | 12VDC |
| - | GS23X-27P5 GS23X-47P5 GS23X-4010 | _ | GS20XA-FAN-C | \$57.00 | GS20X series main cooling fan, replacement | 60x60x25 mm | |
| GS13N-27P5 GS13N-47P5 GS13N-4010 | GS23-27P5 GS23-47P5 GS23-4010 GS23-57P5 GS23-5010 | GS33-27P5 GS33-47P5 GS33-4010 | GS20A-FAN-D | \$30.00 | GS20 series main cooling fan, replacement. | 60x60x25 mm | |
| - | GS23-2010 GS23-2015 GS23-4015 GS23-4020 | GS33-2010 GS33-2015 GS33-4020 | GS20A-FAN-E | \$41.00 | GS20 series main cooling fan, replacement. | 92x92x28 mm | |
| | GS23-2020 GS23-4025 GS23-4030 | GS33-2020 GS33-4025 GS33-4030 | GS20A-FAN-F | \$45.00 | GS20 series main cooling fan, replacement. | 92x92x38 mm | |
| - | - | GS33-2025 GS33-2030 GS33-4040 | GS30A-FAN-G | \$52.00 | GS30 series main cooling fan, replacement | 204x87x50 mm | 24VDC |
| - | _ | GS33-4050 GS33-4060 | GS30A-FAN-H | \$98.00 | GS30 series main cooling fan, replacement | 206x95x50 mm | |
| _ | - | GS33-2040 GS33-2050 GS33-4075 GS33-4100 | GS30A-FAN-I | \$151.00 | GS30 series main cooling fan, replacement | 260x121x50 mm | |





Example GS20A replacement Fan

DuraPulse Optional Accessories – RF Filter

RF Filter

Zero phase reactors, (aka RF noise filters) help reduce radiated noise from the inverter wiring. The wiring must go through the opening to reduce the RF component of the electrical noise. Loop the wires three times (four turns) to attain the full RF filtering effect. For larger wire sizes, place multiple zero-phase reactors (up to four) side by side for a greater filtering effect. These are effective for noise reduction on both the input and output sides of the inverter. Attenuation quality is good in a wide range from 500kHz to 10MHz.




Wiring Method

Wind each wire four times around the core, as shown in diagram A to the right. The reactor must be put at inverter side as closely as possible.

If you are unable to wire as above due to wire size or another aspect of your application, put all wires through four cores in series without winding, as in diagram B to the right.

| RF Filter Selection | | | | | | |
|-----------------------|--------------|------------|----------|--|--|--|
| Drive Series | Filter Model | Drawing | Price | | | |
| GS10 / GS20(X) / GS30 | RF008X00A | <u>PDF</u> | \$40.00 | | | |
| GS30 | RF004X00A | <u>PDF</u> | \$47.00 | | | |
| GS30 (Frame H-I) | RF002X00A | PDF | \$235.00 | | | |



DuraPulse Accessories – Software GSoft2 Drive Configuration Software

GSoft2 Drive Configuration Software

Available for FREE Download

| DURAPULSE Drives GSOFT2 Drive Configuration Software | | | | | |
|--|-----------------|---|--|--|--|
| Part Number | Price* | Description | For GS Drive | | |
| GSOFT2 | \$10.50 | GSOFT2 Windows configuration software, USB or free download. For use with DURApulse GS4, GS10, GS20, GS20X and GS30 series AC drives. Requires PC serial port or USB-485M serial adapter. | GS4 – all GS10 – all GS20(X) – all GS30 – all | | |
| <u>USB-485M</u> | \$69.00 | PC adapter, USB A to RS-485 (RJ45/RJ12). | GS4/GS10 | | |
| USB-CBL-AB3 | \$12.00 | Programming cable, USB A to USB B, 3ft cable length. | GS4 – all (for Drive FW only) GS20(X) – all GS30 – all | | |
| * GSOFT2 can be d | ownloaded for f | ree or purchased on USB from AutomationDirect.com (search | for GSOFT2). | | |

GSOFT2 Drive Configuration Software

GSoft2 is the configuration software for the Automation *Dura*Pulse family of drives. It is designed to allow you to connect a personal computer to the drive, and perform a variety of functions.

GSoft2 includes an integral help file with software instructions. GSoft2 can be downloaded for free or purchased on USB from AutomationDirect.com (search for GSoft2).

Functions

- Create new drive configurations
- · Upload/download drive configurations
- Edit drive configurations
- Archive/store multiple drive configurations on your PC
- Trend drive operation parameters (not available with GS10)
- Tune the drive PID loop
- View real time key operating parameters
- · Real-time trending
- Start/Stop drive and switch directions, provided drive is set up for remote operation
- View drive faults

Computer System Requirements

GSoft2 will run on Windows PCs that meet the following requirements:

- Windows OS: <u>8</u>: 32 & 64 bit, <u>8.1</u>: 32 & 64 bit,
 <u>10</u>: 64 bit, 11
- Edge or Chrome (for HTML help support)
- 32 Mb of available memory
- 10 Mb hard drive space
- Available USB port
- USB to RS485 adapter needed for GS4 and GS10 models



DuraPulse Optional Accessories – Advanced LCD Keypad

Advanced Keypad

NOTE: The keypad described below is included with the GS4 AC Drive, and is also available for purchase separately as a spare/replacement component for GS4, or an optional upgrade for GS10/GS20(X)/GS30.

Keypad Panel-Mounting Kit

NOTE: The keypad panel-mounting kit described below is an optional accessory that is NOT included with the GS10/GS20(X)/GS30 AC drive.

| | GSx S | eries DURAPULSE Drives Keypad and Keypad Panel-Mounting Kit | |
|-------------------|----------|---|--|
| Part Number | Price | Description | For GS Drive |
| <u>GS4-KPD</u> * | \$107.00 | Spare or replacement keypad for GS4 AC drives; optional advanced keypad for GS20(X) drives; includes RJ45 connector; great for maintenance or back-up programs. | GS4 – all GS10 – all GS20(X) – all GS30 – all |
| <u>GS4-BZL</u> ** | \$29.50 | Keypad Panel-Mounting Kit for remote surface mounting or embedded mounting of the AC drive removable keypad; hardware included. Use a standard Cat5e RJ45 patch cable (not included) to connect a remotemounted keypad to the drive. Max cable length for remote-mounted keypad = 5m. | GS4 – all GS10 – all GS20(X) – all GS30 – all |

^{*} A keypad is included with each GS4 AC Drive; additional keypads are available for spare/replacement components.

^{**} The keypad mounting kit is an optional accessory that is NOT included with the GS4 AC drive; for mounting the keypad remotely from the drive. Note: Keypad firmware can only be upgraded when connected to a GS4 drive.

