Programming Software

PS-PGMSW FREE OnLine Download

Productivity Suite is user-friendly programming software designed to allow quick and easy programming of ladder logic programs for the Productivity ® 1000, Productivity ® 2000 and Productivity 3000 © CPUs.

The online help file provides information that will help you get acquainted with the software quickly.

PC Requirements

Productivity Suite, a Windows-based programming software, is available as a FREE download at http://support.automationdirect.com/downloads.httml. Please check our website for your product's current operating system requirements.

Programming Cable

You will need a Micro USB or Cat-5 Ethernet cable for programming, depending on whether you use the USB or Ethernet programming port.

We recommend using a USB programming cable; just plug it in and it works. We sell these USB Type A to Micro Type B USB cables:

- USB-CBL-AMICB6 (6 ft.)
- <u>USB-CBL-AMICB15</u> (15 ft.)
- USB-CBL-AC6 (6 ft.)



Main window

The Main Window is displayed when the program opens. It is divided into Menus, Toolbars, and Windows that work together to make project development as simple as possible.

