



SEE INSTALLATION INSTRUCTIONS FOR COMPLETE LIST OF FASTENERS AND THEIR RESPECTIVE LOCATIONS

FATH MONITOR MOUNTING JOINT

162896

AutomationDirect.com
1-800-633-0405



3rd
ANGLE

NOT TO
SCALE

PART DIMENSIONS MAY DIFFER SLIGHTLY
DUE TO MANUFACTURER'S VARIANCES

METRIC UNITS USED
FOR PART DESIGN

UNLESS OTHERWISE
SPECIFIED UNITS ARE:

mm
[inch]

LATEST VERSION
1/11/2023

SHEET 1 OF 1