


#### NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.



AP100

Units: inches [mm]

Scale: Full

BRYANT ADAPTOR PLATE: USE  
WITH 100A DEVICES

**AUTOMATIONDIRECT**.com