



NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.

AP60

Units: inches [mm]
Scale: Full

BRYANT ADAPTER PLATE: USE WITH
60A DEVICES

AUTOMATIONDIRECT.com