



PACKAGE OF 10. FOR USE WITH GLADIATOR GMCB
SERIES 2-PHASE AND 3-PHASE BUSBARS.

GLADIATOR END CAP

GMCB-BBM-ECAP

AutomationDirect.com
1-800-633-0405



3rd
ANGLE

NOT TO
SCALE

PART DIMENSIONS MAY DIFFER SLIGHTLY
DUE TO MANUFACTURER'S VARIANCES

METRIC UNITS USED
FOR PART DESIGN

UNLESS OTHERWISE
SPECIFIED UNITS ARE:

mm
[inch]

LATEST VERSION
7/23/2024

SHEET 1 OF 1