



NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.

RF008X00A

Units: mm [inches]

Scale: Full

DURAPULSE ZERO PHASE REACTOR,
FOR USE WITH GS4, GS10, & GS20
AC DRIVES