



NOTES:

1. DIMENSIONS CAN BE CHANGED BY MANUFACTURER WITHOUT NOTICE.
2. DIMENSIONS DO NOT IMPLY TOLERANCE.

GWR-FPLT

Units: mm [inches]
 Scale: Full

ProSense ROUND MOUNTING FLANGE
 FOR USE WITH ProSense GWR SERIES
 SENSORS

