

Quick Start: Connect to the P1-UX

1. Power and connection

- Power on the P1-UX, then connect it to an Ethernet network **or** connect it directly to your PC using a **USB cable**.

2. Open the P1-UX in a browser

- Launch a web browser and enter one of the following:
 - <https://p1-ux.local> (default Ethernet domain name)
 - <https://p1-ux-usb.local> (default USB domain name)
 - <https://10.10.10.10> (default IP address)

Note: You may see a device certificate warning in your browser. Accept to continue connecting to the P1-UX.

3. Log in

- When the login screen appears, use:
 - **Username:** admin
 - **Password:** productivity

4. Select *Login*

Note: Before continuing, make sure the switch is set to the **STOP** position.

5. Update domain name & IP address:

- Click on P1-UX image
- Update either IP address and/or domain name.
- Select **Set IP/Domain name**
- Select Confirm

6. Discover Modules

- Select Edit -> Discover Modules
- Select Edit -> Use Discovered Modules
- Select **Apply Settings**

For more information, the full Quick Start Guide is available at:

<https://www.automationdirect.com/pn/P1-UX>