

# CLICK PLC User Manual

---



**Please include the Manual Number and the Manual Issue, both shown below, when communicating with Technical Support regarding this publication.**

**Manual Number:** C0-USER-M  
**Issue:** 6th Edition  
**Issue Date:** 11/2017

<b>Publication History</b>		
<b>Issue</b>	<b>Date</b>	<b>Description of Changes</b>
1st Edition	5/08	Original
1st Edition, Rev. A	10/08	Updated specifications and drawings throughout manual.
2nd Edition	5/09	Added Port 3 and C0-02DD1-D, C0-02DD2-D, C0-02DR-D analog CPU units.
2nd Edition, Rev. A	8/09	Updated wiring diagram for C0-02DR-D CPU module.
3rd Edition	10/10	Added four Standard CPUs and C0-08NE3 and C0-16NE3 24 VAC input modules
3rd Edition, Rev. A	11/10	Revised current consumption specification for Standard and Analog CPUs.
4th Edition	6/13	Added 11 I/O modules: 3 discrete combo, 4 analog in, 2 analog out, 2 analog combo.
4th Edition, Rev. A	10/13	Added 11 I/O modules: 3 discrete combo, 4 analog in, 2 analog out, 2 analog combo.
5th Edition	12/15	Added eight CLICK PLC units with built-in Ethernet
5th Edition, Rev. A	4/17	Added Interlocking examples to Chapter 4, software and firmware updates, and other misc. minor corrections.
6th Edition	11/17	Added twelve CLICK Ethernet Analog PLC units.

## Notes