


Sostituzione bobina *Coil replacement*



| Contactor type | | | Coil type |
|----------------|--------|--------|-----------|
| GH15NT | GH15PT | | B031 |
| GH15MN | GH15NN | GH15PN | |
| GH15RT | GH15ST | GH15TT | B041 |
| GH15RN | GH15SN | GH15TN | |

