

Table of Contents



Introduction	1
Preparing for Installation	3
Installation of KEPDirect EBC I/O Server	9
KEPDirect EBC I/O Server Setup Summary	18
Start a New Project	19
Adding Devices to the New Project	25
Using OPC Quick Client to Test Device	34
Glossary	39
Appendix A	A-1
Project Example Using LookoutDirect as an OPC Client	
Appendix B	B-1
Analog I/O Setup and Diagnostics	
Appendix C	C-1
Parameter Addressing	C-1
Status Addressing	C-2