



WIEGMANN
FREEBURG, ILLINOIS, USA

DIN Rails

1. **DIN rails may be mounted either directly to enclosure studs, adjustable mounting kit (sold separately), or to mounting channels (sold separately).**
2. **If mounting to enclosure studs, line up the slots in DIN rails with studs. Attach 5/16-18 flanged nut to each stud and tighten.**
3. **If mounting to the adjustable mounting kit, line up the slots in DIN rails with studs on the adjustable mounting kit. Attach 5/16-18 flanged nut to each stud and tighten.**
4. **If mounting DIN rails to mounting channels, insert one spring nut for each DIN rail into each mounting channel.**
5. **Attach mounting channels to enclosure studs per separate installation instruction sheet (Ref instruction HFW3309)**
6. **Line up slots in DIN rails with channel nuts. Insert one 1/4-20 round head bolt into each spring nut and tighten.**

P/N: HFW33011