



取扱説明書/INSTRUCTION MANUAL

富士マニュアルモータスタータ
電源側端子カバー (UL508 Type E・F 用)
MANUAL MOTOR STARTER / Line side terminal cover
(For UL508 Type E・F)

TYPE : BZ0TCRE

⚠ 危険 (Warning)





● 取付、保守・点検は電源を切って行って下さい。感電のおそれがあります。

⚠ Warning





WARNING : Turn off the power before starting installation, maintenance, or inspection. Failure to turn off power may result in Electric shock or burn.
ATTENZIONE : Débrancher l'alimentation avant l'installation, la maintenance ou l'inspection. Ne pas le faire expose l'utilisateur à des risques d'électrochoc ou de brûlures.
WARNUNG : Schalten Sie das Gerät ab, bevor Sie mit Installieren, Wartung, oder Inspektion beginnen. Andernfalls besteht die Gefahr eines elektrischen Schocks oder von Verbrennungen.
ATTENTION : Spegnerne l'alimentazione prima di iniziare l'installazione, la manutenzione o il collaudo. L'alimentazione accesa può provocare scosse elettriche o ustioni.
ATENCIÓN : Desconecte la energía antes de iniciar la instalación, mantenimiento o inspección. Si no la desconecta puede resultar en un golpe eléctrico o quemaduras.
ATENCAO : Desligue o produto antes de iniciar a instalação, manutenção ou inspeção. Deixar de fazer isso pode resultar em choque elétrico ou queimadura.
OPGELET : Schakel de stroom uit voor u begint aan installatie, onderhoud of inspectie. Doet u dit niet, dan kunt u een elektrische schok of brandwonden oplopen.

取付け Mounting



取外し Remove



この取扱説明書および製品に対し、ご不明な点がある場合、最寄りの特約店へお問い合わせ願います。
These instructions do not purport to cover all details or variations in equipment nor to provide for every possible contingency to be met in connection with installation operation or maintenance. Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to the Fuji Electric FA.

富士電機機器制御株式会社

〒141-0032 東京都品川区大崎一丁目11番2号
(ゲートシティ大崎 イーストタワー)
TEL (03) 5435-7112
URL <http://www.fujielectric.co.jp/fcs/>

Fuji Electric FA Components & Systems Co., Ltd.

Gate City Ohsaki, East Tower, 11-2, Osaki 1-chome,
Shinagawa-ku, Tokyo 141-0032, Japan
Phone : +81-3-5435-7112
URL <http://www.fujielectric.co.jp/fcs/>