

# TABLE OF CONTENTS

---



## Chapter 1 - Getting Started

<b>Introduction</b> .....	1-2
Purpose of this Manual.....	1-2
Purpose of this Chapter.....	1-2
Online Help Files and Other Documentation.....	1-2
Technical Support.....	1-2
<b>Conventions Used</b> .....	1-3
Key Topics for Each Chapter.....	1-3
<b>Before You Begin</b> .....	1-4
Do-more! PLC System Components.....	1-5
Do-more! Designer Software System Requirements.....	1-5
<b>Step 1: Install Do-more Designer Software</b> .....	1-6
<b>Step 2: Launch Do-more! Designer Software</b> .....	1-9
<b>Step 3: Install Hardware</b> .....	1-11
<b>Step 4: Apply Power to the Do-more! PLC</b> .....	1-12
<b>Step 5: Establish Communication</b> .....	1-13
<b>Step 6: Verify Hardware Configuration</b> .....	1-19
<b>Step 7: Create a Ladder Logic Program</b> .....	1-23
Rung #1.....	1-23
Rung #2.....	1-26
<b>Step 8: Save a Project</b> .....	1-28
<b>Step 9: Write Project to the Do-more PLC</b> .....	1-28
<b>Step 10: Testing Project Using Data View</b> .....	1-29
<b>Accessing the Help File</b> .....	1-31

## Chapter 2 -Do-more! H2 Series PLC Overview

Do-more H2 Series PLC Overview.....	2-2
Do-more/DL205 System Compatibility.....	2-3
Communications.....	2-4

## Chapter 3 Specifications: CPU Modules

CPU Specifications.....	3-2
CPU General Specifications.....	3-2
Communications Ports Specifications.....	3-4
Port 1 Specifications (USB).....	3-4
Port 2 Specifications (Serial).....	3-4
USB Type B Slave Input Specifications.....	3-4
Port 3 Specifications (Ethernet).....	3-5
Ethernet Specifications.....	3-5
Ethernet Expansion I/O.....	3-6
Status Indicators.....	3-8
Mode Switch Functions.....	3-8
DIP Switch Specifications.....	3-9
Battery Replacement.....	3-12

## Chapter 4 - Specifications: Base Units

Base Unit Overview.....	4-2
Choosing a Base Type.....	4-2
AC Powered Base Units.....	4-3
24VDC Powered Base Units.....	4-4
125VDC Powered Base Units.....	4-5
Power Budget.....	4-6
Power Budget Example.....	4-6
Power Requirements.....	4-7

<b>Discrete I/O Modules Overview .....</b>	<b>5-3</b>
Discrete Input Modules .....	5-3
Discrete Output Modules .....	5-4
Discrete Input/Output Module .....	5-4
<b>D2-08ND3, DC Input .....</b>	<b>5-5</b>
<b>D2-16ND3-2, DC Input .....</b>	<b>5-6</b>
<b>D2-32ND3, DC Input.....</b>	<b>5-7</b>
<b>D2-32ND3-2, DC Input.....</b>	<b>5-8</b>
<b>D2-08NA-1, AC Input .....</b>	<b>5-9</b>
<b>D2-08NA-2, AC Input.....</b>	<b>5-10</b>
<b>D2-16NA, AC Input.....</b>	<b>5-11</b>
<b>D2-04TD1, DC Output .....</b>	<b>5-12</b>
<b>D2-08TD1, DC Output .....</b>	<b>5-13</b>
<b>D2-08TD2, DC Output .....</b>	<b>5-14</b>
<b>D2-16TD1-2, DC Output.....</b>	<b>5-15</b>
<b>D2-16TD2-2, DC Output.....</b>	<b>5-16</b>
<b>F2-16TD1P, DC Output With Fault Protection .....</b>	<b>5-17</b>
<b>F2-16TD2P, DC Output with Fault Protection.....</b>	<b>5-19</b>
<b>D2-32TD1, DC Output .....</b>	<b>5-21</b>
<b>D2-32TD2, DC Output .....</b>	<b>5-22</b>
<b>F2-08TA, AC Output.....</b>	<b>5-23</b>
<b>D2-08TA, AC Output .....</b>	<b>5-24</b>
<b>D2-12TA, AC Output .....</b>	<b>5-25</b>
<b>D2-04TRS, Relay Output .....</b>	<b>5-26</b>
<b>D2-08TR, Relay Output .....</b>	<b>5-27</b>
<b>F2-08TR, Relay Output .....</b>	<b>5-28</b>
<b>F2-08TRS, Relay Output .....</b>	<b>5-29</b>
<b>D2-12TR, Relay Output .....</b>	<b>5-30</b>
<b>D2-08CDR, 4 pt. DC Input / 4pt. Relay Output .....</b>	<b>5-31</b>

## Chapter 6 - Specifications: Analog I/O Modules

<b>Analog I/O Modules Overview</b> .....	6-3
Analog Input Modules.....	6-3
Analog Output Modules.....	6-4
Analog Input/Output Module.....	6-4
How to Access the Analog I/O Modules .....	6-5
<b>F2-04AD-1(L) Analog Input</b> .....	6-7
Setting the Module Jumpers.....	6-8
F2-04AD-1(L) Addressing .....	6-9
<b>F2-04AD-2(L), Analog Input</b> .....	6-10
Setting the Module Jumpers.....	6-11
F2-04AD-2(L) Addressing .....	6-12
<b>F2-08AD-1, Analog Input</b> .....	6-13
Setting the Module Jumpers.....	6-14
F2-08AD-1 Addressing.....	6-15
<b>F2-08AD-2, Analog Input</b> .....	6-16
Setting the Module Jumpers.....	6-17
F2-08AD-2 Addressing.....	6-18
<b>F2-04RTD</b> .....	6-19
Setting the Module Jumpers.....	6-20
F2-04RTD Addressing .....	6-22
<b>F2-04THM</b> .....	6-23
Setting the Module Jumpers.....	6-25
<b>F2-02DA-1(L), Analog Output</b> .....	6-29
<b>F2-02DA-2(L), Analog Output</b> .....	6-31
Unipolar Ranges .....	6-34
Bipolar Ranges.....	6-34
<b>F2-02DAS-1, Analog Output</b> .....	6-35
<b>F2-02DAS-2, Analog Output</b> .....	6-37
Setting the Module Jumpers.....	6-38
<b>F2-08DA-1, Analog Output</b> .....	6-40
<b>F2-08DA-2, Analog Output</b> .....	6-42
Setting the Module Jumpers.....	6-43

<b>F2-4AD2DA, Analog Input/Output</b> .....	<b>6-45</b>
Input .....	6-47
Output .....	6-47
<b>F2-8AD4DA-1 Analog Input/Output</b> .....	<b>6-48</b>
Input .....	6-51
Output .....	6-51
Input Configuration Using Do-more Designer Version 1.1 or Newer .....	6-52
Input Resolution Selection (WYn+4) .....	6-53
Input Track and Hold Selection (WYn+6) .....	6-54
<b>F2-8AD4DA-2 Analog Input/Output</b> .....	<b>6-55</b>
Input .....	6-58
Output .....	6-58
Input Configuration Using Do-more Designer Version 1.1 or Newer .....	6-59
Input Resolution Selection (WYn+4) .....	6-60
Input and Output Range Selection (WYn+5) .....	6-61
Input Track and Hold Selection (WYn+6).....	6-62

## Chapter 7 - Specifications: Specialty Modules

<b>Specialty Modules Overview</b> .....	<b>7-3</b>
Specialty Modules .....	7-3
<b>H2-CTRIO(2)</b> .....	<b>7-5</b>
H2-CTRIO(2) Overview.....	7-5
H2-CTRIO(2) Specifications .....	7-7
H2-CTRIO(2) LED Indicators .....	7-8
H2-CTRIO(2) Jumper Setup .....	7-9
H2-CTRIO.....	7-9
H2-CTRIO2.....	7-9
Wiring Information.....	7-10
PNP Field Device (source).....	7-10
NPN Field Device (sink).....	7-10
H2-CTRIO(2) Input Wiring Examples .....	7-11
TTL Quadrature Encoder Field Wiring.....	7-11
TTL Input Wiring Example.....	7-11
Quadrature Encoder Wiring Example .....	7-12
NPN Open Collector Device.....	7-12

## Table of Contents

---

PNP Open Collector Device.....	7-12
H2-CTRIO(2) Output Wiring Examples.....	7-13
<b>H2-ECOM100 .....</b>	<b>7-14</b>
H2-ECOM100 Overview.....	7-14
H2-ECOM100 Specifications.....	7-14
H2-ECOM100 LED Indicators.....	7-15
H2-ECOM100 Network Identifiers.....	7-15
H2-ECOM100 Network Layouts.....	7-18
H2-ECOM100 Network Cabling.....	7-19
<b>H2-ERM(100)/ H2-EBC100.....</b>	<b>7-22</b>
H2-ERM(100) Overview.....	7-22
H2-ERM(100) Specifications.....	7-22
H2-ERM(100) LED Indicators.....	7-23
H2-EBC100 Overview.....	7-23
H2-EBC100 Specifications.....	7-23
H2-EBC100 LED Indicators.....	7-24
H2-ERM(100)/H2-EBC100 Network Identifiers.....	7-24
H2-ERM(100)/H2-EBC100 Network Layouts.....	7-27
H2-ERM(100)/H2-EBC100 Network Cabling.....	7-28
<b>H2-SERIO(-4.) .....</b>	<b>7-30</b>
H2-SERIO(-4) Overview.....	7-30
H2-SERIO(-4) Specifications.....	7-32
H2-SERIO(-4) Wiring: RS-232.....	7-32
H2-SERIO-4 Wiring: RS-422/485.....	7-33
<b>F2-08SIM, Input Simulator .....</b>	<b>7-34</b>
F2-08SIM Specifications.....	7-34

## Chapter 8 - Installation and Wiring

<b>Safety Guidelines .....</b>	<b>8-3</b>
Plan for Safety.....	8-3
Three Levels of Protection.....	8-4
Emergency Stops.....	8-4
Emergency Power Disconnect.....	8-5
Orderly System Shutdown.....	8-5
Class 1, Division 2, Approval.....	8-5

<b>Mounting Guidelines</b> .....	<b>8-6</b>
Base Dimensions .....	8-6
Panel Mounting and Layout .....	8-7
Enclosures .....	8-8
Environmental Specifications .....	8-9
Marine Use.....	8-9
Agency Approvals .....	8-9
24VDC Power Bases .....	8-9
<b>Installing Bases for Do-more</b> .....	<b>8-10</b>
Mounting the Base.....	8-10
Using Mounting Rails .....	8-10
<b>Installing Components in the Base</b> .....	<b>8-11</b>
<b>Base Wiring Guidelines</b> .....	<b>8-12</b>
Base Wiring .....	8-12
<b>I/O Modules Position and Wiring</b> .....	<b>8-13</b>
Slot Numbering.....	8-13
Module Placement Restrictions.....	8-13
Wiring the Different Module Connectors.....	8-14
I/O Wiring Checklist .....	8-15
<b>ZIPLink Wiring System</b> .....	<b>8-16</b>
<b>I/O Wiring Strategies</b> .....	<b>8-18</b>
PLC Isolation Boundaries .....	8-18
Powering I/O Circuits with the Auxiliary Supply .....	8-19
Powering I/O Circuits Using Separate Supplies .....	8-20
Sinking / Sourcing Concepts .....	8-21
I/O “Common” Terminal Concepts.....	8-22
Connecting DC I/O to “Solid State” Field Devices.....	8-23
Solid State Input Sensors.....	8-23
Solid State Output Loads.....	8-23
Relay Output Guidelines.....	8-25
Relay Outputs –	
Transient Suppression for Inductive Loads in a Control System.....	8-26

## Appendix A - Do-more Product Weight Table

Do-more Product Weight Table.....	A-2
-----------------------------------	-----

## Appendix B - European Union Directives (CE)

European Union (EU) Directives .....	B-2
Basic EMC Installation Guidelines .....	B-5