



Air Prep Component Assembly



Component Screw Removal and Reassembly



Use PH1 Screwdriver, Max torque for screw, 0,4 Nm [3.54 in-lb] for Size 1 components

Use PH1 Screwdriver Max torque for screw, 2,5 Nm [22.13 in-lb] for Size 2 components