

TABLE OF CONTENTS



In This Manual

Chapter 1 - Getting Started	1-1
Introduction	1-2
Purpose of this Manual	1-2
Intended Use of This Product	1-2
Benefits of P2CDS-622 with CODESYS Software	1-3
Conventions Used	1-4
Key Topics for Each Chapter.....	1-4
Important Online Resources	1-5
P2CDS-622 System	1-6
Preparation.....	1-6
1. CODESYS IDE Install	1-6
IEC 61131-3 Supported Editor Types:.....	1-7
Install Hardware	1-8
Apply Power to CPU	1-11
Develop HMI Screens directly in the CODESYS Development Environment	1-12
Chapter 2 - Specifications	2-1
P2CDS-622 CPU.....	2-2
P2CDS-622 CPU Features	2-4
P2CDS-622 CPU Programmable RS232/485 Ports.....	2-5
P2CDS-622 CPU Ethernet Ports	2-7
P2CDS-622 CPU USB Type C Programming Port	2-8

Table of Contents

P2CDS-622 CPU microSD Slot.....	2-9
microSD Slot.....	2-9
P2CDS-622 CPU Battery Installation	2-10
Battery (Optional)	2-10
I/O Modules Overview	2-11
P2CDS-622 Wiring, Installation and Safety	2-14

