

Productivity2000 User Manual



Please include the Manual Number and the Manual Issue, both shown below, when communicating with Technical Support regarding this publication.

Manual Number: P2-USER-M
Issue: 1st Edition, Rev. D
Issue Date: 12/17

Publication History		
Issue	Date	Description of Changes
1st Edition	04/15	Original
1st Edition, Rev. A	12/15	Added P2-01DCAC Power Supply, 11 I/O modules: 3 discrete, 4 analog in & 4 analog out.
1st Edition, Rev. B	4/16	Added P2-RS Remote Slave module, and P2-08NTC Thermistor module.
1st Edition, Rev. C	10/16	Added 11 I/O modules: 7 discrete output, 2 discrete input, and 2 analog output.
1st Edition, Rev. D	12/17	Replaced P2-xxND3 discrete expansion modules with P2-xxND3-1 discrete expansion modules.

Notes: